


USER'S GUIDE



MFC-440CN MFC-665CW

If you need to call Customer Service Please complete the following information for future reference:

Model Number: MFC-440CN, MFC-665CW (Circle your model number)

Serial Number: ¹

Date of Purchase:

Place of Purchase:

The serial number is on the back of the unit. Retain this User's Guide with your sales receipt as a permanent record of your purchase, in the event of theft, fire or warranty service.

Register your product on-line at

http://www.brother.com/registration/

By registering your product with Brother, you will be recorded as the original owner of the product. Your registration with Brother:

- may serve as confirmation of the purchase date of your product should you lose your receipt; and
- may support an insurance claim by you in the event of product loss covered by insurance

Approval Information and Compilation and Publication Notice

THIS EQUIPMENT IS DESIGNED TO WORK WITH A TWO WIRE ANALOGUE PSTN LINE FITTED WITH THE APPROPRIATE CONNECTOR.

APPROVAL INFORMATION

Brother advises that this product may not function correctly in a country other than where it was originally purchased, and does not offer any warranty in the event that this product is used on public telecommunication lines in another country.

Compilation and Publication Notice

Under the supervision of Brother Industries Ltd., this manual has been compiled and published, covering the latest product descriptions and specifications.

The contents of this manual and the specifications of this product are subject to change without notice.

Brother reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publication.

i

Table of Contents

Section I General

1	General Information	
	Using the documentation	2
	Symbols and conventions used in the documentation	
	Accessing the Software User's Guide and Network User's Guide	
	Viewing Documentation	
	Control panel overview	6
	LCD display screen	8
	Basic Operations	9
2	Loading documents and paper	
	Loading documents	
	Using the ADF	
	Using the scanner glass	11
	Scanning area	11
	Acceptable paper and other media	
	Recommended media	12
	Handling and using media	12
	Choosing the right media	14
	Loading paper, envelopes and other media	16
	Loading paper and other media	16
	Loading envelopes, post cards and photo paper	18
	Printable area	21
3	General setup	
	Power Save mode	
	Putting your machine in Power Save mode	
	Bringing your machine out of Power Save mode	
	Power Save setting	
	Mode Timer	23
	Paper settings	24
	Paper Type	24
	Paper Size	24
	Volume Settings	25
	Ring Volume	25
	Beeper Volume	25
	Speaker Volume	26
	Setting Daylight Savings Time	26
	LCD display	27
	LCD Contrast	27
	Setting the backlight brightness	27
	Setting the Dim Timer for the backlight	27
	Setting the Off Timer	28
	Setting the Wallpaper	28

4	Security features	
	TX Lock (MFC-440CN only)	29
	Setting and changing the TX Lock password	
	Turning the TX Lock on/off	30
	Memory Security (MFC-665CW only)	
	Setting and changing the memory security password	
	Turning the memory security on/off	
Sec	tion II Fax	
5	Sending a fax	
	Entering Fax mode	34
	Faxing from the ADF	
	Faxing from the scanner glass	
	Faxing Letter size documents from the scanner glass	35
	Colour fax transmission	35
	Cancelling a fax in progress	35
	Broadcasting (Monochrome only)	36
	Cancelling a Broadcast in progress	
	Additional sending operations	
	Sending faxes using multiple settings	
	Contrast	
	Changing fax resolution	
	Dual access (Monochrome only)	
	Real time transmission	
	Overseas Mode	
	Delayed Faxing (Monochrome only)	
	Delayed Batch Transmission (Monochrome only)	
	Checking and cancelling waiting jobs	
	Setting your changes as a new default	
	Restoring all settings to the factory settings	
	Sending a fax manually	
	Sending a fax at the end of a conversation Out of Memory message	
6	Receiving a Fax	
	Receive modes	42
	Choosing the Receive Mode	
	Using receive modes	

 Fax only
 44

 Fax/Tel
 44

 Manual
 44

 TAD (MC) (MFC–665CW only)
 44

 External TAD (MFC-440CN only)
 44

	Receive mode settings	45
	Ring Delay	45
	F/T Ring Time (Fax/Tel mode only)	45
	Fax Detect	46
	Additional receiving operations	47
	Printing a reduced incoming fax	
	Receiving faxes into memory	
	Receiving a fax at the end of a conversation (MFC-665CW only)	
	Printing a fax from the memory	
7	Telephone Services and External devices	
	Voice operations	49
	Making a telephone call (MFC-665CW only)	
	Answering calls with the Speaker Phone (MFC-665CW only)	
	Hold (MFC-665CW only)	
	Tone or Pulse (not available in New Zealand)	
	Fax/Tel mode	
	Fax/Tel mode in Power Save condition	
	Phone line services	
	Do you have Voice Mail?	
	Telephone Service for Australia	
	Telstra® FaxStream® Duet® (Distinctive Ring)	51
	Caller ID	
	How Does the Caller ID Work?	
	The Caller ID is Stored in Your Machine Memory	
	Viewing Caller ID List	
	Telephone Service for New Zealand	
	FaxAbility	
	Caller ID	
	How Does the Caller ID Work?	
	Viewing Caller ID List	
	• • • • • • • • • • • • • • • • • • •	
	Telephone Service for Some Countries	
	Distinctive Ring (For Singapore and Hong Kong)	
	Caller ID (For Singapore and Hong Kong)	
	Viewing Caller ID List	59
	Connecting an external TAD (telephone answering device)	
	Connections	
	Recording outgoing message (OGM) on an external TAD	
	Multi-Line connections (PABX)	
	External and extension phones	
	Connecting an external or extension telephone	
	Operation from extension telephones	
	Using remote codes	62

8	Dialling and storing numbers	
	How to Dial	64
	Manual dialling	64
	Speed-Dialling	
	Search	
	Fax Redial	
	Outgoing Call	65
	Caller ID history	
	Storing numbers	
	Storing a pause	
	Storing Speed-Dial numbers	
	Changing Speed-Dial names or numbers	
	Setting up groups for broadcasting	
	Combining Quick-Dial numbers	
9	Digital TAD (MFC-665CW only)	
	TAD-Mode for internal TAD	72
	Setting up the TAD	
	Outgoing message (OGM)	
	Fax/Tel OGM	
	Activating TAD mode	
	Managing your messages	
	Message indicator	
	Playing voice messages	
	Erasing incoming messages	
	Additional TAD operations	
	Setting maximum time for incoming messages	
	Setting toll saver	
	ICM Recording Monitor	
	Recording a conversation	/6
10	Advanced fax operations (Monochrome only)	
	Fax Forwarding	
	Fax Storage	
	Fax Preview (MFC-665CW only)	
	Setting Fax Preview	78
	How to preview a fax	79
	How to delete all faxes in the list	79
	How to print all faxes in the list	79
	PC Fax Receive	
	Changing the destination PC	
	Turning off Advanced Fax Operations	
	Changing Advanced Fax Operations	
	Remote Retrieval	
	Setting a Remote Access Code	
	Using your Remote Access Code	
	5 ,	

11	Printing Reports	
	Fax reports	87
	Transmission Verification Report	87
	Fax Journal (activity report)	
	Reports	88
	How to print a report	88
12	Polling	
	Polling overview	89
	Polling receive	89
	Setup to receive polling	89
	Setup to receive polling with secure code	89
	Setup to receive delayed polling	90
	Sequential polling (Monochrome only)	90
	Polled transmit (Monochrome only)	91
	Setup for polled transmit	
	Setup for polled transmit with secure code	91
Sec	tion III Copy	
Sec	tion III Copy Making copies	
	Making copies	0.4
	Making copies How to copy	
	Making copies How to copy Entering Copy mode	94
	Making copies How to copy Entering Copy mode Making a single copy	94 94
	Making copies How to copy	94 94
	Making copies How to copy	
	Making copies How to copy	94 94 95 95
	Making copies How to copy	94 95 95 95 95
	Making copies How to copy	94 94 95 95 95 95
	Making copies How to copy	94 95 95 95 95 95 96
	Making copies How to copy	94 95 95 95 95 96 96
	Making copies How to copy Entering Copy mode Making a single copy Making multiple copies Stop copying Copy settings Changing copy speed and quality Enlarging or reducing the image copied Making N in 1 copies or a poster (page layout) Sorting copies using the ADF	94 95 95 95 95 96 96 97
	Making copies How to copy	94 94 95 95 95 95 96 96 97
	Making copies How to copy	94 94 95 95 95 95 96 96 97 98

Section IV Direct Photo Printing

14	Printing	photos	from a	memory	card
17	I IIIIUIIM	DIIOLOG	II VIII a		, card

	PhotoCapture Center™ Operations	102
	Printing from a memory card without a PC	102
	Scanning to a memory card without a PC	
	Using PhotoCapture Center™ from your computer	102
	Using memory cards	102
	Memory card folder structure	102
	Getting started	
	Entering PhotoCapture mode	
	Print Images	
	View Photo(s)	
	Print Index (Thumbnails)	105
	Print All Photos	105
	Print Photos	106
	DPOF printing	106
	PhotoCapture Center™ print settings	107
	Print Quality	108
	Paper options	108
	Adjusting Brightness, Contrast and Colour	109
	Cropping	110
	Borderless printing	
	Setting your changes as a new default	110
	Restoring all the settings to factory settings	110
	Scan to Card	111
	Entering Scan mode	
	How to scan to card	111
	Understanding the Error Messages	112
15	Printing photos from a camera with PictBridge	
	Before Using PictBridge	113
	PictBridge requirements	
	Using PictBridge	
	Setting your digital camera	
	Printing Images	
	DPOF printing	
	Understanding the Error Messages	
	Chadrotanding the Error Meddaged	110

Section V Software

16

Software and Network features

Section VI Appendixes

	Odiety and Legal	
	Choosing a location	120
	To use the machine safely	
	IMPORTANT-For Your Safety	
	LAN connection	
	Important Information for Australia	
	IMPORTANT NOTICE	
	Important safety instructions	
	Important Information for New Zealand	
	Important Safety Instructions	
	IMPORTANT NOTICE	
	Important Information for Some Countries	
	Important Safety Instructions	
	Legal limitations for copying	
	Trademarks	
В	Troubleshooting and Routine Maintenance	
	Troubleshooting	
	If you are having difficulty with your machine	
	Error messages	
	Transferring your faxes or Fax Journal report	
	Document jam	
	Printer jam or paper jam	
	Dial Tone detection	
	Compatibility	
	Routine maintenance	
	Replacing the ink cartridges	
	Cleaning the outside of the machine	
	Cleaning the scanner	
	Cleaning the machine printer platen	
	Cleaning the paper pick-up roller	
	Cleaning the print head	
	Checking the print quality	
	Checking the printing alignment	
	Checking the ink volume	
	Uninstalling the handset and handset cradle (MFC-665CW only)	
	Machine Information	
	Checking the serial number	
	Packing and shipping the machine	155
С	Menu and Features	
	On coroon programming	150
	On-screen programming	
	Memory storage	
	Menu keys Menu table	
	Entering Toyt	17/

D Specifications

General	.175
Print media	. 177
Fax	. 178
TAD (MFC-665CW only)	
Copy	. 180
PhotoCapture Center™	.181
PictBridge	
Scanner	
Printer	. 183
Interfaces	. 184
Computer requirements	.185
Consumable items	
Network (LAN)	

E Glossary

F Index

Section I

General

General Information	2
Loading documents and paper	10
General setup	22
Security features	29

1

General Information

Using the documentation

Thank you for buying a Brother machine! Reading the documentation will help you make the most of your machine.

Symbols and conventions used in the documentation

The following symbols and conventions are used throughout the documentation.

Bold Bold typeface identifies specific

keys on the machine's control

panel.

Italicized typeface emphasizes

an important point or refers you

to a related topic.

Courier New Text in the Courier New font identifies messages on the

LCD of the machine.



Warnings tell you what to do to prevent possible personal injury.



Electrical Hazard icons alert you to possible electrical shock.



Cautions specify procedures you must follow or avoid to prevent possible damage to the machine or other objects.



Notes tell you how you should respond to a situation that may arise or give tips about how the operation works with other features.



Improper Setup icons alert you to devices and operations that are not compatible with the machine.

Accessing the Software User's Guide and Network User's Guide

This User's Guide does not contain all the information about the machine such as how to use the advanced features of the Fax, Printer, Scanner, PC Fax and Network. When you are ready to learn detailed information about these operations, read the **Software User's Guide** and **Network User's Guide** that are on the CD-ROM.

Viewing Documentation

Viewing Documentation (For Windows®)

To view the documentation, from the **Start** menu, point to **Brother**, **MFC-XXXX** (where XXXX is your model name) from the programs group, and then choose **User's Guide**.

If you have not installed the software, you can find the documentation by following the instructions below:

- 1 Turn on your PC. Insert the Brother CD-ROM into your CD-ROM drive.
- 2 If the model name screen appears, click your model name.

If the language screen appears, click your language. The CD-ROM main menu will appear.





If this window does not appear, use Windows[®] Explorer to run the setup.exe program from the root directory of the Brother CD-ROM.

Click User's Guide to view the Software User's Guide and Network User's Guide in HTML format.

How to find Scanning instructions

There are several ways you can scan documents. You can find the instructions as follows:

Software User's Guide

- Scanning
 (For Windows[®] 98/98SE/Me/2000
 Professional and Windows[®] XP)
- ControlCenter3
 (For Windows® 98/98SE/Me/2000
 Professional and Windows® XP)
- Network Scanning

PaperPort® SE with OCR User's Guide

■ The complete ScanSoft[®] PaperPort[®] SE with OCR User's Guide can be viewed from the Help selection in the ScanSoft[®] PaperPort[®] SE with OCR application.

How to find Network setup instructions (MFC-665CW only)

Your machine can be connected to a wireless or wired network. You can find basic setup instructions in the Quick Setup Guide. For more information, or if your access point supports SecureEasySetup™, please see the Network User's Guide on the CD-ROM.

Viewing Documentation (For Macintosh®)

1 Turn on your Macintosh®. Insert the Brother CD-ROM into your CD-ROM drive. The following window will appear.



- 2 Double-click the **Documentation** icon.
- 3 Double-click your language folder.
- Double-click the top page file to view the Software User's Guide and Network User's Guide in HTML format.
- 6 Click the documentation you want to read.
 - Software User's Guide
 - Network User's Guide

How to find Scanning instructions

There are several ways you can scan documents. You can find the instructions as follows:

Software User's Guide

- Scanning
 (For Mac OS® X 10.2.4 or greater)
- ControlCenter2

 (For Mac OS® X 10.2.4 or greater)
- Network Scanning
 (For Mac OS® X 10.2.4 or greater)

Presto!® PageManager® User's Guide

■ The complete Presto![®] PageManager[®] User's Guide can be viewed from the Help selection in the Presto![®] PageManager[®] application.

How to find Network setup instructions (MFC-665CW only)

Your machine can be connected to a wireless or wired network. You can find basic setup instructions in the Quick Setup Guide. For more information, or if your access point supports SecureEasySetup™, please see the Network User's Guide on the CD-ROM.

Control panel overview

MFC-440CN



MFC-665CW





Most of the illustrations in this User's Guide show the MFC-440CN.

1 Dial Pad

Use these keys to dial telephone and fax numbers and as a keyboard for entering information into the machine.

(Not available in New Zealand) The # key lets you temporarily switch the dialling mode during a telephone call from Pulse to Tone.

2 Fax and telephone keys

Search/Speed Dial (MFC-440CN only) Lets you look up and dial numbers that are stored in the memory.

■ Redial/Pause

Redials from the last 30 numbers called. It also inserts a pause when programming quick dial numbers.

■ Hook (MFC-440CN only)

Press before dialling if you want to make sure a fax machine will answer, and then press **Mono Start** or **Colour Start**.

Also, press this key after picking up the handset of an external telephone during the F/T double/pseudo-ring.

■ Recall (MFC-665CW only)

Use this key to gain access to an outside line (for Australia and New Zealand only) and/or to recall the operator or transfer a call to another extension when it is connected to a PABX.

3 Mode keys:

■ Ø Fax

Lets you access Fax mode.

■ Scan

Lets you access Scan mode.

■ © Copy

Lets you access Copy mode.

■ **Solution** PhotoCapture

Lets you access PhotoCapture Center™ mode.

4 Menu keys:

■ Volume keys



In Fax mode, you can press these keys to adjust the ring volume.

■ **Search/Speed Dial** (MFC-665CW only) Lets you look up and dial numbers that are stored in the memory.

■ ◀ or ▶

Press to scroll backward or forward to a menu selection.

■ A or ▼

Press to scroll through the menus and options.

■ Menu

Access the main menu.

■ OK

Selects a setting.

■ Clear/Back

Press to cancel the current setting.

5 Start keys:

■ **Colour Start**

Lets you start sending faxes or making copies in full colour. Also lets you start a scanning operation (in colour or monochrome, depending on the scanning setting in the ControlCenter software).

■ Mono Start

Lets you start sending faxes or making copies in monochrome. Also lets you start a scanning operation (in colour or mono, depending on the scanning setting in the ControlCenter software).

6 Power Save

Lets you put the machine into Power Save mode.

7 Stop/Exit

Stops an operation or exits from a menu.

8 LCD (liquid crystal display)

Displays messages on the screen to help you set up and use your machine.

Also, you can adjust the angle of the LCD display by lifting it.

9 Ink Management

Lets you clean the print head, check the print quality, and check the available ink volume.

10 Fax Preview (MFC-665CW only)

Lets you preview incoming faxes on the LCD.

11 TAD keys (MFC-665CW only):

■ (△i) MC On/Off

Turns the Telephone Answering Device (TAD) on or off. It will also flash if you have new messages.

■ Play/Record

Plays voice messages stored in the memory. Will also let you record telephone calls.

■ Erase/Hold

Deletes voice messages. Lets you place calls on hold.

12 Speaker Phone (MFC-665CW only)


Turns the speaker phone on or off.

13 Microphone (MFC-665CW only)

Picks up your voice when you speak to another party using **Speaker Phone**.

LCD display screen

The LCD shows the current machine status when the machine is idle.



1 Current Receive Mode

Lets you see the current receive mode.

- Fax (Fax only)
- F/T (Fax/Tel)
- TAD (External TAD) (MFC-440CN only)
- MC (Msg Ctr) (MFC-665CW only)
- Mnl (Manual)

2 Fax in memory

Shows how many received faxes are in the memory.

3 Voice message in memory

(MFC-665CW only)

Shows how many received voice messages are in the memory.

4 Memory Status

Lets you see the available memory in the machine.

5 Wireless Status (MFC-665CW only)

A four level indicator shows the current wireless signal strength if you are using a wireless connection.



6 Ink indicator

Lets you see the available ink volume.

Basic Operations


The following steps show how to change a setting in the machine. In this example, the Mode Timer setting is changed from 2 minutes to 30 seconds.

- 1 Press Menu.
- Press ▲ or ▼ to choose
 General Setup.




Press OK.

3 Press ▲ or ▼ to choose Mode Timer.




Press **OK**.

4 Press ▲ or ▼ to choose 30 Secs.



Press **OK**.

You can see the current setting on the LCD:



5 Press Stop/Exit.

Loading documents and paper

Loading documents

You can send a fax, make copies, and scan from the ADF (automatic document feeder) and from the scanner glass (Flatbed).

Using the ADF

The ADF can hold up to 10 pages and feeds each sheet individually. Use standard 80 gsm (20 lb) paper and always fan the pages before putting them in the ADF.

Recommended environment

Temperature: 20 to 30° C (68 to 86° F)

Humidity: 50% to 70%

Paper: 80 gsm A4 (20 lb LTR)

Document Sizes Supported

Length: 148 to 355.6 mm

(5.8 to 14 in.)

Width: 148 to 215.9 mm

(5.8 to 8.5 in.)

Weight: 64 to 90 gsm (17 to 24 lb)

How to load documents




CAUTION

DO NOT pull on the document while it is feeding.

DO NOT use paper that is curled, wrinkled, folded, ripped, stapled, paper clipped, pasted or taped.

DO NOT use cardboard, newspaper or fabric with ADF. Instead use the scanner glass (Flatbed).

- Make sure documents written with ink are completely dry.
- 1 Fan the pages well. Make sure you put the documents **face down, top edge first** in the ADF until you feel them touch the feed roller.
- Adjust the paper guides to fit the width of your documents.
- 3 Unfold the ADF Document Output Support Flap (1).



CAUTION

DO NOT leave thick documents on the scanner glass. If you do this, the ADF may jam.

Using the scanner glass

You can use the scanner glass to fax, copy or scan pages of a book or one page at a time.

Document Sizes Supported

 Length:
 Up to 297 mm (11.7 in.)

 Width:
 Up to 215.9 mm (8.5 in.)

 Weight:
 Up to 2 kg (4.4 lb)


How to load documents



To use the scanner glass, the ADF must be empty.

1 Lift the document cover.

Using the document guidelines on the left, center the document face down on the scanner glass.






3 Close the document cover.

CAUTION

If you are scanning a book or thick document, DO NOT slam the cover down or press on it.

Scanning area

The scannable area depends on the settings in the application you are using. The figures below show the areas you cannot scan on Letter or A4 paper.



Usage	Document Size	Top (1) Bottom (2)	Left (3) Right (4)
Fax	Letter	3 mm (0.12 in.)	4 mm (0.16 in.)
	A4	3 mm (0.12 in.)	1 mm (0.04 in.)
Сору	Letter	3 mm (0.12 in.)	3 mm (0.12 in.)
	A4	3 mm (0.12 in.)	3 mm (0.12 in.)
Scan	Letter	3 mm (0.12 in.)	3 mm (0.12 in.)
	A4	3 mm (0.12 in.)	0 mm (0 in.)

Acceptable paper and other media

The print quality can be affected by the type of paper you use in the machine.

To get the best print quality for the settings you have chosen, always set the Paper Type to match the type of paper you load.

You can use plain paper, inkjet paper (coated paper), glossy paper, transparencies and envelopes.

We recommend testing various paper types before buying large quantities.

For best results, use Brother paper.

- When you print on inkjet paper (coated paper), transparencies and photo paper, be sure to choose the proper media in the 'Basic' tab of the printer driver or in the Paper Type setting of the menu (see Paper Type on page 24).
- When you print on Brother photo paper, load the instruction sheet included with the photo paper in the paper tray first, and then put the photo paper on top of the instruction sheet.
- When you use transparencies or photo paper, remove each sheet at once to prevent smudging or paper jams.
- Avoid touching the printed surface of the paper immediately after printing; the surface may not be completely dry and may stain your fingers.

Recommended media

To get the best print quality, we suggest using Brother paper. (See table below.)

If Brother paper is not available in your country, we recommended testing various papers before purchasing large quantities.

We recommend using '3M Transparency Film' when you print on transparencies.

Brother paper

Paper Type	Item
A4 Plain	BP60PA
A4 Glossy Photo	BP61GLA
A4 Inkjet (Matte)	BP60MA
10×15 cm Glossy Photo	BP61GLP


Handling and using media

- Store paper in its original packaging, and keep it sealed. Keep the paper flat and away from moisture, direct sunlight and heat.
- The coated side of photo paper is shiny. Avoid touching the shiny (coated) side. Load photo paper with the shiny side facing down.
- Avoid touching either side of transparencies because they absorb water and perspiration easily, and this may cause decreased output quality. Transparencies designed for laser printers/copiers may stain your next document. Use only transparencies recommended for inkjet printing.

Maria Maria

DO NOT use the following kinds of paper:

• Damaged, curled, wrinkled, or irregularly shaped paper



- 1 2 mm (0.08 in.) or longer
- Extremely shiny or highly textured paper
- Paper already printed on by a printer
- Paper that cannot be arranged uniformly when stacked
- Paper made with a short grain

Paper capacity of the output paper tray

Up to 50 sheets of 20 lb Letter or 80 gsm A4 paper.

■ Transparencies or photo paper must be picked up from the output paper tray one page at a time to avoid smudging.

Choosing the right media

Paper type and size for each operation for paper tray

Paper Type	Paper Size		Usage			
			Fax	Сору	Photo Capture	Printer
Cut Sheet	Letter	216×279 mm (8 1/2 \times 11 in.)	Yes	Yes	Yes	Yes
	A4	210×297 mm (8.3 \times 11.7 in.)	Yes	Yes	Yes	Yes
	Legal	216×356 mm (8 1/2 \times 14 in.)	Yes	Yes	_	Yes
	Executive	184×267 mm (7 $1/4\times10$ $1/2$ in.)	_	_	_	Yes
	JIS B5	182×257 mm (7.2 \times 10.1 in.)	_	_	_	Yes
	A5	148×210 mm (5.8 \times 8.3 in.)	_	Yes	_	Yes
	A6	105×148 mm (4.1 $\times5.8$ in.)	_	_	_	Yes
Cards	Photo	10 × 15 cm (4 × 6 in.)	_	Yes	Yes	Yes
	Photo L	89×127 mm (3 1/2 \times 5 in.)	_	_	_	Yes
	Photo 2L	13×18 cm (5 \times 7 in.)	_	_	Yes	Yes
	Index Card	127×203 mm (5 \times 8 in.)	_	_	_	Yes
	Post Card 1	100×148 mm (3.9 \times 5.8 in.)	_	_	_	Yes
	Post Card 2 (Double)	$148 \times 200 \text{ mm } (5.8 \times 7.9 \text{ in.})$	_	_	_	Yes
Envelopes	C5 Envelope	162 × 229 mm (6.4 × 9 in.)	_	_	_	Yes
	DL Envelope	$110 \times 220 \text{ mm } (4.3 \times 8.7 \text{ in.})$	_	_	_	Yes
	COM-10	105×241 mm (4 1/8 \times 9 1/2 in.)	_	_	_	Yes
	Monarch	98×191 mm (3 $7/8\times7$ 1/2 in.)	_	_	_	Yes
	JE4 Envelope	$105 \times 235 \text{ mm } (4.1 \times 9.3 \text{ in.})$	_	_	_	Yes
Transparencies	Letter	216 × 279 mm (8 1/2 × 11 in.)	_	Yes	_	Yes
	A4	210×297 mm (8.3 \times 11.7 in.)	_	Yes	_	Yes

Paper weight, thickness and capacity

Paper Type		Weight	Thickness	No. of sheets
Cut	Plain Paper	64 to 120 gsm (17 to 32 lb)	0.08 to 0.15 mm (0.003 to 0.006 in.)	100 ¹
Sheet	Inkjet Paper	64 to 200 gsm (17 to 53 lb)	0.08 to 0.25 mm (0.003 to 0.01 in.)	20
	Glossy Paper	Up to 220 gsm (Up to 58 lb)	Up to 0.25 mm (Up to 0.01 in.)	20
Cards	Photo Card	Up to 240 gsm (Up to 64 lb)	Up to 0.28 mm (Up to 0.01 in.)	20 ²
	Index Card	Up to 120 gsm (Up to 32 lb)	Up to 0.15 mm (Up to 0.006 in.)	30
	Post Card	Up to 200 gsm (Up to 53 lb)	Up to 0.23 mm (Up to 0.01 in.)	30
Envelopes		75 to 95 gsm (20 to 25 lb)	Up to 0.52 mm (Up to 0.02 in.)	10
Transparencies		_	-	10

Up to 50 sheets for Legal size paper 80 gsm (20 lb). Up to 100 sheets of 80 gsm (20 lb) paper.

² For Photo 10×15 cm and Photo L paper, use the photo paper tray. (See *Loading photo paper* on page 19.)

Loading paper, envelopes and other media


Loading paper and other media




To print on Photo 10×15 cm or Photo L paper, you must use the photo paper tray. (See *Loading photo paper* on page 19.)

1 If the paper support flap is open, close it, and then pull the paper tray completely out of the machine.


Lift the output paper tray cover (1).



Press and slide the paper side guides (1) and paper length guide (2) to fit the paper size.




Fan the stack of paper well to avoid paper jams and misfeeds.



Note


Always make sure that the paper is not curled.

Gently put the paper into the paper tray print side down and top edge first. Check that the paper is flat in the tray.






When you use Legal size paper, press and hold the universal guide release button as you slide out the front of the paper tray.




5 Gently adjust the paper side guides with both hands and the paper length guide to the paper.

Make sure the paper side guides touch the sides of the paper.





Be careful that you do not push the paper in too far; it may lift at the back of the tray and cause feed problems. 6 Close the output paper tray cover.



7 Slowly push the paper tray completely into the machine.



8 While holding the paper tray in place, pull out the paper support (1) until it clicks and unfold the paper support flap (2).





Do not use the paper support flap for Legal paper.

Loading envelopes, post cards and photo paper

Loading envelopes

- Use envelopes that weigh from 75 to 95 gsm (20 to 25 lb).
- Some envelopes need margin settings to be set in the application. Make sure you do a test print first.



CAUTION

Do not use any of the following types of envelopes, as they will cause paper feed problems:

- · If they are of a baggy construction.
- That are embossed (have raised writing on them).
- · That have clasps or staples.
- · That are pre-printed on the inside.

Glue	Double flap

Occasionally you may experience paper feed problems caused by the thickness, size and flap shape of the envelopes you are using.

How to load envelopes and post cards




1 Before loading, press the corners and sides of the envelopes or post cards to make them as flat as possible.



Mote


If the envelopes or post cards are 'doublefeeding,' put one envelope in the paper tray at a time.








2 Put the envelopes or post cards into the paper tray with the address side down and the leading edge in first as shown in the illustration. Slide the paper side guides (1) and paper length guide (2) to fit the size of the envelopes or post cards.



If you have problems when printing on envelopes, try the following suggestions:


- 1 Open the envelope flap.
- 2 Make sure the open flap is either to the side of the envelope or to the back edge of the envelope when printing.
- Adjust the size and margin in your application.



Loading photo paper


Use the photo paper tray, which has been assembled on the top of the output paper tray cover, to print on photo 10×15 cm and photo L size paper. You can leave paper in the standard paper tray when using the photo paper tray.

1 Press the tray release button with your left thumb and push the photo paper tray (the top part of the tray) backward until it clicks into the photo printing position.



1 Photo Paper Tray


Press and slide the paper side guides (1) and paper length guide (2) to fit the paper size.



Chapter 2

Put the photo paper into the photo paper tray and gently adjust the paper side guides to the paper.


Make sure the paper side guides touch the sides of the paper.






- Be careful that you do not push the paper in too far; it may lift at the back of the tray and cause feed problems.
- Always make sure that the paper is not curled.
- When you have finished printing photos return the photo paper tray to the normal printing position.

Press the photo paper tray release button with your left thumb and pull the photo paper tray forward until it clicks.



Removing small printouts from the machine


When the machine ejects small paper onto the output paper tray you may not be able to reach it. Make sure printing has finished, and then pull the tray completely out of the machine.




Printable area

The printable area depends on the settings in the application you are using. The figures below show the unprintable areas on cut sheet paper and envelopes. The machine can only print in the shaded areas when the Borderless print feature is available and turned on.

Cut Sheet Paper



Envelopes



	Top (1)	Bottom (2)	Left (3)	Right (4)
Cut Sheet	3 mm (0.12 in.)	3 mm (0.12 in.)	3 mm (0.12 in.)	3 mm (0.12 in.)
Envelopes	12 mm (0.47 in.)	24 mm (0.95 in.)	3 mm (0.12 in.)	3 mm (0.12 in.)



The Borderless feature is not available for envelopes.

Power Save mode

When the machine is idle, you can put the machine into Power Save mode by pressing the **Power Save** key. You can still receive telephone calls in Power Save mode. For further information on receiving faxes in the power save condition, please see the table on On/Off setting on page 23. The delayed faxes that have been set up will be sent. You can even retrieve faxes using Remote Retrieval (See page 82.) if you are away from your machine. If you want to do other operations, you must take the machine out of Power Save mode.



If you have connected an external telephone or TAD, it is always available.

Putting your machine in Power Save mode

Press and hold down the Power Save key until the LCD shows Shutting Down.

The LCD light goes off.

Bringing your machine out of **Power Save mode**

Press the **Power Save** key.

Mote

- · Even if you have put the machine into Power Save mode, it will periodically clean the print head to preserve print quality.
- If you unplug the AC power cord, no machine operations will be available.
- You can customize Power Save mode so that, apart from automatic head cleaning, no machine operations are available.

Power Save setting

You can customize the machine's Power Save key. The factory setting is Fax Receive: On. Your machine can receive faxes or calls even when the machine is in Power Save mode. If you do not want your machine to receive faxes or calls, turn this setting to Fax Receive: Off. (See Power Save mode on page 22.)


- Press Menu.
- Press ▲ or ▼ to choose General Setup. Press OK.
- Press ▲ or ▼ to choose P.Save Setting. Press OK.
- Press ▲ or ▼ to choose Fax Receive:Off (or Fax Receive: On). Press OK.
- Press Stop/Exit.

On/Off setting	Receive mode	Available operations
Fax Receive: On 12 (factory setting)	Fax Only External TAD 3 Fax/Tel 4	Fax Receive Fax Detect Delayed Fax ⁶ Fax Forward ⁶ Fax Storage ⁶ PC Fax Receive ⁶ Remote Retrieval ⁶
	TAD 4	Fax Receive Recording of incoming messages Fax Detect Delayed Fax ⁶ Fax Forward ⁶ Fax Storage ⁶ PC Fax Receive ⁶ Remote Retrieval ⁶
	Manual Fax/Tel ⁵	Fax Detect Delayed Fax ⁶
Fax Receive: Off	_	No machine operations will be available other than cleaning the print head.

- You cannot receive a fax with Mono Start or Colour Start.
- You can receive telephone calls by lifting the handset (MFC-665CW only).
- 3 MFC-440CN only
- 4 MFC-665CW only
- 5 (MFC-440CN only) You cannot receive a fax automatically if you have set the receive mode to Fax/Te1.
- ⁶ Set before you switch off the machine.

Mode Timer

The machine has four temporary mode keys on the control panel: Fax, Scan, Copy and PhotoCapture. You can change the amount of time the machine takes after the last Scan, Copy or PhotoCapture operation before it returns to Fax mode (default). If you choose Off, the machine stays in the mode you used last.



- 1 Press Menu.
- Press ▲ or ▼ to choose
 General Setup.
 Press OK.
- 3 Press ▲ or ▼ to choose Mode Timer.
 Press OK.
- 4 Press ▲ or ▼ to choose 0 Sec, 30 Secs, 1 Min, 2 Mins, 5 Mins or Off. Press OK.
- 5 Press Stop/Exit.

Paper settings

Paper Type

To get the best print quality, set the machine for the type of paper you are using.

- 1 Press Menu.
- Press ▲ or ▼ to choose General Setup. Press OK.
- Press ▲ or ▼ to choose Paper Type. Press OK.
- Press ▲ or ▼ to choose Plain Paper, Inkjet Paper, Brother Photo, Other Photo Of Transparency. Press OK.
- 6 Press Stop/Exit.



The machine ejects paper with printed surfaces face up onto the paper tray in front of the machine. When you use transparencies or glossy paper, remove each sheet at once to prevent smudging or paper jams.

Paper Size

You can use five sizes of paper for printing copies: Letter, Legal, A4, A5, and 10×15 cm $(4\times6$ in.) and three sizes for printing faxes: Letter, Legal and A4. When you change the size of paper you load in the machine, you will need to change the paper size setting at the same time so your machine can fit an incoming fax on the page.

- 1 Press Menu.
- Press ▲ or ▼ to choose General Setup. Press OK.
- Press ▲ or ▼ to choose Paper Size. Press OK.
- Press ▲ or ▼ to choose Letter, Legal, A4, A5 or 10×15cm. Press OK.
- 5 Press Stop/Exit.

Volume Settings

Ring Volume

You can choose a range of ring volume levels, from High to Off.

While in Fax mode (, press <) ◀ or

▶ ◄③) to adjust the volume level. The LCD shows the current setting, and each key press will change the volume to the next level. The machine will keep the new setting until you change it. You can also change the volume through the menu, by following the instructions below:

Setting the Ring Volume from the menu

- 1 Press Menu.
- Press ▲ or ▼ to choose
 General Setup.
 Press OK.
- 3 Press ▲ or ▼ to choose Volume.
 Press OK.
- Press ▲ or ▼ to choose Ring. Press OK.
- Press ▲ or ▼ to choose Low, Med, High or Off. Press OK.
- 6 Press Stop/Exit.

Beeper Volume

When the beeper is on, the machine will beep when you press a key, make a mistake or after you send or receive a fax.

You can choose a range of volume levels, from \mathtt{High} to $\mathtt{Off}.$

- Press Menu.
- Press ▲ or ▼ to choose
 General Setup.
 Press OK.
- 3 Press ▲ or ▼ to choose Volume. Press OK.
- Press ▲ or ▼ to choose Beeper. Press OK.
- 5 Press ▲ or ▼ to choose Low, Med, High or Off Press OK.
- 6 Press Stop/Exit.

Speaker Volume

You can choose a range of speaker volume levels, from High to Off.

- 1 Press Menu.
- Press ▲ or ▼ to choose
 General Setup.
 Press OK.
- 3 Press ▲ or ▼ to choose Volume.
 Press OK.
- Press ▲ or ▼ to choose Speaker. Press OK.
- Press ▲ or ▼ to choose Low, Med, High or Off. Press OK.
- 6 Press Stop/Exit.

You can also adjust the speaker volume by pressing **Hook** or **Speaker Phone**.

- 1 Press Hook or Speaker Phone.
- Press Hook or Speaker Phone.



(MFC-665CW only)

You can adjust the speaker volume while you are listening to your outgoing message (OGM) and incoming messages (ICM's) by pressing ♥⟩ ◀ or ▶ ♥⟩.

Setting Daylight Savings Time

You can set the machine to change for daylight savings time. It will reset itself forward one hour in the Spring and backward one hour in the Autumn. Make sure you have set the correct date and time in the <code>Date/Time</code> setting.

- 1 Press Menu.
- Press ▲ or ▼ to choose General Setup. Press OK.
- 3 Press ▲ or ▼ to choose
 Daylight Save.
 Press OK.
- Press ▲ or ▼ to choose off (or on).
 Press OK.
- 5 Press Stop/Exit.

LCD display

LCD Contrast

If you are having difficulty reading the LCD, try changing the contrast setting.

- 1 Press Menu.
- Press ▲ or ▼ to choose General Setup. Press OK.
- 3 Press ▲ or ▼ to choose
 LCD Settings.
 Press OK.
- 4 Press ▲ or ▼ to choose
 LCD Contrast.
 Press OK.
- Press ▲ or ▼ to choose Light, Med or Dark.
 Press OK.
- 6 Press Stop/Exit.

Setting the backlight brightness

You can adjust the brightness of the LCD backlight. If you are having difficulty reading the LCD, try changing the brightness setting.

- 1 Press Menu.
- Press ▲ or ▼ to choose

 General Setup.

 Press OK.
- 3 Press ▲ or ▼ to choose LCD Settings. Press OK.
- Press ▲ or ▼ to choose Backlight. Press OK.
- Press ▲ or ▼ to choose Light, Med or Dark.
 Press OK.
- 6 Press Stop/Exit.

Setting the Dim Timer for the backlight

You can set how long the LCD backlight stays on after the last key press.

- 1 Press Menu.
- Press ▲ or ▼ to choose
 General Setup.
 Press OK.
- 3 Press ▲ or ▼ to choose
 LCD Settings.
 Press OK.
- Press ▲ or ▼ to choose Dim Timer. Press OK.
- 5 Press ▲ or ▼ to choose 10 Secs, 20 Secs, 30 Secs or Off.
 Press OK.
- 6 Press Stop/Exit.

Setting the Off Timer

You can set how long the LCD stays on after the last key press. This is a power saving feature. The machine can print, scan and receive faxes and voice calls when the LCD is off.

- 1 Press Menu.
- Press ▲ or ▼ to choose
 General Setup.
 Press OK.
- 3 Press ▲ or ▼ to choose
 LCD Settings.
 Press OK.
- Press ▲ or ▼ to choose Off Timer. Press OK.
- 5 Press ▲ or ▼ to choose 1 Min, 2 Mins, 3 Mins, 5 Mins, 10 Mins, 30 Mins or Off. Press OK.
- 6 Press Stop/Exit.



When the display is off, you can press any key to turn it back on.

Setting the Wallpaper

You can change the wallpaper.

- 1 Press Menu.
- Press ▲ or ▼ to choose General Setup. Press OK.
- 3 Press ▲ or ▼ to choose
 LCD Settings.
 Press OK.
- 4 Press ▲ or ▼ to choose Wallpaper. Press OK.
- Press ▲ or ▼ to choose a wallpaper. Press OK.
- 6 Press Stop/Exit.

4

Security features

TX Lock (MFC-440CN only)

TX Lock lets you prevent unauthorized access to the machine. You will not be able to schedule Delayed Faxes or Polling jobs. However, any pre-scheduled Delayed Faxes will be sent even if you turn on TX Lock, so they will not be lost.

While TX Lock is On, the following operations are available:

- Receiving faxes
- Fax Forwarding (If Fax Forwarding was already On)
- Remote retrieval (If Fax Storage was already On)
- PC Fax Receive (if PC Fax Receive was already On)

While TX Lock is On, the following operations are NOT available:

- Sending faxes
- Copying
- PC printing
- Scanning
- PhotoCapture

Setting and changing the TX Lock password

Setting up the password



- If you forget the TX Lock password, please call Brother dealer for service.
- If you have already set the password, you will not need to set it again.
- 1 Press Menu.

- Press ▲ or ▼ to choose Fax.
- 3 Press ▲ or ▼ to choose Miscellaneous. Press OK.
- Press ▲ or ▼ to choose TX Lock. Press OK.
- 5 Enter a 4-digit number for the password. Press **OK**.
- 6 When the LCD shows Verify:, reenter the password.

 Press **OK**.
- 7 Press Stop/Exit.

Changing the TX Lock password

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- 4 Press ▲ or ▼ to choose TX Lock.
 Press OK.
- 5 Press ▲ or ▼ to choose
 Set Password.
 Press OK.
- 6 Enter a 4-digit number for the current password.
 Press **OK**.
- Enter a 4-digit number for a new password.
 Press **OK**.
- 8 When the LCD shows Verify:, reenter the password.
 Press **OK**.
- 9 Press Stop/Exit.

Turning the TX Lock on/off

Turning TX Lock on

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- Press ▲ or ▼ to choose TX Lock. Press OK.
- 5 Press ▲ or ▼ to choose Set TX Lock.
 Press OK.
- 6 Enter the registered 4-digit password. Press **OK**.

 The machine goes offline and the LCD shows TX Lock Mode.

Turning TX Lock off

- 1 Press Menu.
- Enter the registered 4-digit password.Press **OK**.TX lock is automatically turned off.



If you enter the wrong password, the LCD shows Wrong Password and stays offline. The machine will stay in TX Lock mode until the registered password is entered.

Memory Security (MFC-665CW only)

Memory Security lets you prevent unauthorized access to the machine. You will not be able to schedule Delayed Faxes or Polling jobs. However, any pre-scheduled Delayed Faxes will be sent even if you turn on Memory Security, so they will not be lost.

While Memory Security is On, the following operations are available:

- Receiving faxes into memory (limited by memory capacity)
- Fax Forwarding (If Fax Forwarding was already On)
- Remote retrieval (If Fax Storage was already On)

While Memory Security is on, the following operations are NOT available:

- Printing received faxes
- Sending faxes
- Copying
- PC printing
- Scanning
- PhotoCapture
- PC Fax Receive



- To print the faxes in memory, turn off Memory Security.
- You must turn off PC Fax Receive before you can turn on Memory Security. (See Turning off Advanced Fax Operations on page 81.)

Setting and changing the memory security password

Setting a password for the first time



- If you forget the Memory Security password, please call Brother dealer for service.
- If you have already set the password, you will not need to set it again.
- Press Menu.
- Press ▲ or ▼ to choose Fax.
 Press OK.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- Press ▲ or ▼ to choose
 Mem Security.
 Press OK.
- 5 Enter a 4-digit number for the password. Press **OK**.
- 6 When the LCD shows Verify:, reenter the password.

 Press **OK**.
- 7 Press Stop/Exit.

Changing your memory security password

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- Press ▲ or ▼ to choose Mem Security. Press OK.
- 5 Press ▲ or ▼ to choose
 Set Password.
 Press OK.
- 6 Enter the registered 4-digit number for the current password.
 Press **OK**.
- 7 Enter a 4-digit number for a new password. Press **OK**.
- 8 When the LCD shows Verify:, reenter the new password.
 Press **OK**.
- 9 Press Stop/Exit.

Turning the memory security on/off

Turning on the memory security lock

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- Press ▲ or ▼ to choose
 Mem Security.
 Press OK.
- 5 Press ▲ or ▼ to choose
 Set Security.
 Press OK.
- 6 Enter the registered 4-digit password. Press **OK**.
 The machine goes offline and the LCD shows Secure Mode.



If there is a power failure the data will stay in memory for up to 24 hours.

Turning off the memory security

- 1 Press Menu.
- Enter the registered 4-digit password. Press **OK**. Memory Security is automatically turned off.



If you enter the wrong password, the LCD shows <code>Wrong Password</code> and stays offline. The machine will stay in Secure mode until the registered password is entered.

Section II


Fax


Sending a fax	34
Receiving a Fax	42
Telephone Services and External devices	49
Dialling and storing numbers	64
Digital TAD (MFC-665CW only)	72
Advanced fax operations (Monochrome only)	77
Printing Reports	87
Polling	89

Sending a fax

Entering Fax mode

When you want to send a fax, or change fax send or receive settings, press the





The LCD shows:



Press \triangle or ∇ to scroll through the **Fax** key options. Some functions are only available when sending monochrome faxes.

- Fax Resolution (See page 38.)
- Contrast (See page 38.)
- Speed-Dial (See page 64.)
- Outgoing Call (See page 65.)

Please scroll down to see other selections.

- Caller ID hist. (See page 66.)
- Broadcasting (See page 36.)
- Delayed Fax (See page 39.)
- Batch TX (See page 40.)
- Real Time TX (See page 39.)
- Polled TX (See page 91.)
- Polling RX (See page 89.)
- Overseas Mode (See page 39.)

- Scan Size (See page 35.)
- Set New Default (See page 40.)
- Factory Reset (See page 41.)

When the option you want is highlighted, press **OK**.

Faxing from the ADF

- 1 Press 🚳 (Fax).
- Put the document face down in the ADF.
- 3 Enter the fax number using the dial pad, Speed-Dial or Search.
- 4 Press Mono Start or Colour Start.
 The machine starts scanning the document.



- · To cancel, press Stop/Exit.
- If the memory is full, the document will be sent in real time.

F

Faxing from the scanner glass

You can use the scanner glass to fax pages of a book one at a time. The documents can be up to letter or A4 size.

You cannot send multiple pages for colour faxes.



Since you can only scan one page at a time, it is easier to use the ADF if you are sending a multiple page document.

- 1 Press (Fax).
- 2 Load your document face down on the scanner glass.
- 3 Enter the fax number using the dial pad, Speed-Dial or Search.
- Press Mono Start or Colour Start.
 - If you press Mono Start, the machine starts scanning the first page. Go to step 6.
 - If you press Colour Start, the machine starts sending the document.
- 5 Do one of the following:
 - To send a single page, press 2 to choose No (or press Mono Start again).
 - The machine starts sending the document.
 - To send more than one page, press1 to choose Yes and go to step 6.
- 6 Put the next page on the scanner glass. Press **OK**.

The machine starts scanning the page. (Repeat steps **⑤** and **⑥** for each additional page.)



If the memory is full and you are faxing a single page, it will be sent in real time.

Faxing Letter size documents from the scanner glass

When documents are Letter size, you need to set Scan Size to Letter. If you do not, the side portion of the faxes will be missing.

- 1 Press (Fax).
- Press ▲ or ▼ to choose Scan Size. Press OK.
- Press ▲ or ▼ to choose Letter.
 Press OK.



You can save the setting you use most often by setting it as default. (See page 40.)

Colour fax transmission

Your machine can send a colour fax to machines that support this feature.

Colour faxes cannot be stored in the memory. When you send a colour fax, the machine will send it in real time (even if $Real\ Time\ TX$ is set to Off).

Cancelling a fax in progress

If you want to cancel a fax while the machine is scanning, dialling or sending, press **Stop/Exit**.

Broadcasting (Monochrome only)

Broadcasting is when the same fax message is automatically sent to more than one fax number. You can include Groups (See page 69.), Speed-Dial numbers and up to 50 manually dialled numbers in the same broadcast.

After the broadcast is finished, a Broadcast Report will be printed.

- 1 Press (Fax).
- 2 Load your document.
- 3 Press ▲ or ▼ to choose Broadcasting.
 Press OK.
- Press ▲ or ▼ to choose Add Number. Press OK.
- 5 Enter a number using Speed-Dial, a Group, or the dial pad.
 Press **OK**.
- 6 Repeat steps and to enter more fax numbers, and then press or to choose Complete.
 Press OK.
- Press Mono Start.



- If you did not use up any of the numbers for Groups or access codes or credit card numbers, you can 'broadcast' faxes to as many as 210 different numbers.
- The available memory will vary depending on the types of jobs in the memory and the number of locations used for broadcasting. If you broadcast to the maximum numbers available, you will not be able to use dual access and delayed fax.
- Enter the long dialling sequence numbers as you would normally, but remember that each Speed-Dial number counts as one number, so the number of locations you can store becomes limited. (See Combining Quick-Dial numbers on page 71.)
- If the memory is full, press Stop/Exit to stop the job. If more than one page has been scanned, press Mono Start to send the portion that is in the memory.

Cancelling a Broadcast in progress

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Remaining Jobs.

Press OK.

The LCD will show the fax number being dialled and the Broadcast job number.

Press OK. The LCD will ask you the following message:

Cancel Job?
Yes→Press 1
No→Press 2

- Press 1 to clear the number being dialled.
 The LCD will then show the Broadcast
- 6 Press **OK**.
 The LCD will ask you the following message:

Cancel Job?
Yes→Press 1
No→Press 2

job number.

- Press 1 to cancel the Broadcast.
- 8 Press Stop/Exit.

Additional sending operations

Sending faxes using multiple settings

When you send a fax, you can choose any combination of these settings: resolution, contrast, overseas mode, delayed fax timer, polling transmission and real time transmission.

1 Press (Fax).
The LCD shows:



- Press ▲ or ▼ to choose any settings you want to change. Press OK.
- 3 After each setting is accepted, you can continue to change more settings.



- Most settings are temporary and the machine returns to its default settings after you send a fax.
- You can save some of the settings you use most often by setting them as default. These settings will stay until you change them again. (See Setting your changes as a new default on page 40.)

Contrast

If your document is very light or very dark, you may want to change the contrast. For most documents, the factory setting Auto can be used. It automatically chooses the suitable contrast for your document.

Use Light when sending a light document.

Use Dark when sending a dark document.



- Press ▲ or ▼ to choose Contrast. Press OK.
- Press ▲ or ▼ to choose Auto, Light or Dark.
 Press OK.



Even if you choose Light or Dark, the machine will send the fax using the Auto setting in any of the following conditions:

- · When you send a colour fax.
- When you choose Photo as the Fax Resolution.

Changing fax resolution

The quality of a fax can be improved by changing the fax resolution.

- 1 Press (Fax).
- Press ▲ or ▼ to choose
 Fax Resolution.
 Press OK.
- 3 Press ▲ or ▼ to choose the resolution you want. Press OK.



 You can choose four different resolution settings for monochrome faxes and two for colour.

Monochrome	
Standard	Suitable for most typed documents.
Fine	Good for small print and transmits a little slower than Standard resolution.
S.Fine	Good for small print or artwork and transmits slower than Fine resolution.
Photo	Use when the document has varying shades of grey or is a photograph. This has the slowest transmission.

Colour	
Standard	Suitable for most typed documents.
Fine	Use when the document is a photograph. The transmission time is slower than Standard resolution.

If you choose S.Fine or Photo and then use the Colour Start key to send a fax, the machine will send the fax using the Fine setting.

• The time to send will increase when selecting S.Fine or Photo.

Dual access (Monochrome only)

You can dial a number and start scanning the fax into memory—even when the machine is sending from memory, receiving faxes or printing PC data. The LCD shows the new job number and available memory.

The number of pages you can scan into the memory will vary depending on the data that is printed on them.



If the Out of Memory message appears while scanning documents, press Stop/Exit to cancel or Mono Start to send the pages scanned so far.

Real time transmission

When you are sending a fax, the machine will scan the documents into the memory before sending. Then, as soon as the phone line is free, the machine will start dialling and sending.

If the memory is full, the machine will send the document in real time (even if Real Time TX is set to Off).

Sometimes, you may want to send an important document immediately, without waiting for memory transmission. You can turn on Real Time TX.

To send a document at once without waiting for memory transmission, set

Real Time TX to On.

- 1 Press (Fax).
- Press ▲ or ▼ to choose
 Real Time TX.
 Press OK.
- 3 Press ▲ or ▼ to choose on. Press **OK**.



- In real time transmission, the automatic redial feature does not work when using the scanner glass.
- If you are sending a colour fax, the machine will send it in real time (even if Real Time TX is set to Off).

Overseas Mode

If you are having difficulty sending a fax overseas due to possible interference on the phone line, we recommend that you turn on the Overseas mode. After you send a fax using this feature, the feature will turn itself off.

- 1 Press (Fax).
- 2 Load your document.
- 3 Press ▲ or ▼ to choose
 Overseas Mode.
 Press OK.
- Press ▲ or ▼ to choose on (or off).
 Press OK.

Delayed Faxing (Monochrome only)

During the day you can store up to 50 faxes in the memory to be sent within 24-hours. These faxes will be sent at the time of day you enter in step **6**.

- 1 Press 🔊 (Fax).
- 2 Load your document.
- 3 Press ▲ or ▼ to choose Delayed Fax. Press OK.
- Press ▲ or ▼ to choose on. Press OK.

5 Enter the time you want the fax to be sent (in 24-hour format).
(For example, enter 19:45 for 7:45 PM.)
Press **OK**.



The number of pages you can scan into the memory depends on the amount of data that is printed on each page.

Delayed Batch Transmission (Monochrome only)

Before sending the delayed faxes, your machine will help you economize by sorting all the faxes in the memory by destination and scheduled time. All delayed faxes that are scheduled to be sent at the same time to the same fax number will be sent as one fax to save transmission time.

- 1 Press (Fax).
- Press ▲ or ▼ to choose Batch TX. Press OK.
- Press ▲ or ▼ to choose on (or off).
 Press OK.
- 4 Press Stop/Exit.

Checking and cancelling waiting jobs

You can check which jobs are still waiting in the memory to be sent and cancel a job. (If there are no jobs, the LCD shows

No Jobs Waiting.)

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Remaining Jobs. Press OK. Any waiting jobs appear on the LCD.

- Press ▲ or ▼ to scroll through the jobs and choose the job you want to cancel. Press OK.
- Do one of the following:
 - To cancel, press 1 to choose Yes.

 If you want to cancel another job go to step 4.
 - To exit without cancelling, press 2 to choose No.
- 6 When you have finished, press Stop/Exit.

Setting your changes as a new default

You can save the fax settings for

Fax Resolution, Contrast, Real Time TX and Scan Size you use most often by setting them the default setting. These settings will stay until you change them again.

- 1 Press (Fax).
- Press ▲ or ▼ to choose your new setting.
 Press OK.
 Repeat this step for each setting you want to change.
- After changing the last setting, press ▲ or ▼ to choose Set New Default. Press OK.
- 4 Press 1 to choose Yes.
- 5 Press Stop/Exit.

Restoring all settings to the factory settings

You can restore all the settings you have changed to the factory settings. These settings will stay until you change them again.

- 1 Press (Fax).
- Press ▲ or ▼ to choose
 Factory Reset.
 Press OK.
- 3 Press 1 to choose Yes.
- 4 Press Stop/Exit.

Sending a fax manually

Manual transmission lets you hear the dialling, ringing and fax-receiving tones while sending a fax.

- 1 Press (Fax).
- 2 Load your document.
- 3 Pick up the handset of an external phone or the machine and listen for a dial tone.

You can also press **Hook** or **Speaker Phone** and listen for a dial tone.

- 4 Dial the fax number you want to call. If you pressed **Hook** or **Speaker Phone**, dial using the machine's dial pad. If you picked up the external handset, dial on the external phone.
- When you hear the fax tone, press
 Mono Start or Colour Start.
 - If you are using the scanner glass press 1 to send a fax.
- 6 If you picked up the handset replace it.

Sending a fax at the end of a conversation

At the end of a conversation you can send a fax to the other party before you both hang up.

- 1 Ask the other party to wait for fax tones (beeps) and then to press the Start or Send key before hanging up.
- Press (Fax).
- 3 Load your document.
- 4 Press Mono Start or Colour Start.
 If you are using the scanner glass, press 1 to send a fax.
- 5 Replace the handset.

Out of Memory message

If you get an Out of Memory message while scanning the first page of a fax, press **Stop/Exit** to cancel the fax.

If you get an Out of Memory message while scanning a subsequent page, you will have the option to press **Mono Start** to send the pages scanned so far, or to press **Stop/Exit** to cancel the operation.



If you get an Out of Memory message while faxing and you do not want to delete your stored faxes to clear the memory, you can send the fax in real time. (See Real time transmission on page 39.)

Receiving a Fax

Receive modes

You must choose the receive mode depending on the external devices and telephone services you have about your line.


Choosing the Receive Mode

By default, your machine will automatically receive any faxes that are sent to it.


The following diagrams will help you choose the correct mode.

For more detailed information on the receive modes see page 44.

MFC-440CN



MFC-665CW



* We recommend you set Fax Detect to On.

To set a receive mode follow the instructions below.

- 1 Press Menu.
- Press ▲ or ▼ to choose
 Initial Setup.
 Press OK.
- 3 Press ▲ or ▼ to choose

 Receive Mode.

 Press OK.
- Press ▲ or ▼ to choose Fax Only,
 Fax/Tel, External TAD
 (MFC-440CN only) or Manual.
 Press OK.
- 6 Press Stop/Exit.

The LCD will display the current receive mode.

Using receive modes

Some receive modes answer faxes automatically (Fax Only and Fax/Tel). You may want to change the ring delay before using these modes. See *Ring Delay* on page 45.

Fax only

Fax only mode will automatically answer every call as a fax call. If the call is a fax your machine will receive it.

Fax/Tel

Fax/Tel mode helps you automatically manage incoming calls, by recognising whether they are fax or voice calls and dealing with them in one of the following ways:

- Faxes will be automatically received.
- Voice calls will start the F/T ring to tell you to pick up the line. The F/T ring is a fast double ring made by your machine.
- Use this mode if you receive few voice calls.

Also see *F/T Ring Time* (*Fax/Tel mode only*) on page 45 and *Ring Delay* on page 45.

Manual

Manual mode turns off all automatic answering functions unless you are using the Distinctive ¹ feature or you are using an external TAD with the MFC-665CW.

Fax Ability in New Zealand

To receive a fax in manual mode press **Mono Start** or **Colour Start** when you hear fax tones (short repeating beeps). You can also use the Fax Detect feature to receive faxes by lifting a handset on the same line as the machine.

Also see Fax Detect on page 46.

If you use a computer modem or the same line, Faxing will not operate correctly.

TAD (MC) (MFC-665CW only)

TAD (MC) helps you automatically manage incoming calls, by recognising whether they are fax or voice calls and dealing with them in one of the following ways:

- Faxes will be automatically received.
- Voice callers can record a message.

To set up the TAD mode see page 72.



If TAD Mode is On, it will override your receive mode setting. The screen shows MC.



If TAD Mode is Off, the receive mode returns to your original setting. (See *TAD-Mode for internal TAD* on page 72.)

External TAD (MFC-440CN only)

External TAD mode lets an external answering device manage your incoming calls. Incoming calls will be dealt with in one of the following ways:

- Faxes will be automatically received.
- Voice callers can record a message on the external TAD.

For more information see *Connecting an* external TAD (telephone answering device) on page 60.

Receive mode settings

Ring Delay

The Ring Delay sets the number of times the machine rings before it answers in Fax Only or Fax/Tel mode. If you have external or extension phones on the same line as the machine, choose the maximum number of rings.

(See Connecting an external or extension telephone on page 62 and Fax Detect on page 46.)

If toll saver is on, then the ring delay setting has no effect. See *Setting toll saver* on page 75. (MFC-665CW only)

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Setup Receive.
 Press OK
- Press ▲ or ▼ to choose Ring Delay. Press OK.
- (MFC-665CW only) Press ▲ or ▼ to choose Ring Delay. Press OK.
- 6 Press ▲ or ▼ to choose how many times the line rings before the machine answers (2-10 for Australia, 1-10 for New Zealand, 0-10 for some countries). Press **OK**.

 If you choose 0, the line will not ring at
- Press Stop/Exit.

all.

F/T Ring Time (Fax/Tel mode only)

If you set the Receive Mode to Fax/Tel, you need to decide how long the machine will signal you with its special pseudo/double-ring when you have a voice call. If it's a fax call, the machine receives the fax.

This pseudo/double-ring happens after the initial ringing from the phone company. Only the machine rings and no other phones on the same line will ring with the special pseudo/double-ring. However, you can still answer the call on any telephone.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax.
 Press OK.
- 3 Press ▲ or ▼ to choose Setup Receive. Press OK.
- Press ▲ or ▼ to choose F/T Ring Time. Press OK.
- Press ▲ or ▼ to choose how long the machine will ring to alert you that you have a voice call (20, 30, 40 or 70 seconds for Australia and some countries, 20, 30, 40 or 55 for New Zealand).

 Press OK.
- 6 Press Stop/Exit.



Even if the caller hangs up during the pseudo/double-ringing, the machine will continue to ring for the set time.

Fax Detect

If Fax Detect is on:

The machine receives fax calls automatically, even if you lift the machine's handset, press **Speaker Phone**, or lift the handset of an extension or external phone. When you see Receiving on the LCD or when you hear 'chirps' through the handset of an extension phone connected to another wall socket/phone socket, just replace the handset or press **Speaker Phone** and your machine will do the rest.

If Fax Detect is Semi: (MFC-665CW only)

The machine will only receive the fax call if you answered it using the machine's handset or speaker phone.

If Fax Detect is Off:

When you hear a fax tone through the handset or the speaker phone on the machine, you have to press **Mono Start** or **Colour Start** on the machine.

If you are not at your machine, press ★ 5 1 (★ 9 1 for New Zealand) on the extension phone. (See Connecting an external or extension telephone on page 62.)



- If this feature is set to On, but your machine does not connect a fax call when you lift an extension or external phone handset, press the fax receive code * 5 1 (* 9 1 for New Zealand). At the machine, press Mono Start or Colour Start.
- If you send faxes from a computer on the same phone line and the machine intercepts them, set Fax Detect to Off.

- Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Setup Receive. Press OK.
- Press ▲ or ▼ to choose Fax Detect. Press OK.
- 5 Press ▲ or ▼ to choose On, Semi (or Off).
 Press OK.
- 6 Press Stop/Exit.

Additional receiving operations

Printing a reduced incoming fax

The machine automatically reduces each page of an incoming fax to fit on one page of A4, Letter, Legal size paper, with Auto Reduction On. The machine calculates the reduction ratio by using the page size of the fax and your Paper Size setting (See *Paper Size* on page 24).

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Setup Receive.
 Press OK.
- 4 Press ▲ or ▼ to choose
 Auto Reduction.
 Press OK.
- 5 Press ▲ or ▼ to choose on (or off).
 Press OK.
- 6 Press Stop/Exit.

Receiving faxes into memory

This feature is only available for monochrome faxes.

As soon as the paper tray becomes empty during fax reception, the LCD shows No Paper Fed; put some paper in the paper tray. (See *Loading paper and other media* on page 16.) If you are unable to put paper in the paper tray the following will happen:

If Memory Receive is On:

The machine will carry on receving the fax, with the remaining pages being stored in memory, if enough memory is available. Further incoming faxes will also be stored into memory until the memory is full. When the memory is full the machine will stop automatically answering calls. To print the faxes, put fresh paper in the tray.

If Memory Receive is Off:

The machine will carry on receiving the fax, with the remaining pages being stored in memory if enough memory is available. The machine will then stop automatically answering calls until fresh paper is put in the paper tray. To print the last fax you received, put fresh paper in the tray.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Setup Receive.
 Press OK.
- 4 Press ▲ or ▼ to choose

 Memory Receive.

 Press OK.
- Press ▲ or ▼ to choose on (or off).
 Press OK.
- 6 Press Stop/Exit.

Receiving a fax at the end of a conversation (MFC-665CW only)

At the end of a conversation you can ask the other party to send you a fax before you both hang up.

- 1 Ask the other person to place the document in their machine and to press the Start or Send key.
- When you hear the other machine's CNG tones (slowly repeating beeps), press **Mono Start** or **Colour Start**.
- 3 Press 2 to receive a fax.
- 4 Replace the handset.

Printing a fax from the memory

If you have chosen fax storage, you can still print a fax from the memory when you are at your machine. (See *Fax Storage* on page 78.)

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Advanced Fax Operation.
 Press OK.
- 4 Press ▲ or ▼ to choose
 Print Document.
 Press OK.
- 5 Press Mono Start.

7

Telephone Services and External devices

Voice operations

Voice calls can be made either with the handset, the speaker phone, an extension or external telephone, by dialling manually, or by using Quick-Dial numbers.

Making a telephone call (MFC-665CW only)

- 1 To start a voice call, pick up the handset or press **Speaker Phone**.
- When you hear the dial tone, enter a number using the dial pad, Speed-Dial and Search.
- (Speaker phone) speak clearly toward the microphone ...
- 4 To hang up, replace the handset or press **Speaker Phone**.

Answering calls with the Speaker Phone (MFC-665CW only)

When the machine rings, instead of lifting the handset, press **Speaker Phone**. Speak clearly toward the microphone . To end the call, press **Speaker Phone**.



If you have a bad connection, your caller might hear your voice echoed during the call. If you experience this problem, pick up the handset, or hang up and try the call again.

Hold (MFC-665CW only)

If you want to put a call on hold, press **Erase/Hold**. To release the call from hold press **Speaker Phone** or pick up the machine's handset. Picking up an extension handset will *not* release the call from hold.

Tone or Pulse (not available in New Zealand)

If you have a Pulse dialling service, but need to send Tone signals (for example, for telephone banking), follow the instructions below:

- For MFC-440CN, pick up the handset of the external phone or press **Hook**. For MFC-665CW, pick up the handset or press **Speaker Phone**.
- 2 Press # on the machine's control panel. Any digits dialled after this will send tone signals.

When you hang up, the machine will return to the Pulse dialling service.

Fax/Tel mode

When the machine is in Fax/Tel mode, it will use the F/T Ring Time (pseudo/double-ringing) to alert you to pick up a voice call.

(For MFC-665CW) If you are at the machine, you can lift the handset or press **Speaker Phone** to answer.

(For MFC-440CN) Lift the external telephone's handset, and then press **Hook** on the machine to answer.

Fax/Tel mode in Power Save condition

(For MFC-440CN)

Fax/Tel mode does not work in the power save condition. The machine will not answer telephone or fax calls and will keep ringing. If you are at an external or extension phone, lift the handset and talk. If you hear fax tones, hold the handset until Fax Detect activates your machine. If the other party says they want to send you a fax, activate the machine by pressing \times 51 (\times 91 for New Zealand).

(For MFC-665CW)

When the machine is in Fax/Tel mode and F/T rings to tell you to pick up a voice call, you can only answer by picking up the machine's handset.

If you answer before the machine F/T rings, you can also pick up the call at an external or extension phone.

Phone line services

Your machine supports the Caller ID subscriber telephone service that some telephone companies offer.

Features like Voice Mail, Call Waiting, Call Waiting/Caller ID, RingMaster, answering services, alarm systems or other custom features on one phone line may create problems with the operation of your machine.

Do you have Voice Mail?

If you have Voice Mail on the phone line that you will install your new machine on, there is a strong possibility that Voice Mail and the machine will conflict with each other while receiving incoming calls. However, the Distinctive Ring feature allows you to use more than one number on your line, so both Voice Mail and the machine can work together without any problems. If each one has a separate phone number, neither will interfere with the other's operations.

If you decide to get the Distinctive Ring service from the telephone company, you will need to follow the directions on next page to 'register' the new Distinctive Ring pattern they give you. This is so your machine can recognise its incoming calls.

Telephone Service for Australia

Telstra[®] FaxStream[®] Duet[®] (Distinctive Ring)

Telstra® FaxStream® Duet® is an enhanced Public Switched Telephone Service (PSTS) offered by Telstra® that allows you to have an additional number on one phone line, with its own distinctive ring pattern. Telstra® FaxStream® Duet® is a call handling feature that helps users distinguish voice and facsimile calls. With FaxStream® Duet®, incoming calls to a fax number are announced by a different, distinctive ring signal. Only one call can be answered (or made) at any one time and while this call is in progress, incoming calls to either number will be presented with a busy tone.

Your machine has a Distinctive Ring function, allowing you to dedicate one phone number just for receiving faxes.



After you have set the Distinctive Ring feature to On, the receive mode is set to Manual automatically. If you don't have a TAD or Voice Mail set up on the Distinctive Ring number, Manual mode means you must answer all the voice calls yourself. You can not change the receive mode from Manual mode while the Distinctive Ring is set to on.

What is the Advantage of using Telstra[®] FaxStream[®] Duet[®] Function?

Using Telstra® FaxStream® Duet® is the most efficient way to receive both fax and telephone calls on the same line. When the voice call comes in, all phones (extension and external) and the fax machine will ring to alert you to pick it up. If a fax call comes in, the fax machine will answer automatically without ringing, whereas the extension and external phones will ring twice with a distinctive ring pattern. It is also a more efficient way of operating a Fax machine with an extension phone as you do not have to use the remote activation codes. It gives you two independent numbers without the higher cost of a second line.


How does Telstra[®] FaxStream[®] Duet[®] Work?

Incoming calls to the voice number, will have the standard ring pattern of long, long tone, followed by a pause, repeated, while the new fax number will have a different ring pattern of three short bursts of ring, repeated at regular intervals.

When FaxStream[®] Duet[®] is on and you receive a voice call all extension and external phones will ring with a standard ring pattern. The fax machine will ring on the third ring with a standard ring pattern. All external and the extension phones will continue to ring, until you or a telephone answering device can answer the voice number.

When FaxStream[®] Duet[®] is on and you receive a fax call on the Duet[®] number the Fax machine will answer and automatically receive the fax message without ringing. On the other hand, all extension and external phones will ring twice with a distinctive ring pattern. Do not answer the phone as you are receiving a fax message.

Flowchart Sequence of Incoming call



Set the Distinctive Ring to ON Very important!

After you have set the Distinctive Ring feature to ON, the receive mode is set to Manual automatically. Unless you have a TAD or Voice Mail set up on the Distinctive Ring number, Manual mode means you must answer all the calls yourself. You can not change the receive mode to another mode while the Distinctive Ring is set to on.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Miscellaneous. Press OK.
- Press ▲ or ▼ to choose Distinctive. Press OK.
- Press ▲ or ▼ to choose on. Press OK.
- 6 Press Stop/Exit.
 Distinctive Ring is now set to on.

Turning off Distinctive Ring

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- Press ▲ or ▼ to choose Distinctive. Press OK.
- 5 Press ▲ or ▼ to choose off. Press **OK**.
- 6 Press Stop/Exit.



If you turn off Distinctive Ring, the machine will stay in Manual receive mode. You will need to set the Receive Mode again. (See *Choosing the Receive Mode* on page 42.)

Caller ID

Caller ID is a telephone service that allows the subscriber to see a display of the caller's phone number or name as the telephone rings. It is a fast way to screen your calls. You can respond quickly to calls you missed, because Caller IDs are received and stored in your machine memory.



To get the Caller ID Service: apply for the Caller ID service at your local telephone company, if available.

Advantages of Caller ID

For Business

All businesses profit from a quicker response to customer calls. Businesses that provide mail order services, money-lending services or provide confidential information, can protect themselves from false orders or acceptance of false identification.

At Home

Residential customers can protect themselves from unwanted calls.

How Does the Caller ID Work?

The Caller ID Appears on the Display When Your Telephone Rings

As your telephone rings, the display shows you the caller's phone number or name if the name has stored in the Speed-Dial. Once you answer a call, the caller's ID disappears. You will see up to the first 16 characters of the number on the display.



- If Out of Area appears on the display, it means that the call came from outside your caller ID service area or a public phone.
- If Private Call appears on the display, it means the caller intentionally blocked the transmission of his/her ID. 1
 - Depends on network function.

The Caller ID is Stored in Your Machine Memory

The machine can store a maximum of the last 30 incoming caller IDs in the memory, along with the time and date of reception. The 31st call will cause the oldest ID to be erased.

The Caller ID information stored in the memory can be used for the following.

Printing the Caller ID List.

You can review calls you received by checking the Caller IDs in memory. This report will list the Date, Time, Phone Number (Caller ID) name, and type of Call (Comment) if available.

Viewing Caller ID List

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- Press ▲ or ▼ to choose Caller ID. Press OK.
- Press ▲ or ▼ to choose Display#. Press OK. The Caller ID list will appear on the display. If no ID is stored, the beeper will sound and No Caller ID will appear on the display.
- 6 Press ▲ or ▼ to scroll through the Caller ID memory to view the Caller ID information.
 The LCD shows the caller's number or name, the date, and time of the call.
- 7 To finish viewing, press Stop/Exit.



You can also view the Caller ID list by pressing (Fax). (See Caller ID history on page 66.)

Printing Caller ID List

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- Press ▲ or ▼ to choose Caller ID. Press OK.
- Press ▲ or ▼ to choose
 Print Report.
 Press OK.
 If no ID is stored, the beeper will sound
 and No Caller ID will appear on the
 LCD.
- 6 Press Mono Start or Colour Start.
- 7 When the printing has finished, press Stop/Exit.

Telephone Service for New Zealand

FaxAbility

FaxAbility is a service offered by Telecom that allows you to have an additional number on one phone line, with its own distinctive ring pattern. This way, when you get an incoming call, you can identify the number being called by its ring.

How Will the Fax Machine Treat All Other Numbers?

FaxAbility mode ensures that the machine will answer calls to the FaxAbility (secondary) number. When a call comes in to your main number, all the phones will ring. You can set an external answering device (TAD) to answer calls on the other number(s). (See the chart in the following page.)


What is the Advantage of Using the FaxAbility Function?

Using FaxAbility is the most efficient way to receive both fax and telephone calls on the same line. It is much easier for your callers who dial manually. The fax machine will answer with receiving tones so they will not have to press an activation code. And the people who call to talk on your main number will not have to talk to your fax machine. Basically, it gives you two independent numbers without the higher cost of a second line.

How Does FaxAbility Work?

Your telephone number will have the standard ring pattern of long, long tone, while the new number will have a ring pattern of long, silence, long, etc. When FaxAbility is On, you will not hear the first ring of all incoming calls on the fax machine. Extension phones will ring as usual. If the fax machine recognizes the ring pattern, all ringing will stop and the fax machine will answer and automatically receive the fax message. Otherwise, you will hear the extension phones and the fax machine continue to ring. The fax machine always listens to the ring pattern before it answers, so do not pick up the phone during that time. You will quickly learn to recognize the ring pattern for faxes, so you will not be tempted to answer that number. Either you or a telephone answering device can answer the main number(s).

Flowchart Sequence of Incoming call





After you have set the FaxAbility feature to On, the receive mode is set to Manual automatically. Unless you have a TAD or Voice Mail set up on the FaxAbility number, Manual mode means you must answer all the call yourself. You can not change the receive mode to the other mode while the FaxAbility is set to on.

How to Turn FaxAbility OFF or ON

The FaxAbility function is designed to accommodate the FaxAbility service provided by Telecom. To change the setting, repeat steps 1-6; Step 6 is where you can choose either on or off.

Call Waiting beeps caused by incoming calls on your main number can affect fax transmissions. If you have FaxAbility Service but don't have Call Waiting, you need do nothing at this stage. If you do have Call Waiting as well as FaxAbility, set the Call Waiting menu option to On. See below.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK
- Press ▲ or ▼ to choose FaxAbility. Press OK.
- Fress ▲ or ▼ to set FaxAbility to on (or off).
 If you have FaxAbility service, choose

Press OK.

- 6 Press ▲ or ▼ to set Call Waiting to on (or off). If you have Call Waiting service, choose on to avoid the trouble caused by Call Waiting.
 - Press **OK**.

Press Stop/Exit.

Caller ID

Caller ID is a telephone service that allows the subscriber to see a display of the caller's phone number and name if available as the telephone rings. It is a fast way to screen your calls. You can respond quickly to calls you missed, because Caller IDs are received and stored in your machine memory.



To get the Caller ID Service, apply for the Caller ID service at your local telephone company, if available.

Advantages of Caller ID

For Business

All businesses profit from a quicker response to customer calls. Businesses that provide mail order services, money-lending services or provide confidential information, can protect themselves from false orders or acceptance of false identification.

At Home

Residential customers can protect themselves from unwanted calls.

How Does the Caller ID Work?

The Caller ID Appears on the Display When Your Telephone Rings

As your telephone rings, the display shows you the caller's phone number or name if available. Once you answer a call, the caller's ID disappears. You will see up to the first 16 characters of the number and name if available on the display.

Note

- If Out of Area appears on the display, it means that the call came from outside your caller ID service area.
- If Private Call appears on the display, it means the caller intentionally blocked the transmission of his/her ID.
 - ¹ Depends on network function.

Viewing Caller ID List

Your machine stores information for the last thirty calls in the Caller ID list. You can view or print this list. When the thirty-first call comes in to the machine, it replaces information about the first call.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Miscellaneous. Press OK.
- Press ▲ or ▼ to choose Caller ID. Press OK.
- Press ▲ or ▼ to choose Display#.

 Press OK.

The Caller ID list will appear on the display. If no ID is stored, the beeper will sound and No Caller ID will appear on the display.

- 6 Press ▲ or ▼ to scroll through the Caller ID memory to view the Caller ID information.
 - The LCD shows the caller's number or name, the date, and time of the call.
- To finish viewing, press Stop/Exit.



You can also view the Caller ID list by pressing (Fax). (See Caller ID history on page 66.)

Printing Caller ID List

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Miscellaneous. Press OK.
- Press ▲ or ▼ to choose Caller ID. Press OK.
- Press ▲ or ▼ to choose Print Report. Press OK. If no ID is stored, the beeper will sound and No Caller ID will appear on the LCD.
- 6 Press Mono Start or Colour Start.
- When the printing has finished, press Stop/Exit.



If you use the Caller ID for Dial back...

- Please be sure that you use appropriate dialling procedures for local and national call.
- Please be sure that you make sure of the details of the exact number to be called back, and the need to insert prefix(es) for manual dialling.
- Please understand that your machine may not display precisely the digits to be called.

Telephone Service for Some Countries

Distinctive Ring (For Singapore and Hong Kong)

This machine feature lets you use the Distinctive Ring subscriber service offered by some telephone companies, which allows you to have several telephone numbers on one phone line. Each phone number has its own Distinctive Ring pattern, so you will know which phone number is ringing. This is one way you can have a separate phone number for your machine.

Your machine has a Distinctive Ring function, allowing you to dedicate one phone number just for receiving faxes. You will need to set Distinctive Ring to On.



You can switch it off temporarily, then turn it back on. When you get a new fax number, make sure you reset this function.

 The machine will answer only calls to the Distinctive Ring number.



After you have set the Distinctive Ring feature to On, the receive mode is set to Manual automatically. Unless you have a TAD or Voice Mail set up on the Distinctive Ring number, Manual mode means you must answer all the call yourself. You can not change the receive mode to the other mode while the Distinctive Ring is set to on.

Registering the Distinctive Ring pattern

Very important!

After you have set the Distinctive Ring feature to ON, the receive mode is set to Manual automatically. Unless you have a TAD or Voice Mail set up on the Distinctive Ring number, Manual mode means you must answer all the calls yourself. You can not change the receive mode to another mode while the Distinctive Ring is set to on.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax.
 Press OK.
- 3 Press ▲ or ▼ to choose Miscellaneous. Press OK.
- Press ▲ or ▼ to choose Distinctive.
 Press OK
- Fress ▲ or ▼ to choose on. Press OK.
- 6 Press Stop/Exit.
 Distinctive Ring is now set to on.

Turning off Distinctive Ring

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- Press ▲ or ▼ to choose Distinctive. Press OK.
- Press ▲ or ▼ to choose Off. Press OK.
- 6 Press Stop/Exit.



If you turn off Distinctive Ring, the machine will stay in Manual receive mode. You will need to set the Receive Mode again. (See *Choosing the Receive Mode* on page 42.)

Caller ID (For Singapore and Hong Kong)

The Caller ID feature of this machine lets you use the Caller ID subscriber service offered by many local phone companies. This service provides you, by means of the screen display, the telephone number (or name) of your caller as the line rings. (See *Printing Caller ID List* on page 60.)

After a few rings, the screen displays the telephone number of your caller (or name, if available). Once you answer a call, the Caller ID information disappears from the screen, but the call information remains stored in the Caller ID memory.

- You will see the first 16 characters of the number or name.
- Out of Area display means call originates outside your Caller ID service area.
- Private Call display means the caller has intentionally blocked transmission of information.



You can print a list of Caller ID information received by your machine.

Caller ID service varies with different carriers. Call your local phone company to determine the kind of service available in your area.

Viewing Caller ID List

Your machine stores information for the last thirty calls in the Caller ID list. You can view or print this list. When the thirty-first call comes in to the machine, it replaces information about the first call.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- Press ▲ or ▼ to choose Caller ID. Press OK.
- Press ▲ or ▼ to choose Display#.

 Press OK.

 The Caller ID list will appear on the display. If no ID is stored, the beeper will sound and No Caller ID will appear on the display.
- 6 Press ▲ or ▼ to scroll through the Caller ID memory to view the Caller ID information.
 The LCD shows the caller's name or number, the date, and time of the call.
- 7 To finish viewing, press Stop/Exit.



You can also view the Caller ID list by pressing (Fax). (See Caller ID history on page 66.)

Printing Caller ID List

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- Press ▲ or ▼ to choose Caller ID. Press OK.
- Press ▲ or ▼ to choose
 Print Report.
 Press OK.
 If no ID is stored, the beeper will sound
 and No Caller ID will appear on the
 LCD.
- 6 Press Mono Start or Colour Start.
- When the printing has finished, press Stop/Exit.


Connecting an external TAD (telephone answering device)

You may choose to connect an external answering device. However, when you have an **external** TAD on the same telephone line as the machine, the TAD answers all calls and the machine 'listens' for fax calling (CNG) tones. If it hears them, the machine takes over the call and receives the fax. If it does not hear CNG tones, the machine lets the TAD continue playing your outgoing message so your caller can leave you a voice message.

The TAD must answer within two rings. The machine cannot hear CNG tones until the TAD has answered the call, and with four rings there are only 8 to 10 seconds of CNG tones left for the fax 'handshake'. Make sure you carefully follow the instructions in this guide for recording your outgoing message. We do not recommend using the toll saver feature on your external answering machine if it exceeds five rings.



If you do not receive all your faxes, cut the Ring Delay setting on your external TAD.



(Example for Australia)

1 TAD

When the TAD answers a call, the LCD shows Telephone (MFC-440CN only) or Ext. Tel in Use (MFC-665CW only).

0

Improper Setup

Do not connect a TAD elsewhere on the same phone line.

Connections

The external TAD must be connected as shown in the previous illustration.

- 1 Set your external TAD to one or two rings. (The machine's Ring Delay setting does not apply.)
- Record the outgoing message on your external TAD.
- 3 Set the TAD to answer calls.
- 4 Do one of the following:
 - (For MFC-440CN)

 Set the Receive Mode to External

 TAD.
 - (For MFC-665CW)
 Set the Receive Mode to Manual.
 (See Choosing the Receive Mode on page 42.)

Recording outgoing message (OGM) on an external TAD

Timing is important in recording this message. The message sets up the ways to handle both manual and automatic fax reception.

- 1 Record 5 seconds of silence at the beginning of your message. (This allows your machine time to listen for the fax CNG tones of automatic transmissions before they stop.)
- 2 Limit your speaking to 20 seconds.



We recommend beginning your OGM with an initial 5-second silence because the machine cannot hear fax tones over a resonant or loud voice. You may try omitting this pause, but if your machine has trouble receiving, then you must rerecord the OGM to include it.

Multi-Line connections (PABX)

Most offices use a central telephone system.

Brother recommends that all our machines be connected to a discreet (dedicated) line. Although a particular PABX may appear to work with a particular model of fax machine, we cannot guarantee that the unit will operate correctly.


While it is often relatively simple to connect a fax machine to a PABX, (Private Automatic Branch Exchange), we suggest that you contact the company that installed your telephone system and ask them to connect the fax machine for you.

Brother does not recommend the use of a PABX line. PABX limitations in general can cause some functions of the fax machine not to work correctly.

External and extension phones

Connecting an external or extension telephone

You can connect a separate telephone to your machine as shown in the diagram below.



(Example for Australia)

1 Extension telephone

External telephone

When you are using an external or extension phone, the LCD shows Telephone (MFC-440CN only) or Ext. Tel in Use (MFC-665CW only).

Operation from extension telephones

If you answer a fax call on an extension or an external telephone plugged into the correct socket on the machine, you can make your machine take the call by using the Fax Receive Code. When you press the Fax Receive Code * 5 1 (* 9 1 for New Zealand), the machine starts to receive the fax.

If the machine answers a voice call and pseudo/double-rings for you to take over, use the Telephone Answer Code # 5 1 (# 9 1 for New Zealand) to take the call at an extension phone. (See F/T Ring Time (Fax/Tel mode only) on page 45.)

If you answer a call and no one is on the line:

You should assume that you're receiving a manual fax.

Press X 51 (X 91 for New Zealand) and wait for the chirp or until the LCD shows Receiving, and then hang up.



You can also use the Fax Detect feature to make your machine automatically take the call. (See Fax Detect on page 46)

Using remote codes

Fax receive code

If you answer a fax call on an extension or external telephone, you can tell your machine to receive it by dialling the fax receive code ¥ 5 1 (¥ 9 1 for New Zealand). Wait for the chirping sounds then replace the handset. See Fax Detect on page 46. Your caller will have to press Start to send the fax.

Telephone answer code

If you receive a voice call and the machine is in F/T mode, it will start to sound the F/T (double) ring after the initial ring delay. If you pick up the call on an extension phone you can turn the F/T ring off by pressing # 5 1 (# 9 1 for New Zealand) (make sure you press this between the rings).

Changing the remote codes

If you want to use Remote Activation, you have to turn on the remote codes. The preset Fax Receive Code is \times 5 1 (\times 9 1 for New Zealand). The preset Telephone Answer Code is # 5 1 (# 9 1 for New Zealand). If you want to, you can replace them with your own codes.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Setup Receive.
 Press OK.
- Press ▲ or ▼ to choose Remote Codes. Press OK.
- Press ▲ or ▼ to choose on (or off).
 Press OK.
- 6 Enter the new Fax Receive Code.
 Press **OK**
- 7 Enter the new Telephone Answer Code. Press **OK**.
- 8 Press Stop/Exit.



- If you are always disconnected when accessing your external TAD remotely, try changing the Fax Receive Code and Telephone Answer Code to another threedigit code using the numbers 0-9, **, #.
- Remote Codes might not work with some telephone systems.

Dialling and storing numbers

How to Dial

Manual dialling

Press all of the digits of the fax or telephone number.



Speed-Dialling

1 Press Search/Speed Dial.

MFC-440CN

Search / Speed Dial



MFC-665CW

Search/ Speed Dial



You can also choose Speed-Dial by pressing (Fax).

Press the two-digit Speed-Dial number. (See Storing Speed-Dial numbers on page 66.)

If you have two numbers in the location, press ▲ or ▼ to choose the number you want to call.

Press **OK**.



If the LCD shows Not Registered when you enter a Speed-Dial number, a number has not been stored at this location.

Search

You can search for names you have stored in the Speed-Dial memory.

- 1 Press Search/Speed Dial.
 You can also choose Speed-Dial by
 pressing (Fax).
- Press ▲ or ▼ to choose
 Alphabetical Order Or
 Numerical Order.
 Press OK.



- Press X to make the LCD font size larger.
- Press # to make the LCD font size smaller.
- If you chose Alphabetical Order in step ②, use the dial pad to enter the first letter of the name, and then press ▲ or ▼ to choose the name and number you want to call.

 Press OK.

Fax Redial

If you are sending a fax manually and the line is busy, press **Redial/Pause**, and then press **Mono Start** or **Colour Start** to try again. If you want to make a second call to a number you recently dialled, you can press **Redial/Pause** and choose one of the last 30 numbers from the Outgoing Call List.

Redial/Pause only works if you dialled from the control panel. *If you are sending a fax automatically* and the line is busy, the machine will automatically redial up to three times at five minutes interval.

- Press Redial/Pause.
- Press ▲ or ▼ to choose the number you want to redial.
 Press OK.
- Press ▲ or ▼ to choose Send a Fax. Press OK.
- 4 Press Mono Start or Colour Start.



In Real Time Transmission the automatic redial feature does not work when using the scanner glass.

Outgoing Call

The last 30 numbers you telephoned (MFC-665CW only) or sent a fax to will be stored in the outgoing call history. You can choose one of these numbers to telephone (MFC-665CW only), fax to, add to Speed-Dial, or delete from the history.

- 1 Press Redial/Pause.
 You can also choose Outgoing Call
 by pressing (Fax).
- Press ▲ or ▼ to choose the number you want to call.
 Press OK.
- 3 Do one of the following:
 - (MFC-665CW only)
 To make a phone call, press ▲ or ▼
 to choose Make a Phone Call.
 Press OK.
 - To send a fax, press or vo choose Send a Fax.
 Press OK.
 - If you want to store the number, press ▲ or ▼ to choose
 Add to Speed-Dial.
 Press OK.
 (See Storing Speed-Dial numbers from Outgoing Calls on page 67.)
 - Press ▲ or ▼ to choose Delete. Press OK. Then, confirm the Delete by pressing 1.

Caller ID history

This feature requires the Caller ID subscriber service offered by many local telephone companies. (See *Caller ID* on page 53.)

The last 30 numbers of phone calls (MFC-665CW only) or faxes you received will be stored in the Caller ID history. You can choose one of these numbers to telephone (MFC-665CW only), fax to, add to Speed-Dial, or delete from the history.

- 1 Press (Fax).
- Press ▲ or ▼ to choose
 Caller ID hist..
 Press OK.
- 3 Press ▲ or ▼ to choose the number you want to call. Press OK.
- 4 Do one of the following:
 - (MFC-665CW only)
 To make a phone call, press ▲ or ▼
 to choose Make a Phone Call.
 Press OK.
 - To send a fax, press or vo choose Send a Fax.
 Press OK.
 - If you want to store the number, press ▲ or ▼ to choose Add to Speed-Dial. Press OK.
 - (See Storing Speed-Dial numbers from Outgoing Calls on page 67.)

 Press ▲ or ▼ to choose Delete.
 Press OK.
 - Then, confirm the Delete by pressing 1.



You can print the Caller ID list. (See *Printing Caller ID List* on page 54.)

Storing numbers

You can set up your machine to do the following types of easy dialling: Speed-Dial and Groups for broadcasting faxes. When you dial a Quick-Dial number, the LCD shows the name, if you stored it, or the number.



If you lose electrical power, the Quick-Dial numbers that are in the memory will not be lost because they are stored permanently.

Storing a pause

Press **Redial/Pause** to put a 3.5-second pause between numbers. If you are dialling overseas, you can press **Redial/Pause** as many times as needed to increase the length of the pause.

Storing Speed-Dial numbers

You can store up to 80 Speed-Dial numbers with a name, and each name can have two numbers. When you dial you will only have to press a few keys (For example: Search/Speed Dial, the two-digit number, and Mono Start or Colour Start).

- 1 Press Menu.
- 2 Press ▲ or ▼ to choose Fax.
 Press OK.
- 3 Press ▲ or ▼ to choose
 Set Quick-Dial.
 Press OK.
- Press ▲ or ▼ to choose Speed-Dial. Press OK.
- Press ▲ or ▼ to choose the 2-digit Speed-Dial location you want to store the number in. Press OK.

- 6 Do one of the following:
 - Enter the name (up to 16 characters) using the dial pad. Press **OK**.

(To help you enter letters, see *Entering Text* on page 174.)

- To store the number without a name, press **OK**.
- 7 Enter the fax or telephone number (up to 20 digits).
 Press **OK**.
- 8 Do one of the following:
 - Enter the second fax or telephone number (up to 20 digits).
 Press **OK**.
 - If you do not want to store a second number, press OK.
- 9 Do one of the following:
 - To store another Speed-Dial number, go to step **⑤**.
 - To finish the setting, press Stop/Exit.

Storing Speed-Dial numbers from Outgoing Calls

You can also store Speed-Dial numbers from the Outgoing Call history.

- Press Redial/Pause.
 You can also choose Outgoing Call
 by pressing (Fax).
- Press ▲ or ▼ to choose the name or number you want to store. Press OK.
- 3 Press ▲ or ▼ to choose
 Add to Speed-Dial.
 Press OK.
- Press ▲ or ▼ to choose the 2-digit Speed-Dial location you want to store the number in. Press OK.

- 5 Do one of the following:
 - Enter the name (up to 16 characters) using the dial pad.
 Press OK.
 (To help you enter letters, see Entering Text on page 174.)
 - To store the number without a name, press **OK**.
- 6 Press **OK** to confirm the fax or telephone number.
- 7 Do one of the following:
 - Enter the second fax or telephone number (up to 20 digits). Press **OK**.
 - If you do not want to store a second number, press **OK**.
- 8 Press Stop/Exit.

Storing Speed-Dial numbers from the Caller ID history

If you have the Caller ID subscriber service from your telephone company you can also store Speed-Dial numbers from incoming calls in the Caller ID History. (See *Caller ID* on page 53.)

- 1 Press (Fax).
- Press ▲ or ▼ to choose
 Caller ID hist..
 Press OK.
- 3 Press ▲ or ▼ to choose the number you want to store.
 Press OK.
- 4 Press ▲ or ▼ to choose
 Add to Speed-Dial.
 Press OK.
- 5 Press ▲ or ▼ to choose the 2-digit Speed-Dial location you want to store the number in.

 Press OK.

- 6 Do one of the following:
 - Enter the name (up to 16 characters) using the dial pad.
 Press OK.
 (To help you enter letters, see Entering Text on page 174.)
 - To store the number without a name, press **OK**.
- Press **OK** to confirm the fax or telephone number.
- 8 Do one of the following:
 - Enter the second fax or telephone number (up to 20 digits). Press **OK**
 - If you do not want to store a second number, press OK.
- 9 Press Stop/Exit.

Changing Speed-Dial names or numbers

You can change a Speed-Dial name or number that has already been stored.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Set Quick-Dial.
 Press OK.
- Press ▲ or ▼ to choose Speed-Dial. Press OK.
- Press ▲ or ▼ to choose the 2-digit Speed-Dial location you want to change. Press OK.
- 6 Do one of the following:
 - Press ▲ or ▼ to choose Change.
 Press OK.
 - Press ▲ or ▼ to choose Delete. Press OK. Then, confirm the Delete by pressing 1 and Stop/Exit.



How to change the stored name or number:

If you want to change a character, press ◀ or ▶ to position the cursor under the character you want to change, and then press Clear/Back. Re-enter the character.

- 7 Do one of the following:
 - Enter the name (up to 16 characters) using the dial pad.
 Press OK.
 (See Entering Text on page 174.)
 - If you do not want to change the name, press **OK**.
- 8 Do one of the following:
 - Enter the new fax or telephone number (up to 20 digits). Press **OK**.
 - If you do not want to change the number, press OK.
- 9 Do one of the following:
 - Enter the second new fax or telephone number (up to 20 digits). Press **OK**.
 - If you do not want to change the number, press **OK**.
- 10 Press Stop/Exit.

Č

Setting up groups for broadcasting

Groups, which can be stored on a Speed-Dial location, allow you to send the same fax message to many fax numbers by pressing only **Search/Speed Dial**, the two-digit location and **Mono Start**. First, you'll need to store each fax number in a Speed-Dial location. Then you can include them as numbers in the Group. Each Group uses up a Speed-Dial location. You can have up to six Groups, or you can assign up to 158 numbers in large Group if you have 2 numbers in each location.

(See Storing Speed-Dial numbers on page 66 and Broadcasting (Monochrome only) on page 36.)

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax.
 Press OK.
- 3 Press ▲ or ▼ to choose
 Set Quick-Dial.
 Press OK
- 4 Press ▲ or ▼ to choose
 Setup Groups.
 Press OK.
- 5 Press ▲ or ▼ to choose GROUP 1, GROUP 2, GROUP 3, GROUP 4, GROUP 5 or GROUP 6 for the Group name where you will store the fax numbers.

 Press OK.
- 6 Press ▲ or ▼ to choose the 2-digit location where you want to add to the Group. Press OK.



Please choose a Speed-Dial number that has not been used to store a number yet.

- 7 Press ▲ or ▼ to choose Add Number.
 Press OK
- Press ▲ or ▼ to choose the number you want to add.
 Press OK.
 (See Search on page 64.)
- 9 After you have finished adding numbers by repeating steps and press or to choose Complete.
 Press OK.
- 10 Press Stop/Exit.



You can print a list of all the Speed-Dial numbers. Group numbers will be marked in the GROUP column. (See *Reports* on page 88.)

Changing Group name

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Set Quick-Dial. Press OK.
- 4 Press ▲ or ▼ to choose
 Setup Groups.
 Press OK.
- 5 Press ▲ or ▼ to choose the Group name you want to change. Press OK.
- 6 Press ▲ or ▼ to choose
 Change Group name.
 Press OK.



How to change the stored name or number:

If you want to change a character, press ◀ or ▶ to position the cursor under the character you want to change, and then press Clear/Back. Re-enter the character.

- 7 Enter the new name (up to 16 characters) using the dial pad. Press **OK**. (See *Entering Text* on page 174. For example, type NEW CLIENTS).
- 8 Press ▲ or ▼ to choose Complete.
 Press OK
- 9 Press Stop/Exit.

Deleting a Group

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Set Quick-Dial. Press OK.
- 4 Press ▲ or ▼ to choose
 Setup Groups.
 Press OK.
- Press ▲ or ▼ to choose the Group you want to delete.
 Press OK.
- 6 Press ▲ or ▼ to choose Delete. Press OK. Then, confirm the Delete by pressing 1.
- Press ▲ or ▼ to choose Complete. Press OK.
- 8 Press Stop/Exit.

Deleting a number from a Group

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Set Quick-Dial.
 Press OK.
- Press ▲ or ▼ to choose Setup Groups.
 Press OK.
- Fress ▲ or ▼ to choose the Group you want to change.
 Press OK.
- 6 Press ▲ or ▼ to choose the number you want to delete.
 Press OK.
 Then, confirm the Delete by pressing 1.
- 7 Press ▲ or ▼ to choose Complete. Press OK.
- 8 Press Stop/Exit.

Combining Quick-Dial numbers

Sometimes you may want to choose from several long distance carriers when you make a call. Rates may vary depending on the time and destination. To take advantage of low rates, you can store the access codes or long-distance carriers and credit card numbers as Speed-Dial numbers. You can store these long dialling sequences by dividing them and setting them up as separate Speed-Dial numbers in any combination. You can even include manual dialling using the dial pad. (See Storing Speed-Dial numbers on page 66.)

For example, you have stored '555' on Speed-Dial: 03 and '7000' on Speed-Dial: 02.

- 1 Press Search/Speed Dial.
- 2 Enter 03.



If you stored 2 numbers in one Speed-Dial location, you will be asked which number you want to send to.

- 3 Press ▲ or ▼ to choose Speed-Dial. Press OK.
- 4 Enter **02**.
- 5 Press Mono Start or Colour Start. You will dial '555-7000'.

To temporarily change a number, you can substitute part of the number with manual dialling using the dial pad. For example, to change the number to 555-7001 you could press **Search/Speed Dial**, **03** and then press **7001** using the dial pad.



If you must wait for another dial tone or signal at any point in the dialling sequence, create a pause in the number by pressing **Redial/Pause**. Each key press adds a 3.5-second delay.

Digital TAD (MFC-665CW only)

TAD-Mode for internal TAD

The TAD (Telephone Answering Device) feature will store up to 99 incoming voice or fax messages. Messages are stored in the order in which they are received.

Voice messages can be up to 3 minutes in length, and can also be picked up remotely (see *Using your Remote Access Code* on page 83). The number of messages you can store will depend on how much memory is being used by other features (for example, delayed and stored faxes).

Setting up the TAD

Recording the TAD outgoing message is the first step you need to follow before you can use the TAD feature.

To enter TAD mode, follow the steps below:

- 1 Record your TAD OGM.
- 2 Press (i) to activate the TAD mode.

Outgoing message (OGM)

Recording your OGM

You can record the following two different types of OGM:

■ Msg Ctr OGM

This message will be played when a voice call is received in TAD mode. The caller will be able to leave a voice or fax message.

■ F/T OGM

This message is played when a call is received and your machine is set to Fax/Tel mode. The caller will not be able to leave a message. See Fax/Tel OGM on page 73.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Setup Msg Ctr.
 Press OK
- Press ▲ or ▼ to choose OGM. Press OK. The LCD prompts you to choose an OGM.
- 5 Press ▲ or ▼ to choose Msg Ctr OGM or F/T OGM, then press OK.
- 6 Press ▲ or ▼ to choose Record MSG.
 Press OK.
- Record your message, using one of the options below:
 - Pickup the handset, record your message, and replace the handset when finished.

The TAD will play your OGM back to you.

8 Press Stop/Exit.

C

Listening to your OGM

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Setup Msg Ctr. Press OK.
- Press ▲ or ▼ to choose OGM. Press OK.
- Press ▲ or ▼ to choose Msg Ctr OGM or F/T OGM. Press OK.
- 6 Press ▲ or ▼ to choose Playing OGM. Press OK. Adjust the volume by pressing Volume □ ◀ or ▶ □).
- Press Stop/Exit.

Erasing your OGM

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Setup Msg Ctr.
 - Press **OK**.
- Press ▲ or ▼ to choose OGM. Press OK.
- Press ▲ or ▼ to choose Msg Ctr OGM or F/T OGM. Press OK.
- 6 Press ▲ or ▼ to choose Erase MSG. Press OK.
- 7 Do one of the following:
 - Press 1 to erase the OGM.
 - Press 2 to exit without erasing.
- 8 Press Stop/Exit.

Fax/Tel OGM

If your machine is set to Fax/Tel receive mode this message will be played by your Brother machine to a caller. Unlike the TAD OGM, the caller *will not* be able to leave a message.

To record your Fax/Tel OGM follow the instructions on *Outgoing message* (OGM) on page 72.

If you need to review the steps for setting up the Fax/Tel receive mode, see *Receive modes* on page 42.

Activating TAD mode

When the highlight glows, TAD mode is active. Press highlight of enter TAD mode.

Managing your messages

Message indicator

The (i) light flashes if you have any new messages waiting for you.

The LCD displays the total number of voice and fax messages stored in the TAD memory.

Fax messages are only stored when Fax Storage or Fax Preview is turned on. See *Advanced fax operations (Monochrome only)* on page 77.

Playing voice messages

All messages are played in the order they were recorded. The LCD shows the number of the current message, the total number of messages, and the time and date the message was recorded.

Follow the steps below to listen to your voice messages:

Press Play/Record. The following commands are available when playing messages:

★ I◀◀ (RWD) Repeats a message.

▶►I (FWD) Skips to the next message.

Adjusts the volume.

2 Press Stop/Exit.

Erasing incoming messages

To erase voice messages individually

1 Press Play/Record.
The machine will sound a two second beep and begins message playback.
Each message is preceded by one long

beep, and followed by two short beeps.

- 2 To erase a specific message, press **Erase/Hold** immediately after the two short beeps, or while the message is playing.
- 3 Do one of the following:
 - Press **1** to erase the message.
 - Press 2 to cancel.
- 4 Press Stop/Exit.

To erase all of your messages

1 Press Erase/Hold.

The LCD displays the following:

■ Erase All Voice? Yes→Press 1 No→Press 2

- 2 Do one of the following:
 - Press 1 to erase all of your voice messages.
 - Press 2 to cancel.
- 3 Press Stop/Exit.

Additional TAD operations

Setting maximum time for incoming messages

Your machine's default setting will save incoming messages up to 30 seconds long. To change this setting follow the steps below:

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax.
 Press OK.
- 3 Press ▲ or ▼ to choose Setup Msg Ctr. Press OK.
- Press ▲ or ▼ to choose ICM Max.
 Time.
 Press OK.
- Press ▲ or ▼ to choose the maximum time setting for incoming messages (30, 60, 120 or 180 seconds).

 Press OK.
- 6 Press Stop/Exit.

Setting toll saver

When the toll saver feature is on, the machine will answer after two rings if you do have voice or fax messages, and after four rings if you do not have any messages.

This way, when you call your machine for remote retrieval, if it rings three times, you have no messages and can hang up to avoid a toll charge.

The toll saver feature is only available when TAD mode is on. When toll saver is on, it overrides your ring delay setting.

If you are using Distinctive Ring, do not use the Toll Saver feature.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- Press ▲ or ▼ to choose Setup Receive. Press OK.
- Press ▲ or ▼ to choose Ring Delay. Press OK.
- Fress ▲ or ▼ to choose Toll Saver. Press OK.
- 6 Press ▲ or ▼ to choose on (or off).
 Press OK.
- 7 Press Stop/Exit.

ICM Recording Monitor

This feature lets you turn the speaker volume for voice messages <code>On or Off</code>. When you turn the monitor <code>Off</code>, you will not hear messages as they come in.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Setup Msg Ctr. Press OK.
- Press ▲ or ▼ to choose ICM
 Rec.Monitr.
 Press OK.
- Use ▲ or ▼ to choose Off or On. Press OK.
- 6 Press Stop/Exit.

Recording a conversation

If you are using the handset, you can record a telephone conversation by pressing Play/Record during the conversation. Your recording can be as long as the incoming message maximum time (up to 3 minutes). The other party will hear an intermittent beeping while recording. To stop recording, press Stop/Exit.



If you record a telephone conversation, you must give prior warning to the other party.

10

Advanced fax operations (Monochrome only)

You can *only* use one advanced fax operation at a time:

- Fax Forwarding
- Fax Storage
- Fax Preview (MFC-665CW only)
- PC Fax Receive
- Off

You can change your selection at any time. If received faxes are still in the machine's memory when you change the advanced fax operations, a question will appear on the LCD. (See *Changing Advanced Fax Operations* on page 82.)

Fax Forwarding

When you choose Fax Forward, your machine stores the received fax in the memory. The machine will then dial the fax number you have programmed and forward the fax message.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Advanced Fax Operation.
 Press OK.
- 4 Press ▲ or ▼ to choose Forward/Store.
 Press OK.
- Press ▲ or ▼ to choose Fax Forward. Press OK.
- 6 Enter the forwarding number (up to 20 digits).
 Press **OK**.

7 Press ▲ or ▼ to choose
Backup Print:On or
Backup Print:Off.
Press OK.



- If you choose Backup Print:On, the machine will also print the fax at your machine so you will have a copy. This is the safety feature in case there is a power failure before the fax is forwarded or a problem at the receiving machine.
- (MFC-665CW only)
 The machine can store faxes up to 24 hours if there is a power failure.
- When Fax Forwarding is turned on your machine will only receive monochrome faxes into memory. Colour faxes will not be received, unless the sending machine converts them to monochrome before sending.
- 8 Press Stop/Exit.

Fax Storage

If you choose Fax Storage, your machine stores the received fax in the memory. You will be able to retrieve fax messages from another location using the remote retrieval commands. (See page 82.)

If you have set Fax Storage, a backup copy will automatically be printed at the machine.

- Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Advanced Fax Operation.
 Press OK.
- 4 Press ▲ or ▼ to choose
 Forward/Store.
 Press OK
- 5 Press ▲ or ▼ to choose Fax Storage.
 Press OK.
- 6 Press Stop/Exit.



If Fax Storage is turned on your machine cannot receive a colour fax unless the sending machine converts it to monochrome.

Fax Preview (MFC-665CW only)

If you choose Fax Preview you can view received faxes on the LCD by pressing the **Fax Preview** key. When the machine is in Ready mode, a popup message will appear on the LCD to alert you of new faxes. (See page 79.) You can continue all operations.

Setting Fax Preview

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Advanced Fax Operation.
 Press OK.
- 4 Press ▲ or ▼ to choose Forward/Store.
 Press OK.
- Press ▲ or ▼ to choose Fax Preview. Press OK.
- 6 Press Stop/Exit.



Your machine cannot preview colour faxes. It will print the colour faxes it receives.

How to preview a fax

When you receive a fax, you will see the popup message on the LCD. (For example: New Fax(es):02)

1 Press Fax Preview. You can see the new fax list.

Note

You can also see your old fax list by pressing \star . Press # to go back to your new fax list.

Press ▲ or ▼ to choose the fax you want to see.
Press OK.

Note

If your fax is large there may be a delay before it is displayed on the LCD.

3 Press Stop/Exit.

When a fax is open the control panel keys will perform the operations shown below.

Key	Description	
$\overline{\mathcal{H}}$	Enlarge the fax.	
#	Reduce the fax.	
▲ or ▼	Scroll vertically.	
∢ or ▶	Scroll horizontally.	
0	Rotate the fax clockwise.	
2 ABC	Delete the fax.	
	Then, confirm the Delete by pressing 1 .	
7 PORS	Go back to the previous page.	
9 NXYZ	Go to the next page.	
ОК	Go to the next step.	
	(Print, Back and Exit are available.)	
Clear/Back	Go back to the fax list.	
\bigcirc	Print the fax.	
Mono Start		

How to delete all faxes in the list

- 1 Press Fax Preview.
- Press ▲ or ▼ to choose Delete All. Press OK. Then, confirm the Delete by pressing 1.

How to print all faxes in the list

- 1 Press Fax Preview.
- Press ▲ or ▼ to choose Print All. Press OK.

PC Fax Receive

If you turn on the PC-Fax Receive feature your machine will store received faxes in memory and send them to your PC automatically. You can then use your PC to view and store these faxes.

Even if you have turned off your PC (at night or at the weekend, for example), your machine will receive and store your faxes in its memory. The number of received faxes that are stored in the memory will appear at the bottom left side of the LCD.

When you start your PC and run the PC-FAX Receiving software, your machine transfers your faxes to your PC automatically.

To transfer the received faxes to your PC, you must first have the PC-FAX Receiving software running on your PC. (For details, see *PC-FAX receiving* in the Software User's Guide on the CD-ROM.)

If you choose Backup Print: On the machine will also print the fax.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Advanced Fax Operation.
 Press OK.
- 4 Press ▲ or ▼ to choose
 Forward/Store.
 Press OK.
- 5 Press ▲ or ▼ to choose
 PC Fax Receive.
 Press OK.
- 6 Press ▲ or ▼ to choose <USB> or the PC you want to receive.

 Press OK.

- 7 Press ▲ or ▼ to choose
 Backup Print:On Or
 Backup Print:Off.
 Press OK.
- 8 Press Stop/Exit.



- PC Fax Receive is not supported in the Mac OS[®].
- Before you can set up PC Fax Receive you must install the MFL-Pro Suite software on you PC. Make sure your PC is connected and turned on. (For details see PC-FAX Receiving in the Software User's Guide on the CD-ROM.)
- (MFC-665CW only)
 In the event of a power failure, the machine will store your faxes in the memory for up to 24 hours. However, if you choose Backup Print:On the machine will print the fax, so you will have a copy if there is a power failure before it is sent to the PC.
- If you get an error message and the machine cannot print the faxes in memory, you can use this setting to transfer your faxes to your PC. (For details, see *Error* messages on page 140.)
- When PC Fax Receive is turned on only monochrome faxes can be received into the memory and sent to the PC. Colour faxes will be received in real time and printed in colour.

10

Changing the destination PC

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Advanced Fax Operation.
 Press OK.
- 4 Press ▲ or ▼ to choose
 Forward/Store.
 Press OK.
- 5 Press ▲ or ▼ to choose
 PC Fax Receive.
 Press OK.
- 6 Press ▲ or ▼ to choose Change.
 Press OK.
- Press ▲ or ▼ to choose <USB> or the PC you want to receive on the Network. Press OK.
- 8 Press ▲ or ▼ to choose
 Backup Print:On or
 Backup Print:Off.
 Press OK.
- 9 Press Stop/Exit.

Turning off Advanced Fax Operations

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Advanced Fax Operation.
 Press OK.
- Press ▲ or ▼ to choose Forward/Store. Press OK.
- 5 Press ▲ or ▼ to choose Off. Press **OK**.
- 6 Press Stop/Exit.



The LCD will give you more options if there are received faxes still in your machine's memory. (See *Changing Advanced Fax Operations* on page 82.)

Changing Advanced Fax Operations

If received faxes are left in your machine's memory when you change the Advanced Fax Operations, the LCD will ask you one of the following questions:

■ Erase All Doc?

Yes→Press 1

No→Press 2

■ Print All Fax?

Yes→Press 1

No→Press 2

- If you press 1, faxes in the memory will be erased or printed before the setting changes. If a backup copy has already been printed it will not be printed again.
- If you press 2, faxes in the memory will not be erased or printed and the setting will be unchanged.

If received faxes are left in the machine's memory when you change to

PC Fax Receive from another option [Fax Forward, Fax Storage or Fax Preview (MFC-665CW only)], press ▲ or ▼ to choose the PC.

The LCD will ask you the following message:

■ Send Fax to PC?

Yes→Press 1

No→Press 2

- If you press 1, faxes in the memory will be sent to your PC before the setting changes. You will be asked if you want to turn on Backup Print. (For detail, see PC Fax Receive on page 80.)
- If you press 2, faxes in the memory will not be erased or transferred to your PC and the setting will be unchanged.

Remote Retrieval

You can call your machine from any touch tone telephone or fax machine, then use the remote access code and remote commands to retrieve fax messages.

Setting a Remote Access Code

The remote access code lets you access the remote retrieval features when you are away from your machine. Before you can use the remote access and retrieval features, you have to set up your own code. The factory default code is inactive code (---\(\times\)).

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax.
 Press OK.
- 3 Press ▲ or ▼ to choose
 Advanced Fax Operation.
 Press OK.
- 4 Press ▲ or ▼ to choose
 Remote Access.
 Press OK.
- Enter a three-digit code using numbers 0-9, **, or #. Press OK. (The preset '** cannot be changed.)



Do not use the same code as your fax receive code (\times 5 1 (\times 9 1 for New Zealand)) or telephone answer code (# 5 1 (# 9 1 for New Zealand)). (See Connecting an external or extension telephone on page 62.)

6 Press Stop/Exit.



You can change your code at any time by entering a new one. If you want to make your code inactive, press **Clear/Back** in step **5** to restore the inactive setting (---X) and press **OK**.

Using your Remote Access Code

- 1 Dial your fax number from a touch tone telephone or another fax machine.
- When your machine answers, enter your remote access code (3 digits followed by X) at once.
- The machine signals if it has received messages:
 - 1 long beep Fax messages
 - 2 long beeps Voice messages (MFC-665CW only)
 - 3 long beeps Fax & Voice messages (MFC-665CW only)
 - No beeps No messages
- When the machine gives two short beeps, enter a command.

 The machine will hang up if you wait longer than 30 seconds to enter a command.

The machine will beep three times if you enter an invalid command.

- 5 Press **9 0** to stop Remote Access when you have finished.
- 6 Hang up.



If your machine is set to Manual mode and you want to use the remote retrieval features, wait about 2 minutes after it starts ringing, and then enter the remote access code within 30 seconds. This function may not be available in some countries e.g. Australia.

Remote Fax commands

Follow the commands below to access features when you are away from the machine. When you call the machine and enter your remote access code (3 digits followed by \times), the system will give two short beeps and you must enter a remote command.

Remote commands		s	Operation details
91	Playing Voice messages (MFC-665CW only)		After one long beep, the machine plays the ICM.
	Repeat or Skip Backward Skip Forward STOP Playing		Press 1 while listening to an ICM to repeat it. If you press 1 before a message, you will hear the previous message.
			While playing the ICM, you can skip to the next message.
			Stop Playing the ICM.
93	Erase all ICM (MFC-665CW only)		If you hear one long beep, the erase is accepted. If you hear three short beeps, you cannot erase because all voice messages have not been played, or there are no voice message to erase.
			*This code erases all recorded messages, not one at a time.
94	Play and Red (MFC-665CW	cord OGM in Memory V only)	
	1 Play	1 Msg Ctr OGM	The machine plays the selected OGM. You can stop playing
		2 F/T OGM	OGMs by pressing 9.
	2 Record	1 Msg Ctr OGM	After one long beep, you can record the selected OGM. You
		2 F/T OGM	will hear the message played once. You can stop recording the message by pressing 9 .
95	Change the Fax Forwarding or Fax Storage settings		
	1 OFF		You can choose Off after you have retrieved or erased all your messages.
	2 Fax Forwar	ding	One long beep means the change is accepted. If you hear
	4 Fax Forwarding number		three short beeps, you cannot change because something has not been set up (for example, a Fax Forwarding has not
	6 Fax Storage		been registered). You can register your Fax Forwarding number by entering 4. (See <i>Changing your Fax Forwarding number</i> on page 86.) Once you have registered the number, Fax Forwarding will work.
96	Retrieve a fax		
	2 Retrieve all faxes		Enter the number of a remote fax machine to receive stored fax messages. (See <i>Retrieving fax messages</i> on page 86.)
	3 Erase faxes from the memory		If you hear one long beep, fax messages have been erased from the memory.
97	Check the receiving status (MFC-440CN only)		
	1 Fax		You can check whether your machine has received any faxes. If yes, you will hear one long beep. If no, you will hear three short beeps.

Remote commands		Operation details	
97	Check the receiving status (MFC-665CW only)		
	1 Fax	You can check whether your machine has received any	
	2 Voice	faxes or voice messages. If yes, you will hear one long beep. If no, you will hear three short beeps.	
98	Change the Receive Mode (MFC-440CN only)		
	1 External TAD	If you hear one long beep, your change has been accepted.	
	2 Fax/Tel		
	3 Fax Only		
98	Change the Receive Mode (MFC-665CW only)		
	1 Msg Ctr	If you hear one long beep, your change has been accepted.	
	2 Fax/Tel		
	3 Fax Only		
90	Exit	Pressing 9 0 allows you to exit remote retrieval. Wait for the long beep, then replace the handset.	

Retrieving fax messages

You can call your machine from any touch tone phone and have your fax messages sent to a machine.

- 1 Dial your fax number.
- When your machine answers, enter your remote access code (3 digits followed by X) at once. If you hear one long beep, you have messages.
- When you hear two short beeps, press
- Wait for the long beep, enter the number (up to 20 digits) of the remote fax machine you want your fax messages sent to using the dial pad, then enter ##.



You cannot use \times and # as dial numbers. However, press # if you want to create a pause.

- 5 Press **9 0** to reset the machine when you've finished.
- 6 Hang up after you hear your machine beep. Your machine will call the other fax machine, which will then print your fax messages.

Changing your Fax Forwarding number

You can change the default setting of your fax forwarding number from another touch tone telephone or fax machine.

- 1 Dial your fax number.
- When your machine answers, enter your remote access code (3 digits followed by *X) at once. If you hear one long beep, you have messages.
- 3 When you hear two short beeps, press 9 5 4.
- 4 Wait for the long beep, enter the new number (up to 20 digits) of the remote fax machine you want your fax messages forwarded to using the dial pad, then enter ##.



You cannot use \times and # as dial numbers. However, press # if you want to create a pause.

- Press 9 0 to reset the machine when you have finished.
- 6 Hang up after you hear your machine beep.

11

Printing Reports

Fax reports

You need to set up the Transmission Verification Report and Journal Period using the **Menu** keys.

Transmission Verification Report

You can use the Transmission Verification Report as proof that you sent a fax. This report lists the time and date of transmission and whether the transmission was successful (OK). If you choose On or On+Image, the report will print for every fax you send.

If you send a lot of faxes to the same place, you may need more than the job numbers to know which faxes you must send again. Choosing On+Image or Off+Image will print a section of the fax's first page on the report to help you remember.

When the Transmission Verification Report is turned Off or Off+Image, the Report will only print if there is a transmission error, with NG in the RESULT column.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax.
 Press OK.
- 3 Press ▲ or ▼ to choose Report Setting. Press OK.
- 4 Press ▲ or ▼ to choose
 Transmission.
 Press OK.
- Press ▲ or ▼ to choose On, On+Image, Off Or Off+Image. Press OK.
- 6 Press Stop/Exit.

Fax Journal (activity report)

You can set the machine to print a journal at specific intervals (every 50 faxes, 6, 12 or 24 hours, 2 or 7 days). If you set the interval to Off, you can still print the report by following the steps on *How to print a report* on page 88. The factory setting is Every 50 Faxes.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose Report Setting. Press OK.
- 4 Press ▲ or ▼ to choose
 Journal Period.
 Press OK.
- Press ▲ or ▼ to choose an interval. Press OK.

(If you choose 7 days, the LCD will ask you to choose the first day for the 7-day countdown.)

- The machine will print the report at the chosen time and then erase all jobs from its memory. If the machine's memory becomes full with 200 jobs before the time you chose has passed, the machine will print the Journal early and then erase all jobs from the memory. If you want an extra report before it is due to print, you can print it without erasing the jobs from the memory.
- Every 50 Faxes
 The machine will print the Journal when the machine has stored 50 jobs.

6 Enter the time to start printing in 24-hour format.

Press OK.

(For example: enter 19:45 for 7:45 PM.)

Press Stop/Exit.

Reports

The following reports are available:

■ XMIT Verify

Prints a Transmission Verification Report for your last transmission.

■ Help List

A help list about how to quickly program your machine.

■ Quick-Dial

Lists names and numbers stored in the Speed-Dial memory, in alphabetical or numerical order.

■ Fax Journal

Lists information about the last incoming and outgoing faxes. (TX: Transmit.) (RX: Receive.)

■ User Settings

Lists your settings.

■ Network Config

Lists your Network settings.

How to print a report

- 1 Press Menu.
- Press ▲ or ▼ to choose
 Print Reports.
 Press OK.
- Press ▲ or ▼ to choose the report you want.
 Press OK.
- Press Mono Start.

12 Polling

Polling overview

Polling lets you set up your machine so other people can receive faxes from you, but they pay for the call. It also lets you call somebody else's fax machine and receive a fax from it, so you pay for the call. The polling feature needs to be set up on both machines for this to work. Not all fax machines support polling.

Polling receive

Polling receive lets you call another fax machine to receive a fax.

Setup to receive polling

- 1 Press (Fax).
- Press ▲ or ▼ to choose Polling RX. Press OK.
- 3 Press ▲ or ▼ to choose Standard. Press OK.
- 4 Enter the fax number you are polling.
- 5 Press Mono Start or Colour Start.

Setup to receive polling with secure code

Secure Polling lets you restrict who can get the documents you set up to be polled.

Secure Polling only works with Brother fax machines. If you want to get a fax from a secured Brother machine you have to enter the secure code.

- Press (Fax).
- Press ▲ or ▼ to choose Polling RX. Press OK.
- 3 Press ▲ or ▼ to choose Secure.
 Press OK.
- 4 Enter a four-digit secure code.
 This is the same as the security code of the fax machine you are polling.
 Press **OK**.
- 5 Enter the fax number you are polling.
- 6 Press Mono Start or Colour Start.

Setup to receive delayed polling

Delayed polling lets you set the machine to begin polling receive at a later time. You can only set up *one* delayed polling operation.

- 1 Press (Fax).
- Press ▲ or ▼ to choose Polling RX. Press OK
- Press ▲ or ▼ to choose Timer.
 Press OK.
- 4 Enter the time (in 24-hour format) you want to start polling.
 For example, enter 21:45 for 9:45 PM. Press **OK**.
- Enter the fax number you are polling.
- 6 Press Mono Start or Colour Start.
 The machine makes the polling call at the time you entered.

Sequential polling (Monochrome only)

Sequential polling lets you request documents from several fax machines in one operation.

- 1 Press (Fax).
- Press ▲ or ▼ to choose Polling RX. Press OK.
- 3 Press ▲ or ▼ to choose Standard, Secure Or Timer.

 Press OK.
- 4 Do one of the following:
 - If you chose Standard, go to step **6**.
 - If you chose Secure, enter a fourdigit number, press OK, go to step 6.

- If you chose Timer, enter the time (24-hour format) you want to begin polling and press **OK**, go to step **⑤**.
- 5 Press ▲ or ▼ to choose
 Broadcasting.
 Press OK.
- 6 Press ▲ or ▼ to choose Add Number.
 Press OK.
- 7 Enter a number using Speed-Dial, a Group, or dial pad.
 Press **OK**.
- 8 Repeat steps 6 and 7 for all the fax numbers you want to poll, and then press ▲ or ▼ to choose Complete. Press OK.
- Press Mono Start.
 The machine polls each number or group in turn for a document.

Press **Stop/Exit** while the machine is dialling to cancel the polling process.

To cancel all sequential polling receive jobs, see *Checking and cancelling waiting jobs* on page 40.

19

Polled transmit (Monochrome only)

Polled transmit lets you set up your machine to wait with a document so another fax machine can call and retrieve it.

The document will be stored and can be retrieved by any other fax machine until you delete it from the memory. (See *Checking and cancelling waiting jobs* on page 40.)

Setup for polled transmit

- 1 Press (Fax).
- 2 Load your document.
- Press ▲ or ▼ to choose Polled TX. Press OK.
- Press ▲ or ▼ to choose Standard. Press OK.
- Press ▲ or ▼ to choose any settings you want to change. Press OK. After each setting is accepted, you can

continue to change more settings.

6 Press Mono Start.

Setup for polled transmit with secure code

Secure Polling lets you restrict who can get the documents you set up to be polled.

Secure Polling only works with Brother fax machines. If another person wants to retrieve a fax from your machine they will have to enter the secure code.

- 1 Press (Fax).
- 2 Load your document.
- 3 Press ▲ or ▼ to choose Polled TX. Press OK.
- 4 Press ▲ or ▼ to choose Secure.
 Press OK.
- 5 Enter a four-digit number. Press **OK**.
- 6 Press ▲ or ▼ to choose any settings you want to change. Press OK. After each setting is accepted, you can continue to change more settings.
- 7 Press Mono Start.

Section III



Copy

Making copies


94


13 Making copies

How to copy


Entering Copy mode

When you want to make a copy, press





The LCD shows:



No of Copies

You can enter the number of copies you want by using the dial pad.

Press ▲ or ▼ to scroll through the **Copy** key options.

- Quality (See page 95.)
- Enlarge/Reduce (See page 96.)
- Paper Type (See page 99.)
- Paper Size (See page 99.)
- Brightness (See page 98.)
- Contrast (See page 98.)
- Color Adjust (See page 98.)
- Stack/Sort (See page 97.)
- Page Layout (See page 96.)
- Set New Default (See page 99.)
- Factory Reset (See page 99.)

When the option you want is highlighted, press OK.



The default setting is Fax mode. You can change the amount of time that the machine stays in Copy mode after the last copy operation. (See Mode Timer on page 23.)

Making a single copy

- Press 💮 📚 (Copy).
- Load your document. (See Loading documents on page 10.)
- Press Mono Start or Colour Start.

13

Making multiple copies

You can make up to 99 copies.

- 1 Press (Copy).
- 2 Load your document.
- 3 Enter the number of copies you want.
- 4 Press Mono Start or Colour Start.



To sort the copies, press ▲ or ▼ to choose Stack/Sort. (See Sorting copies using the ADF on page 97.)

Stop copying

To stop copying, press Stop/Exit.

Copy settings

You can change the copy settings temporarily for the next copy.

The machine returns to its default settings after 60 seconds, or if the Mode Timer returns the machine to Fax mode. (See *Mode Timer* on page 23.)

If you have finished choosing settings, press **Mono Start** or **Colour Start**.

If you want to choose more settings, press ▲ or ▼.



You can save some of the settings that you use most often by setting them as default. These settings will stay until you change them again. (See Setting your changes as a new default on page 99.)

Changing copy speed and quality

You can choose from a range of quality. The factory setting is Normal.

■ Fast

Fast copy speed and lowest amount of ink used. Use to save time printing documents to be proof-read, large documents or many copies).

■ Normal

Normal is the recommended mode for ordinary print outs. This produces good copy quality with good copy speed.

■ Best

Use best mode to copy precise images such as photographs. This provides the highest resolution and slowest speed.

- 1 Press (Copy).
- 2 Load your document.
- 3 Enter the number of copies you want.
- Press ▲ or ▼ to choose Quality. Press OK.
- 5 Press ▲ or ▼ to choose Fast, Normal or Best.
 Press OK.
- 6 If you do not want to change additional settings, press Mono Start or Colour Start.

Enlarging or reducing the image copied

You can choose an enlargement or reduction ratio.

- 1 Press (Copy).
- 2 Load your document.
- 3 Enter the number of copies you want.
- 4 Press ▲ or ▼ to choose
 Enlarge/Reduce.
 Press OK.
- Do one of the following:
 - Press ▲ or ▼ to choose the enlargement or reduction ratio you want. Press OK.
 - Press ▲ or ▼ to choose Custom(25-400%) and then enter an enlargement or reduction ratio from 25% to 400%. Press OK. (For example, press 5 3 to enter 53%.)

50%	
69% A4→A5	
78% LGL→LTR	
83% LGL→A4	
93% A4→LTR	
97% LTR→A4	
100%*	
104% EXE→LTR	
142% A5→A4	
186% 10×15cm→LTR	
198% 10×15cm→A4	
200%	
Custom(25-400%)	

6 If you do not want to change additional settings, press Mono Start or Colour Start.



Page Layout Options are not available with Enlarge/Reduce.

Making N in 1 copies or a poster (page layout)

The N in 1 copy feature can help you save paper by letting you copy two or four pages onto one printed page.

You can also produce a poster. When you use the poster feature your machine divides your document into sections, then enlarges the sections so you can assemble them into a poster. If you want to make a poster, use the scanner glass.

Important

- Please make sure paper size is set to Letter or A4.
- You can not use the Enlarge/Reduce setting with the N in 1 and Poster features.
- If you are producing multiple colour copies, N in 1 copy is not available.
- (P) means Portrait and (L) means Landscape.
- You can only make one poster copy at a time.
- 1 Press (Copy).
- 2 Load your document.
- 3 Enter the number of copies you want.
- Press ▲ or ▼ to choose Page Layout. Press OK.
- Press ▲ or ▼ to choose Off
 (1 in 1), 2 in 1 (P),
 2 in 1 (L), 4 in 1 (P),
 4 in 1 (L) or Poster (3×3).
 Press OK.

13

- 6 If you do not want to change additional settings, press Mono Start or Colour Start to scan the page.
 If you are making a poster or placed the document in the ADF, the machine scans the pages and starts printing.
 If you are using the scanner glass, go to step 1.
- After the machine scans the page, press 1 to scan the next page.
- 8 Place the next page on the scanner glass.
 Press **OK**.

Repeat steps 7 and 8 for each page of the layout.


After all the pages have been scanned, press 2 to finish.




If photo paper has been chosen in the Paper Type setting for N in 1 copies, the machine will print the images as if Plain paper had been chosen.

Place your document face down in the direction shown below.

■ 2 in 1 (P)



■ 2 in 1 (L)



■ 4 in 1 (P)




■ 4 in 1 (L)



■ Poster (3 x 3)

You can make a poster size copy of a photograph.



Sorting copies using the ADF

You can sort multiple copies. Pages will be stacked in the order 123, 123, 123, and so on.

- 1 Press (Copy).
- 2 Load your document.
- 3 Enter the number of copies you want.
- 4 Press ▲ or ▼ to choose Stack/Sort. Press OK.
- 5 Press ▲ or ▼ to choose Sort. Press OK.
- 6 If you do not want to change additional settings, press Mono Start or Colour Start.

Adjusting Brightness, Contrast and Colour

Brightness

You can adjust the copy brightness to make copies darker or lighter.

- 1 Press (Copy).
- 2 Load your document.
- 3 Enter the number of copies you want.
- 4 Press ▲ or ▼ to choose Brightness. Press OK.
- Press ◀ to make a darker copy or press to make a lighter copy. Press OK.
- 6 If you do not want to change additional settings, press Mono Start or Colour Start.

Contrast

You can adjust the copy contrast to help an image look sharper and more vivid.

- 1 Press (Copy).
- 2 Load your document.
- 3 Enter the number of copies you want.
- Press ▲ or ▼ to choose Contrast. Press OK.
- Press ► to increase the contrast or press ◄ to decrease the contrast. Press OK.
- 6 If you do not want to change additional settings, press Mono Start or Colour Start.

Colour Saturation

- 1 Press (Copy).
- 2 Load your document.
- 3 Enter the number of copies you want.
- Press ▲ or ▼ to choose
 Color Adjust.
 Press OK.
- Fress ▲ or ▼ to choose Red, Green or Blue.
 Press OK.
- 6 Press ▶ to increase the colour saturation, or press ◀ to decrease the colour saturation.

 Press **OK**.
- 7 Do one of the following:
 - If you want to change saturation for another colour, go to step 6.
 - If you want to change additional settings, press or vo choose
 Exit.

Press OK.

 If you do not want to change additional settings, press
 Mono Start or Colour Start.

13

Paper Options

Paper Type

If you are copying on special paper, set the machine for the type of paper you are using to get the best print quality.

- 1 Press (Copy).
- 2 Load your document.
- 3 Enter the number of copies you want.
- Press ▲ or ▼ to choose Paper Type.
 Press OK.
- 5 Press ▲ or ▼ to choose Plain Paper, Inkjet Paper, Brother Photo, Other Photo Or Transparency. Press OK.
- 6 If you do not want to change additional settings, press Mono Start or Colour Start.

Paper Size

If copying on paper other than A4 size, you will need to change the paper size setting. You can copy only on Letter, Legal, A4, A5 or Photo [10 cm (W) \times 15 cm (H)] paper.

- 1 Press (Copy).
- 2 Load your document.
- 3 Enter the number of copies you want.
- Press ▲ or ▼ to choose Paper Size. Press OK.
- 5 Press ▲ or ▼ to choose Letter, Legal, A4, A5 or 10×15cm. Press OK.
- 6 If you do not want to change additional settings, press Mono Start or Colour Start.

Setting your changes as a new default

You can save the copy settings for Quality, Paper Type, Brightness, Contrast and Color Adjust that you use most often by setting them the default settings. These settings will stay until you change them again.

- 1 Press (Copy).
- Press ▲ or ▼ to choose your new setting.
 Press OK.
 Repeat this step for each setting you want to change.
- 3 After changing the last setting, press ▲ or ▼ to choose Set New Default. Press OK.
- 4 Press 1 to choose Yes.
- 5 Press Stop/Exit.

Restoring all settings to the factory settings

You can restore all the settings you have changed to the factory settings. These settings will stay until you change them again.

- 1 Press (Copy).
- Press ▲ or ▼ to choose
 Factory Reset.
 Press OK.
- 3 Press 1 to choose Yes.
- 4 Press Stop/Exit.

'Out of Memory' message

If the Out of Memory message appears while scanning documents, press Stop/Exit to cancel or Mono Start or Colour Start to copy the scanned pages.

You will need to clear some jobs from the memory before you can continue.

To free up extra memory, do the following:

- Turn off Advanced Fax Operation. (See Turning off Advanced Fax Operations on page 81.)
- Print the faxes that are in the memory. (See Printing a fax from the memory on page 48.)

When you get an Out of Memory message, you may be able to make copies if you first print incoming faxes in the memory to restore the memory to 100%.

Section IV



Direct Photo Printing

Printing photos from a memory card	102
Printing photos from a camera with	
PictBridge	113

Printing photos from a memory card

PhotoCapture Center™ Operations

Printing from a memory card without a PC

Even if your machine is not connected to your computer, you can print photos directly from digital camera media. (See *Print Images* on page 104.)

Scanning to a memory card without a PC

You can scan documents and save them directly to a memory card. See *Scan to Card* on page 111.


Using PhotoCapture Center™ from your computer

You can access the memory card that is in the media drive (slot) of the machine from your PC.

(See PhotoCapture Center[™] for Windows[®] or Remote Setup & PhotoCapture Center[™] for Macintosh[®] in the Software User's Guide on the CD-ROM.)

Using memory cards

Your Brother machine includes two media drives (slots) for use with popular digital camera media: CompactFlash[®], Memory Stick[®] Memory Stick Pro™, SecureDigital™, MultiMediaCard™ and xD-Picture Card™.



- miniSD™ can be used with a miniSD™ adapter.
- Memory Stick Duo[™] can be used with a Memory Stick Duo[™] adapter.
- Memory Stick Pro Duo[™] can be used with a Memory Stick Pro Duo[™] adapter.
- Adapters are not included with the machine. Contact a third party supplier for adapters.

The PhotoCapture Center™ feature lets you print digital photos from your digital camera at high resolution to get photo quality printing.

Memory card folder structure

Your machine is designed to be compatible with modem digital camera image files and memory cards; however, please read the points below to avoid errors:

■ The DPOF file on the memory card must be in a valid format. (See *DPOF* printing on page 106.)

(Other image file extensions like .JPEG,.TIF, .GIF and so on will not be recognized).

■ The image file extension must be .JPG

- Walk-up PhotoCapture Center[™] printing must be performed separately from PhotoCapture Center[™] operations using the PC. (Simultaneous operation is not available.)
- IBM MicrodriveTM is not compatible with the machine.
- The machine can read up to 999 files (including the folder inside memory) on a memory card.
- CompactFlash[®] Type II is not supported.
- This product supports xD-Picture Card[™] Type M / Type H (Large Capacity).


Please be aware of the following:

- When printing the INDEX or IMAGE, the PhotoCapture Center™ will print all the valid images, even if one or more images have been corrupted. A portion of the corrupted image may be printed.
- Your machine is designed to read memory cards that have been formatted by a digital camera.

When a digital camera formats a memory card it creates a special folder into which it copies image data. If you need to modify the image data stored on a memory card with your PC, we recommend that you do not modify the folder structure created by the digital camera. When saving new or modified image files to the memory card we also recommend you use the same folder your digital camera uses. If the data is not saved to the same folder, the machine may not be able to read the file or print the image.


Getting started

Firmly put the card into the proper slot.



- 1 CompactFlash®
- 2 SecureDigital™, MultiMediaCard™
- 3 Memory Stick[®], Memory Stick Pro™
- 4 xD-Picture Card™

PhotoCapture key indications:



- PhotoCapture light is on, the memory card is properly inserted.
- **PhotoCapture** light is off, the memory card is not properly inserted.
- PhotoCapture light is blinking, the memory card is being read or written to.



DO NOT unplug the power cord or remove the memory card from the media drive (slot) while the machine is reading or writing to the card (the **PhotoCapture** key is blinking). **You will lose your data or damage the card.** 14

The machine can only read one memory card at a time so do not put more than one card in a slot.

Entering PhotoCapture mode

After you insert the memory card, press the (PhotoCapture) key to illuminate it in green and display the PhotoCapture options on the LCD.

The LCD shows:



Press ▲ or ▼ to scroll through the PhotoCapture key options.

- View Photo(s) (See page 104.)
- Print Index (See page 105.)
- Print All Photos (See page 105.)
- Print Photos (See page 106.)



If your digital camera supports DPOF printing, see *DPOF printing* on page 106.

When the option you want is highlighted, press **OK**.

Print Images

View Photo(s)

You can preview your photos on the LCD before you print them. If your photos are large files there may be a delay before each photo is displayed on the LCD.

1 Make sure you have put the memory card in the proper slot.

Press (PhotoCapture).

Press ▲ or ▼ to choose
 View Photo(s).
Press OK.

3 Press ◀ or ▶ to choose your photo.



Instead of scrolling through your photos, you can use the dial pad to enter the 3-digit number of the image from the index page. (See *Print Index* (*Thumbnails*) on page 105.)

- Press ▲ to ▼to increase or decrease the number of copies.
- 5 Repeat step 3 and step 4 until you have chosen all the photos.



Press **Clear/Back** to go back to the previous level.

- 6 After you have chosen all the photos, do one of the following:
 - Press **OK** and change the print setting. (See page 107.)
 - If you do not want to change any settings, press Colour Start to print.

14

Print Index (Thumbnails)


The PhotoCapture Center™ assigns numbers for images (such as No.1, No.2, No.3, and so on).



The PhotoCapture Center™ does not recognize any other numbers or file names that your digital camera or PC has used to identify the pictures. You can print a thumbnail page (Index page with 6 or 5 images per line). This will show all the pictures on the memory card.

- 1 Make sure you have put the memory card in the proper slot.
 - Press (PhotoCapture).
- Press ▲ or ▼ to choose Print Index. Press OK.
- 3 Press ▲ or ▼ to choose
 5 Images/Line Photo or
 6 Images/Line Fast.

Press OK.



5 Images/Line Photo

6 Images/Line Fast

Print time for 5 Images/Line will be slower than 6 Images/Line, but the quality is better.

4 Press Colour Start to print.

Print All Photos

You can print all the photos on your media card.

- 1 Make sure you have put the memory card in the proper slot.
 - Press (PhotoCapture).
- Press ▲ or ▼ to choose
 Print All Photos.
 Press OK.
- 3 Enter the number of copies you want using the dial pad.
- 4 Do one of the following:
 - Change the print setting. (See page 107.)
 - If you do not want to change any settings, press Colour Start to print.

Print Photos

Before you can print an individual image, you have to know the image number.

1 Make sure you have put the memory card in the proper slot.

Press (PhotoCapture).

- Print the Index. (See Print Index (Thumbnails) on page 105.)
- 3 Press ▲ or ▼ to choose
 Print Photos.
 Press OK.
- 4 Enter the image number that you want to print from the Index page (Thumbnails). Press **OK**.
- 5 Repeat step 4 until you have entered all the image numbers that you want to print.

Note

- 6 After you have chosen all the image numbers, press **OK** again.
- 7 Enter the number of copies you want using the dial pad.
- 8 Do one of the following:
 - Change the print setting. (See page 107.)
 - If you do not want to change any settings, press Colour Start to print.

DPOF printing

DPOF stands for Digital Print Order Format.

Major digital camera manufacturers (Canon Inc., Eastman Kodak Company, Fuji Photo Film Co. Ltd., Matsushita Electric Industrial Co. Ltd. and Sony Corporation) created this standard to make it easier to print images from a digital camera.

If your digital camera supports DPOF printing, you will be able to choose on the digital camera display the images and number of copies you want to print.

When the memory card (CompactFlash[®], Memory Stick[®], Memory Stick Pro[™], SecureDigital[™] MultiMediaCard[™] or xD-Picture Card[™]) with DPOF information is put into your machine, you can print the chosen image easily.

- 1 Make sure you have put the memory card into the proper slot.
 - Press (PhotoCapture). The machine will ask you if you want to use DPOF setting.
- 2 Press 1 to choose Yes.
- 3 Do one of the following:
 - Change the print settings. (See page 107.)
 - If you do not want to change any settings, press Colour Start to print.

PhotoCapture Center™ print settings

You can change the print settings temporarily for the next printing.

The machine returns to its default settings 180 seconds, or if the Mode Timer returns the machine to Fax mode. (See *Mode Timer* on page 23.)



You can save the print settings you use most often by setting them as default. (See Setting your changes as a new default on page 110.)



1 No of prints

(For View Photo(s))

You can see the total number of photos that will be printed.

(For Print All Photos, Print Photos)

You can see the number of copies of each photo that will be printed.

Menu Selections	Option 1	Option 2	Page
Print Quality	Normal/Photo	_	108
Paper Type	Plain Paper/Inkjet Paper/ Brother Photo/Other Photo	_	108
Paper Size	Letter/A4/10x15cm/13x18cm	(When A4 or Letter is chosen) 10x8cm/13x9cm/15x10cm/ 18x13cm/20x15cm/Max. Size	108
Brightness	0 d Light	_	109
Contrast	4	_	109
Color Enhance	On/Off White Balance Sharpness Color Density		109
Cropping	On/Off	-	110
Borderless	On/Off	_	110
Set New Default	Yes/No	_	110
Factory Reset	Yes/No	—	110

Print Quality

- 1 Press ▲ or ▼ to choose
 Print Quality.
 Press OK.
- Press ▲ or ▼ to choose Normal or Photo.

 Press OK.
- If you do not want to change additional settings, press Colour Start to print.

Paper options

Paper Type

- 1 Press ▲ or ▼ to choose Paper Type.
 Press OK.
- Press ▲ or ▼ to choose the type of paper you are using, Plain Paper, Inkjet Paper, Brother Photo or Other Photo. Press OK.
- If you do not want to change additional settings, press **Colour Start** to print.

Paper and print size

- 1 Press ▲ or ▼ to choose Paper Size.
 Press OK.
- Press ▲ or ▼ to choose the size of paper you are using, Letter, A4, 13×18cm, 10×15cm.
 Press OK.
- If you chose Letter or A4, press ▲ or ▼ to choose the print size.
 Press OK.

Example: Printed Position for A4 paper			
1	2	3	
10×8cm	13×9cm	15×10cm	
4	5	6	
18×13cm	20×15cm	Max. Size	

4 If you do not want to change additional settings, press **Colour Start** to print.

14

Adjusting Brightness, Contrast and Colour

Brightness

- 1 Press ▲ or ▼ to choose Brightness. Press OK.
- Press ◀ to make a darker copy or press to make a lighter copy. Press OK.
- If you do not want to change additional settings, press **Colour Start** to print.

Contrast

You can choose the contrast setting. More contrast will make an image look sharper and more vivid.

- 1 Press ▲ or ▼ to choose Contrast.
 Press OK.
- Press ► to increase the contrast or press ◄ to decrease the contrast. Press OK.
- If you do not want to change additional settings, press **Colour Start** to print.

Colour Enhancement

The colour enhancement feature will produce more vivid images. Your photographs will take slightly longer to print.

- 1 Press ▲ or ▼ to choose Color Enhance.
 Press OK.
- 2 Do one of the following:
 - If you want to customize the White Balance, Sharpness or Colour Density, press or to choose on and then go to step .
 - If you do not want to customize, press ◀ or ▶ to choose Off.
 Press OK and then go to step ⑥.

3 Press ▲ or ▼ to choose

White Balance, Sharpness **or** Color Density.

Press OK.

- Press ◀ or ▶ to adjust the degree of the setting.
 Press OK.
- Do one of the following:
 - If you want to customize other colour enhancement, press ▲ or ▼ to choose other option.
 - If you want to change other settings, press ▲ or ▼ to choose Exit, and then press OK.
- 6 If you do not want to change additional settings, press Colour Start to print.



White Balance

This setting adjusts the hue of the white areas of an image. Lighting, camera settings and other factors will effect the appearance of white. By using this adjustment, you can correct this effect and bring the white areas back to pure white.

Sharpness

This setting enhances the detail of an image. It is similar to adjusting the fine focus on a camera. If the image is not in focus and you cannot see the fine details of the picture, then adjust the sharpness.

Colour Density

This setting adjusts the total amount of colour in the image. You can increase or decrease the amount of colour in an image to improve a washed out picture.

Cropping


If your photo is too long or wide to fit the available space on your chosen layout, part of the image will automatically be cropped.

The factory setting is On. If you want to print the whole image, turn this setting to Off.

- 1 Press ▲ or ▼ to choose Cropping.

 Press OK
- Press ▲ or ▼ to choose off (or on).
 Press OK.
- If you do not want to change additional settings, press **Colour Start** to print.

Cropping: On



Cropping: Off



Borderless printing

This feature expands the printable area to the edges of the paper. Printing time will be slightly slower.

- 1 Press ▲ or ▼ to choose Borderless.
 Press OK
- Press ▲ or ▼ to choose off (or on).
 Press OK.
- If you do not want to change additional settings, press **Colour Start** to print.

Setting your changes as a new default

You can save the print settings you use most often by setting them the default settings. These settings will stay until you change them again.

- Press ▲ or ▼ to choose your new setting.
 Press OK.
 Repeat this step for each setting you want to change.
- After changing the last setting, press ▲ or ▼ to choose Set New Default. Press OK.
- Open in the second of the s
- 4 Press Stop/Exit.

Restoring all the settings to factory settings


You can restore all the settings you have changed to the factory settings. These settings will stay until you change them again.

- 1 Press ▲ or ▼ to choose Factory Reset.
 Press OK.
- Press 1 to choose Yes.
- 3 Press Stop/Exit.

Scan to Card

Entering Scan mode

When you want to scan to card, press (Scan) to illuminate it in green.



The LCD shows:



Press ▲ or ▼ to choose Scan to Card.

Press OK.

If you are not connected to your computer only the Scan to Card selection will appear on the LCD.

(See *Scanning* for Windows[®] or Macintosh[®] in the Software User's Guide on the CD-ROM for details about the other menu options.)

How to scan to card

You can scan monochrome and colour documents into a memory card. Monochrome documents will be stored in PDF (*.PDF) or TIFF file formats (*.TIF). Colour documents may be stored in PDF (*.PDF) or JPEG (*.JPG) file formats. For colour documents the factory setting is 150 dpi Color and the default file format is PDF. The machine automatically creates file names based on the current date. (For details, see Quick Setup Guide.) For example, the fifth image scanned on July 1, 2006 would be named 01070605.PDF. You can change the colour, quality and file name.

Quality	Selectable File Format
150 dpi Color	JPEG/PDF
300 dpi Color	JPEG/PDF
600 dpi Color	JPEG/PDF
200x100 dpi B/W	TIFF / PDF
200 dpi B/W	TIFF / PDF

Insert a CompactFlash[®], Memory Stick[®], Memory Stick Pro™, SecureDigital™, MultiMediaCard™ or xD-Picture Card™ into your machine.



WARNING

Do not take out the memory card while **PhotoCapture** is blinking to avoid damaging the card or data stored on the card.

- 2 Load your document.
- 3 Press (Scan).
- 4 Press ▲ or ▼ to choose
 Scan to Card.
 Press OK.

14

- Do one of the following.
 - To change the quality, go to step **6**.
 - Press Mono Start or Colour Start to start scanning without changing additional settings.
- 6 Press ▲ or ▼ to choose
 150 dpi Color,300 dpi Color,
 600 dpi Color,200x100 dpi B/W
 or 200 dpi B/W.
 Press OK.
- 7 Do one of the following.
 - To change the file type, go to step ⑧.
 - Press Mono Start or Colour Start to start scanning without changing additional settings.
- 8 Press ▲ or ▼ to choose JPEG, PDF or TIFF.
 Press OK.



- If you chose colour in the resolution setting, you cannot choose TIFF.
- If you chose monochrome in the resolution setting, you cannot choose JPEG.
- 9 Do one of the following.
 - To change the file name, go to step **(0**.
 - Press Mono Start or Colour Start to start scanning without changing additional settings.
- 10 The file name is set automatically however, you can set a name of your choice using the dial pad. You can only change the first 6 digits.

 Press **OK**.



Press **Clear/Back** to delete the current name.

Press Mono Start or Colour Start.

Understanding the Error Messages

Once you are familiar with the types of errors that can occur while you are using the PhotoCapture Center™, you can easily identify and troubleshoot any problems.

When an error message appears on the LCD, the machine will beep to get your attention.

■ Media Error

This message will appear if you put in a memory card that is either bad or not formatted, or when there is a problem with the media drive. To clear this error, take out the memory card.

■ No File

This message will appear if you try to access a memory card in the drive (slot) that does not contain a .JPG file.

■ Out of Memory

This message will appear if you are working with images that are too large for the machine's memory.

Printing photos from a camera with PictBridge



Your Brother machine supports the PictBridge standard, allowing you to connect to and print photos directly from any PictBridge compatible digital camera.

Before Using PictBridge

PictBridge requirements

To avoid errors, remember the following points:

- The machine and the digital camera must be connected using a suitable USB cable.
- The image file extension must be .JPG (Other image file extensions like .JPEG, .TIF, .GIF and so on will not be recognized).
- PhotoCapture Center operations are not available when using the PictBridge feature.

Using PictBridge Setting your digital camera

Make sure your camera is in PictBridge mode. Some of the settings listed below may not be available for your PictBridge compatible digital camera.

Camera Menu Selections	Options
Paper Size	Letter, A4, 10x15 cm, Printer Settings (Default setting) ²
Paper Type	Plain Paper, Glossy Paper, Inkjet Paper, Printer Settings (Default setting) ²
Layout	Borderless: On, Borderless: Off, Printer Settings (Default setting) ²
DPOF setting ¹	-
Print Quality	Normal, Fine, Printer Settings (Default setting) ²
Colour Enhancement	On, Off, Printer Settings (Default setting) ²

- See DPOF printing on page 114 for more details.
- If your camera is set to use the Printer Settings (Default setting), the machine will print your photo using the settings below.


Settings	Options
Paper Size	10x15 cm
Paper Type	Glossy Paper
Layout	Borderless: On
Print Quality	Fine
Colour Enhancement	Off

Please refer to the documentation supplied with your camera for more detailed information on changing PictBridge settings.

Printing Images

1

Make sure that your camera is turned off. Connect your camera to the PictBridge port on the machine using the USB cable.



1 PictBridge port



Remove any memory cards from the machine before connecting the digital camera.



Turn on the camera.

When the machine has recognized the camera, the LCD shows

Camera Connected.

When the machine starts printing a photo, the LCD will show Printing.



WARNING

To prevent damage to your machine, do not connect any device other than a PictBridge compatible camera to the PictBridge port.

DPOF printing

DPOF stands for Digital Print Order Format.

Major digital camera manufacturers (Canon Inc., Eastman Kodak Company, Fuji Photo Film Co. Ltd., Matsushita Electric Industrial Co. Ltd. and Sony Corporation) created this standard to make it easier to print images from a digital camera.

If your digital camera supports DPOF printing, you will be able to choose on the digital camera display the images and number of copies you want to print.

Understanding the Error Messages

Once you are familiar with the types of errors that can occur while you are using the PictBridge, you can easily identify and troubleshoot any problems.

■ Out of Memory

This message will appear if you are working with images that are too large for the machine's memory.

■ Wrong USB device

This message will appear if you connect a non-PictBridge compatible or broken device to the PictBridge port. To clear the error, unplug the device from the PictBridge port, then press **Power Save** to turn the machine off and then on again.

See *Error messages* on page 140 for the detailed solution.

Section V



Software

Software and Network features

118

Software and Network features

The CD-ROM includes the Software User's Guide and Network User's Guide for features available when connected to a computer (for example, printing and scanning). The guide has easy to use links that, when clicked, will take you directly to a particular section.

You can find information on these features:

- Printing
- Scanning
- ControlCenter3 (for Windows[®])
- ControlCenter2 (for Macintosh®)
- Remote Setup
- Faxing from your computer
- PhotoCapture Center™
- Network Printing
- Network Scanning
- Wireless Network User's (MFC-665CW only)

How to read HTML User's Guide

This is a quick reference for using the HTML User's Guide.

(For Windows®)



If you have not installed the software, see Viewing Documentation on page 3.

- From the **Start** menu, point to **Brother**, MFC-XXXX (where XXXX is your model number) from the programs group, then click User's Guide.
- Click SOFTWARE USER'S GUIDE (or **NETWORK USER'S GUIDE)** from the top menu.



Click the heading you would like to view from the list at the left of the window.



(For Macintosh®)

- Make sure your Macintosh® is turned on. Insert the Brother CD-ROM into your CD-ROM drive.
- Double-click the **Documentation** icon.
- Double-click your language folder, and then double-click the top page file.
- Click SOFTWARE USER'S GUIDE (or NETWORK USER'S GUIDE) in the top menu, and then click the heading you would like to read from the list at the left of the window.



Section VI



Appendixes

Safety and Legal	120
Troubleshooting and Routine Maintenance	134
Menu and Features	158
Specifications	175
Glossary	188

A

Safety and Legal

Choosing a location

Put your machine on a flat, stable surface that is free of vibration and shocks, such as a desk. Put the machine near a telephone socket and a standard grounded electrical socket. Choose a location where the temperature remains between 10° and 35° C (50° F and 95° F).

Q CAUTION

- · Avoid placing your machine in a high-traffic area.
- Avoid placing your machine on a carpet.
- DO NOT put the machine near heaters, air conditioners, refrigerators, medical equipment, chemicals or water.
- DO NOT expose the machine to direct sunlight, excessive heat, moisture, or dust.
- DO NOT connect your machine to electrical socket controlled by wall switches or automatic timers.
- Disruption of power can wipe out information in the machine's memory.
- Do not connect your machine to electrical socket on the same circuit as large appliances or other equipment that might disrupt the power supply.
- Avoid interference sources, such as speakers or the base units of non-Brother cordless phones.







To use the machine safely

Please keep these instructions for later reference and read them before attempting any maintenance.



(MFC-665CW only)


If there are faxes in the machine's memory you need to print them or save them before you unplug the machine from the electrical socket for more than 24 hours. (To print the faxes in memory, see *Printing a fax from the memory* on page 48. To save the faxes in memory, see *Transferring faxes to another fax machine* on page 143 or *Transferring faxes to your PC* on page 143.)



WARNING



There are high voltage electrodes inside the machine. Before you clean the inside of the machine, make sure you have unplugged the telephone line cord first and then the power cord from the electrical socket. Doing this will prevent an electrical shock.





DO NOT handle the plug with wet hands. Doing this might cause an electrical shock.





DO NOT pull on the middle of the AC power cord. Doing this might cause an electrical shock.




DO NOT put your hands on the edge of the machine under the document cover or the scanner cover. Doing this may cause injury.








DO NOT put your hands on the edge of the paper tray under the output paper tray cover. Doing this may cause injury.






DO NOT touch the paper feed roller. Doing this may cause injury.





DO NOT touch the area shaded in the illustration. Doing this may cause injury.







When moving the machine you must lift it from the base, by placing a hand at each side of the unit as shown in the illustration. Do not carry the machine by holding the scanner cover.



If the machine becomes hot, releases smoke, or generates any strong smells, immediately unplug the machine from the electrical socket. Call Brother dealer for service.

If metal objects, water or other liquids get inside the machine, immediately unplug the machine from the electrical socket. Call Brother dealer for service.



WARNING

- Use caution when installing or modifying telephone lines. Never touch telephone wires or terminals that are not insulated unless the telephone line has been unplugged at the wall socket. Never install telephone wiring during a lightning storm. Never install a telephone wall socket in a wet location.
- This product must be installed near an electrical socket that is easily accessible. In case of an emergency, you must unplug the power cord from the electrical socket to shut off the power completely.
- Always make sure the plug is fully inserted.



WARNING

IMPORTANT SAFETY INSTRUCTIONS

When using your telephone equipment, basic safety precautions should always be followed to reduce the risk of fire, electric shock and injury to people, including the following:

- 1 DO NOT use this product near water, for example, near a bath tub, wash bowl, kitchen sink or washing machine, in a wet basement or near a swimming pool.
- 2 Avoid using this product during an electrical storm. There may be a remote risk of electric shock from lightning.
- 3 DO NOT use this product to report a gas leak in the vicinity of the leak.

IMPORTANT-For Your Safety

To ensure safe operation, the two-pin plug or the three-pin plug supplied must be inserted only into a standard two-pin power point or three-pin power point which is effectively grounded through the normal household wiring.

Extension cords used with the equipment must be two-conductor or three-conductor and be correctly wired to provide connection to ground. Incorrectly wired extension cords are a major cause of fatalities.

The fact that the equipment operates satisfactorily does not imply that the power is grounded and that the installation is completely safe. For your safety, if in any doubt about the effective grounding of the power, consult a qualified electrician.

Disconnect device

This machine must be installed near a power outlet, which is easily accessible. In case of emergencies, you must disconnect the power cord from the power outlet in order to shut off power completely.

LAN connection



CAUTION

Do not connect this product to a LAN connection that is subject to over-voltages.

Important Information for Australia

IMPORTANT NOTICE

Under power failure conditions, this telephone may not operate. Please ensure that a separate telephone, not dependent on local power, is available for emergency use in emergencies.

Important safety instructions

- 1 Read all of these instructions.
- 2 Save them for later reference.
- 3 Follow all warnings and instructions marked on the product.
- 4 Unplug this product from the wall socket before cleaning the outside of the machine and the scanner glass. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- 5 Do not use this product near water.
- 6 Do not place this product on an unstable cart, stand, or table. The product may fall, causing serious damage to the product.
- 7 Slots and openings in the casing at the back or bottom are provided for ventilation; to ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heater. This product should never be placed in a built-in installation unless adequate ventilation is provided.
- 8 This product should be connected to an AC power source within the range indicated on the rating label. Do NOT connect it to a DC power source. If you are not sure, contact a qualified electrician.
- 9 This product is equipped with a 3-wire grounded plug, a plug having a third (grounded) pin. This plug will only fit into a grounded power socket. This is a safety feature. If you are unable to insert the plug into the outlet, call your electrician to replace your obsolete outlet. Do not defeat the purpose of the grounded plug.
- 10 Do not place anything on top of the power cord including this machine. Do not allow the power cord to be stepped on.
- 11 Do not place anything in front of the machine that will block received faxes. Do not place anything in the path of received faxes.

- 12 Do not touch a document during printing.
- 13 Never push objects of any kind into this product through cabinet slots, since they may touch dangerous voltage points or short out parts resulting in a risk of fire or electric shock. Never spill liquid of any kind on the product.
- 14 Do not attempt to service this product yourself, because opening or removing covers may expose you to dangerous voltage points and/or other risks. Refer all servicing to service personnel.
- 15 Wait until pages have exited the machine before picking them up.
- 16 Unplug this product from the wall outlet and refer servicing to Authorized Service Personnel under the following conditions:
 - When the power cord is damaged or frayed.
 - If liquid has been spilled into the product.
 - If the product has been exposed to rain or water.
 - If the product does not operate normally when the operating instructions are followed. Adjust only those controls that are covered by the operating instructions. Incorrect adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
 - If the product has been dropped or the casing has been damaged.
 - If the product exhibits a distinct change in performance, indicating a need for service.

Important Information for New Zealand

Important Safety Instructions

- 1 Read all of these instructions.
- 2 Save them for later reference.
- 3 Follow all warnings and instructions marked on the product.
- 4 Unplug this product from the wall outlet before cleaning the outside of the machine and the scanner glass. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- 5 The grant of a Telepermit for any item of terminal equipment indicates only that Telecom has accepted that the item complies with minimum conditions for connection to its network. It indicates no endorsement of the product by Telecom, nor does it provide any sort of warranty. Above all, it provides no assurance that any item will work correctly in all respects with another item of Telepermitted equipment of a different make or model, nor does it imply that any product is compatible with all of Telecom's network services.
- This equipment does not fully meet Telecom's impedance requirements. Performance limitations may occur when used in conjunction with some parts of the network. Telecom will accept no responsibility should difficulties arise in such circumstances.
- 7 If a charge for local calls is acceptable, the "Dial Button" should not be used for local calls. Only the 7-digits of the local number should be dialled from your telephone. Do not dial the area code digit or the "0" prefix.
- 8 This equipment shall not be set to make automatic calls to the Telecom '111' Emergency Service.
- 9 This equipment should not be used under any circumstances which may constitute a nuisance to other Telecom customers.
- 10 Not all telephones will respond to incoming ringing when connected to the extension socket.
- 11 The answer delay setting of this equipment shall not be set to less than the default setting as this will destroy Caller ID information.
- 12 All persons using this device for recording telephone conversations shall comply with New Zealand law. This requires that at least one party to the conversation is to be aware that it is being recorded. In addition, the Principles enumerated in the Privacy Act 1993 shall be complied with in respect to the nature of the personal information collected, the purpose for its collection, how it is to be used and what it disclosed to any other party.
- 13 Do not place this product on an unstable surface, stand, or table. The product may fall, causing serious damage to the product.
- 14 Slots and openings in the casing and the back or bottom are provided for ventilation; to ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or over a radiator or heater. This product should not be placed in a built-in installation unless proper ventilation is provided.

- 15 This product should be connected to an AC power source within the range indicated on the rating label. Do NOT connect it to a DC power source. If you are not sure, contact a qualified electrician.
- 16 This product is equipped with a 3-wire earthed plug. This plug will fit into only an earthed socket. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete socket. Do not defeat the purpose of an earthed plug.
- 17 Do not place anything on top of the power cord including this machine. Do not allow the power cord to be stepped on.
- 18 Do not place anything in front of the machine that will block received faxes. Do not place anything in the path of received faxes.
- 19 Do not touch a document during printing.
- 20 Never push objects of any kind into this product through cabinet slots, since they may touch dangerous voltage points or short out parts resulting in a risk of fire or electric shock. Never spill liquid of any kind on the product.
- 21 Do not attempt to service this product yourself, because opening or removing covers may expose you to dangerous voltage points and/or other risks. Refer all servicing to service personnel.
- 22 Unplug this product from the mains power and telephone line sockets, and refer servicing to qualified Service Personnel under the following conditions:
 - If the power cord is damaged or frayed.
 - If liquid has been spilled into the product.
 - If the product has been exposed to rain or water.
 - If the product does not operate normally when the operating instructions are followed. Adjust only those controls that are covered by the operating instructions. Incorrect adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
 - If the product has been dropped or the casing has been damaged.
 - If the product exhibits a distinct change in performance, indicating a need for service.
- 23 This unit will only work in conjunction with a tone signalling (DTMF) telephone, but some telephones are not compatible. Since noise or speech from the telephone can upset dialling from this unit, errors may result if the devices are used together in other than quiet conditions.
- 24 Where it is necessary to dial prefix digits, such as a Caller Display override code ("0196" or "0197"), this unit will have to be used in conjunction with an associated tone signalling (DTMF) telephone.
- 25 Note that some telephones are not compatible with this unit and dialling errors may result if the two devices are used together in other than quiet conditions. The Telecom Faults Service is not to be called should such problems arise. In such cases, it is recommended that the prefix and wanted number are dialled manually.
- 26 This equipment may not provide for the effective hand-over of a call to another device connected to the same line.

IMPORTANT NOTICE

Under power failure conditions, this telephone may not operate. Please ensure that a separate telephone, not dependent on local power, is available for emergency use in emergencies.

Important Information for Some Countries

Important Safety Instructions

- 1 Read all of these instructions.
- 2 Save them for later reference.
- 3 Follow all warnings and instructions marked on the product.
- 4 Unplug this product from the wall outlet before cleaning the outside of the machine and the scanner glass. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
- 5 Do not place this product near water.
- 6 Do not place this product on an unstable cart, stand, or table. The product may drop, causing serious damage to the product.
- 7 Slots and openings in the casing at the back or bottom are provided for ventilation; to ensure reliable operation of the product and to protect it from overheating, these openings must not be blocked or covered. The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should never be placed near or on a radiator or heater. This product should never be placed in a built-in installation unless adequate ventilation is provided.
- 8 This product should be connected to an AC power source within the range indicated on the rating label. DO NOT connect it to a DC power source. If you are not sure, contact a qualified electrician.
- 9 This product is equipped with a 2-wire grounding type plug or a 3-wire grounding type plug (Only for Singapore, Malaysia, Hong Kong and India), a plug having two or three pins. This plug will only fit into only a grounding-type power socket. This is a safety feature. If you are unable to insert the plug into the outlet, contact your electrician to replace your obsolete outlet. Do not defeat the purpose of the grounding-type plug.
- 10 Do not place anything on top of the power cord including this machine. Do not allow the power cord to be stepped on.
- 11 If an extension cord is used with this product, make sure that the total ampere ratings on the products plugged into the extension cord do not exceed the extension cord ampere rating.
- 12 Do not place anything in front of the machine that will block received faxes. Do not place nything in the path of received faxes.
- 13 Do not touch a document during printing.
- 14 Never push objects of any kind into this product through cabinet slots, since they may touch dangerous voltage points or short out parts resulting in the risk of fire or electric shock. Never spill liquid of any kind on the product.
- 15 Do not attempt to service this product yourself, as opening or removing covers may expose you to dangerous voltage points and/or other risks, and may void your warranty. Please refer all servicing to our Authorized Service Personnel. A list of Authorized Service Centres has been included for your convenience, or you may contact the Brother Dealer for Service.

- 16 Unplug this product from the wall outlet and refer servicing to Authorized Service Personnel under the following conditions:
 - If the power cord is damaged or frayed.
 - If the product has been spilled by liquid.
 - If the product has been exposed to rain or water.
 - If the product does not operate normally when the operating instructions are followed.

 Adjust only those controls that are covered by the operating instructions. Incorrect adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to normal operation.
 - If the product has been dropped or the casing has been damaged.
 - If the product exhibits a distinct change in performance, indicating a need for service.
- 17 To protect your product against power surges, we recommend the use of a power protection device (Surge Protector).



WARNING

For protection against the risk of electrical shock, always disconnect all cables from the wall outlet before servicing, modifying or installing the equipment.

This equipment may not be used on coin service lines provided by the telephone company or connected to party lines.

Brother cannot accept any financial or other responsibilities that may be the result of your use of this information, including direct, special or consequential damages. There are no warranties extended or granted by this document.

Legal limitations for copying

It is an offence to make reproductions of certain items or documents with the intent to commit fraud. This memorandum is intended to be a guide rather than a complete list.

We suggest you check with relevant legal authorities if in doubt about a particular item or document.

The following are examples of documents which may not be copied:

- Money
- Bonds or other certificates of indebtedness
- Certificates of Deposit
- Armed Forces Service or Draft papers.
- Passports
- Postage Stamps (cancelled or uncancelled)
- Immigration Papers
- Welfare documents
- Cheques or Drafts drawn by Governmental Agencies
- Identification Documents, badges or insignias
- Licences and Certificates of Title to motor vehicles

Copyrighted works cannot be copied. Sections of a copyrighted work can be copied for 'fair dealing'. Multiple copies would indicate improper use.

Works of art should be considered the equivalent of copyrighted works.

Licenses and Certificates of Title to motor vehicles may not be copied under certain state/provincial laws.

Trademarks

The Brother logo is a registered trademark of Brother Industries, Ltd.

Brother is a registered trademark of Brother Industries, Ltd.

Multi-Function Link is a registered trademark of Brother International Corporation.

© 2006 Brother Industries, Ltd. All rights reserved.

Windows and Microsoft are registered trademarks of Microsoft in the U.S. and other countries.

Macintosh and TrueType are registered trademarks of Apple Computer, Inc.

PaperPort is a registered trademark of ScanSoft, Inc.

Presto! PageManager is a registered trademark of NewSoft Technology Corporation.

Microdrive is a trademark of International Business Machine Corporation.

CompactFlash is a registered trademark of SanDisk Corporation.

Memory Stick is a registered trademark of Sony Corporation.

SecureDigital is a trademark of Matsushita Electric Industrial Co. Ltd., SanDisk Corporation and Toshiba Corporation.

SanDisk is a licensee of the SD and miniSD trademarks.

MultiMediaCard is a trademark of Infineon Technologies and licensed to the MultiMediaCard Association.

xD-Picture Card is a trademark of Fujifilm Co. Ltd., Toshiba Corporation and Olympus Optical Co. Ltd.

PictBridge is a trademark.

Memory Stick Pro, Memory Stick Pro Duo, Memory Stick Duo and MagicGate are trademarks of Sony Corporation.

BROADCOM, SecureEasySetup and the SecureEasySetup logo are trademarks or registerd trademarks of Broadcom Corporation in the United States and/or other countries.

Each company whose software title is mentioned in this manual has a Software License Agreement specific to its proprietary programs.

All other brand and product names mentioned in this User's Guide, the Software User's Guide and the Network User's Guide are registered trademarks of their respective companies.

B

Troubleshooting and Routine Maintenance

Troubleshooting

If you think there is a problem with your machine, check the chart below and follow the troubleshooting tips.

Most problems can be easily resolved by yourself. If you need additional help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips. Visit us at http://solutions.brother.com.

If you are having difficulty with your machine

Printing

Difficulty	Suggestions
No printout	Check the interface cable or wireless connection (MFC-665CW only) on both the machine and your computer. (See the <i>Quick Setup Guide</i> .)
	Make sure the machine is plugged in and not in Power Save mode.
	One or more ink cartridges are empty. (See <i>Replacing the ink cartridges</i> on page 147.)
	Check to see if the LCD is showing an error message. (See <i>Error messages</i> on page 140.)
	Check that the correct printer driver has been installed and chosen.
	Make sure that the machine is online. Click Start and then Printers and Faxes . Right-click and choose Brother MFC-XXXX (where XXXX is your model name), and make sure that Use Printer Offline is unchecked.
Poor print quality	Check the print quality. (See Checking the print quality on page 152.)
	Make sure that the Media Type setting in the printer driver or the Paper Type setting in the machine's menu matches the type of paper you are using. (See
	Printing for Windows [®] or Printing and Faxing for Macintosh [®] in the Software User's Guide on the CD-ROM and Paper Type on page 24.)
	Make sure that your ink cartridges are fresh. The following may cause ink to clog:
	■ The expiration date written on the cartridge package has passed. (Cartridges stay usable for up to two years if kept in their original packaging.)
	■ The ink cartridge was in your machine over six months.
	■ The ink cartridge may not have been stored properly before use.
	Try using the recommended types of paper. (See Acceptable paper and other media on page 12.)
	The recommended environment for your machine is between 20° C to 33° C (68° F to 91° F).
White horizontal lines appear in text	Clean the print head. (See Cleaning the print head on page 152.)
or graphics.	Try using the recommended types of paper. (See Acceptable paper and other media on page 12.)
	If you want to print on Photo 10×15 cm or photo L 9×13 cm paper, make sure you use the photo paper tray. (See <i>Loading photo paper</i> on page 19.)

Printing (Continued)

Difficulty	Suggestions
The machine prints blank pages.	Clean the print head. (See Cleaning the print head on page 152.)
Characters and lines are stacked.	Check the printing alignment. (See Checking the printing alignment on page 153.)
Printed text or images are skewed.	Make sure the paper is loaded properly in the paper tray and the paper side guide is adjusted correctly. (See <i>Loading paper and other media</i> on page 16.)
	Make sure the Jam Clear Cover is set properly.
Smudged stain at the top center of the printed page.	Make sure the paper is not too thick or curled. (See Acceptable paper and other media on page 12.)
Printing appears dirty or ink seems to run.	Make sure you are using the proper types of paper. (See <i>Acceptable paper and other media</i> on page 12.) Don't handle the paper until the ink is dry.
Stains appear on the reverse side or at the bottom of the page.	Make sure the printer platen is not dirty with ink. (See <i>Cleaning the machine printer platen</i> on page 151.)
	Make sure you are using the paper support flap. (See <i>Loading paper and other media</i> on page 16.)
There are some dense lines.	Check Reverse Order in the Basic tab of the printer driver.
The printouts are wrinkled.	In the printer driver Basic tab, click Settings , and uncheck Bi-Directional Printing .
Cannot perform '2 in 1 or 4 in 1' printing.	Check that the paper size setting in the application and in the printer driver are the same.
Print speed is too slow.	Try changing the printer driver setting. The highest resolution needs longer data processing, sending and printing time. Try the other quality settings in the printer driver Basic tab. Also, click the Settings tab, and make sure you uncheck Colour Enhancement .
	Turn the borderless feature off. Borderless printing is slower than normal printing. (See <i>Printing</i> for Windows [®] or <i>Printing</i> and <i>Faxing</i> for Macintosh [®] in the Software User's Guide on the CD-ROM.)
Colour Enhancement is not working properly.	If the image data is not full colour in your application (such as 256 colour), Colour Enhancement will not work. Use at least 24 bit colour data with the Colour Enhancement feature.
Machine feeds multiple pages.	Make sure the paper is loaded properly in the paper tray. (See <i>Loading paper and other media</i> on page 16.)
	Check that more than two types of paper are not loaded in the paper tray at any one time.
Printed pages are not stacked neatly.	Make sure you are using the paper support flap. (See Loading paper and other media on page 16.)
Printed pages double-feed and cause a paper jam.	Make sure you pull out the paper support until it clicks and unfold the paper support flap.
Machine does not print from Paint Brush.	Try setting the Display setting to '256 coloures'.
Machine does not print from Adobe Illustrator.	Try to reduce the print resolution. (See <i>Printing</i> for Windows [®] or <i>Printing</i> and <i>Faxing</i> for Macintosh [®] in the Software User's Guide on the CD-ROM.)
Machine cannot print full pages of a document.	Reduce the print resolution. (See <i>Printing</i> for Windows [®] or <i>Printing</i> and <i>Faxing</i> for Macintosh [®] in the Software User's Guide on the CD-ROM.)
Out of memory message occurs.	Reduce the complexity of your document and try again. Reduce the graphic quality or the number of font sizes within your application software.

Printing Received Faxes

Difficulty	Suggestions
Condensed print and white streaks across the page or the top and bottom of sentences are cut off.	You probably had a bad connection, with static or interference on the telephone line. Ask the other party to send the fax again.
Vertical black lines when receiving.	The sender's scanner may be dirty. Ask the sender to make a copy to see if the problem is with the sending machine. Try receiving from another fax machine.
Received colour fax prints only in black and white.	Replace the colour ink cartridges that are empty or nearly empty, and then ask the other person to send the colour fax again. (See <i>Replacing the ink cartridges</i> on page 147.) Check that Advanced Fax Operation is set to off. (See <i>Turning off Advanced Fax Operations</i> on page 81.)
Left and Right margins are cut off or a single page is printed on two pages.	Turn on Auto Reduction. (See <i>Printing a reduced incoming fax</i> on page 47.)

Phone Line or Connections

Difficulty	Suggestions
Dialling does not work. (No dial tone)	Make sure the machine is plugged in and not in Power Save mode.
	Check all line cord connections.
	(Not available in New Zealand) Change Tone/Pulse setting. (See <i>Quick Setup Guide</i> .)
	Lift the external phone's handset, (or the machine's handset or cordless handset if available), and then dial the number to send a manual fax.
The machine does not answer when called.	Make sure the machine is in the correct receiving mode for your setup. (See Choosing the Receive Mode on page 42.) Check for a dial tone. If possible, call your machine to hear it answer. If there is still no answer, check the telephone line cord connection. If there is no ringing when you call your machine, ask your telephone company to check the line.

Receiving Faxes

Difficulty	Suggestions
Cannot receive a fax.	Check all line cord connections.
	Make sure the machine is in the correct receiving mode for your setup. (See Receive mode settings on page 45.)
	If you often have interference on the phone line, try changing the menu setting of Compatibility to Basic. (See Compatibility on page 147.)

Sending Faxes

Difficulty	Suggestions
Cannot send a fax.	Check all line cord connections.
	Make sure that the Fax key is illuminated. (See Entering Fax mode on page 34.)
	Ask the other party to check that the receiving machine has paper.
	Print the Transmission Verification Report and check for an error. (See <i>Reports</i> on page 88.)
Transmission Verification Report says 'Result:ERROR'.	There is probably temporary noise or static on the line. Try sending the fax again. If you send a PC FAX message and get 'Result:NG' on the Transmission Verification Report, your machine may be out of memory. To gain extra memory, you can turn off Advanced Fax Operation (see <i>Turning off Advanced Fax Operations</i> on page 81), print fax messages in memory (see <i>Printing a fax from the memory</i> on page 48) or cancel a Delayed Fax or Polling Job (see <i>Cancelling a fax in progress</i> on page 35). If the problem continues, ask the telephone company to check your phone line.
	If you often get transmission errors due to possible interference on the phone line, try changing the menu setting of Compatibility to Basic. (See <i>Compatibility</i> on page 147.)
Poor fax send quality.	Try changing your resolution to Fine or S.Fine. Make a copy to check your machine's scanner operation. If the copy quality is not good, clean the scanner. (See <i>Cleaning the scanner</i> on page 150.)
Vertical black lines when sending.	If the copy you made shows the same problem, clean the scanner. (See Cleaning the scanner on page 150.)

Handling Incoming Calls

Difficulty	Suggestions
The machine 'Hears' a voice as a CNG Tone.	If Fax Detect is set to on, your machine is more sensitive to sounds. It may mistakenly interpret certain voices or music on the line as a fax machine calling and respond with fax receiving tones. Deactivate the machine by pressing Stop/Exit . Try avoiding this problem by turning Fax Detect to off. (See <i>Fax Detect</i> on page 46.)
Sending a fax call to the machine.	If you answered on an external or extension phone, press your Fax Receive Code (the factory setting is \times 5 1 (\times 9 1 for New Zealand)). When your machine answers, hang up.
Custom features on a single line.	If you have Call Waiting, Call Waiting/Caller ID, an alarm system EFTPOS, PC/FAX modem or other custom feature on a single phone line with your machine, it may create a problem sending or receiving faxes.
	For example: If you subscribe to Call Waiting or some other custom service and its signal comes through the line while your machine is sending or receiving a fax, the signal can temporarily interrupt or disrupt the faxes. Brother's ECM feature should help overcome this problem. This condition is related to the telephone system industry and is common to all devices that send and receive information on a single, shared line with custom features. If avoiding a slight interruption is crucial to your business, a separate phone line with no custom features is recommended.

Copying Difficulties

Difficulty	Suggestions
Cannot make a copy.	Make sure that the Copy key is illuminated. (See Entering Copy mode on page 94.)
Vertical streaks appear in copies.	If you see vertical streaks on copies, clean the scanner. (See Cleaning the scanner on page 150.)
Poor copy results when using the ADF.	Try using the scanner glass. (See <i>Using the scanner glass</i> on page 11.)

Scanning Difficulties

Difficulty	Suggestions
TWAIN/WIA errors appear while scanning.	Make sure the Brother TWAIN/WIA driver is chosen as the primary source. In PaperPort® SE with OCR, click File , Scan and choose the Brother TWAIN/WIA driver.
Poor scanning results when using the ADF.	Try using the scanner glass. (See <i>Using the scanner glass</i> on page 11.)

Software Difficulties

Difficulty	Suggestions
Cannot install software or print.	Run the Repair MFL-Pro Suite program on the CD-ROM. This program will repair and reinstall the software.
'Device Busy'	Make sure the machine is not showing an error message on the LCD.

PhotoCapture Center™ Difficulties

Difficulty	Suggestions
Removable Disk does not work	1 Have you installed the Windows® 2000 update? If not, do the following:
properly.	1) Unplug the USB cable.
	 Install the Windows[®] 2000 update, and see the Quick Setup Guide. After the installation the PC will be automatically restarted.
	Wait about 1 minute after you restart the PC, and then connect the USB cable.
	2 Take out the memory card and put it back in again.
	If you have tried 'Eject' from within Windows [®] , take out the memory card before you continue.
	4 If an error message appears when you try to eject the memory card, it means the card is being accessed. Wait a while and then try again.
	5 If all of the above do not work, turn off your PC and machine, and then turn them on again. (You will have to unplug the power cord of the machine to turn it off.)
Cannot access Removable Disk from Desktop icon.	Make sure you have put the memory card into the media slot.

Network Difficulties

Difficulty	Suggestions
Cannot print over the Network.	Make sure that your machine is powered on and is online and in Ready mode. Print a Network Configuration list (see <i>Reports</i> on page 88.) and check the current Network settings printed in this list. Reconnect the LAN cable to the hub to verify that the cabling and network connections are good. If possible, try connecting the machine to a different port on your hub using a different cable. If the connections are good, the machine shows LAN Active for 2 seconds.
	(If you are using a wireless connection (MFC-665CW only) or are having Network problems, see the Network User's Guide on the CD-ROM for more information.)
The network scanning feature does not work. The network PC-Fax Receive feature does not work.	(For Windows® users only) A Firewall setting on your PC may be rejecting the necessary network connection. Follow the instructions below to configure the Firewall. If you are using a personal Firewall software, see the User's Guide for your software or contact the software manufacturer.
leature does not work.	Windows® XP SP2 users>
	Click the Start button, Control Panel and then Windows Firewall . Make sure that Windows Firewall on the General tab is set to On.
	2 Click Advanced tab and Settings button in Network Connection Settings.
	3 Click Add button, and in the "Description of service" field, enter any name. In the "Name or IP Address" field enter "localhost". In the internal and external port numbers fields enter "54925" for network scanning. Choose UDP and click OK. Repeat this step adding Port 54926 for network PC-FAX receiving and Port 137 for Windows [®] .
	4 Make sure the new settings are added and the box is checked, and then click OK .
Your computer cannot find your	<windows<sup>® users></windows<sup>
machine.	Firewall setting on you PC may be rejecting the necessary network connection. For detail, see the instruction above.
	<macintosh<sup>® users></macintosh<sup>
	Re-select your machine in the DeviceSelector application located in Macintosh HD/Library/Printers/Brother/Utilities or from the model of ControlCenter2.

Error messages

As with any sophisticated office product, errors may occur. If this happens, your machine identifies the error and shows an error message. The most common error messages are shown below.

You can correct most errors by yourself. If you need more help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips.

Visit us at http://solutions.brother.com.

Error Message	Cause	Action
Comm.Error	Poor phone line quality caused a communication error.	Try to send the fax again or try to connect the machine to another telephone line. If the problem continues, call the telephone company and ask them to check your phone line.
Connection Fail	You tried to poll a fax machine that is not in Polled Waiting mode.	Check the other fax machine's polling setup.
Cover is Open	The scanner cover is not closed completely.	Lift the scanner cover and then close it again.
	The ink cartridge cover is not completely closed.	Firmly close the ink cartridge cover until it clicks.
Data Remaining	Print data is left in the machine's memory.	Re-start printing from your computer.
	Print data is left in the machine's memory. The USB cable was unplugged while the computer was sending the data to the machine.	Press Stop/Exit . The machine will cancel the job and clear it from the memory. Try to print again.
Disconnected	The other person or other person's fax machine stopped the call.	Try to send or receive again.
Document Jam	The document was not inserted or fed properly, or the document scanned from the ADF was too long.	See Using the ADF on page 10. See Document jam on page 144.
DR Mode in Use	The machine is set to Distinctive Ring mode. You cannot change the Receive Mode from Manual to another mode.	Set Distinctive Ring to off. (See Turning off Distinctive Ring on page 52.)
High Temperature	The print head is too warm.	Allow the machine to cool down.

Error Message	Cause	Action
Ink Empty	One or more of the ink cartridges is empty. The machine will stop all print operations. While memory is available, black and white faxes will be stored in the memory. If a sending machine has a colour fax, the machine's 'handshake' will ask that the fax be sent as black and white. If the sending machine has the ability to convert it, the colour fax will be stored in the memory as a black and white fax.	Replace the ink cartridges. (See Replacing the ink cartridges on page 147.)
Low Temperature	The print head is too cold.	Allow the machine to warm up.
Media Error	The memory card is either corrupted, improperly formatted, or there is a problem with the memory card.	Put the card firmly into the slot again to make sure it is in the correct position. If the error remains, check the media drive by putting in another memory card that you know is working.
Near Empty	One or more of the ink cartridges are running out of ink. If a sending machine has a colour fax, the machine's 'handshake' will ask that the fax be sent as black and white. If the sending machine has the ability to convert it, the colour fax will be received into memory as a monochrome fax.	Order a new ink cartridge.
No Caller ID	There is no incoming call history. You did not receive calls or you have not subscribed to the Caller ID service from your telephone company.	If you want to use the Caller ID feature call your telephone company. (See Caller ID on page 53.)
No Cartridge	An ink cartridge is not installed properly.	Reinstall the ink cartridge. (See Replacing the ink cartridges on page 147.)
No File	The memory card in the media drive does not contain a .JPG file.	Put the correct memory card into the slot again.
No Paper Fed	The machine is out of paper or	Do one of the following:
	paper is not properly loaded in the paper tray.	■ Refill the paper in the paper tray, and then press Mono Start or Colour Start.
		Remove the paper and load it again and then press Mono Start or Colour Start.
	The paper is jammed in the machine.	See Printer jam or paper jam on page 145.
No Response/Busy	The number you dialled does not answer or is busy.	Verify the number and try again.
Not Registered	You tried to access a Speed Dial number that is not programmed.	Set up the Speed Dial number. (See Storing Speed-Dial numbers on page 66.)

Error Message	Cause	Action
Out of Memory	The machine's memory is full.	Fax sending or copy operation in progress
		Do one of the following:
		Press Stop/Exit and wait until the other operations in progress finish and then try again.
		Clear the data in the memory. To gain extra memory, you can turn off Advanced Fax Operation. (See Turning off Advanced Fax Operations on page 81.)
		Print the faxes that are in the memory. (See Printing a fax from the memory on page 48.)
		Printing operation in progress
		Reduce print resolution. (For details, see
		Printing for Windows® or Printing and
		Faxing for Macintosh [®] in the Software User's Guide on the CD-ROM.)
Paper Jam	Paper is jammed in the machine.	Open the Jam Clear Cover (at the back of the machine) and remove the jammed paper. (See <i>Printer jam or paper jam</i> on page 145.)
Unable to Change	The machine has a mechanical problem.	Open the scanner cover and remove any foreign objects inside the machine. If the error message continues, do one of the
Unable to Clean XX	—OR—	following:
Unable to Init. XX	A foreign objects such as a clip or ripped paper is in the machine.	■ (MFC-440CN only)
Unable to Print XX Unable to Scan XX	impred paper to in the machine.	See Transferring your faxes or Fax Journal report on page 143 before disconnecting the machine so you will not lose any important messages. Then, disconnect the machine from the power for several minutes and then reconnect it.
		■ (MFC-665CW only) Disconnect the machine from the power for several minutes, then reconnect it. (The machine can be turned off for up to 24 hours without losing faxes stored in the memory. See Transferring your faxes or Fax Journal report on page 143.)
Wrong Paper Size	Paper is not the correct size.	Load the correct size of paper (Letter, Legal or A4), and then press Mono Start or Colour Start .
Wrong USB device	A non-PictBridge compatible or broken device has been connected to the PictBridge port.	Unplug the device from the PictBridge port, then press Power Save to turn the machine off and then on again.

Transferring your faxes or Fax Journal report

If the LCD shows:

- Unable to Change XX
- Unable to Clean XX
- Unable to Init. XX
- Unable to Print XX
- Unable to Scan XX

We recommend transferring your faxes to another fax machine or to your PC. (See *Transferring faxes to another fax machine* or *Transferring faxes to your PC* as detailed below.)

You can also transfer the Fax Journal report to see if there are any faxes you need to transfer. (See *Transferring Fax Journal report to another fax machine* on page 144.)



If there is an error message on the machine's LCD, after the faxes have been transferred, disconnect the machine from the power source for several minutes, and then reconnect it.

Transferring faxes to another fax machine

If you have not set up your Station ID (See *Quick Setup Guide*.), you cannot enter fax transfer mode.

- 1 Press **Stop/Exit** to interrupt the error temporarily.
- Press Menu.
- Press ▲ or ▼ to choose Service.
 Press OK.
- Press ▲ or ▼ to choose

 Data Transfer.

 Press OK.

- 5 Press ▲ or ▼ to choose Fax Transfer.
 - Press **OK**.
- 6 Do one of the following:
 - If the LCD shows No Data, there are no faxes left in the machine's memory.
 - Press Stop/Exit.
 - Enter the fax number to which faxes will be forwarded.
- 7 Press Mono Start.

Transferring faxes to your PC

You can transfer the faxes from your machine's memory to your PC.

- 1 Press **Stop/Exit** to interrupt the error temporarily.
- 2 Make sure you have installed MFL-Pro Suite on your PC, and then turn on PC FAX Receiving on the PC. (For details see PC- FAX receiving for Windows® in the Software User's Guide on the CD-ROM.)
- Make sure you have set PC Fax
 Receive on the machine. (See PC Fax
 Receive on page 80.)
 If faxes are in the machine's memory
 when you set up PC Fax Receive the
 LCD will ask if you want to transfer the
 faxes to your PC.
- 4 Do one of the following:
 - To transfer all faxes to your PC, press 1. You will be asked if you want a backup print.
 - To exit and leave the faxes in the memory, press 2.
- 5 Press Stop/Exit.

Transferring Fax Journal report to another fax machine

If you have not set up your Station ID, you cannot enter fax transfer mode.

- 1 Press **Stop/Exit** to interrupt the error temporarily.
- Press Menu.
- 3 Press ▲ or ▼ to choose Service. Press OK.
- Press ▲ or ▼ to choose
 Data Transfer.
 Press OK.
- 5 Press ▲ or ▼ to choose
 Report Trans..
 Press OK.
- 6 Enter the fax number to which Fax Journal report will be forwarded.
- Press Mono Start.


Document jam

Documents can jam if they are not inserted or fed properly, or if they are too long. Follow the steps below to clear a document jam.

Document is jammed in the top of the ADF unit

- 1 Take out any paper from the ADF that is not jammed.
- Open the ADF cover.

Pull the jammed document up and to the left.




- 4 Close the ADF cover.
- 5 Press Stop/Exit.



To avoid document jams close the ADF cover properly by pressing it down in the center.

Document is jammed inside the ADF unit

- 1 Take out any paper from the ADF that is not jammed.
- 2 Lift the document cover.
- 3 Pull the jammed document out to the left.




- 4 Close the document cover.
- 5 Press Stop/Exit.


Printer jam or paper jam

Take out the jammed paper depending on where it is jammed in the machine. Open and close the scanner cover to clear the error.


1 Pull the paper tray (1) out of the machine.




Pull out the jammed paper (1).




If you cannot remove the jammed paper from the front of the machine, or the error message still appears on the LCD after you have removed the jammed paper, please go to the next step. 3 Remove the Jam Clear Cover (1) from the back of the machine. Pull the jammed paper out of the machine.






Put the Jam Clear Cover back on. Make sure the cover is set properly.



5 Lift the scanner cover (1) from the front of the machine until it locks securely into the open position.

Make sure that there is no jammed paper left inside the machine. Check both ends of the print carriage.





If the paper is jammed under the print head, unplug the machine from the power source, and then move the print head to take out the paper.


6 Lift the scanner cover to release the lock (1). Gently push the scanner cover support down (2) and close the scanner cover (3).



Push the paper tray firmly back into the machine.



Make sure you pull out the paper support until it clicks.



Dial Tone detection

When you send a fax automatically, by default your machine will wait for a fixed amount of time before it starts to dial the number. By changing the Dial Tone setting to Detection you can make your machine dial as soon as it detects a dial tone. This setting can save a small amount of time when sending a fax to many different numbers. If you change the setting and start having problems with dialling you should change back to the factory No Detection setting.

- Press Menu.
- Press ▲ or ▼ to choose Initial Setup. Press OK.
- Press ▲ or ▼ to choose Dial Tone.
 Press OK.
- Press ▲ or ▼ to choose Detection or No Detection.
 Press OK.
- 5 Press Stop/Exit.

Compatibility

If you are having problems sending or receiving a fax due to possible interference on the phone line, we recommend that you adjust the Equalization for compatibility to reduce the modem speed for fax operations.

- 1 Press Menu.
- Press ▲ or ▼ to choose Fax. Press OK.
- 3 Press ▲ or ▼ to choose
 Miscellaneous.
 Press OK.
- 4 Press ▲ or ▼ to choose Compatibility.
 Press OK.
- 5 Press ▲ or ▼ to choose Normal.
 - Basic reduces the modem speed to 9600 bps. Unless interference is a recurring problem on your phone line, you may prefer to use it only when needed.
 - Normal sets the modem speed at 14400 bps. (factory setting)
 Press **OK**.
- 6 Press Stop/Exit.



When you change the compatibility to Basic, the ECM feature is only available for colour fax sending.

Routine maintenance


Replacing the ink cartridges


Your machine is equipped with an ink sensor. The ink sensor automatically monitors the level of ink in each of the 4 cartridges. When the machine detects an ink cartridge is running out of ink, the machine will tell you with a Near Empty message on the LCD.

The LCD will tell you which ink cartridge is low or needs replacing. Be sure to follow the LCD prompts to replace the ink cartridges in the correct order.


Even though the machine tells you that an ink cartridge is empty, there will be a small amount of ink left in the ink cartridge. It is necessary to keep some ink in the ink cartridge to prevent air from entering the print head assembly.

- 1 Open the ink cartridge cover.
 If one or more ink cartridges are empty,
 for example Black, the LCD shows
 Ink Empty and Black.
- Pull the lock release lever down and take out the ink cartridge for the colour shown on the LCD.






- Open the new ink cartridge bag for the colour shown on the LCD, and then take out the ink cartridge.
- 4 Remove the protective yellow cap (1).



Improper Setup


DO NOT touch the area shown in the illustration below.






If the protective yellow caps come off when you open the bag, the cartridge will not be damaged.

Each colour has its own correct position. Insert the ink cartridge in the direction of the arrow on the label.



6 Lift the lock release lever and push it until it clicks, and then close the ink cartridge cover.



7 The machine will automatically reset the ink dot counter.



• If you replaced an ink cartridge before the LCD shows Near Empty or Ink Empty, the LCD will ask you to verify that it was a brand new one. (For example, Did You Change Black) For each new cartridge you installed, press 1 (Yes) to automatically reset the ink dot counter for that colour. If the ink cartridge you installed is not a brand new one, be sure to press 2 (No).

 If the LCD shows No Cartridge after you install the ink cartridges, check that the ink cartridges are installed properly.



WARNING

If ink gets in your eyes, wash them out with water at once and call a doctor if you are concerned.



CAUTION

DO NOT take out ink cartridges if you do not need to replace them. If you do so, it may reduce the ink quantity and the machine will not know the quantity of ink left in the cartridge.

DO NOT touch the cartridge insertion slots. If you do so, the ink may stain your skin.

If ink stains your skin or clothing, wash with soap or detergent at once.

If you mix the coloures by installing an ink cartridge in the wrong position, clean the print head several times after correcting the cartridge installation.

Once you open an ink cartridge, install it in the machine and use it up within six months of installation. Use unopened ink cartridges by the expiration date written on the cartridge package.

DO NOT dismantle or tamper with the ink cartridge, this can cause the ink to leak out of the cartridge.

Brother multifunction machines are designed to work with ink of a particular specification and will work to a level of optimum performance when used with genuine Brother Branded ink cartridges. Brother cannot guarantee this optimum performance if ink or ink cartridges of other specifications are used. Brother does not therefore recommend the use of cartridges other than genuine Brother Branded cartridges or the refilling of empty cartridges with this machine or the refilling of empty cartridges with ink from other sources. If damage is caused to the print head or other parts of this machine as a result of using incompatible products with this machine, any repairs required as a result may not be covered by the warranty.

Cleaning the outside of the machine



CAUTION


Use neutral detergents. Cleaning with volatile liquids such as thinner or benzine will damage the outside surface of the machine.

DO NOT use cleaning materials that contain ammonia.

DO NOT use isopropyl alcohol to remove dirt from the control panel. It may crack the panel.

Clean the outside of the machine as follows:


1 Pull the paper tray (1) completely out of the machine.



Wipe the outside of the machine with a soft cloth to remove dust.




- 3 Remove anything that is stuck inside the paper tray.
- 4 Wipe the paper tray with a soft cloth to remove dust.




5 Put the paper tray firmly back in the machine.

Cleaning the scanner

1 Lift the document cover (1). Clean the scanner glass (2) and the white plastic (3) with isopropyl alcohol on a soft lint-free cloth.



2 In the ADF unit, clean the white bar (1) and the glass strip (2) under it with isopropyl alcohol on a lint-free cloth.




Cleaning the machine printer platen



WARNING


Be sure to unplug the machine from the electrical socket before cleaning the printer platen (1).

1 Clean the machine printer platen (1) and the area around it, wiping off with a soft, dry, lint-free cloth.




Cleaning the paper pick-up roller

- 1 Pull the paper tray completely out of the machine.
- 2 Unplug the machine from the electrical socket and remove the Jam Clear Cover (1).



3 Clean the Paper Pick-up Roller (1) with isopropyl alcohol on a cotton swab.



- 4 Put the Jam Clear Cover back on.
 Make sure the cover is set properly.
- 5 Put the paper tray firmly back in the machine.
- 6 Re-connect the power cord.

Cleaning the print head

To ensure the good print quality, the machine will regularly clean the print head. You can start the cleaning process manually if needed.

Clean the print head and ink cartridges if you get a horizontal line in the text or graphics on your printed pages. You can clean Black only, three colours at a time (Cyan/Yellow/Magenta), or all four colours at once (Cyan, Yellow, Magenta and Black).

Cleaning the print head consumes ink. Cleaning too often uses ink unnecessarily.

CAUTION

DO NOT touch the print head. Touching the print head may cause permanent damage and may void the print head's warranty.

- 1 Press Ink Management.
- Press ▲ or ▼ to choose Cleaning. Press OK.
- 3 Press ▲ or ▼ to choose Black, Color or All.

Press **OK**.

The machine cleans the print head. When cleaning is finished, the machine will go back to standby mode automatically.



If you clean the print head at least five times and the print has not improved, call your Brother dealer.

Checking the print quality

If faded or streaked coloures and text appear on your output, some of the nozzles may be clogged. You can check this by printing the Print Quality Check Sheet and looking at the nozzle check pattern.

- 1 Press Ink Management.
- Press ▲ or ▼ to choose Test Print. Press OK.
- 3 Press ▲ or ▼ to choose
 Print Quality.
 Press OK.
- 4 Press Colour Start.
 The machine begins printing the Print Quality Check Sheet.
- Check the quality of the four colour blocks on the sheet.
- 6 The LCD asks you if the print quality is OK

Do one of the following:

- If all lines are clear and visible, press 1 (Yes) to finish the Print Quality check.
- If you can see missing short lines as shown below, press 2 to choose No.



- The LCD asks you if the print quality is OK for black and three coloures. Press 1 (Yes) or 2 (No).
- 8 The LCD asks you if you want to start cleaning.

Press 1 (Yes).

The machine starts cleaning the print head.

9 After cleaning is finished, press Colour Start.

The machine starts printing the Print Quality Check Sheet again and then return to step **5**.

If you repeat this procedure at least five times and the print quality is still poor, replace the ink cartridge for the clogged colour.

After replacing the ink cartridge, check the print quality. If the problem still exists, repeat the cleaning and test print procedures at least five times for the new ink cartridge. If ink is still missing, call your Brother dealer.

A CAUTION

DO NOT touch the print head. Touching the print head may cause permanent damage and may void the print head's warranty.





When a print head nozzle is clogged the printed sample looks like this.



After the print head nozzle is cleaned, the horizontal lines are gone.

Checking the printing alignment

You may need to adjust the printing alignment after transporting the machine if your printed text becomes blurred or images become faded.

- 1 Press Ink Management.
- Press ▲ or ▼ to choose Test Print. Press OK.
- 3 Press ▲ or ▼ to choose Alignment. Press OK.
- 4 Press Mono Start or Colour Start.
 The machine starts printing the
 Alignment Check Sheet.
- 5 Check the 600 dpi and 1200 dpi test prints to see if number 5 most closely matches number 0.
- 6 Do one of the following:
 - If the number 5 sample of both the 600 dpi and 1200 dpi are the best matches, press 1 (Yes) to finish the Alignment Check.
 - If another test print number is a better match for either 600 dpi or 1200 dpi, press 2 (No) to choose it.
- 7 For 600 dpi, press the number of the test print that most closely matches the number 0 sample (1-8).
- 8 For 1200 dpi, press the number of the test print that most closely matches the number 0 sample (1-8).
- 9 Press Stop/Exit.

Checking the ink volume

Although an ink volume icon appears on the LCD, you can use the **Ink Management** key to see a large graph showing the ink that is left in each cartridge.

- 1 Press Ink Management.
- Press ▲ or ▼ to choose Ink Volume. Press OK. The LCD shows the ink volume.
- 3 Press Stop/Exit.




You can check the ink volume from your computer. (See *Printing* for Windows[®] or *Printing and Faxing* for Macintosh[®] in the Software User's Guide on the CD-ROM.)

Uninstalling the handset and handset cradle (MFC-665CW only)


If you do not use the handset and the handset cradle, you can remove them.

Uninstalling the handset and handset cradle


1 Unplug the curled handset cord from the machine.



Pull the knob (1) to the left and hold it in position as you push the cradle to the back of the machine.




3 Attach the side cover.



Installing the handset and handset cradle


1 Remove the side cover.




Note

If you cannot open the cover with your hand, use a coin to open.

Align the recessed arrows on the cradle with those on the machine, and then slide the cradle toward the front of the machine until it clicks into place.



3 Connect the curled handset cord to the machine.



Machine Information

Checking the serial number

You can see the machine's serial number on the LCD.

- 1 Press Menu.
- Press ▲ or ▼ to choose

 Machine Info..

 Press OK.
- 3 Press ▲ or ▼ to choose Serial No..
 Press OK.
- 4 Press Stop/Exit.

Packing and shipping the machine


When you transport the machine, use the packing materials that came with your machine. If you do not pack the machine properly, you could void your warranty.

A CAUTION

It is important to allow the machine to 'park' the print head after a print job. Listen carefully to the machine before unplugging it to make sure that all mechanical noise has stopped. Not allowing the machine to finish this parking process may lead to print problems and possible damage to the print head.

- 1 Open the ink cartridge cover.
- Pull the lock release levers down and take out all the ink cartridges. (See Replacing the ink cartridges on page 147.)

Install the yellow protective part, lift each lock release lever and push it until it clicks and then close the ink cartridge cover.




A CAUTION


If you are not able to find the yellow protective part, DO NOT remove the ink cartridges before shipping. It is essential that the machine be shipped with either the yellow protective part or the ink cartridges in position. Shipping without them will cause damage to your machine and may void your warranty. Please keep machine upright.

- 4 Unplug the machine from the telephone wall socket and take the telephone line cord out of the machine.
- 5 Unplug the machine from the electrical socket and from the machine.
- 6 Using both hands, use the plastic tabs on both sides of the machine to lift the scanner cover until it locks securely into the open position. Then unplug the interface cable from the machine, if it is connected.


7 Lift the scanner cover (1) to release the lock. Gently push the scanner cover support down (2) and close the scanner cover (3).




- 8 If your machine has a handset, remove it and the handset curled cord.
- Wrap the machine in the bag and put it in the original carton with the original packing material.



Pack the printed materials in the original carton as shown below. Do not pack the used ink cartridges in the carton.





C

Menu and Features

On-screen programming

Your machine is designed to be easy to use with LCD on-screen programming using the menu keys. User-friendly programming helps you take full advantage of all the menu selections your machine has to offer.

Since your programming is done on the LCD, we have created step-by-step on-screen instructions to help you program your machine. All you need to do is follow the instructions as they guide you through the menu selections and programming options.

Memory storage

Even if there is a power failure, you will not lose the settings you have chosen using the Menu key because they are stored permanently. Also, you will not lose your settings in the PhotoCapture, Fax and Copy mode key menus if you have chosen Set New Default. You may have to reset the date and time.



During a power failure the MFC-665CW will retain messages that are in the memory for up to 24 hours.

Menu keys

Menu	Access the main menu.
Scan Copy Photo Capture	Access the mode and its menu of temporary settings.
A	Scroll through the current menu level.
•	Go back to the previous menu level.
•	Go to the next menu level.
OK	■ Go to the next menu level. ■ Accept an option.
Clear / Back	Cancel the current operation.Go back to the previous menu level.
Stop/Exit	■ Stop the current operation.

Menu table

The menu table will help you understand the menu selections and options that are found in the machine's programs. The factory settings are shown in Bold with an asterisk.

Menu (enu)

Level1	Level2	Level3	Options	Descriptions	Page
General Setup	Mode Timer	_	Off	Sets the time to return to	23
			0 Sec	Fax mode.	
			30 Secs	Sets the time to return to Fax mode. Sets the type of paper in the paper tray.	
			1 Min		
			2 Mins*		
			5 Mins		
	Paper Type	_	Plain Paper*		24
			Inkjet Paper	the paper tray.	
			Brother Photo	Sets the size of the paper	
			Other Photo		
			Transparency		
	Paper Size	_	Letter		24
			Legal	in the paper tray.	
			A4*		
			A5		
			10x15cm		
	Volume	Ring	Off	Adjusts the ring volume.	25
			Low		
			Med*	Adjusts the ring volume.	
			High		
		Beeper	Off		25
			Low*	of the beeper.	
			Med		
			High		
		Speaker	Off		26
Low volume.	volume.				
			Med*		
			High		
	Daylight Save	_	On		26
			Off	Savings Time manually.	

Level1	Level2	Level3	Options	Descriptions	Page
General Setup (Continued)	P.Save Setting	_	Fax Receive:On* Fax Receive:Off	Customizes the Power Save key to receive faxes even in off mode.	22
	LCD Settings	LCD Contrast	Light Med* Dark	Adjusts the contrast of the LCD.	27
	Backlight	Light* Med Dark	You can adjust the brightness of the LCD backlight.	27	
		Dim Timer	Off 10 Secs 20 Secs 30 Secs*	You can set how long the LCD backlight stays on after the last key press.	27
		Off Timer	Off* 1 Min 2 Mins 3 Mins 5 Mins 10 Mins 30 Mins	You can set how long the LCD stays on for after the last key press.	28
		Wallpaper	_	You can choose the wallpaper of the LCD.	
Fax	Setup Receive	Ring Delay (MFC-440CN only)	2-10 (2*) (Example for Australia)	Sets the number of rings before the machine answers in Fax Only or Fax/Tel mode.	45
		Ring Delay (MFC-665CW only)	Ring Delay 2-10(2*) (Example for Australia)	Sets the number of rings before the machine answers in Fax Only or Fax/Tel mode.	45
			Toll Saver On Off*	Cost saving feature: the machine rings 2 times if there are messages and 4 times if there are no messages, so you can hang up and not pay for the call.	75
	The factory settings	s are shown in Bold	I with an asterisk.		

Level1	Level2	Level3	Options	Descriptions	Page
Fax (Continued)	Setup Receive (Continued) Set Quick-Dial	F/T Ring Time	20 Sec 30 Sec* 40 Sec 70 Sec (for Australia and some countries) 55 Sec	Sets the pseudo/double- ring time in Fax/Tel mode.	45
		Fax Detect	on* Off Semi (MFC-665CW only)	Receives fax messages without pressing the Mono Start or Colour Start key.	46
		Remote Codes	On* (**51, #51) (**91, #91 for New Zealand) Off	Allows you to answer all calls at an extension or external phone and use codes to turn the machine on or off. You can personalize these codes.	62
		Auto Reduction	On*	Reduces the size of incoming faxes.	47
		Memory Receive	On*	Automatically stores any incoming faxes in its memory if it runs out of paper.	47
	Set Quick-Dial	Speed-Dial	_	Stores Speed-Dial numbers, so you can dial by pressing only a few keys (and Start).	66
		Setup Groups	_	Sets up a Group number for Broadcasting.	69
	Report Setting	Transmission	On On+Image Off* Off+Image	Initial setup for Transmission Verification Report and Fax Journal Report.	87
		Journal Period	Off Every 50 Faxes* Every 6 Hours Every 12 Hours Every 24 Hours		87
	The factory settings	s are shown in Bold	Every 2 Days Every 7 Days with an asterisk.		

Level1	Level2	Level3	Options	Descriptions	Page
Fax (Continued)	Advanced Fax Operation	Forward/Store	Off* Fax Forward Fax Storage Fax Preview (MFC-665CW only) PC Fax Receive	Sets the machine to forward fax messages, to call your pager, to store incoming faxes in the memory (so you can retrieve them while you are away from your machine), to preview faxes or to send faxes to your PC.	77 78 78 80
		Remote Access	Access Code:	Set your own code for Remote Retrieval.	82
		Print Document (Backup Print)	_	Prints incoming faxes stored in the memory.	48
	Remaining Jobs	_	_	Check which jobs are in the memory and lets you cancel chosen jobs.	40
	Setup Msg Ctr (MFC-665CW only)	OGM	Msg Ctr OGM F/T OGM	Play/Record or erase the outgoing message.	72
		ICM Max.Time	30 Sec* 60 Sec 120 Sec 180 Sec	Choose the maximum length of incoming messages.	75
		ICM Rec.Monitr	On Off	Allows you to turn the speaker volume for voice messages as they come in On or Off.	75
	Miscellaneous	TX Lock (MFC-440CN only)	_	Prohibits most operations other than receiving faxes.	29
		Mem Security (MFC-665CW only)	On Off*	Prohibits most functions except receiving faxes into memory.	30
		Compatibility	Normal* Basic	Adjusts the transmissions that are having problems.	147
		Distinctive (Not available in New Zealand)	On Off*	Use with phone company distinctive ringing service allows you to have a voice number and fax number on the one phone line.	51 58
	The factory settings	s are shown in Bold	with an asterisk.		

Level1	Level2	Level3	Options	Descriptions	Page
Fax	Miscellaneous	Faxability	On	If you have FaxAbility from	55
(Continued)	(Continued)	(For New Zealand Only)	Off*	Telecom, you can use this function to store the ringing pattern of your fax number.	
				And if you set in to ON, you should use the registered number only.	
		Caller ID	Display#	View or print a list of the last 30 Caller IDs stored in	53
			Print Report	memory.	56
					59
LAN (MFC-440CN	TCP/IP	BOOT Method	Auto*	Chooses the BOOT method that best suits	See Network
only)			Static	your needs.	User's
			RARP		Guide on
			BOOTP		the CD-ROM
			DHCP		
		IP Address	[000-255].	Enter the IP address.	
			[000-255].		
			[000-255].		
		[000-255]			
	Subnet Mask	[000-255].	Enter the Subnet mask.		
			[000-255].		
			[000-255].		
			[000-255]		
		Gateway	[000-255].	Enter the Gateway	
			[000-255].	address.	
			[000-255].		
			[000-255]		
		Node Name	BRN_XXXXXX	Enter the Node name.	
		WINS Config	Auto*	Chooses the WINS	
			Static	configuration mode.	
		WINS Server	(Primary) 000.000.000.000	Specifies the IP address of the primary or	
			(Secondary) 000.000.000.000	secondary server.	
		DNS Server	(Primary) 000.000.000.000	Specifies the IP address of the primary or secondary server.	
			(Secondary) 000.000.000.000	Secondary Server.	
		APIPA	On*	Automatically allocates the IP address from the	
			Off	link-local address range.	
	The factory setting	s are shown in Bold	d with an asterisk.	1	

Level1	Level2	Level3	Options	Descriptions	Page
LAN (MFC-440CN	Setup Misc.	Ethernet	_	Chooses the Ethernet link mode.	See Network
only) (Continued)	Factory Reset		_	Restores all network settings to the factory default.	User's Guide on the CD-ROM
LAN (MFC-665CW only)	TCP/IP(Wired)	BOOT Method	Auto* Static RARP BOOTP	Chooses the BOOT method that best suits your needs.	
		11	DHCP	Futor the ID address	-
		IP Address	[000-255]. [000-255]. [000-255].	Enter the IP address.	
		Subnet Mask	[000-255]. [000-255]. [000-255].	Enter the Subnet mask.	
		Gateway	[000-255]. [000-255]. [000-255]. [000-255]	Enter the Gateway address.	
		Node Name	BRN_XXXXXX	Enter the Node name.	
		WINS Config	Auto* Static	Chooses the WINS configuration mode.	
		WINS Server	(Primary) 000.000.000.000 (Secondary) 000.000.000.000	Specifies the IP address of the primary or secondary server.	
		DNS Server	(Primary) 000.000.000.000 (Secondary) 000.000.000.000	Specifies the IP address of the primary or secondary server.	
<i>()</i>	The factory settings	APIPA	On* Off	Automatically allocates the IP address from the link-local address range.	

The factory settings are shown in Bold with an asterisk.

Level1	Level2	Level3	Options	Descriptions	Page
LAN	TCP/IP(WLAN)	BOOT Method	Auto*	Chooses the BOOT	See
(MFC-665CW			Static	method that best suits your needs.	Network User's
only)			RARP	,	Guide on
(Continued)			BOOTP		the CD-ROM
			DHCP		02 / 10///
		IP Address	[000-255].	Enter the IP address.	
			[000-255].		
			[000-255].		
			[000-255]		
		Subnet Mask	[000-255].	Enter the Subnet mask.	
			[000-255].		
			[000-255].		
			[000-255]		
		Gateway	_	Enter the Gateway address.	
		Node Name	BRW_XXXXXX	Enter the Node name.	
		WINS Config	Auto*	Chooses the WINS	
			Static	configuration mode.	
		WINS Server	(Primary) 000.000.000.000	Specifies the IP address of the primary or	
			(Secondary)	secondary server.	
		DNS Server	(Primary) 000.000.000.000	Specifies the IP address of the primary or	
			(Secondary) 000.000.000.000	secondary server.	
		APIPA	On*	Automatically allocates	
			Off	the IP address from the link-local address range.	

LAN					
(MFC-665CW	Setup WLAN	Setup Wizard	_	You can configure your print server.	See Network
only) (Continued)		SecureEasySetup	_	You can configure the wireless network easily.	User's Guide on the
	WLAN Status	Status	_	You can see the current wireless network status.	CD-ROM
		Signal	_	You can see the current wireless network signal strength.	
		SSID	_	You can see the current SSID.	
		Comm. Mode	_	You can see the current Communication Mode.	
	Setup Misc.	Wired LAN	Auto*	Chooses the Ethernet link	
			100B-FD	mode.	
			100B-HD		
			10B-FD		
			10B-HD		
	Network I/F	_	Wired LAN*	You can choose the	
			WLAN	network connection type.	
	Factory Reset	_	Yes No	Restores all wired and wireless network settings to the factory default.	
Print Reports	XMIT Verify	_	_	Prints these lists and reports.	88
	Help List	_	_		
	Quick-Dial	Alphabetical Order	_		
		Numerical Order			
	Fax Journal	_	_		
	User Settings	_	_		
	Network Config	_			
Machine Info.	Serial No.	_	_	Lets you check the serial number of your machine.	155
Initial Setup	Receive Mode	_	Fax Only* Fax/Tel External TAD	Choose the receive mode that best suits your needs.	42
			(MFC-440CN only)		
			Manual		

Level1	Level2	Level3	Options	Descriptions	Page
Initial Setup (Continued)	Date/Time	_	_	Puts the date and time on the LCD and in headings of faxes you send.	See Quick Setup Guide
	Station ID	_	Fax: Name:	Set your name and fax number to appear on each page you fax.	
	Tone/Pulse (not available in New Zealand)	_	Tone* Pulse	Choose the dialling mode.	See Quick Setup Guide
					49
	Dial Tone	_	Detection No Detection*	You can shorten the dial tone detect pause.	146



Level1	Level2	Level3	Options	Descriptions	Page
Fax Resolution	_	_	Standard*	Sets the resolution for outgoing faxes.	38
			Fine		
			S.Fine		
			Photo		
Contrast	_	_	Auto*	Changes the lightness or	38
			Light	darkness of faxes you send.	
			Dark		
Speed-Dial	_	_	Alphabetical Order	You can dial by pressing only	64
				a few keys (and Start).	
			Numerical Order		
Outgoing Call	Make a Phone Call (MFC-665CW only) Send a fax Add to Speed- Dial Delete	_	_	You can choose a number from the Outgoing Call history and then make a phone call to it, send a fax to it, add it to Speed-Dial, or delete it.	65
The factory settings are shown in Bold with an asterisk.					

Level1	Level2	Level3	Options	Descriptions	Page
Caller ID hist.	Make a Phone Call (MFC-665CW only) Send a fax	_	_	You can choose a number from the Caller ID history and then make a phone call to it, send a fax to it, add it to Speed-Dial, or delete it.	66
	Add to Speed- Dial				
	Delete				
Broadcasting	Add Number Complete	_	_	You can send the same fax message to more than one fax number.	36
Delayed Fax	_	_	On	Sets the time of day in	39
			Off*	24-hour format that the delayed faxes will be sent.	
Batch TX	_	_	On	Combines delayed faxes to	the
			Off*	the same fax number at the same time of day into one transmission.	
Real Time TX	_	_	On Off*	You can send a fax without using the memory.	39
Polled TX	_	_	Standard	Sets up your machine with an document to be retrieved by another fax machine.	91
			Secure		
			Off*		
Polling RX	_	_	Standard	Sets up your machine to poll another fax machine.	89
			Secure		
			Timer		
			Off*		
Overseas Mode	_	_	On	If you are having difficulty	39
			Off*	sending faxes overseas, set this to On.	
Scan Size		_	A4*	Adjust the scan area of the	35
			Letter	scanner glass to the size of the document.	
Set New Default	_	_	Yes	You can save your fax	40
			No	settings.	
Factory Reset	_	_	Yes	You can restore all the settings to factory settings.	41
	I	1	No		

Scan (🔊)

Level1	Option1	Option2	Option3	Descriptions	Page
Scan to E-mail	_	_	_	You can scan a monochrome or a colour document into your E-mail application.	See Software User's Guide on the CD-ROM
Scan to Image	_	_	_	You can scan a colour picture into your graphics application.	
Scan to OCR	_	_	_	You can have your text document converted to an editable text file.	
Scan to File	_	_	_	You can scan a monochrome or a colour document into your computer.	
Scan to Card	150 dpi Color*	PDF*/JPEG	(File Name)	You can choose the scan resolution, file format and enter a file name for your document.	111
(when a card is inserted)	300 dpi Color	PDF*/JPEG	xxxxxxx		
,	600 dpi Color	PDF*/JPEG			
	200x100 dpi B/W	TIFF*/PDF			
	200 dpi B/W	TIFF*/PDF			
The factory settings are shown in Bold with an asterisk.					

Copy (🕞)

Level1	Level2	Level3	Options	Descriptions	Page	
Quality	_	_	Fast	Choose the Copy resolution	95	
			Normal*	for your type of document.		
			Best			
Enlarge/Reduce	_	_	50%	You can choose the	96	
			69% A4→A5	enlargement or reduction ratio for your type of		
			78% LGL→LTR	document.		
			83% LGL→A4			
			93% A4→LTR			
			97% LTR→A4			
			100%*			
			104% EXE→LTR			
			142% A5→A4			
			186%			
			10x15cm→LTR			
			198% 10x15cm→A4			
			200%			
			Custom(25-400%)			
Paper Type	_	_	Plain Paper*	Choose the paper type that	99	
121			Inkjet Paper	matches the paper in the		
			Brother Photo	tray.		
			Other Photo			
			Transparency			
Paper Size	_	_	Letter	Choose the paper size that	99	
			Legal	matches the paper in the		
			A4*	tray.		
			A5			
			10×15cm			
Brightness	_	_	Light	Adjusts the brightness of	98	
			+2	copies.		
			+1 0			
			-1			
			-2			
The factory settings are shown in Bold with an asterisk.						

Level1	Level2	Level3	Options	Descriptions	Page
Contrast	_	_	+2	Adjusts the contrast of copies.	98
Color Adjust	Red	_	+2 ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' '	Adjusts the amount of Red in copies.	98
	Green	_	+2 · · · · · · · · · · · · · · · · · · ·	Adjusts the amount of Green in copies.	
	Blue	_	+2 ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' ' '	Adjusts the amount of Blue in copies.	
Stack/Sort	_	_	Stack* Sort	You can choose to stack or sort multiple copies.	97
Page Layout	_	_	Off(1 in 1)* 2 in 1 (P) 2 in 1 (L) 4 in 1 (P) 4 in 1 (L) Poster(3 x 3)	You can make N in 1 or Poster copies.	96
Set New Default	_	_	Yes No	You can save your copy settings.	99
Factory Reset	_	_	Yes No	You can restore all the settings to factory settings.	99
	The factory setting	s are shown in Bold	with an asterisk.		

171

PhotoCapture ()

Level1	Level2	Level3	Options	Descriptions	Page
View Photo(s)	_	_	See the print settings table below.	You can preview your photos on the LCD.	104
Print Index	_	_	6 Images/Line Fast 5 Images/Line Photo	You can print a thumbnail page.	105
Print All Photos	_	_	See the print settings table below.	You can print all photos in your memory card.	105
Print Photos	_	_	See the print settings table below.	You can print an individual image.	106

Print Settings

Option1	Option2	Option3	Option4	Descriptions	Page
Print Quality	Normal	_	_	Choose the print quality.	108
	Photo*				
Paper Type	Plain Paper	_	_	Choose the paper type.	108
	Inkjet Paper				
	Brother Photo				
	Other Photo*				
Paper Size	Letter	(When A4 or	_	Choose the paper and print	108
	A4	Letter is chosen)		size.	
	13×18cm	10×8cm			
	10×15cm*	13×9cm			
		15×10cm			
		18×13cm			
		20×15cm			
		Max. Size*			
Brightness	Light	_	_	Adjusts the brightness.	109
	+2				
	+1 — C				
	-1 -1				
	-2 Dark				
	The factory settings	s are shown in Bold	with an asterisk.	•	1

Option1	Option2	Option3	Option4	Descriptions	Page
Contrast	+2 '	_	_	Adjusts the contrast.	109
Color Enhance	On Off*	White Balance	+2	Adjusts the hue of the white areas.	109
		Sharpness	+2 · · · · · · · · · · · · · · · · · · ·	Enhances the detail of the image.	
		Color Density	+2 · · · · · · · · · · · · · · · · · · ·	Adjusts the total amount of colour in the image.	
Cropping	On* Off	_	_	Crops the image around the margin to fit the paper size or print size. Turn this feature off if you want to print whole images or prevent unwanted cropping.	110
Borderless	On*	_	_	Expands the printable area to fit the edges of the paper.	110
Set New	Yes	_	_	You can save your print	110
Default	No			settings.	
Factory Reset	Yes No	_	_	You can restore all the settings to factory settings.	110
	The factory setting	s are shown in Bold	with an asterisk.		

Entering Text

When you are setting certain menu selections, such as the Station ID, you may need to enter text into the machine. Most dial pad keys have three or four letters printed on keys. The keys for $\mathbf{0}$, $\mathbf{\#}$ and $\mathbf{\times}$ do not have printed letters because they are used for special characters.

By pressing the proper dial pad key repeatedly, you can access the character you want.

Press Key	one time	two times	three times	four times
2	Α	В	С	2
3	D	Е	F	3
4	G	Н	I	4
5	J	K	L	5
6	M	N	Ο	6
7	Р	Q	R	S
8	Т	U	V	8
9	W	Х	Υ	Z

Putting spaces

To enter a space in a fax number, press ▶ once between numbers. To enter a space in a name, press ▶ twice between characters.

Making corrections

If you entered an incorrect letter and want to change it, press ◀ to move the cursor under the incorrect character. Then press Clear/Back. Re-enter the correct character. You can also back up and insert letters.

Repeating letters

If you need to enter a letter that is on the same key as the letter before, press ▶ to move the cursor to the right before you press the key again.

Special characters and symbols

Press \times , # or 0, repeatedly until you see the special character or symbol you want.

Specifications

General

Memory Capacity 32 MB

ADF (automatic document Up to 10 pages

feeder)

Temperature: 20° C - 30° C (68° F - 86° F)

Humidity: 50% - 70%

Paper: [80 gsm (20 lb)] A4 size

Paper Tray 100 Sheets [80 gsm (20 lb)]

Printer Type Ink Jet

Print Method Mono: Piezo with 94×1 nozzles

Colour: Piezo with 94×3 nozzles

LCD (liquid crystal display) (MFC-440CN)

50.8 mm (2.0 in.) Colour LCD

(MFC-665CW)

63.5 mm (2.5 in.) Colour LCD

Power Source AC 220 V to 240 V 50/60 Hz

Power Consumption (MFC-440CN)

Power Save Mode: Average 5 W


Standby: Average 8 W

Operating: Average 33 W


(MFC-665CW)

Power Save Mode: Average 5.5 W Standby: Average 8 W Operating: Average 35 W

Dimensions (MFC-440CN)



(MFC-665CW)



Weight MFC-440CN 8.2 kg (18.1 lb)

MFC-665CW 8.5 kg (18.7 lb)

Noise Operating: 50 dB or less ¹

Temperature Operating: 10 to 35° C (50° F to 95° F)

Best Print Quality: 20 to 33° C (68° F to 91° F)

Humidity Operating: 20 to 80% (without condensation)

Best Print Quality: 20 to 80% (without condensation)

This depends on printing conditions.

Print media

Paper Input

Paper Tray

■ Paper type:

Plain paper, inkjet paper (coated paper), glossy paper ², transparencies ^{1 2} and envelopes

■ Paper size:

Letter, Legal, Executive, A4, A5, A6, JIS B5, envelopes (commercial No.10, DL, C5, Monarch, JE4),

Photo 2L 13×18 cm, Index card and Post card ³.

For more details, see *Paper weight, thickness and capacity* on page 15.

Maximum paper tray capacity: Approx. 100 sheets of 80 gsm (20 lb) plain paper

Photo Paper Tray

■ Paper type:

Plain paper, inkjet paper (coated paper) and glossy paper ²

■ Paper size:

Photo 10×15 cm and Photo L

Width: 89 mm (3.5 in.) - 101.6 mm (4.0 in.)

Height: 127 mm (5.0 in.) - 152.4 mm (6.0 in.)

■ Maximum paper tray capacity: Approx. 20 sheets
Up to 50 sheets of 80 gsm (20 lb) plain paper (face up print delivery to the output paper tray) ²

Paper Output

Use only transparencies recommended for inkjet printing.

For glossy paper or transparencies, we recommend removing printed pages from the output paper tray immediately after they exit the machine to avoid smudging.

³ See Paper type and size for each operation for paper tray on page 14.

Fax

Compatibility ITU-T Group 3

Coding System MH/MR/MMR/JPEG
Modem Speed Automatic Fallback

14400 bps

Document Size ADF Width: 148 mm to 215.9 mm (5.8 in. to 8.5 in.)

ADF Height: 148 mm to 355.6 mm (5.8 in. to 14 in.) Scanner Glass Width: Max. 215.9 mm (8.5 in.) Scanner Glass Height: Max. 297 mm (11.7 in.)

Scanning Width 208 mm (8.2 in.)

Printing Width 204 mm (8.03 in.)

Grey Scale 256 levels

Polling Types Standard, Secure, Sequential: (Monochrome only)

Contrast Control Automatic/Light/Dark

(manual setting)

Resolution ■ Horizontal 8 dot/mm (203 dot/in.)

■ Vertical

Standard

3.85 line/mm (98 line/in.) (Monochrome)

7.7 line/mm (196 line/in.) (Colour)

Fine

7.7 line/mm (196 line/in.) (Monochrome/Colour)

Photo

7.7 line/mm (196 line/in.) (Monochrome)

Superfine

15.4 line/mm (392 line/in.) (Monochrome)

Speed-Dial 80 stations \times 2 numbers

Broadcasting 210 stations

Automatic Redial 3 times after 5 minutes

Auto Answer 2, 3, 4, 5, 6, 7, 8, 9 or 10 rings (for Australia)

1, 2, 3, 4, 5, 6, 7, 8, 9 or 10 rings (for New Zealand) 0, 1, 2, 3, 4, 5, 6, 7, 8, 9 or 10 rings (for some

countries)

Communication Source Public switched telephone network.

Memory TransmissionUp to 480 1/400 2 pagesOut of Paper ReceptionUp to 480 1/400 2 pages

TAD (MFC-665CW only)

TAD Yes

ICM Recording Time Max. 29 minutes / Max. 99 messages

(Max.180 secs / 1 message)

Toll Saver Yes
Recording Conversation Yes
OGM Yes
Recording OGM Time 20 secs

^{1 &#}x27;Pages' refers to the 'Brother Standard Chart No. 1' (a typical business letter, Standard resolution, MMR code). Specifications and printed materials are subject to change without prior notice.

^{2 &#}x27;Pages' refers to the 'ITU-T Test Chart #1' (a typical business letter, Standard resolution, MMR code). Specifications and printed materials are subject to change without prior notice.

Copy

Colour/

Monochrome Yes/Yes

Document Size ADF Width: 148 mm to 215.9 mm (5.8 in. to 8.5 in.)

ADF Height: 148 mm to 355.6 mm (5.8 in. to 14 in.)

Scanner Glass Width: Max. 215.9 mm (8.5 in.) Scanner Glass Height: Max. 297 mm (11.7 in.)

Copy Width: Max. 210 mm (8.26 in.)

Copy Speed MFC-440CN Mono: Up to 18 pages/minute (A4 paper) ¹

Colour: Up to 16 pages/minute (A4 paper) 1

MFC-665CW Mono: Up to 20 pages/minute (A4 paper) ¹

Colour: Up to 18 pages/minute (A4 paper) 1

Multiple Copies Stacks/Sorts up to 99 pages

Enlarge/Reduce 25% to 400% (in increments of 1%)

Resolution (Monochrome)

■ Scans up to 600×1200 dpi

■ Prints up to 1200×1200 dpi

(Colour)

■ Scans up to 600×1200 dpi

■ Prints up to 600×1200 dpi

Based on Brother standard pattern. (Fast mode/Stack Copy) Copy speeds vary with the complexity of the document.

PhotoCapture Center™

Available Media CompactFlash®

(Type I only)

(Microdrive[™] is not compatible)

(Compact I/O cards such as Compact LAN card and

Compact Modem card are not supported.)

Memory Stick®

Memory Stick Pro™

(Not available for music data with MagicGate™)

MultiMediaCard™ Secure Digital™

xD-Picture Card [™] ¹

File Extension

(Media Format)DPOF, EXIF, DCF(Image Format)Photo Print: JPEG 2

Scan to Card: JPEG, PDF (Colour)

TIFF, PDF (Black)

Number of Files Up to 999 files in the memory card (including the folder inside

media)

Folder File must be in the 3rd folder level of the Memory Card.

Borderless Letter, A4, Photo 10×15 cm, Photo 13×18 cm³

PictBridge

Compatibility Supports the Camera & Imaging Products Association

PictBridge standard CIPA DC-001.

VIsit http://www.cipa.jp/pictbridge for more information.

Interface PictBridge (USB) Port

¹ xD-Picture Card™ Conventional Card from 16MB to 512MB xD-Picture Card™ Type M from 256MB to 1GB xD-Picture Card™ Type H from 256MB to 1GB

² Progressive JPEG format is not supported.

See Paper type and size for each operation for paper tray on page 14.

Scanner

Colour/Monochrome Yes/Yes

TWAIN Compliant Yes (Windows® 98/98SE/Me/2000 Professional/XP/

Windows® XP Professional x64 Edition)

Mac OS® X 10.2.4 or greater

WIA Compliant

Yes (Windows® XP 1)

Colour Depth 36 bit colour Processing (Input)

24 bit colour Processing (Output)

Resolution Up to 19200×19200 dpi (interpolated) ²

Up to 600×2400 dpi (optical)

Scanning Speed Mono: Up to 3.59 sec.

Colour: Up to 5.66 sec.

(Letter size at 100×100 dpi)

Document Size ADF Width: 148 mm to 215.9 mm (5.8 in. to 8.5 in.)

ADF Height: 148 mm to 355.6 mm (5.8 in. to 14 in.)

Scanner Glass Width: Max. 215.9 mm (8.5 in.)

Scanner Glass Height: Max. 297 mm (11.7 in.)

Scanning Width 210 mm (8.26 in.)

Grey Scale 256 levels

Windows® XP in this User's Guide includes Windows® XP Home Edition, Windows® XP Professional, and Windows® XP Professional x64 Edition.

Maximum 1200×1200 dpi scanning when using the WIA Driver for Windows[®] XP (resolution up to 19200×19200 dpi can be selected by using the Brother scanner utility)

Printer

Printer Driver Windows® 98/98SE/Me/2000 Professional/XP/

Windows[®] XP Professional x64 Edition driver supporting Brother Native Compression mode and

bi-directional capability

Brother Ink Driver

For Mac OS® X 10.2.4 or greater

Resolution Up to 1200×6000 dpi ¹

 $1200 \times 2400 \text{ dpi}$ $1200 \times 1200 \text{ dpi}$ $600 \times 600 \text{ dpi}$ $600 \times 300 \text{ dpi}$ $600 \times 150 \text{ dpi}$

Print Speed MFC-440CN Up to 25 pages/minute (Mono) 4

Up to 20 pages/minute (Colour) 4

MFC-665CW Up to 27 pages/minute (Mono) ⁴

Up to 22 pages/minute (Colour) 4

Printing Width 204 mm [210 mm (borderless) ³] (A4 Size)

Disk-Based Fonts 35 TrueType Fonts bundled with the CD-ROM.

Borderless Letter, A4, A6, Photo 10×15 cm, Index Card,

Photo L 9×13 cm, Photo 2L 13×18 cm, Post Card ⁴

Output image quality varies based on many factors including, but not limited to input image resolution and quality and print media.

Based on Brother standard pattern. A4 size in draft mode.

³ When you set the Borderless feature to On.

⁴ See Paper type and size for each operation for paper tray on page 14.

Interfaces

USB A USB 2.0 interface cable that is no longer than 2.0 m

(6 feet). 12

LAN cable ³ Ethernet UTP cable category 5 or greater.

Wireless LAN Your machine supports IEEE 802.11b/g wireless

(MFC-665CW only) communication with your wireless LAN using Infrastructure

mode or a wireless Peer-to-Peer connection in Ad-Hoc

Mode.

Your machine has a USB 2.0 Full-speed interface. This interface is compatible with USB 2.0 Hi-Speed; however, the maximum data transfer rate will be 12 Mbits/s. The machine can also be connected to a computer that has a USB 1.1 interface.

- Third party USB ports are not supported for Macintosh[®].
- ³ See the *Network User's Guide* on the CD-ROM for detailed network specifications.

Computer requirements

	Minimum	System Requ	irements a	nd Supported	PC Softw	are Funct	ions	
Operating	Platform & System	Supported PC Software	Interfaces	Processor	Minimum RAM	Recommended RAM	Availabl Disk Spa	
Version		Functions		Speed			for Drivers	for Applications
Windows® 1	98, 98SE	Printing,	USB	Intel [®] Pentium [®] II or	32MB	128MB	120MB	130MB
Operating	Ме	PC Fax ⁴ ,		equivalent				
Systems	2000 Professional	Scanning, Removable	Ethernet		64MB	256MB		
	XP Home	Disk ³	Wireless		128MB	256MB	170MB	220MB
	XP Professional		802.11 b/g					
	XP Professional		(MFC-665CW	AMD Opteron™	256MB	512MB	170MB	220MB
	x64 Edition		only)	AMD Athlon™64				
				Intel [®] Xeon™ with Intel [®] EM64T				
				Intel [®] Pentium [®] 4 with Intel [®] EM64T				
Apple [®] Macintosh [®] Operating Systems	OS X 10.2.4 or greater	Printing, PC Fax Send ⁴ , Scanning, Removable Disk ³	USB ² Ethernet Wireless 802.11 b/g (MFC-665CW	PowerPC G3 350MHz ⁵	128MB	256MB	80MB	200MB
			only)					
1 Microso	oft [®] Internet Explo	orer 5 or	,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,,					
_	arty USB ports ar	e not		st driver updates, ons.brother.com/	access the	Brother So	lutions Cer	iter at
³ Remov	able disk is a fun apture Center™.							
⁴ PC Fax only.	supports black a	nd white faxing						
⁵ Power I Solo/Du	PC G3/G4/G5, In io.	tel [®] Core™						

Consumable items

Ink

Service Life of Ink Cartridge

The machine uses individual Black, Yellow, Cyan and Magenta ink cartridges that are separate from the print head assembly.

Replacement Ink Cartridges

Black - Approximately 500 pages at 5% coverage Yellow, Cyan and Magenta - Approximately 400 pages at 5% coverage

- The first time you install a set of ink cartridges the machine will use an amount of ink to fill the ink delivery tubes for high quality print outs. This process will only happen once. With all following ink cartridges you can print the specified number of pages.
- The above figures assume continuous printing at a resolution of 600 x 600 dpi in normal mode after installing new ink cartridge.
- The number of pages a cartridge will print may change depending on how often you use the machine and how many pages you print with each use.
- The machine will automatically and periodically clean the print head assembly, a process that uses a small amount of ink.
- When the machine identifies a cartridge as empty there may be a small amount of ink left in it. This is necessary to prevent air from drying out and damaging the print head assembly.

Replacement Consumables

<Black> LC57BK, <Cyan> LC57C, <Magenta> LC57M, <Yellow> LC57Y



Brother does not recommend the use of consumables other than genuine Brother consumables.

Your machine warranty may not cover any damage arising from the use of non genuine Brother consumables.

Network (LAN)

LAN You can connect your machine to a network for Network Printing,

Network Scanning and PC Fax Send and PC Fax Receive ¹

(Windows® only). Also included is Brother BRAdmin Professional

Network Management software.

Support for Windows® 98/98SE/Me/2000/XP/XP Professional x64 Edition

Mac OS® X 10.2.4 or greater

Ethernet 10/100 BASE-TX Auto Negotiation (Wired LAN)

IEEE 802.11 b/g (Wireless LAN) (MFC-665CW only)

Protocols TCP/IP

ARP, RARP, BOOTP, DHCP, APIPA (Auto IP), NetBIOS Name

Resolution, WINS DNS Resolver, LPR/LPD, Custom Raw Port/Port9100, FTP Server, mDNS, TELNET, SNMP

Network Security SSID/ESSID, 128 (104) / 64 (40) bit WEP, WPA/WPA2-PSK

(MFC-665CW only) (TKIP/AES)

SecureEasySetup™ Yes (simple setup with your SecureEasySetup™-capable access

(MFC-665CW only) point/router)

¹ See the Computer Requirements chart on page 185.

Glossary

This is a comprehensive list of features and terms that appear in Brother manuals. Availability of these features depends on the model you purchased.

ADF (automatic document feeder)

Documents can be placed in the ADF and scanned one page at a time automatically.

Auto Reduction

Reduces the size of incoming faxes.

Automatic fax transmission

Sending a fax without picking up the handset of an external phone.

Automatic Redial

A feature that enables your machine to redial the last fax number after five minutes if the fax did not go through because the line was busy.

Backup Print

Your machine prints a copy of every fax that is received and stored in memory. This is a safety feature so you will not lose messages during a power failure.

Batch Transmission

(Black and white faxes only) As a cost saving feature, all delayed faxes to the same fax number can be sent as one transmission.

Beeper Volume

Volume setting for the beep when you press a key or make an error.

Brightness

Changing the Brightness makes the whole image lighter or darker.

Broadcasting

The ability to send the same fax message to more than one location.

Caller ID

A service purchased from the telephone company that lets you see the number (or name) of the party calling you.

CNG tones

The special tones (beeps) sent by fax machines during automatic transmission to tell the receiving machine that a fax machine is calling.

Coding method

Method of coding the information contained in the document. All fax machines must use a minimum standard of Modified Huffman (MH). Your machine is capable of greater compression methods, Modified Read (MR), Modified Modified Read (MMR) and JPEG, if the receiving machine has the same capability.

Colour Enhancement

Adjusts the colour in the image for better print quality by improving sharpness, white balance and colour density.

Communication error (Comm. Error)

An error during fax sending or receiving, usually caused by line noise or static.

Compatibility group

The ability of one fax unit to communicate with another. Compatibility is assured between ITU-T Groups.

Contrast

Setting to compensate for dark or light documents, by making faxes or copies of dark documents lighter and light documents darker.

Delayed Fax

Sends your fax at a specified time later.

Distinctive Ring

A subscriber service purchased from the telephone company that gives you another phone number on an existing phone line. The Brother machine uses the new number to simulate a dedicated fax line.

Dual Access

Your machine can scan outgoing faxes or scheduled jobs into memory at the same time it is sending a fax from memory or receiving or printing an incoming fax.

ECM (Error Correction Mode)

Detects errors during fax transmission and resends the pages of the fax that had an error.

Extension phone

A telephone using the same line as your fax but plugged into a separate wall socket.

External phone

A TAD (telephone answering device) or telephone that is connected to your machine.

F/T Ring Time

The length of time that the Brother machine rings (when the Receive Mode setting is Fax/Tel) to notify you to pick up a voice call that it answered.

FaxAbility

A subscriber service purchased from the telephone company that provides another phone number on an existing phone line. The Brother fax machine uses the new number to simulate a dedicated fax line.

Fax Detect

Enables your machine to respond to CNG tones if you interrupt a fax call by answering it.

Fax Forwarding

Sends a fax received into the memory to another pre-programmed fax number.

Fax Receive Code

Press this code (*** 5 1** (*** 9 1** for New Zealand)) when you answer a fax call on an extension or external phone.

Fax Storage

You can store received faxes in memory.

Fax tones

The signals sent by sending and receiving fax machines while communicating information.

Fax/Tel

You can receive faxes and telephone calls. Do not use this mode if you are using a telephone answering device (TAD).

Fine resolution

Resolution is 203×196 dpi. It is used for small print and graphs.

Grey scale

The shades of grey available for copying, scanning and faxing photographs.

Group number

A combination of Speed-Dial numbers that are stored in a Speed-Dial location for Broadcasting.

Help list

A printout of the complete Menu table that you can use to program your machine when you do not have the User's Guide with you.

Fax Journal

Lists information about the last 200 incoming and outgoing faxes. TX means Transmit. RX means Receive.

Journal Period

The pre-programmed time period between automatically printed Fax Journal Reports. You can print the Fax Journal on demand without interrupting the cycle.

LCD (liquid crystal display)

The display screen on the machine that shows interactive messages during On-Screen Programming and shows the date and time when the machine is idle.

Manual fax

Depending on your model, you can lift the handset, cordless handset, or handset of the external telephone or you can press **Hook** or **Speaker Phone** to hear the receiving fax machine answer before you press **Mono Start** or **Colour Start** to begin sending.

Menu mode

Programming mode for changing your machine's settings.

OCR (optical character recognition)

The bundled ScanSoft[®] PaperPort[®] SE with OCR or Presto![®] PageManager[®] software application converts an image of text to text you can edit.

Out of Paper Reception

Receives faxes into the machine's memory when the machine is out of paper.

Overseas Mode

Makes temporary changes to the fax tones to accommodate noise and static on overseas phone lines.

Pause

Allows you to place a 3.5 second delay in the dialling sequence stored on Speed-Dial numbers. Press **Redial/Pause** as many times as needed for longer pauses.

PhotoCapture Center™

Allows you to print digital photos from your digital camera at high resolution for photo quality printing.

Photo resolution

A resolution setting that uses varying shades of grey for the best representation of photographs.

PictBridge

Allows you to print photos directly from your digital camera at high resolution for photo quality printing.

Polling

The process of a fax machine calling another fax machine to retrieve waiting fax messages.

Pulse (not available in New Zealand)

A form of rotary dialling on a telephone line.

Quick Dial List

A listing of names and numbers stored in Speed-Dial memory, in numerical order.

Real Time Transmission

When memory is full, you can send faxes in real time.

Remaining jobs

You can check which jobs are waiting in memory and cancel jobs individually.

Remote Access Code

Your own four-digit code (---X) that allows you to call and access your machine from a remote location.

Remote Retrieval Access

The ability to access your machine remotely from a touch tone phone.

Resolution

The number of vertical and horizontal lines per inch. See: Standard, Fine, Super Fine and Photo.

Ring Delay

The number of rings before the machine answers in Fax Only and Fax/Tel modes.

Ring Volume

Volume setting for the machine's ring.

Scanning

The process of sending an electronic image of a paper document into your computer.

Scan to Card

You can scan a black and white or colour document into a Memory Card. Black and white images can be in TIFF or PDF file format and colour images can be in PDF or JPEG file format.

Search

An electronic, alphabetical listing of stored Speed-Dial and Group numbers.

Speed-Dial

A pre-programmed number for easy dialling. You must press
Search/Speed Dial, the two digit code, and Mono Start or Colour Start to start the dialling process.

Standard resolution

 203×97 dpi. It is used for regular size text and quickest transmission.

Station ID

The stored information that appears on the top of faxed pages. It includes the sender's name and fax number.

Super Fine resolution

 392×203 dpi. Best for very small print and line art.

TAD (telephone answering device)

You can connect an external TAD to your machine.

Telephone Answer Code (For Fax/Tel mode only)

When the machine answers a voice call, it pseudo/double-rings. You can pick up at an extension phone by pressing this code (# 5 1).

Temporary settings

You can choose certain options for each fax transmission and copy without changing the default settings.

Tone (not available in New Zealand)

A form of dialling on the telephone line used for Touch Tone telephones.

Transmission

The process of sending faxes over the phone lines from your machine to the receiving fax machine.

User Settings

A printed report that shows the current settings of the machine.

Xmit Report (Transmission Verification Report)

A listing for each fax sent, that shows its date, time and number.

Index

A	paper size	99
	paper type	99
Access codes, storing and dialling71	quality	
ADF (automatic document feeder) 10, 34	return to default	
Answering machine (TAD)60	set new default	99
connecting61	single	94
Apple [®] Macintosh [®]	sort (ADF only)	97
See Software User's Guide on the	using ADF	95
CD-ROM	using scanner glass	11
Automatic	Custom telephone features on a	
fax receive42	single line	137
Fax Detect46	_	
В	D	
	Daylight Savings Time	26
Broadcasting36	Dialling	
setting up Groups for69	a pause	
	Caller ID history	66
C	Groups	36
	manual	64
Caller ID	Outgoing Call	65
print list54, 57, 60	Speed-Dial	64
Cancelling	Distinctive Ring	52, 58
Fax Forwarding84	Document	
jobs awaiting redial40	loading	10, 11
Cleaning	Dual Access	
paper pick-up roller151		
print head152	E	
printer platen151		
scanner150	Envelopes14,	15, 18
Connecting	Error messages on LCD	
external TAD60	Comm. Error	
external telephone62	Ink Empty	
Consumable items186	Near Empty	
Control panel overview6	No Paper Fed	
ControlCenter	Not Registered	
See Software User's Guide on the	Out of Memory	
CD-ROM.	while scanning a document	
Copy	Unable to Change	
brightness98	Unable to Clean	
colour saturation98	Unable to Init.	
contrast98	Unable to Print	
enlarge/reduce96	Unable to Scan	
enter Copy mode94	Extension telephone, using	
multiple95	External telephone, connecting	
out of memory100	External telephone, conflicting	02
page layout (N in 1)96		

F

Fax codes			
changing		63,	82
Fax Receive Code			.62
Remote Access Code			
Telephone Answer Code			.62
using			
Fax Forwarding			
changing remotely		84,	86
programming a number			
Fax Storage			
printing from memory			
turning on			
Fax, from PC			
See Software User's Guide on the	е		
CD-ROM			
Fax, stand-alone			
receiving			42
at end of conversation			
difficulties			
F/T Ring Time, setting		,	
Fax Detect			
Fax Forwarding			
Fax Preview			
FaxStream [®] Duet [®]	••••	, 0,	52
from extension phone			62
into PC			
into the memory			
phone line interference			
printing from memory			
Receive Mode, choosing			
reducing to fit on paper			
retrieving from a remote site			
Ring Delay, setting			
sending			
at end of conversation			
Broadcasting			
cancelling from memory			
contrast			
delayed batch transmission			
delayed fax			
enter Fax mode			
from memory (Dual Access)			
from scanner glass			
manual			
overseas			
phone line interference		••••	14/

Real Time Transmission Resolution return to factory setting set new default Fax/Tel mode Announcement answering at extension phones double-ringing (voice calls) F/T Ring Time Fax Detect Fax Receive Code Ring Delay Telephone Answer Code	38 41 40 72 32 45 45 46 32 45
G	
Grey scale178, 18 Groups for Broadcasting6	
Н	
HELP LCD messages	58 59
Ink cartridges checking ink volume	47
J	
Jams paper14	14
CD (liquid en etal display)	-0
LCD (liquid crystal display) 15 Brightness 27, 2 Contrast 2 Dim Timer 2 Help List 8 Off Timer 2	28 27 27 38

M	interference	147
	multi-line (PABX)	61
Macintosh [®]	PhotoCapture Center™	
See Software User's Guide on the	Borderless	110
CD-ROM	CompactFlash [®]	102
Maintenance, routine147	Cropping109	
Manual	DPOF printing	
dialling64	from PC	
receive42	See Software User's Guide on the	
transmission41	CD-ROM	
Memory Security	Memory Stick Pro™	
Memory Storage158	Memory Stick®	
Mode, entering	MultiMediaCard™	
Copy94	Preview photos	
Fax34	Print settings	10-
	Brightness	100
PhotoCapture7	Colour Enhancement	
Scan	Contrast	
Multi-line connections (PABX)61		
N.I.	Paper & print size	
N	Paper type	
	Quality107	
Network	Return to factory setting	
Printing	Set new default	
See Network User's Guide on the	Printing Index	
CD-ROM	Printing photos109	
Scanning	Scan to Card	
See Software User's Guide on the	SecureDigital™	102
CD-ROM	specifications	181
	xD-Picture Card™	102
0	PictBridge	
	DPOF Printing	114
Outgoing Message (Msg Ctr OGM)72	Power failure	158
	Presto! [®] PageManager [®]	
P	See Help in Presto!® PageManager®	⁾ to
	access the User's Guide on the	
Packing the machine155	CD-ROM	
Paper12, 18, 177	Print	
capacity15	difficulties134	4. 136
loading16, 18, 19	drivers	
printable area21	fax from memory	
size24	paper jams	
size of document10	report	
	resolution	183
type14, 24 PaperPort [®] SE with OCR	specifications	183
	Printing	
See Software User's Guide on the	index	
CD-ROM.	on small paper	
Phone line	photos109	5, 106
connections61	See Software User's Guide on the	
difficulties136	CD-ROM	
	Programming your machine	158

Resolution copy 180 Quick-Dial print 183 Access codes and credit card numbers71 scan 182 Broadcasting36 Ring Delay, setting45 using Groups36 Group dial S changing 67, 68 setting up Groups for Broadcasting69 Safety Instructions 121 Scannable area11 Search64 Speed-Dial Scanning See Software User's Guide on the changing 67, 68 CD-ROM. setting up by 2-digit location66 Serial Number setting up from Caller ID history67 how to find setting up from outgoing calls67 See inside front cover using64 Shipping the machine 155 R Speed-Dial changing67, 68 Receive Mode42 dialling 64 External TAD42 Fax Only42 т Fax/Tel42 Manual42 TAD (telephone answering device), Redial/Pause65 external42, 60 Reducing connecting60, 61 copies96 receive mode42 incoming faxes47 recording OGM61 Remote Retrieval82 access code 82, 83 TAD mode erasing messages74 commands84 Fax/Tel announcement (F/T OGM) 73 getting your faxes86 outgoing message (Msg Ctr OGM) 72 Remote Setup See Software User's Guide on the playing voice messages74 recording a conversation 76 CD-ROM. setting toll saver75 Reports87 setting up72, 73 Caller ID List54, 57, 60 Telstra® FaxStream® Duet® Fax Journal88 (Distinctive Ring)51 Journal Period87 Help List88 special characters 174 how to print88 Transferring your faxes or Network Configuration88 Quick-Dial List88 Fax Journal report 143 Transparencies12, 15, 177 Transmission Verification 87, 88 Troubleshooting 134 User Settings88 checking ink volume 154 document jam 144 error messages on LCD140

if you are having difficulty	
copying	.138
document jam	
incoming calls	
Network	
phone line or connections	
PhotoCapture Center [™]	
printing	
printing received faxes	
receiving faxes	
scanning	
sending faxes	
software	
paper jam	
TX Lock	
17. LOOK	00
V	
•	
Volume, setting	
beeper	25
ring	
speaker	
W	
Wireless Network	
See Quick Setup Guide and Network	
User's Guide on the CD-ROM	

For Australia

Warranty – For details about the warranty on your Brother Product, please visit: www.brother.com.au

Repair – For warranty service for your Brother Product you will need evidence of original purchase (e.g. a copy of the sales docket).

Contact Brother International (Aust) Pty Ltd for details about your nearest Authorised Warranty Centre or visit: www.brother.com.au

Support – For support for your Brother Product other than what you can resolve through the User Guide.

Visit our website: www.brother.com.au

or visit our Solutions website for FAQs (Frequently Asked Questions), Driver Updates & Utilities,

Product Support: http://solutions.brother.com

You can contact the Product Support Centre for any technical or customer care/support enquiry you may have about your Brother Product.

Product Support Centre – Australia Brother Intenational (Aust) Pty Ltd

Phone: 02 8875 6000 Fax: 02 9870 7223 email: productsupport@brother.com.au

http://www.brother.com.au



Visit us on the World Wide Web http://www.brother.com

This machine is approved for use in the country of purchase only. Local Brother companies or their dealers will only support machines purchased in their own countries.