


**brother**<sup>®</sup>

# ADVANCED USER'S GUIDE

---



**DCP-9270CDN**

Version 0

UK/IRE

# User's Guides and where do I find it?

Which manual?	What's in it?	Where is it?
<b>Safety and Legal</b>	Read this Guide first. Please read the Safety Instructions before you set up your machine. See this Guide for trademarks and legal limitations.	Printed / In the box
<b>Quick Setup Guide</b>	Follow the instructions for setting up your machine and installing the drivers and software for the operating system and connection type you are using.	Printed / In the box
<b>Basic User's Guide</b>	Learn the basic Copy, Scan and Direct Print operations and how to replace consumables. See troubleshooting tips.	PDF file / Documentation CD-ROM / In the box
<b>Advanced User's Guide</b>	Learn more advanced operations: Copy, security features, printing reports and performing routine maintenance.	PDF file / Documentation CD-ROM / In the box
<b>Software User's Guide</b>	Follow these instructions for Printing, Scanning, Network Scanning and using the Brother ControlCenter utility.	PDF file / Documentation CD-ROM / In the box
<b>Network Glossary</b>	This Guide provides basic information about advanced network features of Brother machines along with explanations about general networking and common terms.	PDF file / Documentation CD-ROM / In the box
<b>Network User's Guide</b>	This Guide provides useful information about wired and wireless network settings and security settings using the Brother machine. You can also find supported protocol information for your machine and detailed troubleshooting tips.	PDF file / Documentation CD-ROM / In the box

# Table of Contents

<b>1</b>	<b>General Setup</b>	<b>1</b>
	Memory storage.....	1
	Automatic daylight savings time .....	1
	Ecology features .....	2
	Toner Save .....	2
	Sleep mode .....	2
	Deep Sleep mode.....	3
	LCD screen.....	3
	Setting the backlight brightness.....	3
	Setting the Dim Timer for the backlight .....	3
	User Settings Report .....	4
	Network Configuration Report .....	4
<b>2</b>	<b>Security features</b>	<b>5</b>
	Secure Function Lock 2.0 .....	5
	Setting and changing the Administrator Password .....	5
	Setting up and changing the Public user mode .....	6
	Setting up and changing restricted users .....	7
	Turning Secure Function Lock on/off.....	8
	Switching Users.....	9
<b>3</b>	<b>Printing reports</b>	<b>10</b>
	Reports .....	10
	How to print a report.....	10
<b>4</b>	<b>Making copies</b>	<b>11</b>
	Copy settings .....	11
	Stop copying .....	11
	Improving copy quality.....	11
	Enlarging or reducing the image copied .....	12
	Duplex (2-sided) Copying .....	13
	Tray selection .....	14
	Adjusting Brightness and Contrast .....	15
	Sorting copies using the ADF .....	15
	Making N in 1 copies (page layout) .....	16
	2 in 1 ID Copy .....	17
	Adjusting Colour (Saturation) .....	18
	Setting your changes as the new default.....	19
	Restoring all copy settings to the factory settings .....	19
	Setting your favourites.....	20

---

<b>A</b>	<b>Routine maintenance</b>	<b>21</b>
Cleaning and checking the machine.....	21	
Checking the Page Counters.....	21	
Checking the remaining life of parts .....	21	
Replacing periodic maintenance parts.....	22	
Packing and shipping the machine .....	23	
<b>B</b>	<b>Options</b>	<b>33</b>
Optional paper tray (LT-300CL).....	33	
Memory board.....	33	
SO-DIMM Types .....	33	
Installing extra memory .....	34	
<b>C</b>	<b>Glossary</b>	<b>36</b>
<b>D</b>	<b>Index</b>	<b>37</b>

---

## Memory storage

Your menu settings are stored permanently, and in the event of a power failure will *not* be lost. Temporary settings (for example, Contrast) *will* be lost. Also, during a power failure the machine will retain the date and time up to 60 hours.

## Automatic daylight savings time

You can set the machine to change automatically for Daylight Savings Time. It will set itself forward one hour in the Spring, and back one hour in the Autumn.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display Initial Setup.  
Press Initial Setup.
- 3 Press Date&Time.
- 4 Press Auto Daylight.
- 5 Press On or Off.
- 6 Press Stop/Exit.

# Ecology features

## Toner Save

You can save toner using this feature. When you set Toner Save to On, prints appear lighter. The default setting is off.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display General Setup.  
Press General Setup.
- 3 Press ▲ or ▼ to display Ecology.  
Press Ecology.
- 4 Press Toner Save.
- 5 Press On or Off.
- 6 Press Stop/Exit.



### Note

We do not recommend Toner Save for printing Photo or Greyscale images.

## Sleep mode

The Sleep Mode Setting can reduce power consumption. When the machine is in Sleep Mode (Power Save mode) it acts as though it were turned off. Receiving data or starting an operation wakes up the machine from Sleep mode to Ready mode.

You can choose how long the machine must be idle before it goes into sleep mode. When the machine receives computer data or makes a copy, the timer will be reset. The default setting is 3 minutes.

When the machine goes into Sleep mode, the LCD backlight turns off.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display General Setup.  
Press General Setup.
- 3 Press ▲ or ▼ to display Ecology.  
Press Ecology.
- 4 Press Sleep Time.
- 5 Using the dial pad on the Touchscreen, enter the length of time the machine will remain idle before entering sleep mode.  
Press OK.
- 6 Press Stop/Exit.

## Deep Sleep mode

If the machine is in Sleep mode and does not receive any jobs for a certain length of time, the machine will go into Deep Sleep mode automatically. Deep Sleep mode uses less power than Sleep mode. The machine will wake up and start warming up when the machine receives a computer data, or when you press the Touchscreen or a key on the control panel.

When the machine is in Deep Sleep mode, the LCD backlight is Off and the mode keys are dimmed.

If the machine has secure print data it will not enter Deep Sleep mode.

## LCD screen

### Setting the backlight brightness

You can adjust the brightness of the LCD backlight. If you are having difficulty reading the LCD, try changing the brightness setting.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display General Setup.  
Press General Setup.
- 3 Press ▲ or ▼ to display LCD Settings.  
Press LCD Settings.
- 4 Press Backlight.
- 5 Press Light, Med or Dark.
- 6 Press Stop/Exit.

### Setting the Dim Timer for the backlight

You can set how long the LCD backlight stays on after you go back to the Ready screen.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display General Setup.  
Press General Setup.
- 3 Press ▲ or ▼ to display LCD Settings.  
Press LCD Settings.
- 4 Press Dim Timer.
- 5 Press Off, 10 Secs, 20 Secs or 30 Secs.
- 6 Press Stop/Exit.

## User Settings Report

You can print a report of your programmed settings.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display Print Reports.  
Press Print Reports.
- 3 Press User Settings.
- 4 Press **Mono Start** or **Colour Start**.
- 5 Press **Stop/Exit**.

## Network Configuration Report

You can print a report showing the current network configuration, including the internal print server settings.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display Print Reports.  
Press Print Reports.
- 3 Press Network Config.
- 4 Press **Mono Start** or **Colour Start**.
- 5 Press **Stop/Exit**.

## Secure Function Lock 2.0

Secure Function Lock lets you restrict Public access to the following machine functions:

- Copy
- Scan
- Direct Print
- Print
- Color Print

This feature also prevents users from changing the Default settings of the machine by limiting access to the Menu settings.

Before using the security features you must first enter an administrator password.

Access to restricted operations can be enabled by creating a restricted user.

Restricted users must enter a user password to use the machine.

Make a careful note of your password. If you forget it, you will have to reset the password stored in the machine. For information about how to reset the password call your Brother dealer for service.



### Note

- Secure Function Lock can be set manually at the control panel or by using Web Based Management. We recommend using Web Based Management to configure this feature. For more information, see the *Network User's Guide*.
- Only administrators can set limitations and make changes for each user.

## Setting and changing the Administrator Password

2

### Setting up the password

The password you set in these steps is for the administrator. This password is used to set up users and to turn Secure Function Lock on or off. (See *Setting up and changing restricted users* on page 7 and *Turning Secure Function Lock on/off* on page 8.)



### Note

Make a careful note of the administrator password. If you enter the wrong password, the LCD will show Wrong Password. Re-enter the correct password. If you forget it, please call your Brother dealer for service.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display General Setup.  
Press General Setup.
- 3 Press ▲ or ▼ to display Function Lock.  
Press Function Lock.
- 4 Enter a four-digit number for the password by pressing the buttons on the Touchscreen.  
Press OK.
- 5 Re-enter the password when the LCD shows Verify.  
Press OK.
- 6 Press Stop/Exit.

## Changing the password

- 1 Press MENU.
- 2 Press ▲ or ▼ to display General Setup.  
Press General Setup.
- 3 Press ▲ or ▼ to display Function Lock.  
Press Function Lock.
- 4 Press Set Password.
- 5 Enter the registered four-digit password by pressing the buttons on the Touchscreen.  
Press OK.
- 6 Enter a four-digit number for the new password by pressing the buttons on the Touchscreen.  
Press OK.
- 7 Re-enter the password when the LCD shows Verify.  
Press OK.
- 8 Press Stop/Exit.

## Setting up and changing the Public user mode

Public user mode restricts the functions that are available for Public users. Public users do not need to enter a password to access the features made available through this setting. You can set up one Public user.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display General Setup.  
Press General Setup.
- 3 Press ▲ or ▼ to display Function Lock.  
Press Function Lock.
- 4 Press Setup ID.
- 5 Enter the administrator password by pressing the buttons on the Touchscreen.  
Press OK.
- 6 Press ▲ or ▼ to display Public.  
Press Public.
- 7 Do one of the following:
  - To set up the Public user, press Enable or Disable for each operation, as follows: Press Copy. Then press Enable or Disable. After you have set Copy, repeat these steps for Scan, Direct Print, Print and Color Print.
  - To change the Public user settings, press ▲ or ▼ to display the setting you want to change. Press the setting and press Enable or Disable. Repeat this step until you finish changing settings.
- 8 Press Stop/Exit.

## Setting up and changing restricted users

You can set up users with restrictions and a password for functions that are available to them. You can set up more advanced restrictions, such as by page count or PC user login name, through Web Based Management. (For more information, see the *Network User's Guide*.) You can set up to 25 restricted users with restrictions and a password.

### Setting up restricted users

- 1 Press MENU.
- 2 Press ▲ or ▼ to display General Setup.  
Press General Setup.
- 3 Press ▲ or ▼ to display Function Lock.  
Press Function Lock.
- 4 Press Setup ID.
- 5 Enter the four-digit administrator password by pressing the buttons on the Touchscreen.  
Press OK.
- 6 Press ▲ or ▼ to display User01.  
Press User01.
- 7 Enter the user name by pressing the buttons on the Touchscreen. (See *Entering text in Appendix C of the Basic User's Guide*.)  
Press OK.
- 8 Enter a four-digit user password by pressing the buttons on the Touchscreen.  
Press OK.

- 9 To set up the restricted user, press Enable or Disable for each operation, as follows: Press Copy. Then press Enable or Disable. After you have set Copy, repeat these steps for Scan, Direct Print, Print and Color Print.

- 10 Repeat steps 6 to 9 for entering each additional user and password.

- 11 Press Stop/Exit.



#### Note

You cannot use the same name as another user's name.

### Changing user name, password or settings for restricted users

- 1 Press MENU.
- 2 Press ▲ or ▼ to display General Setup.  
Press General Setup.
- 3 Press ▲ or ▼ to display Function Lock.  
Press Function Lock.
- 4 Press Setup ID.
- 5 Enter the four-digit administrator password by pressing the buttons on the Touchscreen.  
Press OK.
- 6 Press ▲ or ▼ to display the existing restricted user you want to change.  
Press the user name.
- 7 Press Change.  
To change the user name, enter a new user name by pressing the buttons on the Touchscreen. (See *Entering text in Appendix C of the Basic User's Guide*.)  
Press OK.

- 8 To change the password, enter a new four-digit user password by pressing the buttons on the Touchscreen.  
Press OK.
- 9 To change a restricted user's settings, press ▲ or ▼ to display the setting you want to change. Press the setting and then press Enable or Disable. Repeat this step until you are finished making changes.
- 10 Press **Stop/Exit**.



#### Note

You cannot use the same name as another user's name.

### Reset existing restricted users

- 1 Press MENU.
- 2 Press ▲ or ▼ to display General Setup.  
Press General Setup.
- 3 Press ▲ or ▼ to display Function Lock.  
Press Function Lock.
- 4 Press Setup ID.
- 5 Enter the four-digit administrator password by pressing the buttons on the Touchscreen.  
Press OK.
- 6 Press ▲ or ▼ to display the existing restricted user you want to reset.  
Press the user name.
- 7 Press Reset.
- 8 Press Yes to reset the existing restricted user.
- 9 Press **Stop/Exit**.

## Turning Secure Function Lock on/off

### Turning Secure Function Lock on

- 1 Press MENU.
- 2 Press ▲ or ▼ to display General Setup.  
Press General Setup.
- 3 Press ▲ or ▼ to display Function Lock.  
Press Function Lock.
- 4 Press Lock Off-On.
- 5 Enter the registered four-digit administrator password by pressing the buttons on the Touchscreen.  
Press OK.

### Turning Secure Function Lock off

- 1 Press Public or xxxx on the LCD. (Where xxxx is the user's name.)
- 2 Press Lock On-Off.
- 3 Enter the registered four-digit administrator password by pressing the buttons on the Touchscreen.  
Press OK.



#### Note

If you enter the wrong password, the LCD will show Wrong Password. Re-enter the correct password.

## Switching Users

This setting allows you to switch between registered restricted users or Public mode when Secure Function Lock is turned on.

### Changing to the restricted user Mode

- 1 Press Public or **xxxxx** (where **xxxxx** is the user's name).  
Press Change User.
- 2 Press **▲** or **▼** to display your user name.
- 3 Press your user name.
- 4 Enter the registered four-digit user password by pressing the buttons on the Touchscreen.  
Press OK.

### Changing to the Public Mode

- 1 Press **xxxxx** (where **xxxxx** is the user's name).
- 2 Press Go to Public.



#### Note

- After a restricted user has finished using the machine, it will return to the Public setting in two minutes.
- If your ID has set page limit restrictions and already reached the maximum number of pages, the LCD will show Limit Exceeded when you print data. Contact your administrator to check your Secure Function Lock Settings.
- If your ID has set Colour Print restrictions to Disable, the LCD will show No Permission when you try to print coloured data. The machine prints the data in black & white only.

# 3

# Printing reports

## Reports

The following reports are available:

1 Journal Report

Prints a list of information about your last  
200 outgoing E-mails.

2 User Settings

Print a list of your current settings.

3 Network Config

Lists your network settings.

4 Drum Dot Print

Prints the drum dot check sheet to  
troubleshoot a dotted print problem.

## How to print a report

1 Press MENU.

2 Press ▲ or ▼ to display  
Print Reports.  
Press Print Reports.

3 Press the report you want to print.

4 Press **Mono Start** or **Colour Start**.

5 Press **Stop/Exit**.

## Copy settings

You can change the copy settings temporarily for the next copy.

These settings are temporary, and the machine returns to its default settings one minute after copying.

To change a setting, press  (COPY) and then press ▲ or ▼ to scroll through the copy settings. When the setting you want is displayed, press the button.

When you are finished choosing settings, press **Mono Start** or **Colour Start**.

## Stop copying

To stop copying, press **Stop/Exit**.

## Improving copy quality

You can choose from a range of quality settings. The default setting is **Auto**.

- **Auto**

Auto is the recommended mode for ordinary printouts. Suitable for documents that contain both text and photographs.

- **Text**

Suitable for documents containing mainly text.

- **Photo**

Better copy quality for photographs.

- **Graph**

Suitable for copying receipts.

- 1 Press  (COPY).
- 2 Load your document.
- 3 Enter the number of copies you want.
- 4 Press ▲ or ▼ to display Quality. Press Quality.
- 5 Press Auto, Text, Photo or Graph.
- 6 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

## Enlarging or reducing the image copied

To enlarge or reduce the next copy follow the instructions below:

- 1 Press  (COPY).
- 2 Load your document.
- 3 Enter the number of copies you want.
- 4 Press **◀** or **▶** to display Enlarge/Reduce.  
Press Enlarge/Reduce.
- 5 Press 100%, Enlarge, Reduce or Custom (25-400%).
- 6 Do one of the following:
  - If you chose Enlarge or Reduce, press the enlargement or reduction ratio button you want.
  - If you chose Custom (25-400%), enter an enlargement or reduction ratio from 25% to 400%.  
Press OK.
  - If you chose 100%, go to step 7.

100%*
104% EXE → LTR
141% A5 → A4
200%
50%
70% A4 → A5
78% LGL → LTR
83% LGL → A4
85% LTR → EXE
91% Full Page
94% A4 → LTR
97% LTR → A4
Custom (25-400%)

- 7 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.



### Note

Page Layout Options 2 in 1 (P), 2 in 1 (L), 2 in 1 (ID), 4 in 1 (P) and 4 in 1 (L) are *not* available with Enlarge/Reduce.

## Duplex (2-sided) Copying


If you want to use the automatic duplex copy feature, load your document in the ADF.

If you get an Out of Memory message while you are making duplex copies, try installing extra memory. (See *Installing extra memory* on page 34.)


You must choose a 2-sided copy layout from the following options before you can start duplex copying. The layout of your document determines which 2-sided copy layout you should choose.

### ■ 2side~2side

Portrait




Landscape




### ■ 1side~2side Long Edge Flip

Portrait




Landscape




### ■ 2side~1side Long Edge Flip

Portrait




Landscape




### ■ 1side~2side Short Edge Flip

Portrait




Landscape




### ■ 2side~1side Short Edge Flip

Portrait



Landscape



1 Press (COPY).

2 Load your document.

3 Enter the number of copies you want.

- 4 Press **◀** or **▶** to display Duplex Copy.  
Press Duplex Copy.
- 5 Press **◀** or **▶** to display the following layout options:  
2side→2side,  
1side→2side LongEdgeFlip,  
2side→1side LongEdgeFlip,  
1side→2side ShortEdgeFlip,  
2side→1side ShortEdgeFlip,  
Off  
  
Press the option you want.
- 6 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

## Tray selection

You can temporarily change the Tray Use option for the next copy.

- 1 Press  **(COPY)**.
  - 2 Load your document.
  - 3 Enter the number of copies you want.
  - 4 Press **◀** or **▶** to display **Tray Use**.  
Press **Tray Use**.
  - 5 Press **MP>T1**, **MP>T1>T2**<sup>1</sup>, **T1>MP**,  
**T1>T2>MP**<sup>1</sup>, **Tray#1 Only**,  
**Tray#2 Only**<sup>1</sup> or **MP Only**.
- <sup>1</sup> **T2 and Tray#2 Only** appears only if the optional lower tray is installed.
- 6 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.



### Note

To change the default setting for **Tray Use**, see *Tray Use in copy mode* in *Chapter 2* of the *Basic User's Guide*.

## Adjusting Brightness and Contrast

### Brightness

Adjust the copy brightness to make copies darker or lighter.

- 1 Press  (COPY).
- 2 Load your document.
- 3 Enter the number of copies you want.
- 4 Press **◀** or **▶** to display Brightness. Press Brightness.
- 5 Press **◀** to make a darker copy or press **▶** to make a lighter copy. Press OK.
- 6 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

### Contrast

Adjust the contrast to help an image look sharper and more vivid.

- 1 Press  (COPY).
- 2 Load your document.
- 3 Enter the number of copies you want.
- 4 Press **◀** or **▶** to display Contrast. Press Contrast.
- 5 Press **◀** to decrease the contrast or press **▶** to increase the contrast. Press OK.
- 6 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

## Sorting copies using the ADF

You can sort multiple copies. Pages will be stacked in the order 1 2 3, 1 2 3, 1 2 3, and so on.

- 1 Press  (COPY).
- 2 Load your document in the ADF.
- 3 Enter the number of copies you want.
- 4 Press **◀** or **▶** to display Stack / Sort. Press Stack / Sort.
- 5 Press Sort.
- 6 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.



### Note

Sort is available only when the document is in the ADF.

## Making N in 1 copies (page layout)

You can reduce the amount of paper used when copying by using the N in 1 copy feature. This allows you to copy two or four pages onto one page. If you want to copy both sides of an ID card onto one page, see *2 in 1 ID Copy* on page 17.

### ! IMPORTANT

- Please make sure the paper size is set to Letter, A4, Legal or Folio.
- You cannot use the Enlarge/Reduce setting with the N in 1 feature.
- (P) means Portrait and (L) means Landscape.

- 1 Press (COPY).
- 2 Load your document.
- 3 Enter the number of copies you want.
- 4 Press or to display Page Layout. Press Page Layout.
- 5 Press or to display Off (1in1), 2in1(P), 2in1(L), 2in1(ID)<sup>1</sup>, 4in1(P) or 4in1(L). Press the button you want.

<sup>1</sup> For details about 2in1(ID), see *2 in 1 ID Copy* on page 17.

- 6 If you do not want to change additional settings, press **Mono Start** or **Colour Start** to scan the page. If you placed the document in the ADF, the machine scans the pages and starts printing.

If you are using the scanner glass, go to step 7.

- 7 After the machine scans the page, press Yes to scan the next page.

8 Put the next page on the scanner glass. Press **Mono Start** or **Colour Start**. Repeat steps 7 and 8 for each page of the layout.

9 After all the pages have been scanned, press No in step 7 to finish.


### If you are copying from the ADF:

Insert your document *face up* in the direction shown below:

#### ■ 2 in 1 (P)



#### ■ 2 in 1 (L)



#### ■ 4 in 1 (P)



#### ■ 4 in 1 (L)




## If you are copying from the scanner glass:

Insert your document *face down* in the direction shown below:

### ■ 2 in 1 (P)




### ■ 2 in 1 (L)



### ■ 4 in 1 (P)



### ■ 4 in 1 (L)



## 2 in 1 ID Copy

You can copy both sides of your identification card onto one page, keeping the original card size.




### Note

You can copy an identification card to the extent permitted under applicable laws. See *Unlawful use of copying equipment* in the *Safety and Legal Booklet*.

4

- 1 Press (COPY).
- 2 Place your identification card *face down* on the left side of the scanner glass.



- Even if a document is placed on the ADF, the machine scans the data from the scanner glass.

- 3 Enter the number of copies you want.
- 4 Press or to display Page Layout. Press Page Layout.
- 5 Press or to display 2in1 (ID). Press 2in1 (ID).
- 6 Press **Mono Start** or **Colour Start**. After the machine scans the first side of the card, the LCD will display Turn over the ID Card Then Press Start.
- 7 Turn over your identification card and place it on the left side of the scanner glass.

- 8 Press **Mono Start** or **Colour Start**. The machine scans the other side of the card and prints the page.

 **Note**

When 2 in 1 ID Copy is chosen, the machine sets the quality to Photo and the contrast to +2.

## Adjusting Colour (Saturation)

You can change the default setting for colour saturation.

- 1 Press  **(COPY)**.
- 2 Load your document.
- 3 Enter the number of copies you want.
- 4 Press **◀** or **▶** to display Color Adjust. Press **Color Adjust**.
- 5 Press **Red**, **Green** or **Blue**.
- 6 Press **◀** to decrease or **▶** to increase the colour saturation. Press **OK**.
- 7 Repeat steps 5 and 6 if you want to adjust the next colour. Press .
- 8 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

## Setting your changes as the new default

You can save the copy settings for Quality, Brightness, Contrast and Color Adjust you use most often by setting them as the default. These settings will stay until you change them again.

- 1 Press  (COPY).
- 2 Press **◀** or **▶** to choose the setting you want to change, and then press the new option.  
Repeat this step for each setting you want to change.
- 3 After changing the last setting, press **◀** or **▶** to display Set New Default.  
Press Set New Default.
- 4 Press Yes.
- 5 Press Stop/Exit.

## Restoring all copy settings to the factory settings

You can restore all the copy settings you have changed to the factory settings. These settings will stay until you change them again.

- 1 Press  (COPY).
- 2 After changing the last setting, press **◀** or **▶** to display Factory Reset.  
Press Factory Reset.
- 3 Press Yes.
- 4 Press Stop/Exit.

## Setting your favourites

You can store the copy settings that you use most often by setting them as a favourite. You can set up to three favourites.

- 1 Press  (COPY).
- 2 Choose the copy option and settings you want to store.
- 3 Press **◀** or **▶** to display Favorite Settings.  
Press Favorite Settings.
- 4 Press Store.
- 5 Press the location where you want to store your setting for Favorite:1, Favorite:2 or Favorite:3.
- 6 Do one of the following:
  - If you want to rename your setting, press  to delete characters. Then enter the new name (up to 12 characters). Press OK.
  - If you do not want to rename your setting, press OK.
- 7 Press Stop/Exit.

## Retrieving your favourite setting

When you are ready to use one of your favourite set of settings, you can recall it.

- 1 Press  (COPY).
- 2 Press Favorite.
- 3 Press the favourite setting you want to retrieve.
- 4 Press Mono Start or Colour Start.

## Rename your favourite setting

After you stored your favourite setting, you can rename it.

- 1 Press  (COPY).
- 2 Press **◀** or **▶** to display Favorite Settings.  
Press Favorite Settings.
- 3 Press Rename.
- 4 Press the favourite setting you want to rename.
- 5 Enter the new name (up to 12 characters).
- 6 Press OK.
- 7 Press Stop/Exit.

# A

# Routine maintenance

## Cleaning and checking the machine

Clean the outside and inside of the machine regularly with a dry, lint-free cloth. When you replace the toner cartridge or the drum unit, make sure that you clean the inside of the machine. If printed pages are stained with toner, clean the inside of the machine with a dry, lint-free cloth.



### WARNING

DO NOT use cleaning materials that contain ammonia, alcohol, any type of spray, or any type of flammable substance to clean the outside or inside of the machine. Doing this may cause a fire or electrical shock.

See *To use the product safely* in the *Safety and Legal Booklet* for how to clean the machine.



Be careful not to inhale toner.



### IMPORTANT

Use neutral detergents. Cleaning with volatile liquids such as thinner or benzine will damage the surface of the machine.

## Checking the Page Counters

You can see the machine's Page Counters for copies, printed pages, reports and lists or a summary total.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display Machine Info..  
Press Machine Info..
- 3 Press Page Counter.  
The LCD shows number of pages for Total, List, Copy or Print.
- 4 Press Total, List, Copy or Print to see the page counters for Colour and Black & White.
- 5 Do one of the following:
  - To see the other options, press □.
  - To exit, press Stop/Exit.

A

## Checking the remaining life of parts

You can see the machine's parts life on the LCD.

- 1 Press MENU.
- 2 Press ▲ or ▼ to display Machine Info..  
Press Machine Info..
- 3 Press Parts Life.
- 4 Press ▲ or ▼ to see the approximate remaining parts life of the Drum, Belt Unit, Fuser, Laser, PF Kit MP, PF Kit 1 and PF Kit 2.
- 5 Press Stop/Exit.

# Replacing periodic maintenance parts

The periodic maintenance parts will need to be replaced regularly to maintain the print quality. The parts listed below will have to be replaced after printing approximately 50,000 pages<sup>1</sup> for PF Kit MP and 100,000 pages<sup>1</sup> for PF Kit 1, PF Kit 2, Fuser and Laser. Please call your Brother dealer when the following messages appear on the LCD.


<sup>1</sup> A4 or Letter size single-sided pages.

LCD message	Description
Replace Parts Fuser Unit	Replace the fuser unit.
Replace Parts Laser Unit	Replace the laser unit.
Replace Parts PF Kit 1	Replace the paper feeding kit for the paper tray.
Replace Parts PF Kit 2	Replace the paper feeding kit for the lower tray (option).
Replace Parts PF Kit MP	Replace the paper feeding kit for the multi-purpose tray.

# Packing and shipping the machine

## ⚠ WARNING

This machine is heavy and weighs approximately 28.5 kg. To prevent possible injuries at least two people should lift the machine. Be careful not to pinch your fingers when you put the machine down.



If you use a Lower Tray, carry it separately from your machine.


## ❗ IMPORTANT

When shipping the machine, the waste toner box must be removed from the machine and put in a plastic bag, and then sealed. Failure to remove it and put it in a plastic bag before shipping may cause severe damage to the machine and may void the warranty.

### Note

If for any reason you must ship your machine, carefully repack the machine in the original packaging to avoid any damage during transit. The machine should be adequately insured with the carrier.


Make sure that you have the following parts for repacking:




- 1 Plastic bag for the waste toner box
- 2 Orange packing materials for locking the internal parts (4 pieces)
- 3 A piece of paper (A4 or Letter) to protect the belt unit (Please supply this yourself)

A


- 1 Turn off the machine. Disconnect all cables, and then unplug the power cord from the electrical socket.
- 2 Press the front cover release button and then open the front cover.



- 3 Hold the green handle of the drum unit. Pull the drum unit out until it stops.




- 4 Turn the green lock lever (1) at the left of the machine anticlockwise to the release position. Holding the green handles of the drum unit, lift the front of the drum unit and remove it from the machine.




## ! IMPORTANT

- Hold the green handles of the drum unit when you carry it. DO NOT hold the sides of the drum unit.
- We recommend that you place the drum unit on a clean, flat surface with a piece of disposable paper underneath it in case you accidentally spill or scatter toner.
- Handle the toner cartridge and the waste toner box carefully. If toner scatters on your hands or clothes, wipe or wash it off with cold water.
- To prevent damage to the machine from static electricity, DO NOT touch the electrodes shown in the illustration.






A

- 5 Hold the green handle of the belt unit with both hands and lift the belt unit up, then pull it out.




- 6 Remove the two pieces of orange packing material and discard them.



 **Note**

This step is only necessary when you are replacing the waste toner box for the first time, and is not required for the replacement waste toner box. The orange packing pieces are installed at the factory to protect your machine during shipment from the factory.



- 7 Remove the waste toner box from the machine using the green handle, and then put it in a plastic bag and seal the bag completely.



**! IMPORTANT**

Handle the waste toner box carefully. If toner scatters on your hands or clothes, wipe or wash it off with cold water.





- 8 Put the belt unit back into the machine. Make sure the belt unit is level and fits firmly into place.




A

9 Install orange packing materials to the drum unit as follows:


- To secure the toner cartridges, install the matching orange packing strips (1) (marked L and R) to the drum unit on the left and right sides, as shown in the illustration.
- Attach the orange packing strip (2) to the left side of the drum unit, as shown in the illustration.
- Slide the small orange packing material (3) onto the metal shaft on the right side of the drum unit, as shown in the illustration.




- 10 Put a piece of paper (A4 or Letter) on the belt unit to prevent damage to the belt unit.




- 11 Make sure the green lock lever (1) is in the release position as shown in the illustration.



- 12 Match the guide ends (2) of the drum unit to the ▶ marks (1) on both sides of the machine, then gently slide the drum unit into the machine until it stops at the green lock lever.





- 13 Turn the green lock lever (1) clockwise to the lock position.




A

- 14 Push the drum unit in until it stops.





- 15 Close the front cover of the machine.


- 16 Put the Styrofoam piece (2) into the lower carton (1). Then put the waste toner box in the Styrofoam piece.





- 17 Wrap the machine with a plastic bag. Put the machine on the Styrofoam piece (1).



- 18 Put the Styrofoam piece (2) into the back side of Styrofoam piece (1) as shown in the illustration.




- 19 Place the upper carton (1) over the machine and the lower carton (2). Align the joint holes of the upper carton with the joint holes of the lower carton. Secure the upper carton to the lower carton using the four plastic joints (3) as shown in the illustration.



A

- 20 Put the two Styrofoam pieces (1) into the carton matching the right of the machine to the "RIGHT" mark on one of the Styrofoam pieces, and the left of the machine to the "LEFT" mark on the other Styrofoam piece. Put the AC power cord and printed materials in the original carton as shown in the illustration.




- 21 Close the carton and tape it shut.

## Optional paper tray (LT-300CL)

An optional lower tray can be installed, and it can hold up to 500 sheets of 80 g/m<sup>2</sup> paper.

When an optional tray is installed, the machine can hold up to 800 sheets of plain paper.



For setup, see the Instructions that we have supplied with the lower tray unit.

## Memory board

DCP-9270CDN has 256 MB of standard memory. The machine has one slot for optional memory expansion. You can increase the memory up to maximum of 512 MB by installing one SO-DIMM (Small Outline Dual In-line Memory Module).

### SO-DIMM Types

You can install the following SO-DIMMs:

- 128 MB Kingston KTH-LJ2015/128
- 256 MB Kingston KTH-LJ2015/256
- 128 MB Transcend TS128MHP422A
- 256 MB Transcend TS256MHP423A



#### Note

- For more information, visit the Kingston Technology website at <http://www.kingston.com/>.
- For more information, visit the Transcend website at <http://www.transcend.com.tw/>.

In general, the SO-DIMM must have the following specifications:

Type: 144-pin and 16-bit output

CAS latency: 4

Clock frequency: 267 MHz (533 Mb/S/Pin) or more

Capacity: 64, 128 or 256 MB

Height: 30.0 mm (1.18 in.)

DRAM type: DDR2 SDRAM



#### Note

- There might be some SO-DIMMs that will not work with the machine.
- For more information, call the dealer you bought the machine from or Brother Customer Service.

## Installing extra memory


- 1 Turn off the machine's power switch.
- 2 Disconnect the interface cable from the machine, and then unplug the power cord from the electrical socket.



### Note

Be sure to turn off the machine's power switch before you install or remove the SO-DIMM.

- 3 Remove the plastic (1) and then metal (2) SO-DIMM covers.




- 4 Unpack the SO-DIMM and hold it by its edges.


### ! IMPORTANT

To prevent damage to the machine from static electricity, DO NOT touch the memory chips or the board surface.

- 5 Hold the SO-DIMM by the edges and align the notches in the SO-DIMM with the protrusions in the slot. Insert the SO-DIMM diagonally (1), then tilt it toward the interface board until it clicks into place (2).



- 6 Put the metal (2) and then the plastic (1) SO-DIMM covers back on.



- 7 Plug the machine's power cord back into the electrical socket first, and then connect the interface cable.
- 8 Turn on the machine's power switch.

**Note**

To make sure that you have installed the SO-DIMM properly, you can print the user settings page that shows the current memory size. (See *User Settings Report* on page 4.)

# C

# Glossary

This is a comprehensive list of features and terms that appear in Brother manuals. Availability of these features depends on the model you purchased.

## **Beeper Volume**

Volume setting for the beep when you press a key or make an error.

## **Cancel Job**

Cancels a programmed print job and clears the machine's memory.

## **Fine resolution**

Resolution is 203 × 196 dpi. It is used for small print and graphs.

## **Greyscale**

The shades of grey available for copying.

## **Help List**

A printout of the complete Menu table that you can use to program your machine when you do not have the User's Guides with you.

## **LCD (liquid crystal display)**

The display screen on the machine that shows interactive messages during On-Screen Programming and shows the date and time when the machine is idle.

## **Menu mode**

Programming mode for changing your machine's settings.

## **OCR (optical character recognition)**

ScanSoft™ PaperPort™ 12SE with OCR or Presto! PageManager software application converts an image of text to text you can edit.

## **Resolution**

The number of vertical and horizontal lines per inch.

## **Scanning**

The process of sending an electronic image of a paper document into your computer.

## **Search**

An electronic, alphabetical listing of LDAP entries.

## **Temporary settings**

You can choose certain options for each copy without changing the default settings.

## **User Settings List**

A printed report that shows the current settings of the machine.

# D

# Index

## A

Apple Macintosh  
See Software User's Guide.

## C

ControlCenter2 (for Macintosh)

See Software User's Guide.

ControlCenter4 (for Windows®)

See Software User's Guide.

Copy

2 in 1 ID Copy .....	17
brightness .....	15
contrast .....	15
Enlarge/Reduce .....	12
key .....	11
N in 1 (page layout) .....	16
quality .....	11
sort (ADF only) .....	15
temporary settings .....	11
using ADF .....	15
using scanner glass .....	16

## D

Daylight Savings Time .....	1
Deep Sleep mode .....	3
Drum unit	
checking (remaining life) .....	21
Duplex copy .....	13

## E

Enlarge/Reduce .....	12
----------------------	----

## L

LCD (liquid crystal display)	
backlight brightness .....	3

## M

Machine information

checking remaining life of parts .....	21
page counts .....	21

Macintosh

See Software User's Guide.

Maintenance, routine .....

checking the remaining life of parts .....	21
--	----

Memory

adding DIMM (option) .....	33
installing .....	34
storage .....	1

## N

N in 1 (page layout) .....	16
----------------------------	----

Network

printing

    See Network User's Guide.

scanning

    See Software User's Guide.

## P

Page layout (N in 1) .....	16
----------------------------	----

PaperPort™ 12SE with OCR

    See Software User's Guide and Help in the PaperPort™ 12SE application to access How-to-Guides.

Power failure .....	1
---------------------	---

Presto! PageManager

    See Software User's Guide. See also Help in the Presto! PageManager application.

Printing

    See Software User's Guide.

## Q

Quality

copying .....	11
---------------	----

## D

## R

---

Reducing copies .....	12
Remote setup	
See Software User's Guide.	
Reports	
Network Configuration .....	4, 10
Restricted users .....	7

## S

---

Scanning	
See Software User's Guide.	
Security	
Secure function lock	
administrator password .....	5
Public user mode .....	6
restricted users .....	7
Sleep mode .....	2
Sort .....	15

## T

---

Temporary copy settings .....	11
Toner Save .....	2

## W

---

Windows®	
See Software User's Guide.	

# brother®

This machine is approved for use in the country of purchase only. Local Brother companies or their dealers will only support machines purchased in their own countries.