


## BASIC USER'S GUIDE



DCP-J515W DCP-J715W

## If you need to call Customer Service

Please complete the following information for future reference:

Model Number: DCP-J515W, DCP-J715W (Circle your model number)

Serial Number: <sup>1</sup>
Date of Purchase:

Place of Purchase:

The serial number is on the back of the unit. Retain this User's Guide with your sales receipt as a permanent record of your purchase, in the event of theft, fire or warranty service.

### Register your product on-line at

http://www.brother.com/registration/

By registering your product with Brother, you will be recorded as the original owner of the product. Your registration with Brother:

- may serve as confirmation of the purchase date of your product should you lose your receipt; and
- may support an insurance claim by you in the event of product loss covered by insurance.

## **User's Guides and where do I find it?**

Which manual?	What's in it?	Where is it?
Safety and Legal	Please read the Safety Instructions before you set up your machine.	Printed / In the box
Quick Setup Guide	Read this Guide first. Follow the instructions for setting up your machine and installing the drivers and software for the operating system and connection type you are using.	Printed / In the box
Basic User's Guide	Learn the basic Copy, Scan and PhotoCapture Center™ operations and how to replace consumables. See troubleshooting tips.	Printed / In the box
Advanced User's Guide	Learn more advanced operations: Copy, printing reports and performing routine maintenance.	PDF file / Documentation CD-ROM
Software User's Guide	Follow these instructions for Printing, Scanning, Network Scanning, PhotoCapture Center™, and using the Brother ControlCenter utility.	PDF file / Documentation CD-ROM
Network User's Guide	This Guide provides more advanced information for configuring the Ethernet and Wireless network connections. In addition, find information about network utilities, network printing, troubleshooting tips and supported network specifications.	PDF file / Documentation CD-ROM

# **Table of Contents** (BASIC USER'S GUIDE)

1	General information	1
	Using the documentation	1
	Symbols and conventions used in the documentation	1
	Accessing the Advanced User's Guide, Software User's Guide and	
	Network User's Guide	1
	Viewing Documentation	
	Accessing Brother Support (Windows®)	3
	Accessing Brother Support (Macintosh)	3
	Control panel overview	4
	LCD display indications	5
	Basic Operations	6
	Warning LED indications	6
	LCD display	7
	Setting the backlight brightness	7
2	Loading paper	8
	2.1.1	
	Loading paper and other print media	
	Loading envelopes and postcards	
	Loading photo paper	
	Removing small printouts from the machine	
	Printable area	
	Paper settings	
	Paper Type	
	Paper Size	
	Acceptable paper and other print media	
	Recommended print media	
	Handling and using print media	
	Choosing the right print media	19
3	Loading documents	21
	How to load documents	21
	Using the ADF (DCP-J715W only)	
	Using the scanner glass	
	Scannable area	
4	Making copies	23
	How to copy	23
	Stop copying	
	Copy settings	
	Paper options	
	·	

5	Printing photos from a memory card or USB Flash memory drive	25
	PhotoCapture Center™ Operations	
	Using a memory card or USB Flash memory drive	
	Getting started	
	Print Images	
	View Photos	
	PhotoCapture Center™ print settings How to scan to a memory card or USB Flash memory drive	
6	How to print from a computer	31
	Printing a document	31
7	How to scan to a computer	32
	Scanning a document	
	Scanning using the scan key	
	Scanning using a scanner driver	32
Α	Routine maintenance	33
	Replacing the ink cartridges	33
	Cleaning and checking the machine	
	Cleaning the scanner glass	35
	Cleaning the paper pick-up rollers	36
	Cleaning the print head	37
	Checking the print quality	
	Checking the print alignment	38
В	Troubleshooting	39
	Error and Maintenance messages	39
	Error animation	
	Document jam (DCP-J715W only)	
	Printer jam or paper jam	
	Troubleshooting	
	If you are having difficulty with your machine	
	Machine Information	
	Checking the serial number	
	Reset functions  How to reset the machine	
	now to reset the machine	31
С	Menu and features	52
	On-screen programming	
	Menu table	
	Entering Text	
	Inserting special characters	
	IVIANITY CUITECTIONS	

D	Specifications	69
	General	
	Print media	71
	Copy	72
	PhotoCapture Center™	73
	PictBridge (DCP-J715W only)	74
	Scanner	75
	Printer	
	Interfaces	77
	Computer requirements	78
	Consumable items	79
	Network (LAN)	80
E	Index	81

# Table of Contents (ADVANCED USER'S GUIDE)

The Advanced User's Guide explains the following features and operations.

You can view the Advanced User's Guide on the Documentation CD-ROM.

### 1 General setup

Memory storage Sleep Mode LCD display

### 2 Printing reports

Reports

#### 3 Making copies

Copy settings

## 4 Printing photos from a memory card or USB Flash memory drive

PhotoCapture Center™ operations
Print Images
PhotoCapture Center™ print settings
Scan to a memory card or USB Flash
memory drive

## 5 Printing photos from a camera (DCP-J715W only)

Printing photos directly from a PictBridge camera Printing photos directly from a digital camera (without PictBridge)

#### A Routine maintenance

Cleaning and checking the machine Packing and shipping the machine

### **B** Glossary

#### C Index

## 1

## **General information**

## Using the documentation

Thank you for buying a Brother machine! Reading the documentation will help you make the most of your machine.

## Symbols and conventions used in the documentation

The following symbols and conventions are used throughout the documentation.

**Bold** Bold typeface identifies specific

buttons on the machine's control panel, or on the computer screen.

Italicized typeface emphasizes

an important point or refers you

to a related topic.

Courier New Text in the Courier New font identifies messages on the LCD of the machine.



### **WARNING**

<u>WARNING</u> indicates a potentially hazardous situation which, if not avoided, could result in death or serious injuries.



### CAUTION

<u>CAUTION</u> indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injuries.



### **IMPORTANT**

<u>IMPORTANT</u> indicates a potentially hazardous situation which may result in property-damage-only accidents or loss of product functionality.



Notes tell you how you should respond to a situation that may arise or give tips about how the operation works with other features.



Electrical Hazard icons alert you to possible electrical shock.

## Accessing the Advanced User's Guide, Software User's Guide and Network User's Guide

This Basic User's Guide does not contain all the information about the machine such as how to use the advanced features for Copy, PhotoCapture Center™, Printer, Scanner and Network. When you are ready to learn detailed information about these operations, read the Advanced User's Guide, Software User's Guide and Network User's Guide that are on the Documentation CD-ROM.

## **Viewing Documentation**



Turn on your computer. Insert the Documentation CD-ROM into your CD-ROM drive.




(Windows<sup>®</sup> users)
If the screen does not appear automatically, go to

My Computer (Computer), double-click the CD-ROM icon, and then double-click index.html.



(Macintosh users)
Double-click the CD-ROM icon, and then double-click **index.html**.

3 Click your country.



4 Point to your language, point to **View Guide**, and then click the guide you want to read.







- (Windows<sup>®</sup> users only)
   Your web browser may display a yellow bar at the top of the page that contains a security warning about Active X controls. For the page to display correctly you must click on the bar, click Allow Blocked Content, then click Yes in the Security Warning dialog box.
- (Windows<sup>®</sup> users only) <sup>1</sup>
   For faster access, you can copy all user documentation in PDF format to a local folder on your computer. Point to your language, then click Copy to local disk.
  - Microsoft<sup>®</sup> Internet Explorer<sup>®</sup> 6.0 or greater.

### How to find Scanning instructions

There are several ways you can scan documents. You can find the instructions as follows:

#### Software User's Guide

- Scanning
- ControlCenter
- Network Scanning

## ScanSoft™ PaperPort™11SE with OCR How-to-Guides (DCP-J715W only)

■ The complete ScanSoft<sup>™</sup>
PaperPort<sup>™</sup>11SE with OCR
How-to-Guides can be viewed from the
Help selection in the ScanSoft<sup>™</sup>
PaperPort<sup>™</sup>11SE application.

## Presto! PageManager User's Guide (DCP-J715W only)



Presto! PageManager must be downloaded and installed before use. See *Accessing Brother Support (Macintosh)* on page 3 for further instructions.

The complete Presto! PageManager User's Guide can be viewed from the Help selection in the Presto! PageManager application.

## How to find Network setup instructions

Your machine can be connected to a wireless or wired network. (Wired network is not available for DCP-J515W model.) You can find basic setup instructions in the Quick Setup Guide. If your wireless access point or router supports Wi-Fi Protected Setup or AOSS™, follow the steps in the Quick Setup Guide. For more information about network setup please see the *Network User's Guide* on the Documentation CD-ROM.

# Accessing Brother Support (Windows®)

You can find all the contacts you will need, such as Web support (Brother Solutions Center) on the Installation CD-ROM.

Click Brother Support on the Top Menu. The following screen will appear:



- To access our website (<a href="http://www.brother.com">http://www.brother.com</a>), click Brother Home Page.
- For the latest news and product support information (<a href="http://solutions.brother.com/">http://solutions.brother.com/</a>), click
   Brother Solutions Center.
- To visit our website for original Brother Supplies (<u>http://www.brother.com/original/</u>), click Supplies Information.
- To access the Brother CreativeCenter (<a href="http://www.brother.com/creativecenter/">http://www.brother.com/creativecenter/</a>) for FREE photo projects and printable downloads, click

**Brother CreativeCenter.** 

■ To return to the **Top Menu**, click **Back** or if you have finished, click **Exit**.

# Accessing Brother Support (Macintosh)

You can find all the contacts you will need, such as Web support (Brother Solutions Center) on the Installation CD-ROM.


■ Double-click the **Brother Support** icon. The following screen will appear:



- (DCP-J715W only)
  To download and install Presto!
  PageManager, click
  Presto! PageManager.
- To register your machine from the Brother Product Register Page (<u>http://www.brother.com/registration/</u>), click **On-Line Registration**.
- For the latest news and product support information (<a href="http://solutions.brother.com/">http://solutions.brother.com/</a>), click
   Brother Solutions Center.
- To visit our website for original Brother Supplies (<a href="http://www.brother.com/original/">http://www.brother.com/original/</a>), click Supplies Information.

## **Control panel overview**

The DCP-J515W and DCP-J715W have the same control panel keys.



#### 1 LCD (Liquid Crystal Display)

Displays messages on the screen to help you set up and use your machine.

Also, you can adjust the angle of the LCD screen by lifting it.

#### 2 Number of Copies

Use this key to make multiple copies.

#### 3 Menu keys:

#### ■ < or >

Press to scroll backward or forward to a menu selection.

Also, press to choose options.

#### ■ A or ▼

Press to scroll through the menus and options.

#### ■ Clear

Press to go back to the previous menu level.

#### ■ Menu

Lets you access the main menu to program the machine.

#### ■ OK

Lets you confirm a selection.

#### 4 Start keys:

## ■ Mono Start

Lets you start making copies in monochrome. Also lets you start a scanning operation (in colour or mono, depending on the scanning setting in the ControlCenter software).

## ■ Colour Start

Lets you start making copies in full colour. Also lets you start a scanning operation (in colour or mono, depending on the scanning setting in the ControlCenter software).

## 5 Stop/Exit

Stops an operation or exits from a menu.

#### 6 On/Off

You can turn the machine on and off.

If you turn the machine off, it will still
periodically clean the print head to maintain
print quality. To prolong print head life, provide
the best ink cartridge economy, and maintain
print quality, you should keep your machine
connected to the power at all times.

#### 7 Mode keys:

■ SCAN

Lets you access Scan mode.

■ PHOTO CAPTURE

Lets you access PhotoCapture Center™ mode.

## 8 Warning LED


Turns orange and blinks when the LCD displays an error or an important status message.



Most of the illustrations in this User's Guide show the DCP-J515W.

## LCD display indications

The LCD display shows the mode the machine is in, the current settings, and the available ink volume.



#### 1 Ink indicator

Lets you see the available ink volume.

#### 2 Memory Status

Lets you see the available memory in the machine.

#### 3 Wireless Status

A four level indicator shows the current wireless signal strength if you are using a wireless connection.



The warning icon ! appears when there is an error or a maintenance message. For details, see *Error and Maintenance messages* on page 39.

## **Basic Operations**

The following steps show how to change a setting in the machine. In this example the Paper Type setting is changed from

Plain Paper to Inkjet Paper.


- 1 Press Menu.
- Press ▲ or ▼ to choose General Setup.



Press OK.

- 3 Press ▲ or ▼ to choose Paper Type.
- 4 Press ◀ or ▶ to choose Inkjet Paper.
  Press OK.

You can see the current setting on the LCD:



5 Press Stop/Exit.

## **Warning LED indications**

The Warning LED (light emitting diode) is a light that shows the status of the machine, as shown in the table.



LED	DCP status	Description
ð	Ready	The DCP is ready for use.
Off		
Orango	Cover open	The cover is open. Close the cover. (See <i>Error</i> and <i>Maintenance</i> messages on page 39.)
Orange	Cannot Print	Replace the ink cartridge with a new one. (See Replacing the ink cartridges on page 33.)
	Paper error	Put paper in the tray or clear the paper jam. Check the LCD message. (See Error and Maintenance messages on page 39.)
	Other messages	Check the LCD message. (See Error and Maintenance messages on page 39.)

## **LCD** display

## Setting the backlight brightness

If you are having difficulty reading the LCD, try changing the brightness setting.

- 1 Press Menu.
- Press ▲ or ▼ to choose
  General Setup.
  Press OK.
- 3 Press A or ▼ to choose LCD Settings. Press OK.
- 4 Press A or V to choose Backlight.
- Press ◀ or ▶ to choose Light, Med or Dark.
  Press OK.
- 6 Press Stop/Exit.


## Loading paper

## Loading paper and other print media




To print on Photo ( $10 \times 15$  cm) or Photo L ( $89 \times 127$  mm) paper, you must use the photo paper tray. (See *Loading photo paper* on page 12.)

1 If the paper support flap is open, close it, and then close the paper support. Pull the paper tray completely out of the machine.




2 Lift the output paper tray cover (1).




With both hands, gently press and slide the paper side guides (1) and then the paper length guide (2) to fit the paper size.

Make sure that the triangular marks (3) on the paper side guides (1) and paper length guide (2) line up with the marks for the paper size you are using.






When you use Legal size paper, press and hold the universal guide release button (1) as you slide out the front of the paper tray.




Fan the stack of paper well to avoid paper jams and misfeeds.



## IMPORTANT

Always make sure that the paper is not curled.

Gently put the paper into the paper tray print side down and top edge in first.
Check that the paper is flat in the tray.




## IMPORTANT


Be careful that you do not push the paper in too far; it may lift at the back of the tray and cause feed problems.

6 Gently adjust the paper side guides (1) to fit the paper with both hands.


Make sure the paper side guides touch the sides of the paper.



Close the output paper tray cover.



8 Slowly push the paper tray completely into the machine.



9 While holding the paper tray in place, pull out the paper support (1) until it clicks, and then unfold the paper support flap (2).



## IMPORTANT

DO NOT use the paper support flap for Legal size paper.

## Loading envelopes and postcards


### About envelopes

- Use envelopes that weigh between 80 to 95 g/m².
- Some envelopes need margin settings to be set in the application. Make sure you do a test print first before printing many envelopes.

## ! IMPORTANT

DO NOT use any of the following types of envelopes, as they will cause paper feed problems:

- That are of a baggy construction.
- That are embossed (have raised writing on them).
- · That have clasps or staples.
- That are pre-printed on the inside.



Occasionally you may experience paper feed problems caused by the thickness, size and flap shape of the envelopes you are using.

### How to load envelopes and postcards

1 Before loading, press the corners and sides of envelopes or postcards to make them as flat as possible.

## ! IMPORTANT


If envelopes or postcards are "double-feeding", put one envelope or postcard in the paper tray at a time.








Put envelopes or postcards in the paper tray with the address side down and the leading edge (top of the envelopes) in first. With both hands, gently press and slide the paper side guides (1) and paper length guide (2) to fit the size of the envelopes or postcards.



### If you have problems printing on envelopes with the flap on the short edge, try the following suggestions:

- Open the envelope flap.
- Put the envelope into the paper tray with the address side down and the flap positioned as shown in the illustration.




3 Adjust the size and margin in your application.

## Loading photo paper


Use the photo paper tray which has been assembled on the top of the output paper tray cover to print on Photo ( $10 \times 15$  cm) and Photo L ( $89 \times 127$  mm) size paper. When you use the photo paper tray, you do not have to take out the paper that is in the tray beneath it.

1 Squeeze the blue photo paper tray release button (1) using your right index finger and thumb and push the photo paper tray forward until it clicks into the photo printing position (2).



**Photo Paper Tray** 

Press and slide the paper side guides (1) and paper length guide (2) to fit the paper size.



3 Put the photo paper into the photo paper tray and gently adjust the paper side guides to the paper.


Make sure the paper side guides touch the sides of the paper. Check that the paper is flat in the tray.



- Be careful that you do not push the paper in too far; it may lift at the back of the tray and cause feed problems.
- Always make sure that the paper is not curled or wrinkled.

When you have finished printing photos return the photo paper tray to the *Normal* printing position.

Squeeze the blue photo paper tray release button (1) using your right index finger and thumb and pull the photo paper tray back until it clicks (2).



## • IMPORTANT

If you do not return the photo paper tray to the *Normal* printing position after printing photos, you will get a No Paper Fed error when you use standard paper.




Photo paper tray in the normal printing position





Photo paper tray in the photo printing position

## Removing small printouts from the machine


When the machine ejects small paper onto the output paper tray cover you may not be able to reach it. Make sure printing has finished, and then pull the tray completely out of the machine.




## Printable area

The printable area depends on the settings in the application you are using. The figures below show the unprintable areas on cut sheet paper and envelopes. The machine can print in the shaded areas of cut sheet paper when the Borderless print feature is available and turned on. (See *Printing* for Windows<sup>®</sup> or *Printing* and *Faxing* for Macintosh in the *Software User's Guide*.)

### **Cut Sheet Paper**



### **Envelopes**



	Top (1)	Bottom (2)	Left (3)	Right (4)
Cut Sheet	3 mm	3 mm	3 mm	3 mm
Envelopes	12 mm	24 mm	3 mm	3 mm



The Borderless feature is not available for envelopes.

## **Paper settings**

## **Paper Type**

To get the best print quality, set the machine for the type of paper you are using.

- 1 Press Menu.
- Press ▲ or ▼ to choose

  General Setup.

  Press OK.
- 3 Press ▲ or ▼ to choose Paper Type.
- 4 Press ◀ or ▶ to choose Plain Paper, Inkjet Paper, Brother BP71, Brother BP61, Other Glossy Or Transparency.
  Press OK.

5 Press Stop/Exit.



The machine ejects paper with printed surfaces face up onto the paper tray in front of the machine. When you use transparencies or glossy paper, remove each sheet at once to prevent smudging or paper jams.

## **Paper Size**

You can use five sizes of paper for printing copies: A4, A5, Letter, Legal and  $10 \times 15$  cm. When you load a different size of paper in the machine, you will need to change the paper size setting at the same time.

- 1 Press Menu.
- Press ▲ or ▼ to choose
  General Setup.
  Press OK.
- 3 Press ▲ or ▼ to choose Paper Size.
- Press ◀ or ▶ to choose A4, A5, 10x15cm, Letter or Legal. Press OK.
- 5 Press Stop/Exit.

## Acceptable paper and other print media

The print quality can be affected by the type of paper you use in the machine.

To get the best print quality for the settings you have chosen, always set the Paper Type to match the type of paper you load.

You can use plain paper, inkjet paper (coated paper), glossy paper, transparencies and envelopes.

We recommend testing various paper types before buying large quantities.

For best results, use Brother paper.

- When you print on inkjet paper (coated paper), transparencies and glossy paper, be sure to choose the correct print media in the "Basic" tab of the printer driver or in the Paper Type setting of the menu. (See Paper Type on page 24.)
- When you print on Brother photo paper, load one extra sheet of the same photo paper in the paper tray. An extra sheet has been included in the paper package for this purpose.
- When you use transparencies or photo paper, remove each sheet at once to prevent smudging or paper jams.
- Avoid touching the printed surface of the paper immediately after printing; the surface may not be completely dry and may stain your fingers.

## Recommended print media

To get the best print quality, we suggest using Brother paper. (See the table below.)

If Brother paper is not available in your country, we recommend testing various papers before purchasing large quantities.

We recommend using "3M Transparency Film" when you print on transparencies.

#### **Brother paper**

Paper Type	Item
A4 Plain	BP60PA
A4 Glossy Photo	BP71GA4
A4 Inkjet (Matte)	BP60MA
10 × 15 cm Glossy	BP71GP


## Handling and using print media

- Store paper in its original packaging, and keep it sealed. Keep the paper flat and away from moisture, direct sunlight and heat.
- Avoid touching the shiny (coated) side of photo paper. Load photo paper with the shiny side facing down.
- Avoid touching either side of transparencies because they absorb water and perspiration easily, and this may cause decreased output quality. Transparencies designed for laser printers/copiers may stain your next document. Use only transparencies recommended for inkjet printing.

## ! IMPORTANT

DO NOT use the following kinds of paper:

 Damaged, curled, wrinkled, or irregularly shaped paper



- 1 2 mm or greater curl may cause jams to occur.
- Extremely shiny or highly textured paper
- Paper that cannot be arranged uniformly when stacked
- · Paper made with a short grain

## Paper capacity of the output paper tray cover

Up to 50 sheets of 80 g/m<sup>2</sup> A4 paper.

Transparencies and photo paper must be picked up from the output paper tray cover one page at a time to avoid smudging.

## **Choosing the right print media**

## Paper type and size for each operation

Paper Type	Paper Size		Usage	Usage		
			Сору	Photo Capture	Printer	
Cut Sheet	A4	210 × 297 mm (8.3 × 11.7 in.)	Yes	Yes	Yes	
	Letter	215.9 $\times$ 279.4 mm (8 1/2 $\times$ 11 in.)	Yes	Yes	Yes	
	Legal	215.9 $\times$ 355.6 mm (8 1/2 $\times$ 14 in.)	Yes	_	Yes	
	Executive	184 $\times$ 267 mm (7 1/4 $\times$ 10 1/2 in.)	_	_	Yes	
	JIS B5	$182 \times 257 \text{ mm } (7.2 \times 10.1 \text{ in.})$	_	_	Yes	
	A5	148 $\times$ 210 mm (5.8 $\times$ 8.3 in.)	Yes	_	Yes	
	A6	$105 \times 148 \text{ mm } (4.1 \times 5.8 \text{ in.})$	_	_	Yes	
Cards	Photo	10 × 15 cm (4 × 6 in.)	Yes	Yes	Yes	
	Photo L	$89\times127$ mm (3 1/2 $\times$ 5 in.)	_	_	Yes	
	Photo 2L	$13 \times 18$ cm (5 × 7 in.)	_	Yes	Yes	
	Index Card	127 $\times$ 203 mm (5 $\times$ 8 in.)	_	_	Yes	
	Postcard 1	100 $\times$ 148 mm (3.9 $\times$ 5.8 in.)	_	_	Yes	
	Postcard 2 (Double)	148 $\times$ 200 mm (5.8 $\times$ 7.9 in.)	_	_	Yes	
Envelopes	C5 Envelope	162 × 229 mm (6.4 × 9 in.)	_	_	Yes	
	DL Envelope	$110 \times 220 \text{ mm } (4.3 \times 8.7 \text{ in.})$	_	_	Yes	
	COM-10	$105 \times 241 \text{ mm } (4  1/8 \times 9  1/2 \text{ in.})$	_	_	Yes	
	Monarch	98 $\times$ 191 mm (3 7/8 $\times$ 7 1/2 in.)	_	_	Yes	
	JE4 Envelope	$105 \times 235$ mm (4.1 $\times$ 9.3 in.)	_	_	Yes	
Transparencies	A4	210 × 297 mm (8.3 × 11.7 in.)	Yes	_	Yes	
	Letter	215.9 $\times$ 279.4 mm (8 1/2 $\times$ 11 in.)	Yes	_	Yes	
	Legal	215.9 $\times$ 355.6 mm (8 1/2 $\times$ 14 in.)	Yes	_	Yes	
	A5	$148 \times 210 \text{ mm } (5.8 \times 8.3 \text{ in.})$	Yes	_	Yes	

## Paper weight, thickness and capacity

Paper T	уре	Weight	Thickness	No. of sheets
Cut	Plain Paper	64 to 120 g/m <sup>2</sup>	0.08 to 0.15 mm	100 <sup>1</sup>
Sheet	Inkjet Paper	64 to 200 g/m <sup>2</sup>	0.08 to 0.25 mm	20
	Glossy Paper	Up to 220 g/m <sup>2</sup>	Up to 0.25 mm	20 <sup>2 3</sup>
Cards	Photo Card	Up to 220 g/m <sup>2</sup>	Up to 0.25 mm	20 <sup>2 3</sup>
	Index Card	Up to 120 g/m <sup>2</sup>	Up to 0.15 mm	30
	Postcard	Up to 200 g/m <sup>2</sup>	Up to 0.25 mm	30
Envelop	es	75 to 95 g/m <sup>2</sup>	Up to 0.52 mm	10
Transpa	rencies	_	-	10

Up to 100 sheets of 80 g/m<sup>2</sup> paper.

For Photo 10  $\times$  15 cm paper and Photo L 89  $\times$  127 mm paper, use the photo paper tray. (See *Loading photo paper* on page 12.)

<sup>&</sup>lt;sup>3</sup> BP71 260 g/m<sup>2</sup> paper is especially designed for Brother inkjet machines.

## 3

## **Loading documents**

## How to load documents

You can make copies and scan from the ADF (automatic document feeder) and from the scanner glass.

## Using the ADF (DCP-J715W only)

The ADF can hold up to 15 pages and feeds each sheet individually. Use standard 80 g/m<sup>2</sup> paper and always fan the pages before putting them in the ADF.

#### **Document Sizes Supported**

 Paper:
 80 g/m² A4

 Length:
 148 to 355.6 mm

 Width:
 148 to 215.9 mm

 Weight:
 64 to 90 g/m²


#### How to load documents

## ! IMPORTANT

- DO NOT pull on the document while it is feeding.
- DO NOT use paper that is curled, wrinkled, folded, ripped, stapled, paper clipped, pasted or taped.
- DO NOT use cardboard, newspaper or fabric.

Make sure documents written with ink are completely dry.

- 1 Unfold the ADF Document Output Support Flap (1).
- 2 Fan the pages well.
- 3 Adjust the paper guides (2) to fit the width of your document.
- 4 Make sure you place your documents, face down, top edge first in the ADF underneath the guides until you feel them touch the feed roller and the LCD shows ADF Ready.



## ! IMPORTANT

DO NOT leave thick documents on the scanner glass. If you do this, the ADF may jam.

## Using the scanner glass

You can use the scanner glass to copy or scan pages of a book or one page at a time.

### **Document Sizes Supported**

Length: Up to 297 mm

Width: Up to 215.9 mm


Weight: Up to 2 kg


#### How to load documents



To use the scanner glass, the ADF must be empty. (DCP-J715W only)

- 1 Lift the document cover.
- Using the document guidelines on the left and top, place the document face down in the upper left corner of the scanner glass.






Close the document cover.

## ! IMPORTANT

If you are scanning a book or thick document, DO NOT slam the cover down or press on it.

### Scannable area

The scannable area depends on the settings in the application you are using. The figures below show unscannable areas.



Usage	Document	Top (1)	Left (3)
	Size	Bottom (2)	Right (4)
Сору	A4	3 mm	3 mm
	Letter	3 mm	3 mm
Scan	A4	3 mm	3 mm
	Letter	3 mm	3 mm

## 4

## Making copies

## How to copy

The following steps show the basic copy operation. For details about each option, see the *Advanced User's Guide*.

- Do one of the following to load your document:
  - Place the document *face down* in the ADF. (DCP-J715W only)

(See Using the ADF (DCP-J715W only) on page 21.)

■ Load your document *face down* on the scanner glass.

(See *Using the scanner glass* on page 21.)

Press + or - repeatedly until the number of copies you want appears (up to 99).



1 No. of Copies





If you want to sort copies, use the ADF. (DCP-J715W only)

## Stop copying

To stop copying, press Stop/Exit.

## Copy settings

You can change the following copy settings. Press ▲ or ▼ to scroll through the copy settings. When the setting you want is highlighted, press **OK**.

#### (Basic User's Guide)

For details about changing the following copy settings, see page 24.

- Paper Type
- Paper Size

#### (Advanced User's Guide)

For details about changing the following copy settings, see chapter 3:

- Quality
- Enlarge/Reduce
- Density
- Ink Save Mode
- Stack/Sort (DCP-J715W only)
- Page Layout
- Book Copy
- Watermark Copy
- Set New Default
- Factory Reset

## **Paper options**

### **Paper Type**

If you are copying on special paper, set the machine for the type of paper you are using to get the best print quality.

- 1 Load your document.
- Enter the number of copies you want.
- 3 Press ▲ or ▼ to choose Paper Type.
- 4 Press ◀ or ▶ to choose Plain Paper, Inkjet Paper, Brother BP71, Brother BP61, Other Glossy Or Transparency.
  Press OK.
- If you do not want to change additional settings, press Mono Start or Colour Start.

## **Paper Size**

If you are copying on paper other than A4 size, you will need to change the paper size setting.

You can copy only on A4, Legal, Letter, A5 or Photo  $10 \times 15$  cm paper.

- 1 Load your document.
- 2 Enter the number of copies you want.
- 3 Press ▲ or ▼ to choose Paper Size.
- 4 Press ◀ or ▶ to choose A4, A5, 10x15cm, Letter or Legal. Press OK.
- 5 If you do not want to change additional settings, press **Mono Start** or **Colour Start**.

## 5

# Printing photos from a memory card or USB Flash memory drive

## PhotoCapture Center™ Operations



USB Flash memory is not available for DCP-J515W model.

Even if your machine is not connected to your computer, you can print photos directly from digital camera media or a USB Flash memory drive. (See *Print Images* on page 28.)

You can scan documents and save them directly to a memory card or USB Flash memory drive. (See How to scan to a memory card or USB Flash memory drive on page 29.)

You can access a memory card or USB Flash memory drive that is inserted in the front of the machine from your computer.

(See PhotoCapture Center™ for Windows® or Remote Setup & PhotoCapture Center™ for Macintosh in the Software User's Guide.)


## Using a memory card or USB Flash memory drive

Your Brother machine has media drives (slots) for use with the following popular digital camera media: Memory Stick™, Memory Stick PRO™, Memory Stick Duo™, Memory Stick PRO Duo™, SD, SDHC and USB Flash memory drives.

The PhotoCapture Center™ feature lets you print digital photos from your digital camera at high resolution to get photo quality printing.

## **Getting started**

Firmly put a memory card or USB Flash memory drive into the correct slot.



### 1 USB Flash memory drive (DCP-J715W only)



## ! IMPORTANT

The USB direct interface supports only a USB Flash memory drive, a PictBridge compatible camera, or a digital camera that uses the USB mass storage standard. Any other USB devices are not supported.


#### 2 Memory card slot

Slot	Compatible memory cards		
Upper slot		Memory Stick™ Memory Stick PRO™	
		Memory Stick Duo™ Memory Stick PRO Duo™	
		Memory Stick Micro™ (Adapter required)	
Lower slot		SD SDHC	
		mini SD (Adapter required) micro SD (Adapter required)	

## ! IMPORTANT

DO NOT insert a Memory Stick Duo™ into the lower SD slot, this may cause damage to the machine.

#### PHOTO CAPTURE key indications:



- PHOTO CAPTURE light is on, the memory card or USB Flash memory drive is correctly inserted.
- PHOTO CAPTURE light is off, the memory card or USB Flash memory drive is not correctly inserted.
- PHOTO CAPTURE light is blinking, the memory card or USB Flash memory drive is being read or written to.

## ! IMPORTANT

DO NOT unplug the power cord or remove the memory card or USB Flash memory drive from the media drive (slot) or USB direct interface while the machine is reading or writing to the memory card or USB Flash memory drive (the **PHOTO CAPTURE** key is blinking). **You will lose your data or damage the card.** 

The machine can only read one device at a time.

## **Print Images**

### **View Photos**

You can preview your photos on the LCD before you print them. If your photos are large files there may be a delay before each photo is displayed on the LCD.

1 Make sure you have put the memory card or USB Flash memory drive in the correct slot.

Press (PHOTO CAPTURE).

- Press ▲ or ▼ to choose

  View Photo(s).

  Press OK.
- 3 Press ◀ or ▶ to choose your photo.
- 4 Press + or repeatedly to enter the number of copies you want.
- 5 Repeat steps 3 and 4 until you have chosen all the photos.



Press **Clear** to go back to the previous level.

- 6 After you have chosen all the photos, do one of the following:
  - Press **OK** and change the print settings. (See *PhotoCapture* Center<sup>™</sup> print settings on page 28.)
  - If you do not want to change any settings, press Colour Start to print.


## PhotoCapture Center™ print settings

You can change the print settings temporarily for the next print.

The machine returns to its default settings after 3 minutes.



You can save the print settings you use most often by setting them as the default. (See Setting your changes as a new default in chapter 4 in the Advanced User's Guide.)



#### 1 No. of prints

(For View Photo(s), Search by Date, Slide Show)

You can see the total number of photos that will be printed.

(For Print All Photos, Print Photos, Enhance Photos, Trimming)

You can see the number of copies of each photo that will be printed.

(For DPOF printing)

This does not appear.

# How to scan to a memory card or USB Flash memory drive

You can scan monochrome and colour documents into a memory card or USB Flash memory drive. Monochrome documents will be stored in PDF (\*.PDF) or TIFF (\*.TIF) file formats. Colour documents may be stored in PDF (\*.PDF) or JPEG (\*.JPG) file formats. The factory setting is Color 150 and the default file format is PDF. The machine automatically creates file names based on the current date. (For details, see the *Quick Setup Guide*.) For example, the fifth image scanned on July 1, 2010 would be named 01071005.PDF. You can change the colour and quality.

Quality	Selectable File Format
Color 150	JPEG/PDF
Color 300	JPEG/PDF
Color 600	JPEG/PDF
B/W 200x100	TIFF/PDF
B/W 200	TIFF / PDF


1 Make sure you have put the memory card or USB Flash memory drive in the correct slot.

### !MPORTANT

DO NOT take out the memory card or USB Flash memory drive while **PHOTO CAPTURE** is blinking to avoid damaging the card, USB Flash memory drive or data stored on it.

- 2 Load your document.
- When you want to scan to a memory card or USB Flash memory drive, press (SCAN).

4 Press ▲ or ▼ to choose
Scan to Media.



#### Press OK.

- 5 Do one of the following:
  - To change the quality, press \( \Delta \) or \( \T \) to choose Quality. Go to step \( \Delta \).
  - Press Mono Start or Colour Start to start scanning without changing additional settings.
- 6 Press ◀ or ▶ to choose
  Color 150, Color 300, Color 600,
  B/W 200x100 or B/W 200.
  Press OK.
- 7 Do one of the following:
  - To change the file type, go to step **3**.
  - Press Mono Start or Colour Start to start scanning without changing additional settings.
- 8 Press A or ▼ to choose File Type.
  Press ◀ or ▶ to choose JPEG, PDF or
  TIFF.
  Press OK.

### Note

- If you chose a Color resolution in step 6, you cannot choose TIFF.
- If you chose a B/W resolution in step 6, you cannot choose JPEG.
- 9 Do one of the following:
  - To change the file name, go to step **(**0.
  - Press Mono Start or Colour Start to start scanning without changing additional settings.

#### Chapter 5

- The file name is set automatically; however, you can set a name of your choice using the ▲, ▼, ◀ or ▶ keys.

  Press ▲ or ▼ to choose File Name.

  Press OK.

  Enter the new name. (See Entering Text on page 68.)

  You can only change the first 6 characters.

  Press ▲, ▼, ◀ or ▶ to select ○K, and press OK.
- 11 Press Mono Start or Colour Start.



You can place multiple documents on the scanner glass and scan them as separate files. (See *Auto Crop* in *chapter 4* in the *Advanced User's Guide*.)

## 6

### How to print from a computer

### Printing a document

The machine can receive data from your computer and print it. To print from a computer, install the printer driver.

(See *Printing* for Windows<sup>®</sup> or *Printing* and *Faxing* for Macintosh in the *Software User's Guide* for the details about the print settings.)

- Install the Brother printer driver on the Installation CD-ROM. (See the *Quick Setup Guide*.)
- 2 From your application, choose the Print command.
- 3 Choose the name of your machine in the **Print** dialog box and click **Properties**.
- 4 Choose the settings you want in the Properties dialog box.
  - Media Type/Quality
  - Paper Size
  - Page Layout
  - Colour Settings
  - Scaling
  - Use Watermark
  - Print Date & Time
- 5 Click **OK**.
- 6 Click **OK** to begin printing.

### How to scan to a computer

### Scanning a document

There are several ways to scan documents. You can use the **SCAN** key on the machine or the scanner drivers on your computer.

- 1 To use the machine as a scanner, install a scanner driver. If the machine is on a Network, configure it with a TCP/IP address.
  - Install the scanner drivers on the Installation CD-ROM. (See the Quick Setup Guide and Scanning in the Software User's Guide.)
  - Configure the machine with a TCP/IP address if network scanning does not work. (See Configuring Network Scanning in the Software User's Guide.)
- Load your document. (See Loading documents on page 21.)
  - Use the ADF to scan multiple pages of documents. It feeds each sheet automatically. (DCP-J715W only)
  - Use the scanner glass to scan a page of a book or one sheet at a time.
- 3 Do one of the following:
  - To scan using the **SCAN** key, go to Scanning using the scan key.
  - To scan using a scanner driver at your computer, go to Scanning using a scanner driver.

## Scanning using the scan key

For more information, see *Using the Scankey* in the *Software User's Guide*.

- 1 Press the **SCAN** key.
- 2 Choose the scan mode you want.
  - Scan to File
  - Scan to Media
  - Scan to E-mail
  - Scan to OCR 1
  - Scan to Image
  - DCP-J715W only (Macintosh users) Presto! PageManager must be downloaded and installed before use. See Accessing Brother Support (Macintosh) on page 3 for further instructions.
- (For network users)
  Choose the computer you want to send the data to.
- 4 Press Start to begin scanning.

## Scanning using a scanner driver

For more information, see Scanning a document using the TWAIN driver or Scanning a document using the WIA driver in the Software User's Guide.

- 1 Start a scanning application and click the **Scan** button.
- 2 Adjust the settings such as Resolution, Brightness and Scan Type in the Scanner Setup dialog box.
- 3 Click **Start** or **Scan** to begin scanning.

## A

### **Routine maintenance**

## Replacing the ink cartridges

Your machine is equipped with an ink dot counter. The ink dot counter automatically monitors the level of ink in each of the 4 cartridges. When the machine detects an ink cartridge is running out of ink, the machine will tell you with a message on the LCD.

The LCD will tell you which ink cartridge is low or needs replacing. Be sure to follow the LCD prompts to replace the ink cartridges in the correct order.


Even though the machine tells you to replace an ink cartridge, there will be a small amount of ink left in the ink cartridge. It is necessary to keep some ink in the ink cartridge to prevent air from drying out and damaging the print head assembly.


### IMPORTANT

Brother multifunction machines are designed to work with ink of a particular specification and will work to a level of optimum performance and reliability when used with genuine Brother Original ink cartridges. Brother cannot guarantee this optimum performance and reliability if ink or ink cartridges of other specifications are used. Brother does not therefore recommend the use of cartridges other than genuine Brother Original cartridges or the refilling of used cartridges with ink from other sources. If damage is caused to the print head or other parts of this machine as a result of using incompatible products with this machine, any repairs required as a result may not be covered by the warranty.

- Open the ink cartridge cover.


  If one or more ink cartridges have reached the end of their life, the LCD shows B&W Print Only or Cannot Print.
- Press the lock release lever as shown to release the cartridge indicated on the LCD. Remove the cartridge from the machine.







3 Open the new ink cartridge bag for the colour shown on the LCD, and then take out the ink cartridge.

4 Turn the green knob on the protective yellow cap clockwise until it clicks to release the vacuum seal, then remove the cap (1).






5 Each colour has its own correct position. Insert the ink cartridge in the direction of the arrow on the label.



6 Gently push the ink cartridge in until it clicks, and then close the ink cartridge cover.



7 The machine will automatically reset the ink dot counter.



- If you replaced an ink cartridge, for example Black, the LCD may ask you to verify that it was a brand new one (for example, Did You Change BK Black). For each new cartridge you installed, press + (Yes) to automatically reset the ink dot counter for that colour. If the ink cartridge you installed is not a brand new one, be sure to press (No).
- If the LCD shows No Ink Cartridge or Cannot Detect after you install the ink cartridges, check that the ink cartridges are installed correctly.

### **A** CAUTION

If ink gets in your eyes, wash it out with water at once and call a doctor if you are concerned.


### ! IMPORTANT

- DO NOT take out ink cartridges if you do not need to replace them. If you do so, it may reduce the ink quantity and the machine will not know the quantity of ink left in the cartridge.
- DO NOT touch the cartridge insertion slots. If you do so, the ink may stain your skin.
- If ink gets on your skin or clothing immediately wash it off with soap or detergent.
- If you mix the colours by installing an ink cartridge in the wrong position, clean the print head several times after correcting the cartridge installation.
- Once you open an ink cartridge, install it in the machine and use it up within six months of installation. Use unopened ink cartridges by the expiration date written on the cartridge package.
- DO NOT dismantle or tamper with the ink cartridge, this can cause the ink to leak out of the cartridge.


## Cleaning and checking the machine

### Cleaning the scanner glass

1 Lift the document cover (1). Clean the scanner glass (2) and the white plastic (3) with a soft lint-free cloth moistened with a non-flammable glass cleaner.



(DCP-J715W only)
In the ADF unit, clean the white bar (1) and the glass strip (2) with a lint-free cloth moistened with a non-flammable glass cleaner.







In addition to cleaning the glass strip with a non-flammable glass cleaner, run your finger tip over the glass strip to see if you can feel anything on it. If you feel dirt or debris, clean the glass strip again concentrating on that area. You may need to repeat the cleaning process three or four times. To test, make a copy after each cleaning attempt.

### Cleaning the paper pick-up rollers

- 1 Pull the paper tray completely out of the machine.
- 2 Unplug the machine from the electrical socket and open the Jam Clear Cover (1) at the back of the machine.



3 Clean the Paper Pick-up Rollers (1) with isopropyl alcohol on a cotton swab.



- 4 Close the Jam Clear Cover.

  Make sure the cover is closed correctly.
- 5 Re-connect the power cord.
- 6 Slowly push the paper tray completely back into the machine.

#### A

### Cleaning the print head

To maintain good print quality, the machine will automatically clean the print head when needed. You can start the cleaning process manually if there is a print quality problem.

Clean the print head and ink cartridges if you get a horizontal line in the text or graphics, or blank text on your printed pages. You can clean Black only, three colours at a time (Cyan/Magenta/Yellow), or all four colours at once.

Cleaning the print head consumes ink. Cleaning too often uses ink unnecessarily.

### IMPORTANT

DO NOT touch the print head. Touching the print head may cause permanent damage and may void the print head's warranty.

- 1 Press Menu.
- Press ▲ or ▼ to choose
  Ink Management.
  Press OK.
- 3 Press A or ▼ to choose Cleaning. Press OK.
- 4 Press ▲ or ▼ to choose Black, Color or All.

Press OK.

The machine cleans the print head. When cleaning is finished, the machine will go back to standby mode automatically.



If you clean the print head at least five times and the print has not improved, try installing a new Brother Original Innobella™ ink cartridge for each problem colour. Try cleaning the print head again up to five more times. If the print has not improved call your Brother dealer.

### Checking the print quality

If faded or streaked colours and text appear on your output, some of the nozzles may be clogged. You can check this by printing the Print Quality Check Sheet and looking at the nozzle check pattern.

- 1 Press Menu.
- 2 Press ▲ or ▼ to choose
  Ink Management.
  Press OK.
- Press A or ▼ to choose Test Print.
  Press OK.
- Press ▲ or ▼ to choose
  Print Quality.
  Press OK.
- 5 Press Colour Start.
  The machine begins printing the Print Quality Check Sheet.
- 6 Check the quality of the four colour blocks on the sheet.
- 7 Do one of the following:
  - If all lines are clear and visible, press + to choose Yes, and go to step ①.
  - If you can see missing short lines as shown below, press to choose No.

OK Poor





- 8 The LCD asks you if the print quality is OK for black and the three colours. Press + (Yes) or (No).
- The LCD asks you if you want to start cleaning.

Press + (Yes).

The machine starts cleaning the print head.

10 After cleaning is finished, press Colour Start.

The machine starts printing the Print Quality Check Sheet again. Return to step **6**.

11 Press Stop/Exit.

If you repeat this procedure at least five times and the print quality is still poor, replace the ink cartridge for the clogged colour.

After replacing the ink cartridge, check the print quality. If the problem still exists, repeat the cleaning and test print procedures at least five times for the new ink cartridge. If ink is still missing, call your Brother dealer.

### ! IMPORTANT

DO NOT touch the print head. Touching the print head may cause permanent damage and may void the print head's warranty.





When a print head nozzle is clogged the printed sample looks like this.



After the print head nozzle is cleaned, the horizontal lines are gone.

### Checking the print alignment

You may need to adjust the print alignment after transporting the machine, if your printed text becomes blurred or images become faded.

- 1 Press Menu.
- Press ▲ or ▼ to choose
  Ink Management.
  Press OK.
- 3 Press A or ▼ to choose Test Print. Press OK.
- 4 Press ▲ or ▼ to choose Alignment. Press OK.
- 5 Press Mono Start or Colour Start.
  The machine starts printing the
  Alignment Check Sheet.
- 6 Check the 600 dpi and 1200 dpi test prints to see if number 5 most closely matches number 0.
  - If the number 5 samples of both the 600 dpi and 1200 dpi test prints are the best matches, press + (Yes) to finish Alignment Check, and go to step 9.
  - If another test print number is a better match for either 600 dpi or 1200 dpi, press (No) to choose it.
- For 600 dpi, press ◀ or ▶ to choose the number of the test print that most closely matches the number 0 sample (1-8). Press OK.
- 8 For 1200 dpi, press ◀ or ▶ to choose the number of the test print that most closely matches the number 0 sample (1-8). Press **OK**.
- 9 Press Stop/Exit.

## B

### **Troubleshooting**

### **Error and Maintenance messages**

As with any sophisticated office product, errors may occur and consumable items may need to be replaced. If this happens, your machine identifies the error and shows an error message. The most common error and maintenance messages are shown below.

You can correct most errors and routine maintenance by yourself. If you need more help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips.

Visit us at http://solutions.brother.com/

Error Message	Cause	Action
B&W Print Only Replace Ink	One or more of the colour ink cartridges have reached the end of their life. You can use the machine in black & white mode for approximately four weeks depending on the number of pages you print. While this message appears on the LCD, each operation works in the following way:	Replace the ink cartridges. (See Replacing the ink cartridges on page 33.)
	Printing If you click Greyscale in the Advanced tab of the printer driver you can use the machine as a monochrome printer.	
	■ Copying  If the paper type is set to  Plain Paper or  Inkjet Paper you can  make copies in monochrome.	
	If the paper type is set to Other Glossy, Brother BP71 or Brother BP61 the machine will stop all print operations. If you unplug the machine, or take out the ink cartridge, you cannot use the machine until you change to a new ink cartridge.	

Error Message	Cause	Action
Cannot Detect	You installed a new ink cartridge too quickly and the machine did not detect it.	Take out the new ink cartridge and re-install it slowly.
	If you are using non Brother Original ink the machine may not detect the ink cartridge.	Replace the cartridge with a Brother Original ink cartridge. If the error message remains, contact your Brother dealer.
	An ink cartridge is not installed correctly.	Take out the new ink cartridge and re-install it slowly until it clicks. (See Replacing the ink cartridges on page 33.)
Cannot Print Replace Ink	One or more of the ink cartridges have reached the end of their life. The machine will stop all print operations.	Replace the ink cartridges. (See Replacing the ink cartridges on page 33.)
Cover is Open	The scanner cover is not completely closed.	Lift the scanner cover and then close it again.
	The ink cartridge cover is not completely closed.	Firmly close the ink cartridge cover until it clicks.
Data Remaining	Print data is left in the machine's memory.	Press <b>Stop/Exit</b> . The machine will cancel the job and clear it from the memory. Try to print again.
Document Jam (DCP-J715W only)	The document was not inserted or fed correctly, or the document scanned from the ADF was too long.	(See Using the ADF (DCP-J715W only) on page 21.) (See Document jam (DCP-J715W only) on page 43.)
High Temperature	The print head is too warm.	Allow the machine to cool down.
Hub is Unusable.	A Hub or USB Flash memory drive with Hub has been connected to the USB direct interface.	A Hub or USB Flash memory drive with Hub are not supported. Unplug the device from the USB direct interface.
Image Too Long.	The proportions of your photo are irregular so effects could not be added.	Choose a regularly proportioned image.
Image Too Small.	The size of your photo is too small to trim.	Choose a larger image.
Ink Absorber Full	Internal servicing required. This problem may be caused by the use of cartridges other than genuine Brother Original cartridges or the refilling of empty cartridges with ink from other sources. If damage is caused to the print head or other parts of this machine as a result of using other brands of ink or ink cartridges, any repairs required as a result may not be covered by the warranty.	Call Brother Customer Service / your Brother dealer.

Error Message	Cause	Action
Ink Absorber NearFull	The ink absorber box or flushing box is near full.	Call Brother Customer Service / your Brother dealer.
Ink low	One or more of the ink cartridges are near the end of their life.	Order a new ink cartridge.
Low Temperature	The print head is too cold.	Allow the machine to warm up.
Media Error	The memory card is either corrupted, incorrectly formatted, or there is a problem with the memory card.	Put the card firmly into the slot again to make sure it is in the correct position. If the error remains, check the media drive (slot) of the machine by putting in another memory card that you know is working.
Media is Full.	The memory card or USB Flash memory drive you are using already contains 999 files.	Your machine can only save to your memory card or USB Flash memory drive if it contains less than 999 files. Try deleting unused files to free some space and try again.
No File	The memory card or USB Flash memory drive in the media drive does not contain a .JPG file.	Put the correct memory card or USB Flash memory drive into the slot again.
No Ink Cartridge	An ink cartridge is not installed correctly.	Take out the ink cartridge and put it in again seating it properly. (See Replacing the ink cartridges on page 33.)
No Paper Fed	The Photo Paper Tray is in the <i>Photo</i> printing position.	Make sure that the Photo Paper Tray is in the <i>Normal</i> printing position. (See step 4 and the Important note in <i>Loading photo paper</i> on page 12.)
	The machine is out of paper or	Do one of the following:
	paper is not correctly loaded in the paper tray.	Refill the paper in the paper tray, and then press Mono Start or Colour Start.
		Remove the paper and load it again and then press Mono Start or Colour Start. (See Loading paper and other print media on page 8.)
	The paper is jammed in the machine.	Remove the jammed paper by following the steps in <i>Printer jam or paper jam</i> on page 44.
	The Jam Clear Cover is not closed correctly.	Check the Jam Clear Cover is closed evenly at both ends. (See <i>Printer jam or paper jam</i> on page 44.)

Error Message	Cause	Action
Out of Memory	The machine's memory is full.	Copy operation in progress:
		Press <b>Stop/Exit</b> and wait until the other operations in progress finish and then try again.
	The memory card or USB Flash memory drive you are using does not have enough free space to scan the documents.	Delete unused files from your memory card or USB Flash memory drive to make some free space and then try again.
Paper Jam	Paper is jammed in the machine.	Remove the jammed paper by following the steps in <i>Printer jam or paper jam</i> on page 44.
		Make sure the paper length guide is adjusted to the correct paper size.
Unable to Clean XX	The machine has a mechanical	Open the scanner cover and remove any
Unable to Init. XX	problem.	foreign objects and paper scraps inside the machine. If the error message continues,
Unable to Print XX	-OR-	disconnect the machine from the power for
Unable to Scan XX	A foreign object such as a paper clip or ripped paper is in the machine.	several minutes, then reconnect it.
Unusable Device	A broken device has been	Unplug the device from the USB direct
Disconnect device from front connector & turn machine off & then on	connected to the USB direct interface.	interface, then press <b>On/Off</b> to turn the machine off and then on again.
Unusable Device	A USB device or USB Flash	Unplug the device from the USB direct
Please Disconnect USB Device.	memory drive that is not supported has been connected to the USB direct interface. (For more information, visit us at <a href="http://solutions.brother.com/">http://solutions.brother.com/</a> )	interface.
Wrong Paper Size	Paper is not the correct size.	Check that the Paper Size setting matches the size of paper in the tray. Load the correct size of paper, and then press <b>Mono Start</b> or <b>Colour Start</b> . (See <i>Paper Size</i> on page 16.)

#### **Error** animation


Error animations display step-by-step instructions when paper gets jammed. You can read the steps at your own pace by pressing ▶ to see the next step and ◀ to go backward.

## Document jam (DCP-J715W only)

Documents can jam in the ADF unit if they are not inserted or fed correctly, or if they are too long. Follow the steps below to clear a document jam.

### Document is jammed in the top of the ADF unit

- 1 Take out any paper from the ADF that is not jammed.
- Open the ADF cover.
- 3 Pull the jammed document up and to the left.




- 4 Close the ADF cover.
- 5 Press Stop/Exit.

### IMPORTANT

To avoid future document jams close the ADF cover correctly by pushing it gently in the middle.

### Document is jammed inside the ADF unit

- 1 Take out any paper from the ADF that is not jammed.
- 2 Lift the document cover.
- 3 Pull the jammed document out to the left.





- Close the document cover.
- 5 Press Stop/Exit.

### Printer jam or paper jam

Take out the jammed paper depending on where it is jammed in the machine.


- 1 Unplug the machine from the electrical socket.
- Open the Jam Clear Cover (1) at the back of the machine. Pull the jammed paper out of the machine.






3 Close the Jam Clear Cover.


Make sure the cover is closed correctly.




4 If the paper support flap is open, close it, and then close the paper support. Pull the paper tray completely out of the machine.



5 Pull out the jammed paper (1).




6 Using both hands, grasp the plastic tabs on both sides of the machine and lift the scanner cover (1) until it locks securely in the open position.



Move the print head (if necessary) to take out any paper remaining in this area. Make sure that jammed paper is not left in the corners of the machine. Check *both* ends of the print carriage.




If the print head is at the right corner as shown in the illustration, you cannot move it. Re-connect the power cord, then hold down **Stop/Exit** until the print head moves to the middle. Unplug the machine from the power source, and take out the paper.




### ! IMPORTANT

If ink gets on your skin or clothing immediately wash it off with soap or detergent.

7 Lift the scanner cover to release the lock (1). Gently push the scanner cover support down (2) and close the scanner cover (3) using both hands.



- 8 Push the paper tray firmly back into the machine.
- 9 While holding the paper tray in place, pull out the paper support (1) until it clicks, and then unfold the paper support flap (2).



Make sure you pull out the paper support until it clicks.

### IMPORTANT

DO NOT use the paper support flap for Legal size paper.

10 Re-connect the power cord.

### **Troubleshooting**

If you think there is a problem with your machine, check the chart below and follow the troubleshooting tips.

Most problems can be easily resolved by yourself. If you need additional help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips. Visit us at http://solutions.brother.com/

### If you are having difficulty with your machine

#### **Printing**

Difficulty	Suggestions
No printout	Check the interface cable on both the machine and your computer. (See the Quick Setup Guide.)
	Make sure the machine is plugged in and not turned off.
	Check to see if the LCD is showing an error message. (See <i>Error and Maintenance messages</i> on page 39.)
	One or more ink cartridges have reached the end of their life. (See <i>Replacing the ink cartridges</i> on page 33.)
	If the LCD says Cannot Print and Replace Ink, see Replacing the ink cartridges on page 33.
	Check that the correct printer driver has been installed and chosen.
	Make sure that the machine is online. Click <b>Start</b> and then <b>Printers and Faxes</b> . Choose <b>Brother DCP-XXXX</b> (where XXXX is your model name), and make sure that <b>Use Printer Offline</b> is unchecked.
	When you choose the <b>Print Odd Pages</b> and <b>Print Even Pages</b> settings, you may see a print error message on your computer, as the machine pauses during the printing process. The error message will disappear after the machine re-starts printing.
Poor print quality	Use only Genuine Brother Consumables as ink from other manufactures can cause print quality problems.
	Check the print quality. (See Checking the print quality on page 37.)
	Make sure that the <b>Media Type</b> setting in the printer driver or the Paper Type setting in the machine's menu matches the type of paper you are using. (See <i>Printing</i> for Windows <sup>®</sup> or <i>Printing</i> and <i>Faxing</i> for Macintosh in the <i>Software User's Guide</i> and <i>Paper Type</i> on page 16.)
	Make sure that your ink cartridges are fresh. The following may cause ink to clog:
	The expiration date written on the cartridge package has passed. (Brother Original cartridges stay usable for up to two years if kept in their original packaging.)
	■ The ink cartridge was in your machine over for six months.
	■ The ink cartridge may not have been stored correctly before use.
	Try using the recommended types of paper. (See Acceptable paper and other print media on page 17.)
	The recommended environment for your machine is between 20 °C to 33 °C.

### Printing (continued)

Difficulty	Suggestions
White horizontal lines appear in text	Clean the print head. (See Cleaning the print head on page 37.)
or graphics.	Make sure you are using Brother Original Innobella™ ink.
	Try using the correct types of paper. (See Acceptable paper and other print media on page 17.)
	If you want to print on Photo 10 $\times$ 15 cm or Photo L 89 $\times$ 127 mm paper, make sure you use the photo paper tray. (See <i>Loading photo paper</i> on page 12.)
The machine prints blank pages.	Clean the print head. (See Cleaning the print head on page 37.)
Characters and lines are stacked.	Check the printing alignment. (See Checking the print alignment on page 38.)
Printed text or images are skewed.	Make sure the paper is loaded correctly in the paper tray and the paper side guides are adjusted correctly. (See <i>Loading paper and other print media</i> on page 8.)
	Make sure the Jam Clear Cover is closed correctly.
Smudged stain at the top centre of the printed page.	Make sure the paper is not too thick or curled. (See Acceptable paper and other print media on page 17.)
Smudged stain at the right or left corner of the printed page.	Make sure the paper is not curled when you print on the back side of the paper with the <b>Print Odd Pages</b> and <b>Print Even Pages</b> settings.
Printing appears dirty or ink seems to run.	Make sure you are using the recommended types of paper. (See <i>Acceptable paper and other print media</i> on page 17.) Don't handle the paper until the ink is dry.
	If you are using photo paper, make sure that you have set the correct paper type. If you are printing a photo from your PC, set the <b>Media Type</b> in the <b>Basic</b> tab of the printer driver.
	Make sure you are using Brother Original Innobella™ ink.
Stains appear on the reverse side or at the bottom of the page.	Make sure the printer platen is not dirty with ink. (See Cleaning the machine's printer platen in appendix A in the Advanced User's Guide.)
	Make sure you are using the paper support flap. (See Loading paper and other print media on page 8.)
The machine prints dense lines on the page.	Check Reverse Order in the Basic tab of the printer driver.
The printouts are wrinkled.	In the printer driver <b>Advanced</b> tab, click <b>Colour Settings</b> , and uncheck <b>Bi-Directional Printing</b> .
	Make sure you are using Brother Original Innobella™ ink.
Cannot perform "Page Layout" printing.	Check that the paper size setting in the application and in the printer driver are the same.
Print speed is too slow.	Try changing the printer driver setting. The highest resolution needs longer data processing, sending and printing time. Try the other quality settings in the printer driver <b>Advanced</b> tab. Also, click the <b>Colour Settings</b> , and make sure you uncheck <b>Colour Enhancement</b> .
	Turn the borderless feature off. Borderless printing is slower than normal printing.
	(See <i>Printing</i> for Windows <sup>®</sup> or <i>Printing and Faxing</i> for Macintosh in the <i>Software User's Guide</i> .)
Colour Enhancement is not working correctly.	If the image data is not full colour in your application (such as 256 colour), Colour Enhancement will not work. Use at least 24 bit colour data with the Colour Enhancement feature.

### Printing (continued)

Difficulty	Suggestions
Photo paper does not feed correctly.	When you print on Brother Photo paper, load one extra sheet of the same photo paper in the paper tray. An extra sheet has been included in the paper package for this purpose.
	Clean the paper pick-up rollers. (See Cleaning the paper pick-up rollers on page 36.)
Machine feeds multiple pages.	Make sure the paper is loaded correctly in the paper tray. (See Loading paper and other print media on page 8.)
	Check that more than two types of paper are not loaded in the paper tray at any one time.
There is a paper jam.	Make sure the paper length guide is set to the correct paper size. Do not extend the paper tray when you load A5 or smaller size paper. (See <i>Printer jam or paper jam</i> on page 44.)
Printed pages are not stacked neatly.	Make sure you are using the paper support flap. (See Loading paper and other print media on page 8.)
Machine does not print from Adobe <sup>®</sup> Illustrator <sup>®</sup> .	Try to reduce the print resolution. (See <i>Printing</i> for Windows <sup>®</sup> or <i>Printing</i> and <i>Faxing</i> for Macintosh in the <i>Software User's Guide</i> .)

### **Copying Difficulties**

Difficulty	Suggestions
Vertical black lines or streaks appear on copies.	Vertical black lines or streaks on copies are typically caused by dirt or correction fluid on the scanner. Clean scanner glass and white plastic above it. (See <i>Cleaning the scanner glass</i> on page 35.)
Poor copy results when using the ADF. (DCP-J715W only)	Try using the scanner glass. (See <i>Using the scanner glass</i> on page 21.)
Vertical black lines or streaks appear in copies. (DCP-J715W only)	Vertical black lines or streaks on copies are typically caused by dirt or correction fluid on the glass strip. Clean the glass strip. (See <i>Cleaning the scanner glass</i> on page 35.)
Fit to Page does not work correctly.	Make sure the document is not skewed on the scanner glass. Reposition the document and try again.

### **Scanning Difficulties**

Difficulty	Suggestions
TWAIN/WIA errors appear when starting to scan.	Make sure the Brother TWAIN/WIA driver is chosen as the primary source. In PaperPort™11SE with OCR, click <b>File</b> , <b>Scan or Get Photo</b> and click <b>Select</b> to choose the Brother TWAIN/WIA driver. (DCP-J715W only)
Poor scanning results when using the ADF. (DCP-J715W only)	Try using the scanner glass. (See <i>Using the scanner glass</i> on page 21.)
OCR does not work. (DCP-J715W only)	Try increasing the scanner resolution.  (Macintosh users)  Presto! PageManager must be downloaded and installed before use.  See Accessing Brother Support (Macintosh) on page 3 for further instructions.

### **Software Difficulties**

Difficulty	Suggestions
Cannot install software or print.	(Windows <sup>®</sup> users only) Run the <b>Repair MFL-Pro Suite</b> program on the Installation CD-ROM. This program will repair and reinstall the software.
"Device Busy"	Make sure the machine is not showing an error message on the LCD.
Cannot print images from FaceFilter Studio.	To use FaceFilter Studio, you must install the FaceFilter Studio application from the Installation CD-ROM supplied with your machine. To install FaceFilter Studio see the <i>Quick Setup Guide</i> .
	Also, before you start FaceFilter Studio for the first time, you must make sure your Brother machine is turned on and connected to your computer. This will allow you to access all the functions of FaceFilter Studio.

### PhotoCapture Center™ Difficulties

Difficulty	Suggestions
Removable Disk does not work	1 Have you installed the Windows <sup>®</sup> 2000 update? If not, do the following:
correctly.	1) Unplug the USB cable.
	2) Install the Windows <sup>®</sup> 2000 update using one of the following methods.
	<ul><li>Install MFL-Pro Suite from the Installation CD-ROM. (See the Quick Setup Guide.)</li></ul>
	Download the latest service pack from the Microsoft Web site.
	<ol><li>Wait about 1 minute after you restart the PC, and then connect the USB cable.</li></ol>
	2 Take out the memory card or USB Flash memory drive and put it back in again.
	3 If you have tried "Eject" from within Windows <sup>®</sup> , take out the memory card or USB Flash memory drive before you continue.
	4 If an error message appears when you try to eject the memory card or USB Flash memory drive, it means the card is being accessed. Wait a while and then try again.
	5 If all of the above do not work, turn off your PC and machine, and then turn them on again. (You will have to unplug the power cord of the machine to turn it off.)
Cannot access Removable Disk from Desktop icon.	Make sure that you have correctly inserted the memory card or USB Flash memory drive.
Part of my photo is missing when printed.	Make sure that Borderless Printing and Cropping are turned off. (See Borderless printing in chapter 4 and Cropping in chapter 4 in the Advanced User's Guide.)

### **Network Difficulties**

Difficulty	Suggestions
Cannot print over the Network.	Make sure that your machine is powered on and is online and in Ready mode.  Print a Network Configuration list (see <i>Printing Reports</i> in <i>chapter 2</i> in the  Advanced User's Guide) and check the current Network settings printed in this list.
	(DCP-J715W only) Reconnect the LAN cable to the hub to verify that the cabling and network connections are good. If possible, try connecting the machine to a different port on your hub using a different cable. If the connections are good, the machine shows LAN Active for 2 seconds.  (If you are having Network problems, see the Network User's Guide for more information.)
The network scanning feature does not work.	(Windows® users) It is necessary to configure third-party Security/Firewall Software to allow Network scanning. To add port 54925 for Network scanning, enter the information below:
	In Name: Enter any description, for example Brother NetScan.
	In Port number: Enter 54925.
	In Protocol: UDP is selected.
	Please refer to the instruction manual that came with your third-party Security/Firewall Software or contact the software manufacturer.
	(Macintosh users) Re-select your machine in the <b>Device Selector</b> application located in <b>Macintosh HD/Library/Printers/Brother/Utilities/DeviceSelector</b> or from the model list in ControlCenter2.
The Brother software cannot be installed.	(Windows <sup>®</sup> users) Allow network access to the following programs if your security software displays an alert message during MFL-Pro Suite installation.
	BrC3Rgin.exe
	BmIPMon
	Brother Status Monitor (Network)
	ControlCenter Program
	Generic Host Process f
	Setup.exe
	Spooler SubSystem App
	wdsw MFC Application
	(Macintosh users) Re-select your machine in the <b>Device Selector</b> application located in <b>Macintosh HD/Library/Printers/Brother/Utilities/DeviceSelector</b> or from the model list in ControlCenter2.
Cannot connect to wireless network.	Investigate the problem using the WLAN Report.  Press Menu key, choose Print Reports and then press OK. Choose WLAN Report.  For details, see the Network User's Guide.
Reset the network settings.	Press <b>Menu</b> key, choose Network and then press <b>OK</b> . Choose Network Reset. For details, see the <i>Network User's Guide</i> .

#### B

### **Machine Information**

### Checking the serial number

You can see the machine's serial number on the LCD.

- 1 Press Menu.
- Press ▲ or ▼ to choose

  Machine Info.

  Press OK.
- 3 Press A or ▼ to choose Serial No. Press OK.
- 4 Press Stop/Exit.

#### **Reset functions**

The following reset functions are available:

1 Network

You can reset the print server back to its default factory settings such as the IP address information.

2 All Settings

You can reset all the machine settings back to the settings that were set at the factory.

Brother strongly recommends you use this operation when you dispose of the machine.



Unplug the interface cable before you choose Network or All Settings. (DCP-J715W only)

#### How to reset the machine

- 1 Press Menu.
- Press ▲ or ▼ to choose
  Initial Setup.
  Press OK.
- Press ▲ or ▼ to choose Reset.
  Press OK.
- Press ▲ or ▼ to choose the type of reset you want to use. Press OK. Press + to confirm.
- 5 Press + to reboot the machine.

C

### Menu and features

## On-screen programming

Your machine is designed to be easy to operate with LCD on-screen programming using the menu keys. User-friendly programming helps you take full advantage of all the menu selections your machine has to offer.

Since your programming is done on the LCD, we have created step-by-step on-screen instructions to help you program your machine. All you need to do is follow the instructions as they guide you through the menu selections and programming options.

### Menu table

The menu table will help you understand the menu selections and options that are found in the machine's programs. The factory settings are shown in Bold with an asterisk.



Level1	Level2	Level3	Options	Descriptions	Page
Ink Management	Test Print	_	Print Quality	Lets you check the print	37
			Alignment	quality or alignment.	
	Cleaning	_	Black	Lets you clean the print	37
			Color	head.	
			All		
	Ink Volume	_	_	Lets you check the available ink volume.	See <sup>1</sup> .
General Setup	Paper Type	_	Plain Paper*	Sets the type of paper in	16
			Inkjet Paper	the paper tray.	
			Brother BP71		
			Brother BP61		
			Other Glossy		
			Transparency		
	Paper Size	_	A4*	Sets the size of the	16
			A5	paper in the paper tray.	
			10x15cm		
			Letter		
			Legal		
	LCD Settings	Backlight	Light*	You can adjust the	7
			Med	brightness of the LCD backlight.	
			Dark	, and the second	
		Dim Timer	Off	You can set how long	See <sup>1</sup> .
			10Secs	the LCD backlight stays on for after you go back	
			20Secs	to the Ready screen.	
			30Secs*		

<sup>&</sup>lt;sup>1</sup> See Advanced User's Guide.



Level1	Level2	Level3	Options	Descriptions	Page
General Setup	Sleep Mode	_	1Min	You can choose how	See <sup>1</sup> .
(Continued)			2Mins	long the machine must be idle before it goes into	
			3Mins	sleep mode.	
			5Mins*		
			10Mins		
			30Mins		
			60Mins		

See Advanced User's Guide.



The factory settings are shown in Bold with an asterisk.

### Network menu (DCP-J515W)

Level1	Level2	Level3	Options	Descriptions
Network	TCP/IP	BOOT Method	Auto*	Chooses the BOOT method
			Static	that best suits your needs.
			RARP	
			BOOTP	
			DHCP	
		IP Address	[000-255].	Enter the IP address.
			[000-255].	
			[000-255].	
			[000-255]	
		Subnet Mask	[000-255].	Enter the subnet mask.
			[000-255].	
			[000-255].	
			[000-255]	
		Gateway	[000-255].	Enter the Gateway address.
			[000-255].	
			[000-255].	
			[000-255]	
		Node Name	BRWXXXXXXXXXXX	You can see the current Node name.
		WINS Config	Auto*	You can choose the WINS
			Static	configuration mode.

See Network User's Guide.



Level1	Level2	Level3	Options	Descriptions
Network	TCP/IP	WINS Server	(Primary)	Specifies the IP address of
(Continued)	(Continued)		000.000.000.000	the primary or secondary server.
			(Secondary)	
			000.000.000.000	
		DNS Server	(Primary)	Specifies the IP address of
			000.000.000.000	the primary or secondary server.
			(Secondary)	
			000.000.000.000	
		APIPA	On*	Automatically allocates the
			Off	IP address from the link-local address range.
	Setup Wizard	_		You can manually configure your print server for a wireless network.
	WPS/AOSS	_	_	You can easily configure your wireless network settings using the one-button push method.
	WPS w/PIN Code	_	_	You can easily configure your wireless network settings using WPS with a PIN code.
	WLAN Status	Status	_	You can see the current wireless network status.
		Signal	_	You can see the current wireless network signal strength.
		SSID	_	You can see the current SSID.
		Comm. Mode	_	You can see the current Communication Mode.
	MAC Address	_	_	You can see your machine's Mac address from the control panel.
	WLAN Enable	_	On Off*	Lets you use the wireless network connection.
	Network Reset	_	_	Restores all network settings to factory default.



### Network menu (DCP-J715W)

Level1	Level2	Level3	Level4	Options	Descriptions
Network	Wired LAN	TCP/IP	BOOT Method	Auto*	Chooses the
				Static	BOOT method that best suits
				RARP	your needs.
				BOOTP	
				DHCP	
			IP Address	[000-255].	Enter the IP
				[000-255].	address.
				[000-255].	
				[000-255]	
			Subnet Mask	[000-255].	Enter the Subnet
				[000-255].	mask.
				[000-255].	
				[000-255]	
			Gateway	[000-255].	Enter the
				[000-255].	Gateway address.
				[000-255].	
				[000-255]	
			Node Name	BRNXXXXXXXXXXX	Enter the Node name.
			WINS Config	Auto*	Chooses the WINS
				Static	configuration mode.
			WINS Server	(Primary) 000.000.000.000	Specifies the IP address of the
				(Secondary)	primary or secondary server.
			DNS Server	(Primary) 000.000.000.000	Specifies the IP address of the
			(Secondary)	primary or secondary server.	
			APIPA	On*	Automatically allocates the IP address from the link-local address range.
	See Network Use	r's Guide.	1	ı	



Level1	Level2	Level3	Level4	Options	Descriptions
Network	Wired LAN	Ethernet	_	Auto*	Chooses the
(Continued)	(Continued)			100B-FD	Ethernet link mode.
				100B-HD	
				10B-FD	
				10B-HD	
		MAC Address	_	_	You can see you machine's Mac address from the control panel.
	WLAN	TCP/IP	BOOT Method	Auto*	Chooses the
				Static	BOOT method that best suits
				RARP	your needs.
				BOOTP	
				DHCP	
			IP Address	[000-255].	Enter the IP
				[000-255].	address.
				[000-255].	
			[000-255]		
			Subnet Mask	[000-255].	Enter the Subne
				[000-255].	mask.
				[000-255].	
				[000-255]	
			Gateway	[000-255].	Enter the
				[000-255].	Gateway address.
				[000-255].	address.
				[000-255]	
			Node Name	BRWXXXXXXXXXXX	Enter the Node name.
			WINS Config	Auto*	Chooses the
				Static	WINS configuration mode.
			WINS Server	(Primary) 000.000.000.000	Specifies the IP address of the
				(Secondary)	primary or secondary server.
			DNS Server	(Primary) 000.000.000	Specifies the IP address of the
				(Secondary) 000.000.000	primary or secondary server.

Level1	Level2	Level3	Level4	Options	Descriptions
Network WLAN (Continued)	WLAN (Continued)	TCP/IP (Continued)	APIPA	On* Off	Automatically allocates the IP address from the link-local address range.
		Setup Wizard	_	_	You can manually configure your print server for a wireless network.
		WPS/AOSS	_	_	You can easily configure your wireless network settings using the one-button push method.
		WPS w/PIN Code	_	_	You can easily configure your wireless network settings using WPS with a PIN code.
		WLAN Status	Status	_	You can see the current wireless network status.
			Signal		You can see the current wireless network signal strength.
			SSID	_	You can see the current SSID.
			Comm. Mode	_	You can see the current Communication Mode.
		MAC Address	_	_	You can see your machine's Mac address from the control panel.
	Network I/F	_	Wired LAN*	_	You can choose the network connection type.
	Network Reset	_	Yes No	_	Restores all wired and wireless network settings to the factory default.
	See Network User	r's Guide.			



### Menu (Menu) (continued)

Level1	Level2	Level3	Options	Descriptions	Page
Print Reports	Help List	_	_	You can print these lists	See <sup>1</sup> .
	User Settings	_	_	and reports.	
	Network Config	_	_		
	WLAN Report	_	_		
Machine Info.	Serial No.	_	_	Lets you check the serial number of your machine.	51
Initial Setup	Date&Time	_	_	Puts the date and time in your machine.	See <sup>2</sup> .
	Reset	Network	_	Resets the print server back to its factory default settings, such as the IP address information.	51
		All Settings	_	Resets all the machine's settings back to the settings that were set at the factory.	51
	Local Language		(Choose the language you want to use)	Allows you to change the LCD language for your country.	See <sup>1</sup> .

<sup>&</sup>lt;sup>1</sup> See Advanced User's Guide.

<sup>&</sup>lt;sup>2</sup> See Quick Setup Guide.



### Copy (Default display)

Level1	Level2	Level3	Options	Descriptions	Page
Quality	_	_	Fast	Choose the Copy	See <sup>1</sup> .
			Normal*	resolution for your type of document.	
			Best		
Enlarge/Reduce	100%*	_	_	_	
	Enlarge	_	142% A5→A4	You can choose the	
			186% 10x15cm→LTR	enlargement ratio for the next copy.	
			198% 10x15cm→A4	пол сору.	
	Reduce	_	47% A4→10x15cm	You can choose the	
			69% A4→A5	reduction ratio for the	
			(DCP-J515W)	next copy.	
			83%		
			93% A4→LTR		
			97% LTR→A4		
			(DCP-J715W)		
			83% LGL→A4		
			93% A4→LTR		
			97% LTR→A4		
	Fit to Page	_	_	Your machine will adjust	
				the size automatically to	
	G			the paper size you set.	
	Custom(25-400%)	_	_	You can choose the enlargement or reduction	
				ratio for the next copy.	
Paper Type	_	_	Plain Paper*	Choose the paper type	24
			Inkjet Paper	that matches the paper in the tray.	
			Brother BP71	and adj.	
			Brother BP61		
			Other Glossy		
			Transparency	Observation and the second of	0.4
Paper Size	_	_	A4*	Choose the paper size that matches the paper in	24
			A5	the tray.	
			10x15cm		
			Letter		
			Legal		



Level1	Level2	Level3	Options	Descriptions	Page
Density		-	*	Adjusts the density of copies.	See <sup>1</sup> .
Ink Save Mode	_	_	On Off*	You can save some ink.	
Stack/Sort (DCP-J715W only)	_	_	Stack* Sort	You can choose to stack or sort multiple copies.	
Page Layout			Off(1 in 1)* 2 in 1 (P) 2 in 1 (L) 4 in 1 (P) 4 in 1 (L) Poster(3 x 3)	You can make N in 1 or Poster copies.	
Book Copy	On (Preview)  Off*	— (Skew Adjustment) (Shadow Revise)		Corrects dark borders and skew when copying from the scanner glass.	
Watermark Copy	Watermark Copy	_	On  Off*  (If you choose On, see the watermark copy settings in the following table.)	You can place a logo or text into your document as a Watermark.	
	Current Setting Exit	_	_		
Set New Default	_	_	_	You can save your copy settings.	
Factory Reset		_	_	You can restore all settings to the factory settings.	
	<sup>1</sup> See Advanced	User's Guide.	-		
	The factory settings	s are shown in Bold	with an asterisk.		

### **Watermark Copy Settings**

Option1	Option2	Option3	Option4	Descriptions	Page
   Template	_	Text	CONFIDENTIAL*	Places a text into your	See <sup>1</sup> .
			DRAFT	document as a Watermark using a	
			COPY	template.	
		Position	А		
			В		
			С		
			D		
			E*		
			F		
			G		
			Н		
			I		
			Pattern		
		Size	Small		
			Medium*		
			Large		
		Angle	-90°		
			-45°*		
			0°		
			45°		
			90°		
		Transparency	-2		
			-1		
			0*		
			+1		
			+2		
		Colour	Red		
			Orange		
			Yellow		
		Blue			
			Green		
			Purple		
			Black*		
		Apply	_	1	



Option1	Option2	Option3	Option4	Descriptions	Page
Media	(Select image from media)	Position	A	Places a logo or text into	See <sup>1</sup> .
			В	your document as a Watermark using an	
			С	image from removable	
			D	media.	
			E*		
			F		
			G		
			Н		
			I		
			Pattern		
		Size	Small		
		Angle	Medium*		
			Large		
			-90°		
			-45°*		
			0°		
			45°		
			90°		
		Transparency	-2		
			-1		
			0*		
			+1		
			+2		
		Apply	_		
Scan	(Set page and press <b>Start</b> )	Transparency	-2	Places a logo or text into	
			-1	your document as a Watermark using a	
			0*	scanned image.	
			+1		
			+2		
		Apply	_		

<sup>&</sup>lt;sup>1</sup> See Advanced User's Guide.



### PHOTO CAPTURE ( )

Level1	Level2	Level3	Options	Descriptions	Page
View Photo(s)	_	_	See the print settings in the following table.	You can preview your photos on the LCD.	28
Print Index	Layout Format		6 Images/Line*	You can print a thumbnail page.	See <sup>1</sup> .
			5 Images/Line		
	Paper Type		Plain Paper*		
			Inkjet Paper		
			Brother BP71		
			Brother BP61		
			Other Glossy		
	Paper Size		A4*		
			Letter		
Print Photos	_	_	See the print settings in the	You can print an individual image.	
Enhance Photos	Auto Correct	_	following table.	You can adjust your photos with these settings.	
	Enhance Skin				
	Enhance Scenery				
	Remove Red-Eye				
	Monochrome				
	Sepia				
Search by Date	_	_		You can search your photos in date order.	
Print All Photos	_	_		You can print all photos in your media card or USB Flash memory drive.	
Slide Show	_	_		The machine starts a Slide Show of your photos.	
Trimming	_	_		You can trim your photo and print a part of the image.	
	<sup>1</sup> See Advanced	User's Guide.		1	1
		s are shown in Bold	with an actorial		



## **Print Settings**

Option1	Option2	Option3	Option4	Descriptions	Page
Print Quality	Normal	_	_	Choose the print quality.	See <sup>1</sup> .
(Does not appear for DPOF printing.)	Photo*				
Paper Type	Plain Paper	_	_	Choose the paper type.	
	Inkjet Paper				
	Brother BP71				
	Brother BP61				
	Other Glossy*				
Paper Size	10x15cm*	(When Letter or	_	Choose the paper and	
	13x18cm	A4 is chosen)		print size.	
	A4	8 x 10cm			
	Letter	9 x 13cm			
		10 x 15cm			
		13 x 18cm			
		15 x 20cm			
		Max. Size*			
Brightness		_	_	Adjusts the brightness.	
(Does not appear when					
Enhance Photos	*				
is chosen.)					
Contrast		_	_	Adjusts the contrast.	
(Does not appear					
when Enhance Photos	*				
is chosen.)					
	1 See Advanced	User's Guide			
	See Auvanceu	s are shown in Bold			

Option1 Option2		Option3	Option4	Descriptions	Page	
Color Enhance (Does not appear when Enhance Photos is chosen.)	On Off*	White Balance	+2 · · · · · · · · · · · · · · · · · · ·	Adjusts the hue of the white areas.	See <sup>1</sup> .	
		Sharpness	+2 · · · · · · · · · · · · · · · · · · ·	Enhances the detail of the image.		
		Color Density	+2 ' · · · · · · · · · · · · · · · · · ·	Adjusts the total amount of colour in the image.		
Cropping	On*		_	Crops the image around the margin to fit the paper size or print size. Turn this feature off if you want to print whole images or prevent unwanted cropping.		
Borderless	On*	_	_	Expands the printable area to fit the edges of the paper.		
Date Print (Does not appear when DPOF Print is chosen.)	On Off*		_	Prints the date on your photo.		
Set New Default	_	_	_	You can save your print settings.		
Factory Reset	_	_	_	You can restore all the settings to factory settings.		

See Advanced User's Guide.



The factory settings are shown in Bold with an asterisk.

## SCAN ( )

Level1	Option1	Option2	Option3	Descriptions	Page
Scan to File	_	_	_	You can scan a monochrome or a colour document into your computer.	See <sup>1</sup> .
Scan to Media	Quality	_	Color 150*	You can choose the scan	29
(When a memory			Color 300	resolution and file format for your document.	
card or USB Flash memory			Color 600		
drive is inserted.)			B/W 200x100		
			B/W 200		
	File Type	_	(If you chose Colour option in Quality setting)		
			PDF*		
			JPEG		
			(If you chose Mono option in Quality setting)		
			PDF*		
			TIFF		
	File Name	_	_		
	Auto Crop	_	On	Scan multiple documents	See <sup>2</sup> .
			Off*	placed on the scanner glass to a memory card or USB Flash memory drive one at a time.	
	Set New Default	_	_	You can save your scan settings.	
	Factory Reset	_	_	You can restore all settings to the factory settings.	
Scan to E-mail	_	_	_	You can scan a monochrome or a colour document into your E-mail application.	See <sup>1</sup> .
Scan to OCR <sup>3</sup> (DCP-J715W only)	_	_	_	You can have your text document converted to an editable text file.	
Scan to Image	_	_	_	You can scan a colour picture into your graphics application.	

- See Software User's Guide.
- <sup>2</sup> See Advanced User's Guide.
- (Macintosh users)
  Presto! PageManager must be downloaded and installed before use. See Accessing Brother Support (Macintosh) on page 3 for further instructions.



The factory settings are shown in Bold with an asterisk.

## **Entering Text**

Press ▲, ▼, ◀ or ▶ to select numbers or characters you want to choose, and press **OK** repeatedly until the file name is complete.

Press **△**, **▼**, **◄** or **▶** to select **○**K, and press **OK**.



### **Inserting special characters**

To enter special characters, press **△**, **▼**, **◄** or **▶** to select <u>A10</u>, and press **OK**.

### **Making corrections**

If you entered an incorrect letter and want to change it, press  $\blacktriangle$ ,  $\blacktriangledown$ ,  $\blacktriangleleft$  or  $\blacktriangleright$  to select  $\bigcirc$  or  $\bigcirc$ . Press **OK** several times to move the cursor under the incorrect character. Then press  $\blacktriangle$ ,  $\blacktriangledown$ ,  $\blacktriangleleft$  or  $\blacktriangleright$  to select  $\bigcirc$  and press **OK**. Re-enter the correct letter.

## **Specifications**

## **General**

Printer Type Inkjet

**Print Method** Mono: Piezo with  $94 \times 1$  nozzle

Colour: Piezo with  $94 \times 3$  nozzles

**Memory Capacity** 40 MB

LCD (Liquid Crystal Display) Wide 3.3 in. (82.79 mm) TFT Colour LCD

Power Source AC 220 to 240V 50/60Hz

Power Consumption <sup>1</sup> (DCP-J515W)

Copying Mode: Approx. 17 W<sup>2</sup>

Standby Mode: Approx. 3.5 W
Sleep Mode: Approx. 2 W
Off: Approx. 0.5 W

(DCP-J715W)

Copying Mode: Approx. 17 W <sup>3</sup>
Standby Mode: Approx. 6 W
Sleep Mode: Approx. 3.5 W
Off: Approx. 0.5 W


When all the modes are connected to USB.


When resolution: standard, draft: ISO/IEC24712 printed pattern.

When using ADF, resolution: standard, draft: ISO/IEC24712 printed pattern.


#### **Dimensions**

#### (DCP-J515W)





#### (DCP-J715W)



Weight (DCP-J515W) 6.9 kg

(DCP-J715W) 7.5 kg

**Noise** Operating: LPAm = 50 dB (A) or less  $^1$ 

Noise per ISO9296 Operating: LwAd = 62.3 dB (A) (Mono)

LwAd = 56.7 dB (A) (Colour)

Office equipment with LwAd > 63.0 dB (A) is not suitable for use in rooms where people do primarily intellectual work. Such equipment should be placed in separate rooms because of the noise emission.

**Temperature** Operating: 10 - 35 °C

Best Print Quality: 20 - 33 °C

**Humidity** Operating: 20 - 80% (without condensation)

Best Print Quality: 20 - 80% (without condensation)

ADF (automatic document feeder) (DCP-J715W only)

Up to 15 pages

Paper: 80 g/m<sup>2</sup> A4 or Letter size

**Document Size** ADF Width (DCP-J715W): 148 mm to 215.9 mm

ADF Length (DCP-J715W): 148 mm to 355.6 mm

Scanner Glass Width: Max. 215.9 mm Scanner Glass Length: Max. 297 mm

Noise depends on printing conditions.

### **Print media**

#### **Paper Input**

#### **Paper Tray**

■ Paper type:

Plain paper, inkjet paper (coated paper), glossy paper <sup>1</sup>, transparencies <sup>1 2</sup> and envelopes

■ Paper size:

A4, Legal, Executive, Letter, A5, A6, JIS B5, envelopes (commercial No.10, DL, C5, Monarch, JE4), Photo  $10 \times 15$  cm, Photo 2L  $13 \times 18$  cm, Index card and Postcard  $^3$ 

Width: 98 mm - 215.9 mm

Length: 148 mm - 355.6 mm

For more details, see *Paper weight, thickness and capacity* on page 20.

■ Maximum paper tray capacity:

Approx. 100 sheets of 80 g/m<sup>2</sup> plain paper

#### **Photo Paper Tray**

■ Paper type:

Plain paper, inkjet paper (coated paper) and glossy paper <sup>1</sup>

■ Paper size:

Photo 10  $\times$  15 cm and Photo L 89  $\times$  127 mm

Width: 89 mm - 102 mm

Length: 127 mm - 152 mm

■ Maximum paper tray capacity:

Approx. 20 sheets

#### **Paper Output**

Up to 50 sheets of A4 plain paper (face up print delivery to the output paper tray) <sup>1</sup>

For glossy paper or transparencies, we recommend removing printed pages from the output paper tray immediately after they exit the machine to avoid smudging.

<sup>&</sup>lt;sup>2</sup> Use only transparencies recommended for inkjet printing.

<sup>&</sup>lt;sup>3</sup> See Paper type and size for each operation on page 19.

## Copy

**Colour/Monochrome** 

**Copy Width** 

**Multiple Copies** 

Enlarge/Reduce

Resolution

Yes/Yes

Max. 210 mm

Stacks up to 99 pages

25% to 400% (in increments of 1%)

(Monochrome)

■ Prints up to 1200 × 1200 dpi

(Colour)

■ Prints up to 600 × 1200 dpi

## PhotoCapture Center™

Compatible Media <sup>1</sup> Memory Stick™ (16 MB - 128 MB)

Memory Stick PRO™ (256 MB - 16 GB)
Memory Stick Duo™ (16 MB - 128 MB)

Memory Stick PRO Duo™ (256 MB - 16 GB)
Memory Stick Micro™ (M2™) with adapter

SD (16 MB to 2 GB) SDHC (4 GB to 16 GB) microSD with adapter miniSD with adapter

USB Flash memory drive <sup>2</sup> (DCP-J715W only)

**Resolution** Up to  $1200 \times 2400$  dpi

File Extension DPOF (ver.1.0, ver.1.1), Exif DCF (up to ver.2.1)

(Media Format) Photo Print: JPEG <sup>3</sup>, AVI <sup>4</sup>, MOV <sup>4</sup>

(Image Format) Scan to Media: JPEG, PDF (Colour)

TIFF, PDF (Monochrome)

Number of Files Up to 999 files

(The folder inside memory cards or USB Flash memory drive

is also counted.)

**Folder** File must be stored in the 4th folder level of the memory card

or USB Flash memory drive.

**Borderless** A4, Letter, Photo  $10 \times 15$  cm, Photo 2L  $13 \times 18$  cm  $^5$ 

Memory cards, adapters and USB Flash memory drive are not included.

USB 2.0 standard USB Mass Storage standard from 16 MB to 32 GB Support format: FAT12/FAT16/FAT32

<sup>&</sup>lt;sup>3</sup> Progressive JPEG format is not supported.

<sup>4</sup> Motion JPEG only

<sup>&</sup>lt;sup>5</sup> See Paper type and size for each operation on page 19.

## PictBridge (DCP-J715W only)

**Compatibility** Supports the Camera & Imaging Products Association

PictBridge standard CIPA DC-001.

Visit <a href="http://www.cipa.jp/pictbridge">http://www.cipa.jp/pictbridge</a> for more information.

Interface USB direct interface

### Scanner

Colour/Monochrome Yes/Yes

TWAIN Compliant

Yes (Windows® 2000 Professional/Windows® XP/

Windows® XP Professional x64 Edition/Windows Vista®/

Windows® 7)

Mac OS X 10.4.11 - 10.5.x - 10.6.x 1

WIA Compliant

Yes (Windows® XP <sup>2</sup>/Windows Vista®/Windows® 7)

ICA Compliant Yes (Mac OS X 10.6.x)

**Colour Depth** 36 bit colour Processing (Input)

24 bit colour Processing (Output)

(Actual Input: 30 bit colour/Actual Output: 24 bit colour)

**Resolution** Up to  $19200 \times 19200$  dpi (interpolated) <sup>3</sup>

Up to 1200 × 2400 dpi (optical) (Scanner Glass)

Up to  $1200 \times 600$  dpi (optical) (ADF) (DCP-J715W)

**Scanning Speed** Monochrome: up to 3.44 sec.

Colour: up to 4.83 sec.

(A4 size at  $100 \times 100$  dpi)

Scanning WidthUp to 210 mmScanning LengthUp to 291 mmGreyscale256 levels

For the latest driver updates for the Mac OS X you are using, visit us at http://solutions.brother.com/

Windows<sup>®</sup> XP in this User's Guide includes Windows<sup>®</sup> XP Home Edition, Windows<sup>®</sup> XP Professional, and Windows<sup>®</sup> XP Professional x64 Edition.

Maximum  $1200 \times 1200$  dpi scanning when using the WIA Driver for Windows<sup>®</sup> XP, Windows Vista<sup>®</sup> and Windows<sup>®</sup> 7 (resolution up to  $19200 \times 19200$  dpi can be chosen by using the Brother scanner utility).

## **Printer**

**Resolution** Up to  $1200 \times 6000 \text{ dpi}$ 

Printing Width 204 mm [210 mm (borderless) 1] 3

**Borderless** A4, Letter, A6, Photo  $10 \times 15$  cm,

Index Card 127  $\times$  203 mm, Photo L 89  $\times$  127 mm, Photo 2L 13  $\times$  18 cm, Postcard 1 100  $\times$  148 mm  $^2$ 

When you set the Borderless feature to On.

- <sup>2</sup> See Paper type and size for each operation on page 19.
- When printing on A4 size paper.

## **Interfaces**

USB 12 Use a USB 2.0 interface cable that is no longer than 2 m.

LAN cable <sup>3</sup> (DCP-J715W only) Use an Ethernet UTP cable category 5 or greater.

Wireless LAN IEEE 802.11b/g (Infrastructure/Ad-hoc Mode)

- <sup>2</sup> Third party USB ports are not supported.
- <sup>3</sup> See *Network (LAN)* on page 80 and the *Network User's Guide* for detailed network specifications.

Your machine has a Hi-Speed USB 2.0 interface (DCP-J715W only).

The machine can also be connected to a computer that has a USB 1.1 interface.

## **Computer requirements**

SUPPORTED OPERATING SYSTEMS AND SOFTWARE FUNCTIONS								
Computer Platform & Operating System Version		Supported PC Software Functions	DC.	Processor Minimum Speed	Minimum RAM	Recommended -	Hard Disk Space to install	
			Interface				For Drivers	For Applications
Windows <sup>®</sup> Operating System <sup>1</sup>	Windows <sup>®</sup> 2000 Professional <sup>4</sup>	Printing, Scanning, Removable Disk <sup>5</sup>	USB, 10/100 Base-TX (Ethernet) (DCP-J715W)	Intel <sup>®</sup> Pentium <sup>®</sup> II or equivalent	64 MB	256 MB	110 MB	340 MB
	Windows <sup>®</sup> XP Home <sup>2 4</sup> Windows <sup>®</sup> XP Professional <sup>2 4</sup>			·	128 MB		110 MB	340 MB
	Windows <sup>®</sup> XP Professional x64 Edition <sup>2</sup>		Wireless 802.11b/g	64-bit (Intel <sup>®</sup> 64 or AMD64) supported CPU	256 MB	512 MB	110 MB	340 MB
	Windows Vista <sup>® 2</sup>			Intel® Pentium® 4	512 MB	1 GB	600 MB	530 MB
	Windows <sup>®</sup> 7 <sup>2</sup>			or equivalent 64-bit (Intel <sup>®</sup> 64 or AMD64) supported CPU	1 GB (32 bit) 2 GB (64 bit)	1 GB (32 bit) 2 GB (64 bit)	650 MB	530 MB
	Windows Server® 2003 (print only via network)	Printing	10/100 Base-TX	Intel <sup>®</sup> Pentium <sup>®</sup> III or equivalent	256 MB	512 MB	50 MB	N/A
200 (pr Wir	Windows Server® 2003 x64 Edition (print only via network)	(DC Wi 802	(Ethernet) (DCP-J715W) Wireless 802.11b/g	64-bit (Intel <sup>®</sup> 64 or AMD64) supported CPU				
	Windows Server® 2003 R2 (print only via network)			Intel <sup>®</sup> Pentium <sup>®</sup> III or equivalent				
	Windows Server <sup>®</sup> 2003 R2 x64 Edition (print only via network)			64-bit (Intel <sup>®</sup> 64 or AMD64) supported CPU	512 MB	1 GB		
200 netv	Windows Server® 2008 (print only via network)			Intel <sup>®</sup> Pentium <sup>®</sup> 4 or equivalent 64-bit (Intel <sup>®</sup> 64 or AMD64) supported CPU		2 GB		
	Windows Server® 2008 R2 (print only via network)			64-bit (Intel <sup>®</sup> 64 or AMD64) supported CPU				
Macintosh Operating System	Mac OS X 10.4.11 - 10.5.x	Printing, Scanning, Removable	USB <sup>3</sup> , 10/100 Base-TX	PowerPC G4/G5 Intel <sup>®</sup> Core™ Processor	512 MB	1 GB	80 MB	400 MB
	Mac OS X 10.6.x	Disk <sup>5</sup>	(Ethernet) (DCP-J715W) Wireless 802.11b/g	Intel <sup>®</sup> Core™ Processor	1 GB	2 GB		

#### Conditions:

Microsoft<sup>®</sup> Internet Explorer<sup>®</sup> 5.5 or greater.

For WIA, 1200 × 1200 resolution. Brother Scanner Utility enables to enhance up to  $19200 \times 19200$  dpi.

Third party USB ports are not supported.
PaperPort<sup>™</sup>11SE supports Microsoft<sup>®</sup> SP4 or higher for Windows<sup>®</sup> 2000 and SP2 or higher for XP (DCP-J715W only).

Removable disk is a function of PhotoCapture Center™.

For the latest driver updates, visit http://solutions.brother.com/

All trademarks, brand and product names are the property of their respective companies.

### Consumable items

Ink

The machine uses individual Black, Yellow, Cyan and Magenta ink cartridges that are separate from the print head assembly.

## Service Life of Ink Cartridge

The first time you install a set of ink cartridges the machine will use an amount of ink to fill the ink delivery tubes for high quality printouts. This process will only happen once. After this process is complete the cartridges provided with your machine will have a lower yield than standard cartridges (65%). With all following ink cartridges you can print the specified number of pages.

## Replacement Consumables

(DCP-J515W)

<Low Yield Black> LC985BK, <Low Yield Cyan> LC985C, <Low Yield Magenta> LC985M, <Low Yield Yellow> LC985Y

Black - Approximately 300 pages <sup>1</sup>

Cyan, Magenta, Yellow - Approximately 260 pages <sup>1</sup> (DCP-J715W)

<Standard Black> LC1100BK, <Standard Cyan> LC1100C, <Standard Magenta> LC1100M, <Standard Yellow> LC1100Y

Black - Approximately 450 pages 1

Cyan, Magenta, Yellow - Approximately 325 pages 1

<sup>1</sup> Approx. cartridge yield is declared in accordance with ISO/IEC 24711

For more information about the replacement consumables, visit us at www.brother.com/pageyield

#### What is Innobella™?

Innobella™ is a range of genuine consumables offered by Brother. The name "Innobella™" derives from the words "Innovation" and "Bella" (meaning "Beautiful" in Italian) and is a representation of the "innovative" technology providing you with "beautiful" and "long lasting" print results.



When you print photo images, Brother recommends Innobella™ glossy photo paper (BP71 series) for high quality. Brilliant prints are made easier with Innobella™ Ink and paper.

## **Network (LAN)**



For details about the full Network specifications, see the Network User's Guide.

**LAN** You can connect your machine to a network for Network Printing,

Network Scanning and access photos from PhotoCapture Center  $^{\rm TM}$  1. Also included is Brother BRAdmin Light 2 Network Management

software.

**Wireless Network** 

SSID (32 chr), WEP 64/128 bit, WPA-PSK (TKIP/AES),

Security

WPA2-PSK (AES)

**Setup Support Utility** 

AOSS™ Yes

WPS Yes

See the Computer Requirements chart on page 78.

If you require more advanced printer management, use the latest Brother BRAdmin Professional utility version that is available as a download from http://solutions.brother.com/

# Index

A	G
ADF (automatic document feeder)21 Apple Macintosh	Greyscale75
See Software User's Guide.	Н
C	Help
Cleaning paper pick-up roller	LCD messages
scanner	Ink cartridges ink dot Counter
ControlCenter See Software User's Guide. Copy	replacing
paper size24 paper type24	J
using scanner glass21	Jams document
Document	L
loading 21, 22	LCD (Liquid Crystal Display)
Envelopes 10, 11, 12, 19, 20	M
Error messages on LCD       39         B&W Print Only       39         Cannot Print       40         Cover is Open       40	Macintosh See Software User's Guide. Maintenance, routine
Data Remaining40 Document Jam40 Ink Low41	replacing ink cartridges
No Ink Cartridge41  No Paper Fed41  Out of Memory42	Scan5
Paper Jam42 Unable to Clean42	Network
Unable to Init	Printing See Network User's Guide. Scanning See Software User's Guide.
	Number of Copies key

#### 0

On/Off key4 Out of Memory message42
P
Paper
in the PaperPort™11SE application.  Photo Paper Tray12  PhotoCapture Center™  from PC  See Software User's Guide.
Memory Stick PRO™       25         Memory Stick™       25         Preview photos       28         Print settings
Quality       28         SD       25         SDHC       25         specifications       73         Presto! PageManager
See Software User's Guide. See also Help in the Presto! PageManager application.  Print
area       15         difficulties       46         improving quality       37         on small paper       14         paper jams       44         resolution       76         specifications       76         Programming your machine       52

#### R

Resolution

print	72 76 75
S	
Scannable area Scanner glass	22
cleaning	35 21
Scanning See Software User's	
Serial Number how to find	See inside front cover

#### I

Transparencies 16, 17, 18, 19, 20 Troubleshooting	•
•	
document jam	
error messages on LCD	39
if you are having difficulty	
copying	48
Network	50
PhotoCapture Center™	49
printing	46
scanning	48
software	49
paper jam	44
print alignment	
print quality	

## W

Windows<sup>®</sup> See Software User's Guide.



Visit us on the World Wide Web http://www.brother.com

This machine is approved for use in the country of purchase only. Local Brother companies or their dealers will only support machines purchased in their own countries.