


# Basic User's Guide

MFC-J245



## **If you need to contact Customer Service**

**Please complete the following information for future reference:**

**Model Number:** MFC-J245

**Serial Number:** <sup>1</sup> \_\_\_\_\_

**Date of Purchase:** \_\_\_\_\_

**Place of Purchase:** \_\_\_\_\_

<sup>1</sup> **The serial number is on the back of the unit. Retain this User's Guide with your sales receipt as a permanent record of your purchase, in the event of theft, fire or warranty service.**

**Register your product on-line at**

**<http://www.brother.com/registration/>**

# User's Guides and where do I find them?

Which Guide?	What's in it?	Where is it?
<b>Product Safety Guide</b>	Read this Guide first. Please read the Safety Instructions before you set up your machine. See this Guide for trademarks and legal limitations.	Printed / In the box
<b>Quick Setup Guide</b>	Follow the instructions for setting up your machine and installing the drivers and software for the operating system and connection type you are using.	Printed / In the box
<b>Basic User's Guide</b>	Learn the basic Fax, Copy and Scan operations, and how to replace consumables. See troubleshooting tips.	Printed / In the box <sup>1</sup>
<b>Advanced User's Guide</b>	Learn more advanced operations: Fax, Copy, security features, printing reports and performing routine maintenance.	PDF file / CD-ROM
<b>Software and Network User's Guide <sup>2</sup></b>	This Guide provides instructions for Scanning, Printing, PC-Fax and other operations that can be performed by connecting your Brother machine to a computer. You can also find useful information about using the Brother ControlCenter utility, using your machine in a network environment, and frequently used terms.	HTML file/CD-ROM

<sup>1</sup> This may differ depending on your country.

<sup>2</sup> Network features are not supported by the MFC-J245.

# Table of Contents

## (Basic User's Guide)

<b>1</b>	<b>General information</b>	<b>1</b>
	Using the documentation .....	1
	Symbols and conventions used in the documentation .....	1
	Accessing Brother Utilities (Windows® 8) .....	2
	Accessing the Advanced User's Guide and Software and Network User's Guide .....	2
	Viewing User's Guides .....	2
	Accessing Brother Support (Windows®) .....	4
	Accessing Brother Support (Macintosh) .....	5
	Control panel overview .....	6
	Basic Operations .....	8
	Volume Settings .....	8
	Ring Volume .....	8
	Beep Volume .....	9
	Speaker Volume .....	9
	LCD display .....	9
	LCD Contrast .....	9
<b>2</b>	<b>Loading paper</b>	<b>10</b>
	Loading paper and other print media .....	10
	Loading envelopes .....	12
	Unprintable area .....	15
	Paper settings .....	16
	Paper Type .....	16
	Paper Size .....	16
	Acceptable paper and other print media .....	16
	Recommended print media .....	17
	Handling and using print media .....	17
	Choosing the right print media .....	18
<b>3</b>	<b>Loading documents</b>	<b>19</b>
	How to load documents .....	19
	Using the ADF .....	19
	Using the scanner glass .....	20
	Unscannable area .....	21
<b>4</b>	<b>Sending a fax</b>	<b>22</b>
	How to send a fax .....	22
	Stop faxing .....	23
	Setting scanner glass size for faxing .....	23
	Colour fax transmission .....	23
	Cancelling a fax in progress .....	23
	Transmission Verification Report .....	24

<b>5</b>	<b>Receiving a fax</b>	<b>25</b>
	Receive Modes .....	25
	Choose the Receive Mode .....	25
	Using Receive Modes .....	26
	Fax Only .....	26
	Fax/Tel.....	26
	Manual.....	26
	External TAD .....	26
	Receive Mode settings .....	27
	Ring Delay .....	27
	F/T Ring Time (Fax/Tel mode only).....	27
	Fax Detect .....	28
<b>6</b>	<b>Telephone and external devices</b>	<b>29</b>
	Voice operations .....	29
	Fax/Tel mode.....	29
	Caller ID (U.K. and Ireland only).....	29
	Telephone services.....	30
	Setting the Telephone Line Type.....	30
	Voice over Internet Protocol (VoIP).....	31
	Connecting an external TAD (telephone answering device).....	32
	Connection settings .....	32
	Recording an outgoing message (OGM) on an external TAD.....	33
	Multi-line connections (PBX) .....	33
	External and extension telephones.....	34
	Connecting an external or extension telephone .....	34
	Operation from external and extension telephones .....	34
	Using extension telephones (U.K. only) .....	35
	Using remote codes.....	36
<b>7</b>	<b>Dialling and storing numbers</b>	<b>37</b>
	How to dial .....	37
	Manual dialling.....	37
	Speed Dialling .....	37
	Fax Redial .....	37
	Storing numbers .....	38
	Storing a pause .....	38
	Storing Speed Dial numbers.....	38
	Changing and deleting Speed Dial numbers .....	39
<b>8</b>	<b>Making copies</b>	<b>40</b>
	How to copy .....	40
	Stop copying.....	40
	Copy options.....	41
	Paper Type .....	41
	Paper Size .....	41

<b>9</b>	<b>How to print from a computer</b>	<b>42</b>
	Printing a document.....	42
<b>10</b>	<b>How to scan to a computer</b>	<b>43</b>
	Before scanning.....	43
	Scanning a document as a PDF file using ControlCenter4 (Windows®).....	43
	How to change the machine's SCAN mode settings for PDF scanning using ControlCenter4 (Windows®).....	47
	How to scan a document as a PDF file using the control panel (Windows® and Macintosh).....	49
<b>A</b>	<b>Routine maintenance</b>	<b>50</b>
	Replacing the ink cartridges.....	50
	Cleaning and checking the machine.....	53
	Cleaning the scanner glass.....	53
	Cleaning the print head.....	54
	Checking the print quality.....	54
	Checking the print alignment.....	55
	Setting the date and time.....	56
<b>B</b>	<b>Troubleshooting</b>	<b>57</b>
	Identifying your problem.....	57
	Error and maintenance messages.....	59
	Transferring your faxes or Fax Journal report.....	66
	Document jam.....	67
	Printer jam or paper jam.....	68
	If you are having difficulty with your machine.....	76
	Dial Tone detection.....	86
	Telephone line interference / VoIP.....	86
	Machine Information.....	87
	Checking the serial number.....	87
	Checking the firmware version.....	87
	Reset functions.....	87
	How to reset the machine.....	87
<b>C</b>	<b>Settings and features tables</b>	<b>88</b>
	Using the Settings tables.....	88
	Menu keys.....	88
	Menu table.....	90
	Entering Text.....	103
	Inserting spaces.....	103
	Making corrections.....	103
	Repeating letters.....	103
	Special characters and symbols.....	104

---

**D Specifications 105**

---

General ..... 105  
Print media..... 107  
Fax..... 108  
Copy ..... 109  
Scanner ..... 110  
Printer ..... 111  
Interfaces ..... 112  
Computer requirements ..... 113  
Consumable items ..... 114

**E Index 115**

---

# Table of Contents

## (Advanced User's Guide)

The Advanced User's Guide explains the following features and operations.

You can view the Advanced User's Guide on the CD-ROM.

### **1 General setup**

---

*Memory Storage*  
*Automatic Daylight Saving Time (MFC model)*  
*Sleep Mode*  
*Auto Power Off (DCP model)*  
*LCD*  
*Mode Timer (MFC model)*

### **2 Security features (MFC model)**

---

*TX Lock*

### **3 Sending a fax (MFC model)**

---

*Additional sending options*  
*Additional sending operations*

### **4 Receiving a fax (MFC model)**

---

*Memory Receive (Monochrome only)*  
*Additional receiving operations*

### **5 Dialling and storing numbers (MFC model)**

---

*Voice operations*  
*Additional dialling operations*  
*Additional ways to store numbers*

### **6 Printing reports**

---

*Fax reports (MFC model)*  
*Reports*

### **7 Making copies**

---

*Copy options*

### **A Routine maintenance**

---

*Cleaning and checking the machine*  
*Packing and shipping the machine*

### **B Glossary**

---

### **C Index**

---



## Using the documentation

Thank you for buying a Brother machine! Reading the documentation will help you make the most of your machine.

## Symbols and conventions used in the documentation

---

The following symbols and conventions are used throughout the documentation.

<b>Bold</b>	Bold typeface identifies specific buttons on the machine's control panel, or on the computer screen.
<i>Italics</i>	Italicized typeface emphasizes an important point or refers you to a related topic.
Courier New	Text in the Courier New font identifies messages on the LCD of the machine.

### **WARNING**

WARNING indicates a potentially hazardous situation which, if not avoided, could result in death or serious injuries.

### **CAUTION**


CAUTION indicates a potentially hazardous situation which, if not avoided, may result in minor or moderate injuries.

### **IMPORTANT**

IMPORTANT indicates a potentially hazardous situation which, if not avoided, may result in damage to property or loss of product functionality.

### **NOTE**


Notes tell you how to respond to a situation that may arise or give tips about how the operation works with other features.

 Electrical Hazard icons alert you to possible electrical shocks.


## Accessing Brother Utilities (Windows® 8)

If you are using a tablet or PC running Windows® 8, you can make your selections either by tapping the screen or by clicking with your mouse.


After the printer driver is installed,

 (**Brother Utilities**) appears on both the Start screen and the desktop.

- 1 Tap or click **Brother Utilities** from either the Start screen or the desktop.



- 2 Select your machine.



- 3 Choose the function you want to use.


## Accessing the Advanced User's Guide and Software and Network User's Guide

This Basic User's Guide does not contain all the information about the machine, such as how to use the advanced Fax, Copy, Printer, Scanner, and PC-Fax. When you are ready to learn detailed information about these operations, you can read the **Advanced User's Guide** and **Software and Network User's Guide** in HTML format that are on the CD-ROM.


### Viewing User's Guides

#### (Windows®)

(Windows® XP/Windows Vista®/  
Windows® 7)

 (**Start**), **All Programs**, select **Brother**, **MFC-XXXX** (where XXXX is your model name) from the programs list, and then choose **User's Guides**.

(Windows® 8)


Click  (**Brother Utilities**), and then click the drop-down list and select your model name (if not already selected). Click **Support** in the left navigation bar, and then click **User's Guides**.

If you have not installed the software, you can find the documentation on the CD-ROM by following these instructions:


- 1 Turn on your PC. Insert the Brother CD-ROM into your CD-ROM drive.

## NOTE

If the Brother screen does not appear, go to **Computer** or **My Computer**. (For

Windows<sup>®</sup> 8: Click  (**File Explorer**) on the taskbar, and then go to **Computer**.) Double-click the CD-ROM icon, and then double-click **start.exe**.

- 2 If the model name screen appears, click your model name.
- 3 If the language screen appears, click your language. The CD-ROM **Top Menu** will appear.



- 4 Click **User's Guides**.
- 5 Click **PDF/HTML documents**. If the country screen appears, choose your country. After the list of User's Guides appears, choose the guide you want to read.

## (Macintosh)

- 1 Turn on your Macintosh. Insert the Brother CD-ROM into your CD-ROM drive. The following window will appear.



- 2 Double-click the **User's Guides** icon.
- 3 Select your model and language if needed.
- 4 Click **User's Guides**. If the country screen appears, choose your country.
- 5 After the list of User's Guides appears, choose the Guide you want to read.

## How to find Scanning instructions

There are several ways you can scan documents. You can find the instructions as follows:

### Software and Network User's Guide

- *Scan*
- *ControlCenter*

### Nuance<sup>™</sup> PaperPort<sup>™</sup> 12SE

#### How-to-Guides

#### (Windows<sup>®</sup>)

- The complete Nuance<sup>™</sup> PaperPort<sup>™</sup> 12SE How-to-Guides can be viewed from the Help section in the PaperPort<sup>™</sup> 12SE application.

## Presto! PageManager User's Guide (Macintosh)

### NOTE


Presto! PageManager must be downloaded and installed before use. For more information, see *Accessing Brother Support (Macintosh)* on page 5.

- The complete Presto! PageManager User's Guide can be viewed from the Help section in the Presto! PageManager application.

## Accessing Brother Support (Windows®)

You can find all the contacts you will need, such as web support (Brother Solutions Center) on the CD-ROM.

- Click **Brother Support** on the **Top Menu**. The following screen will appear:



- To access our website (<http://www.brother.com/>), click **Brother Home Page**.
- For the latest news and product support information (<http://solutions.brother.com/>), click **Brother Solutions Center**.
- To visit our website for original Brother Supplies (<http://www.brother.com/original/>), click **Supplies Information**.
- To access the Brother CreativeCenter (<http://www.brother.com/creativecenter/>) for FREE photo projects and printable downloads, click **Brother CreativeCenter**.
- To return to the top menu, click **Back** or if you have finished, click **Exit**.

# Accessing Brother Support (Macintosh)


You can find all the contacts you will need, such as web support (Brother Solutions Center) on the CD-ROM.

- Double-click the **Brother Support** icon. The following screen will appear:



- To download and install Presto! PageManager, click **Presto! PageManager**.
- To register your machine from the Brother Product Registration Page (<http://www.brother.com/registration/>), click **On-Line Registration**.
- For the latest news and product support information (<http://solutions.brother.com/>), click **Brother Solutions Center**.
- To visit our website for original Brother Supplies (<http://www.brother.com/original/>), click **Supplies Information**.




# Control panel overview













## 1 LCD (Liquid Crystal Display)

Displays messages on the screen to help you set up and use your machine.



## 2 Mode keys:

-  **FAX**  
Lets you access the Fax mode.
-  **SCAN**  
Lets you access the Scan mode.
-  **COPY**  
Lets you access the Copy mode.

## 3 Menu keys:

-      
While the machine is idle, you can press these keys to adjust the ring volume.
-    
Lets you store, look up, and dial numbers that are stored in the memory.
-  or   
Press  or  to move the selected area left or right on the LCD.

## ■ or

Press  or  to scroll through the menus and options.

## ■ **Menu**

Access the main menu.

## ■ **Clear**

Press to delete characters or to go back to the previous menu level.

## ■ **OK**

Lets you choose a setting.

## 4 **Copy Options**

Lets you temporarily change the copy settings when in copy mode.

## 5 **Telephone keys:**


### ■ **Redial/Pause**

Redials the last number called. It also inserts a pause when dialling.

### ■ **Tel/R**

This key is used to have a telephone conversation after picking up the external handset during the F/T Ring (fast double-ring).


Also, when connected to a PBX, you can use this key to gain access to an outside line or to transfer a call to another extension.




## 6 Start keys:


- Mono Start**  
 Lets you start sending faxes or making copies in monochrome. Also lets you start a scanning operation (in colour or mono depending on the scan setting in the ControlCenter software).
- Colour Start**  
 Lets you start sending faxes or making copies in full colour. Also lets you start a scanning operation (in colour or mono, depending on the scan setting in the ControlCenter software).

## 7 Power On/Off

Press  to turn on the machine.

Press and hold down  to turn off the machine. The LCD will show *Shutting Down* and will stay on for a few seconds before turning off.

If you have connected an external telephone or TAD, it is always available.

If you turn off the machine using , it will still periodically clean the print head to maintain print quality. To prolong the life of the print head, provide better ink efficiency and maintain print quality, you should keep your machine connected to the power at all times.

## 8 Stop/Exit

Stops an operation or exits the menu.

## 9 Dial Pad






Use these keys to dial telephone and fax numbers and as a keyboard for entering information into the machine.

## 10 Fax Resolution

Lets you temporarily change the resolution when sending a fax.

## Basic Operations

The following steps show how to change a setting in the machine. In this example, the Receive Mode setting is changed from *Fax Only* to *Fax/Tel*.

- 1 Press  (**FAX**).
- 2 Press **Menu**, **3**, **1**, **1**.  
  

- 3 Press **▲** or **▼** to choose *Fax/Tel*.  

- 4 Press **OK**.  


### NOTE



Press **Clear** if you want to go back to the previous level.

- 5 Press **Stop/Exit**.

## Volume Settings

### Ring Volume

You can choose from a range of ring volume levels, from *High* to *Off*.

While the machine is idle, press  **◀** or **▶**  to adjust the volume level. The LCD shows the current setting, and each key press will change the volume to the next level. The machine will keep the new setting until you change it.

You can also change the volume through the menu, by following the instructions below:

### Setting the Ring Volume

- 1 Press **Menu**, **2**, **4**, **1**.
- 2 Press **▲** or **▼** to choose *Low*, *Med*, *High* or *Off*.  
Press **OK**.
- 3 Press **Stop/Exit**.



## Beep Volume

---

When the beep is on, the machine will make a sound when you press a key, or if you make a mistake, or after you send or receive a fax.

You can choose from a range of sound volume levels.

- 1 Press **Menu, 2, 4, 2**.
- 2 Press **▲** or **▼** to choose *Low, Med, High* or *Off*. Press **OK**.
- 3 Press **Stop/Exit**.

## Speaker Volume

---

You can choose from a range of speaker volume levels.

- 1 Press **Menu, 2, 4, 3**.
- 2 Press **▲** or **▼** to choose *Low, Med, High* or *Off*. Press **OK**.
- 3 Press **Stop/Exit**.

## LCD display

### LCD Contrast

---

You can adjust the LCD contrast for a sharper and more vivid display. If you are having difficulty reading the LCD, try changing the contrast setting.

- 1 Press **Menu, 2, 5**.
- 2 Press **▲** or **▼** to choose *Light* or *Dark*. Press **OK**.
- 3 Press **Stop/Exit**.

# 2


## Loading paper

### Loading paper and other print media

Load only one size of paper and one type of paper in the paper tray at any time.


(For more information about paper size, weight and thickness, see *Choosing the right print media* on page 18.)

- 1 Pull the paper tray completely out of the machine.




#### NOTE

- If the paper support flap (1) is open, close it, and then close the paper support (2).




- When you load a different paper size in the tray, you will need to change the Paper Size setting in the menu of the machine at the same time.  
(See *Paper Size* on page 16.)


- 2 Lift the output paper tray cover (1).



- 3 Gently press and slide the paper width guides (1) and then the paper length guide (2) to fit the paper size. Make sure that the triangular marks (3) on the paper width guides (1) and paper length guide (2) line up with the marks for the paper size you are using.




- 4 Fan the stack of paper well to avoid paper jams and misfeeds.



### NOTE

Always make sure that the paper is not curled or wrinkled.

- 5 Gently put the paper into the paper tray print side down and top edge in first. Check that the paper is flat in the tray.




### IMPORTANT

Be careful not to push the paper in too far; it may lift at the back of the tray and cause paper feed problems.


### NOTE

If you want to add paper before the tray is empty, remove the paper from the tray and combine it with the paper you are adding. Always fan the stack of paper well before loading it in the tray. If you add paper without fanning the stack, the machine may feed multiple pages.


- 6 Gently adjust the paper width guides (1) to fit the paper. Make sure the paper width guides lightly touch the sides of the paper.




- 7 Close the output paper tray cover.



- 8 *Slowly and firmly* push the paper tray completely into the machine.



- 9 While holding the paper tray in place, pull out the paper support (1) until it locks into place, and then unfold the paper support flap (2).



## Loading envelopes

### About envelopes

- Use envelopes that weigh between 80 to 95 g/m<sup>2</sup>.
- Some envelopes need margin settings to be set in the application. Make sure you do a test print first before printing multiple envelopes.

### IMPORTANT

DO NOT use the following types of envelopes, as they will not feed correctly:

- That are of a baggy construction.
- That have windows.
- That are embossed (have raised writing on them).
- That have clasps or staples.
- That are pre-printed on the inside.

Glue	Double flaps


Occasionally you may experience paper feed problems caused by the thickness, size and flap shape of the envelopes you are using.

## Loading envelopes


- 1 Before loading, press the corners and sides of envelopes to make them as flat as possible.

### IMPORTANT

If envelopes are “double-feeding”, put one envelope in the paper tray at a time.




- 2 Put envelopes in the paper tray with the address side down. If the envelope flaps are on the long edge, load the envelopes in the tray with the flap on the left, as shown in the illustration. Gently press and slide the paper width guides (1) and paper length guide (2) to fit the size of the envelopes.



**If you have problems printing on envelopes with the flap on the short edge, try the following:**

- 1 Open the envelope flap.
- 2 Put the envelope into the paper tray with the address side down and the flap positioned as shown in the illustration.




- 3 Select **Reverse Print** (Windows®) or **Reverse page orientation** (Macintosh) in the printer driver's dialog box, and then adjust the size and margin in your application.  
(See Software and Network User's Guide.)

## Unprintable area


The printable area depends on the settings in the application you are using. The figures show the unprintable areas on cut-sheet paper and envelopes. The machine can print in the shaded areas of cut-sheet paper when the Borderless print feature is available and turned on.

(See Software and Network User's Guide.)

### Cut-Sheet Paper



### Envelopes



	Top (1)	Left (2)	Bottom (3)	Right (4)
Cut-Sheet	3 mm	3 mm	3 mm	3 mm
Envelopes	22 mm	3 mm	22 mm	3 mm

### NOTE

The Borderless print feature is not available for envelopes and 2-sided printing.

## Paper settings

### Paper Type

To get the best print quality, set the machine for the type of paper you are using.

- 1 Press **Menu**, **2**, **2**.
- 2 Press **▲** or **▼** to choose **Plain Paper**, **Inkjet Paper**, **Brother BP71**, **Other Glossy** or **Transparency**. Press **OK**.
- 3 Press **Stop/Exit**.

#### NOTE

The machine ejects paper with the printed surface face up onto the paper tray at the front of the machine. When you use transparencies or glossy paper, remove each sheet at once to prevent smudging or paper jams.

### Paper Size

You can use the following sizes of paper for printing copies: A4, A5, Photo (10 × 15 cm) and Letter. You can use the following sizes of paper for printing faxes: A4 and Letter. When you change the size of paper you load in the machine, you will need to change the **Paper Size** setting at the same time so your machine can fit an incoming fax on the page.

- 1 Press **Menu**, **2**, **3**.
- 2 Press **▲** or **▼** to choose **A4**, **A5**, **10x15cm** or **Letter**. Press **OK**.
- 3 Press **Stop/Exit**.

## Acceptable paper and other print media

The print quality can be affected by the type of paper you use in the machine.

To get the best print quality for the settings you have chosen, always set the Paper Type to match the type of paper that is loaded in the tray.

You can use plain paper, inkjet paper (coated paper), glossy paper, transparencies and envelopes.

We recommend testing various paper types before buying large quantities.

For best results, use Brother paper.

- When you print on inkjet paper (coated paper), transparencies and glossy paper, be sure to choose the correct print media in the printer driver's **Basic** tab or the machine's Paper Type setting.

(See *Paper Type* on page 16.)

- When you print on Brother Photo paper, load one extra sheet of the same photo paper in the paper tray. An extra sheet has been included in the paper package for this purpose.
- When using transparencies or photo paper, remove each sheet at once to prevent smudging or paper jams.
- Avoid touching the printed surface of the paper immediately after printing; the surface may not be completely dry and may stain your fingers.



## Recommended print media

To get the best print quality, we suggest using the Brother paper in the table.

If Brother paper is not available in your country, we recommend testing various papers before purchasing large quantities.

We recommend using 3M Transparency Film when you print on transparencies.

### Brother paper

Paper Type	Item
A4 Plain	BP60PA
A4 Glossy Photo	BP71GA4
A4 Inkjet (Matte)	BP60MA
10 × 15 cm Glossy Photo	BP71GP


## Handling and using print media

- Store paper in its original packaging and keep it sealed. Keep the paper flat and away from moisture, direct sunlight and heat.
- Avoid touching the shiny (coated) side of the photo paper. Load photo paper with the shiny side facing down.
- Avoid touching either side of the transparency paper because they absorb water and perspiration easily, and this may cause decreased output quality. Transparencies designed for laser printers/copiers may stain your next document. Use only transparencies recommended for inkjet printing.

## IMPORTANT

DO NOT use the following kinds of paper:

- Damaged, curled, wrinkled, or irregularly shaped paper



**1 2 mm or greater curl may cause jams to occur.**

- Extremely shiny or highly textured paper
- Paper that cannot be arranged uniformly when stacked
- Short grain paper

## Paper capacity of the output paper tray cover

Up to 50 sheets of 80 g/m<sup>2</sup> A4 paper.

- Transparencies and photo paper must be picked up from the output paper tray cover one page at a time to avoid smudging.

## Choosing the right print media

### Paper type and size for each operation

Paper Type	Paper Size		Usage		
			Fax	Copy	Printer
Cut-Sheet	A4	210 × 297 mm (8.3 × 11.7 in.)	Yes	Yes	Yes
	Letter	215.9 × 279.4 mm (8 1/2 × 11 in.)	Yes	Yes	Yes
	Executive	184 × 267 mm (7 1/4 × 10 1/2 in.)	–	–	Yes
	A5	148 × 210 mm (5.8 × 8.3 in.)	–	Yes	Yes
	A6	105 × 148 mm (4.1 × 5.8 in.)	–	–	Yes
Cards	Photo	10 × 15 cm (4 × 6 in.)	–	Yes	Yes
	Photo 2L	13 × 18 cm (5 × 7 in.)	–	–	Yes
	Index Card	127 × 203 mm (5 × 8 in.)	–	–	Yes
Envelopes	C5 Envelope	162 × 229 mm (6.4 × 9 in.)	–	–	Yes
	DL Envelope	110 × 220 mm (4.3 × 8.7 in.)	–	–	Yes
	Com-10	105 × 241 mm (4 1/8 × 9 1/2 in.)	–	–	Yes
	Monarch	98 × 191 mm (3 7/8 × 7 1/2 in.)	–	–	Yes
Transparencies	A4	210 × 297 mm (8.3 × 11.7 in.)	–	Yes	Yes
	Letter	215.9 × 279.4 mm (8 1/2 × 11 in.)	–	Yes	Yes
	A5	148 × 210 mm (5.8 × 8.3 in.)	–	Yes	Yes

### Paper weight, thickness and capacity

Paper Type		Weight	Thickness	No. of sheets
Cut-Sheet	Plain Paper	64 to 120 g/m <sup>2</sup>	0.08 to 0.15 mm	100 <sup>1</sup>
	Inkjet Paper	64 to 200 g/m <sup>2</sup>	0.08 to 0.25 mm	20
	Glossy Paper	Up to 220 g/m <sup>2</sup>	Up to 0.25 mm	20 <sup>2</sup>
Cards	Photo Card	Up to 220 g/m <sup>2</sup>	Up to 0.25 mm	20 <sup>2</sup>
	Index Card	Up to 120 g/m <sup>2</sup>	Up to 0.15 mm	30
Envelopes		80 to 95 g/m <sup>2</sup>	Up to 0.52 mm	10
Transparencies		–	–	10

<sup>1</sup> Up to 100 sheets of 80 g/m<sup>2</sup> paper.

<sup>2</sup> BP71 (260 g/m<sup>2</sup>) paper is especially designed for Brother inkjet machines.

# 3

## Loading documents

### How to load documents

You can send a fax, make copies, or scan from the ADF (automatic document feeder) and from the scanner glass.

### Using the ADF

The ADF can hold up to 20 pages and feeds each sheet individually. Use paper that is within the sizes and weights shown in the table. Always fan the edges of the pages before placing them in the ADF.

### Document Sizes and Weights

Length:	148 to 355.6 mm
Width:	148 to 215.9 mm
Weight:	64 to 90 g/m <sup>2</sup>


### How to load documents

#### IMPORTANT


- DO NOT pull on the document while it is feeding.
- DO NOT use paper that is curled, wrinkled, folded, ripped, stapled, paper clipped, glued or taped.
- DO NOT use cardboard, newspaper or fabric.

Make sure documents written with ink or modified with correction fluid are completely dry.

- 1 Unfold the ADF Document Support (1).



- 2 Fan the pages well.
- 3 Adjust the paper guides (1) to fit the width of your documents.




- 4 Place your documents **face down, top edge first** in the ADF underneath the guides until you feel them touch the feed rollers.  
The screen will display *ADF Ready*.


#### IMPORTANT

DO NOT leave thick documents on the scanner glass. If you do this, the ADF may jam.

- After using the ADF, close the ADF Document Support. Push down on the upper-left portion of the ADF Document Support to close it completely.



- Using the document guidelines on the left and top, place the document **face down** in the upper left corner of the scanner glass.



1 document cover

## Using the scanner glass

You can use the scanner glass to fax, copy, or scan single pages or pages of a book.

### Document sizes supported


Length:	Up to 297 mm
Width:	Up to 215.9 mm
Weight:	Up to 2 kg

### How to load documents

#### NOTE

To use the scanner glass, the ADF must be empty.

- Lift the document cover.




- Close the document cover.

#### IMPORTANT

If you are scanning a book or thick document, **DO NOT** slam the cover down or press on it.

## Unscannable area

The scannable area depends on the settings in the application you are using. The figures show the unscannable areas.



Usage	Document Size	Top (1) Bottom (3)	Left (2) Right (4)
Fax	A4	3 mm	3 mm <sup>1</sup>
	Letter		4 mm
	Legal		
Copy	All paper sizes	3 mm	3 mm
Scan		1 mm	1 mm

<sup>1</sup> The unscannable area is 1 mm when you use the ADF.

# 4

## Sending a fax

### How to send a fax

The following steps show how to send a fax.

- 1 Do one of the following to load your document:
  - Place the document *face down* in the ADF. (See *Using the ADF* on page 19.)
  - Load your document *face down* on the scanner glass. (See *Using the scanner glass* on page 20.)

#### NOTE

- To send colour faxes with multiple pages, use the ADF.
- If you send a mono fax from the ADF when the memory is full, it will be sent in real time.
- You can use the scanner glass to fax pages of a book one at a time. The documents can be up to A4 or Letter size.
- Since you can only scan one page at a time, it is easier to use the ADF if you are sending a multiple-page document.

- 2 Press  (FAX).

- 3 You can change the following fax-sending settings.

#### (Basic User's Guide)

For information about changing the following fax-sending settings, see pages 23 to 24.

- Glass Scan Size
- Colour Fax Transmission
- Transmission Verification Report (Setup)

#### (Advanced User's Guide)

For more advanced fax-sending operations and settings (See Advanced User's Guide: *Sending a fax (MFC model).*)

- Contrast
- Fax Resolution
- Faxing at the end of a call
- Broadcasting
- Real Time Transmission
- Overseas Mode
- Cancelling Waiting Jobs

- 4 Enter the fax number using the dial pad, Speed Dial or Search.

- 5 Press **Mono Start** or **Colour Start**.

### Faxing from the ADF

- The machine starts scanning the document to be sent.

### Faxing from the scanner glass

- If you pressed **Mono Start**, the machine starts scanning the first page. Go to step 6.
- If you pressed **Colour Start**, the machine starts dialling and sending the document.

- 6 When the LCD asks you `Next Page?`, do one of the following:

- To send a single page, press **2** to choose `No (Dial)` (or press **Mono Start** again).

The machine starts sending the document.

- To send more than one page, press **1** to choose `Yes` and go to step 7.


- 7 Place the next page on the scanner glass.  
Press **OK**.  
The machine starts scanning the page. (Repeat steps 6 and 7 for each additional page.)
- 8 After all the pages have been scanned, press **2** or **Mono Start** to start.

## Stop faxing

To stop faxing, press **Stop/Exit**.

## Setting scanner glass size for faxing

When documents are Letter size, you need to set the Scan Size to Letter. If you do not, the side portion of the faxes will be missing.

- 1 Load your document.
- 2 Press  (**FAX**).
- 3 Press **Menu, 3, 2, 0**.
- 4 Press **▲** or **▼** to choose `Letter` (or `A4`). Press **OK**.
- 5 Press **Stop/Exit**.
- 6 Enter the fax number.
- 7 Press **Mono Start** or **Colour Start**.

### NOTE

This setting is only available for sending documents from the scanner glass.

## Colour fax transmission

Your machine can send a colour fax to machines that support this feature.

Colour faxes cannot be stored in the machine's memory. When you send a colour fax, the machine will send it in real time (even if `Real Time TX` is set to `Off`).

## Cancelling a fax in progress

If you want to cancel a fax while the machine is scanning, dialling or sending, press **Stop/Exit**.

## Transmission Verification Report

---

You can use the Transmission Verification Report as proof that you sent a fax. This report lists the sender's name or fax number, the time and date of the transmission, duration of the transmission, the number of pages sent, and whether or not the transmission was successful.

There are several settings available for the Transmission Verification Report:

- **On:** Prints a report after every fax you send.
- **On+Image:** Prints a report after every fax you send. A portion of the fax's first page appears on the report.
- **Off:** Prints a report if your fax is unsuccessful due to a transmission error. `Off` is the default setting.
- **Off+Image:** Prints a report if your fax is unsuccessful due to a transmission error. A portion of the fax's first page appears on the report.

- 1 Press **Menu**, **3**, **3**, **1**.
- 2 Press **▲** or **▼** to choose `Off+Image`, `On`, `On+Image` or `Off`. Press **OK**.
- 3 Press **Stop/Exit**.

## NOTE

---

- If you choose `On+Image` or `Off+Image` the image will only appear on the Transmission Verification Report if Real Time Transmission is set to `Off`. The image will not appear on the report when you send a colour fax. (See Advanced User's Guide: *Real Time Transmission*.)
  - If your transmission is successful, `OK` will appear next to `RESULT` on the Transmission Verification Report. If the transmission is not successful, `ERROR` will appear next to `RESULT`.
-



# 5

## Receiving a fax


### Receive Modes

You must choose a Receive Mode depending on the external devices and telephone services you have on your line.


### Choose the Receive Mode

By default, your machine will automatically receive any faxes that are sent to it. The diagram below will help you choose the correct receive mode.

For more detailed information on the Receive Modes, see *Using Receive Modes* on page 26.



To set the Receive Mode follow the instructions:

- 1 Press  (FAX).
- 2 Press **Menu, 3, 1, 1**.

#### NOTE

If the option to change the receive mode is unavailable, make sure the BT Call Sign feature is set to **Off**. (See *Advanced User's Guide: To enable the machine to work with BT Call Sign (with your external telephone only)*.)

- 3 Press **▲** or **▼** to choose **Fax Only, Fax/Tel, External TAD** or **Manual**. Press **OK**.
- 4 Press **Stop/Exit**.

## Using Receive Modes

Some Receive Modes answer automatically (**Fax Only** and **Fax/Tel**). You may want to change the Ring Delay before using these modes. (See *Ring Delay* on page 27.)

### Fax Only

---

**Fax Only** mode will automatically answer every call as a fax call.

### Fax/Tel

---

**Fax/Tel** mode helps you manage incoming calls by recognising whether they are fax or voice calls and dealing with them in one of the following ways:

- Faxes will be automatically received.
- Voice calls will start the **F/T Ring** to tell you to pick up the line. The **F/T Ring** is a fast double-ring made by your machine.

If you use **Fax/Tel** mode, see *F/T Ring Time (Fax/Tel mode only)* on page 27 and *Ring Delay* on page 27.

### Manual

---

**Manual** mode turns off all automatic answering functions unless you are using the **BT Call Sign** feature.

To receive a fax in **Manual** mode, lift the handset of an external telephone. When you hear fax tones (short repeating beeps), press **Mono Start** or **Colour Start**, and then press **2** to choose **Receive**. You can also use the **Fax Detect** feature to receive faxes by lifting a handset on the same line as the machine.

(See *Fax Detect* on page 28.)

### External TAD

---

**External TAD** mode lets an external answering device manage your incoming calls. Incoming calls will be dealt with in one of the following ways:

- Faxes will be automatically received.
- Voice callers can record a message on the external TAD.


To connect your External TAD, see *Connecting an external TAD (telephone answering device)* on page 32.

## Receive Mode settings

### Ring Delay

The Ring Delay sets the number of times the machine rings before it answers in **Fax Only** or **Fax/Tel** mode. If you have external or extension telephones on the same line as the machine, choose the maximum number of rings.

(See *Operation from external and extension telephones* on page 34 and *Fax Detect* on page 28.)

- 1 Press  (**FAX**).
- 2 Press **Menu, 3, 1, 2**.
- 3 Press **▲** or **▼** to choose how many times you want the machine to ring before it answers.  
Press **OK**.  
If you choose **00**, the machine will answer immediately and the line will not ring at all.
- 4 Press **Stop/Exit**.


### F/T Ring Time (Fax/Tel mode only)

When somebody calls your machine, you and your caller will hear the normal telephone ring. The number of rings is set by the ring delay setting.

If the call is a fax, then your machine will receive it. However, if it is a voice call then the machine will sound the F/T Ring (a fast double-ring) for the time you have set in the F/T Ring Time setting. If you hear the F/T Ring, it means that you have a voice caller on the line.

Because the F/T Ring is made by the machine, extension and external telephones will not ring. However, you can still answer the call on any telephone by using a remote code.

(For more information, see *Using remote codes* on page 36.)

- 1 Press  (**FAX**).
- 2 Press **Menu, 3, 1, 3**.
- 3 Press **▲** or **▼** to choose how long the machine will ring to alert you that you have a voice call (20, 30, 40 or 70 seconds).  
Press **OK**.
- 4 Press **Stop/Exit**.

### NOTE

Even if the caller hangs up during the fast double-ring, the machine will continue to ring for the set time.

## Fax Detect

---

### If Fax Detect is On:

The machine receives a fax call automatically, even if you answer the call. When you see *Receiving* on the LCD or when you hear “chirps” through the handset you are using, just replace the handset. Your machine will do the rest.

### If Fax Detect is Off:


If you are at the machine and answer a fax call by lifting the handset, press **Mono Start** or **Colour Start**, then press **2** to receive the fax.

If you answered at an extension or external telephone, press \* **5 1**. (See *Operation from external and extension telephones* on page 34.)

### NOTE

---

- If this feature is set to *On*, but your machine does not connect a fax call when you lift an extension or external telephone handset, press the remote activation code \* **5 1**.
- If you send faxes from a computer on the same telephone line and the machine intercepts them, set Fax Detect to *Off*.

- 
- 1 Press  (**FAX**).
  - 2 Press **Menu, 3, 1, 4**.
  - 3 Press **▲** or **▼** to choose *On* (or *Off*). Press **OK**.
  - 4 Press **Stop/Exit**.

## Voice operations

### Fax/Tel mode

---

When the machine is in Fax/Tel mode, it will use the F/T Ring (fast double-ring) to alert you to pick up a voice call.

If you are at an external telephone, lift the handset of the external telephone, and then press **Te/R** to answer.

If you are at an extension telephone, you'll need to lift the handset during the F/T Ring Time and then press **# 5 1** between the fast double-rings. If no one is on the line, or if someone wants to send you a fax, send the call back to the machine by pressing **\* 5 1**.

### Caller ID (U.K. and Ireland only)

---

The Caller ID feature lets you use the Caller ID subscriber service offered by many local telephone companies. Call your telephone company for details. This service shows the telephone number, or name if it is available, of your caller as the line rings.

After a few rings, the LCD shows the telephone number of your caller (and name, if available). Once you answer a call, the Caller ID information disappears from the LCD, but the call information stays stored in the Caller ID memory.

- You can see the first 16 characters of the number (and name).
- The **ID Unknown** message means the call originated outside your Caller ID service area.
- The **ID Withheld** message means the caller has intentionally blocked transmission of information.

You can print a list of the Caller ID information received by your machine. (See *Advanced User's Guide: How to print a report.*)

### NOTE

---

The Caller ID service varies with different carriers. Call your local telephone company to find out about the kind of service available in your area.

---

## Setting the Caller ID to On

If you have Caller ID on your line, then this function should be set to `On` to display the caller's phone number on the LCD as the telephone rings.

- 1 Press **Menu, 3, 0, 3**.
- 2 Press **▲** or **▼** to choose `On` (or `Off`). Press **OK**.
- 3 Press **Stop/Exit**.

## Viewing the Caller ID List

Your machine stores information for the last thirty calls in the Caller ID list. You can view or print this list. When the thirty-first call comes in to the machine, it replaces information about the first call.

- 1 Press **Menu, 3, 0, 3**.
- 2 Press **▲** or **▼** to choose `Display ID`. Press **OK**.

The Caller ID of the last call will appear on the LCD. If no ID is stored, the beeper will sound and `No Caller ID` will appear on the LCD.

- 3 Press **▲** or **▼** to scroll through the Caller ID memory to choose the Caller ID you want to view, and then press **OK**. The LCD shows the caller's number or name and the date and time of the call.
- 4 To finish viewing, press **Stop/Exit**.

## Printing Caller ID List

- 1 Press **Menu, 5, 5**.
- 2 If no ID is stored, the beeper will sound and `No Caller ID` will appear on the LCD.
- 3 Press **Mono Start** or **Colour Start**.
- 4 After printing has finished, press **Stop/Exit**.

## Telephone services

Your machine supports the Caller ID subscriber telephone service that some telephone companies offer.

Features like Voice Mail, Call Waiting, Call Waiting/Caller ID, answering services, alarm systems or other custom features on one telephone line may create problems with the operation of your machine.

### NOTE

Caller ID is available for U.K. and Ireland only.

## Setting the Telephone Line Type

If you are connecting the machine to a line that features PBX or ISDN to send and receive faxes, it is also necessary to change the Telephone Line Type accordingly by completing the following steps.

- 1 Press **Menu, 0, 5**.
- 2 Press **▲** or **▼** to choose `Normal`, `PBX` or `ISDN`. Press **OK**.
- 3 Press **Stop/Exit**.

## PBX and TRANSFER

The machine is initially set to `Normal`, which lets the machine connect to a standard PSTN (Public Switched Telephone Network) line. However, many offices use a central telephone system or Private Branch Exchange (PBX). Your machine can be connected to most types of PBX. The machine's recall feature supports timed break recall only (TBR). TBR will work with most PBX systems allowing you to gain access to an outside line, or transfer calls to another extension. The feature works when the **Tel/R** key on the control panel is pressed.


**NOTE**

You can program a press of the **Tel/R** key as part of a number stored in a Speed Dial location. When programming the Speed Dial number, press **Tel/R** first (the LCD shows '!'), then enter the telephone number. If you do this, you do not need to press **Tel/R** each time before you dial using a Speed Dial location. (See *Storing numbers* on page 38.) However, if your Telephone Line Type is not set to PBX on the machine, you cannot use the Speed Dial location that the **Tel/R** is programmed into.

## Voice over Internet Protocol (VoIP)

VoIP is a type of phone system that uses an Internet connection instead of a traditional telephone line. Telephone providers frequently bundle VoIP together with Internet and cable services.

Your machine may not work with some VoIP systems. If you want to use your machine to send and receive faxes on a VoIP system, make sure that one end of your telephone cord is connected to the socket labelled **LINE** on your machine. The other end of the telephone cord may be connected to a modem, phone adapter, splitter, or other such device.



- **If you have questions about how to connect your machine to the VoIP system, contact your VoIP provider.**

After you have connected your machine to the VoIP system, check for a dial tone. Lift the external telephone's handset and listen for a dial tone. If there is no dial tone, call your VoIP provider.

If you are having problems sending or receiving faxes over a VoIP system, we recommend changing the machine's modem speed to the **Basic (for VoIP)** setting (see *Telephone line interference / VoIP* on page 86).


## Connecting an external TAD (telephone answering device)

You may choose to connect an external answering device. However, when you have an **external** TAD on the same telephone line as the machine, the TAD answers all calls and the machine “listens” for fax-calling (CNG) tones. If it hears them, the machine takes over the call and receives the fax. If it does not hear CNG tones, the machine lets the TAD continue playing your outgoing message so your caller can leave a voice message.

The TAD must answer within four rings (the recommended setting is two rings). The machine cannot hear CNG tones until the TAD has answered the call, and with four rings, there are only 8 to 10 seconds of CNG tones left for the fax “handshake”. Make sure you carefully follow the instructions in this guide for recording your outgoing message. We do not recommend using the toll saver feature on your external answering machine if it exceeds five rings.

### NOTE

If you do not receive all your faxes, shorten the Ring Delay setting on your external TAD.



### 1 TAD

When the TAD answers a call, the LCD shows `Telephone`.

### IMPORTANT

DO NOT connect a TAD elsewhere on the same telephone line.

## Connection settings

The external TAD must be connected as shown in the previous illustration.

- 1 Place both hands under the plastic tabs on both sides of the machine to lift the scanner cover into the open position.
- 2 Carefully guide the telephone line cord into the cable channel and out the back of the machine.
- 3 Lift the scanner cover to release the lock. Gently push the scanner cover support down and close the scanner cover using both hands.
- 4 Set your external TAD to one or two rings. (The machine's Ring Delay setting does not apply.)
- 5 Record the outgoing message on your external TAD.



- 6 Set the TAD to answer calls.
- 7 Set the Receive Mode to `External TAD`. (See *Choose the Receive Mode* on page 25.)

## Recording an outgoing message (OGM) on an external TAD

---

Timing is important in recording this message.

- 1 Record 5 seconds of silence at the beginning of your message. (This allows your machine time to listen for the fax CNG tones of automatic transmissions before they stop.)
- 2 Limit your speaking to 20 seconds.

### NOTE

---

We recommend beginning your OGM with an initial 5 second silence because the machine may not hear the fax tones over a voice. You may try omitting this pause, but if your machine has trouble receiving, then you must re-record the OGM to include it.

---

## Multi-line connections (PBX)

---

We suggest you ask the company who installed your PBX to connect your machine. If you have a multi-line system, we suggest you ask the installer to connect the unit to the last line on the system. This prevents the machine being activated each time the system receives telephone calls. If all incoming calls will be answered by a switchboard operator, we recommend that you set the Receive Mode to `Manual`.

We cannot guarantee that your machine will operate correctly under all circumstances when connected to a PBX. Any difficulties with sending or receiving faxes should be reported first to the company who handles your PBX.

### NOTE

---

Make sure the Telephone Line Type is set to PBX. (See *Setting the Telephone Line Type* on page 30.)


---

## External and extension telephones

### Connecting an external or extension telephone

You can connect a separate telephone (2) to your machine as shown in the diagram.

Carefully guide the telephone line cord into the cable channel and out the back of the machine.



- 1 Extension telephone
- 2 External telephone

#### NOTE

Please make sure you use an external telephone with a cable no more than 3 metres long.

### Operation from external and extension telephones

If you answer a fax call on an extension or an external telephone, you can make your machine take the call by using the Remote Activation Code. When you press the Remote Activation Code \* 5 1, the machine starts to receive the fax.

If the machine answers a voice call and fast double-rings for you to take over, use the Remote Deactivation Code # 5 1 to take the call at an extension telephone. (See *F/T Ring Time (Fax/Tel mode only)* on page 27.)

#### If you answer a call and no one is on the line:

Assume you are receiving a manual fax.

Press \* 5 1 and wait for the chirp or until the LCD shows *Receiving*, and then hang up.

#### NOTE

You can also use the Fax Detect feature to make your machine automatically take the call. (See *Fax Detect* on page 28.)

## Using extension telephones (U.K. only)

Your premises may already be wired with parallel extension telephones, or you may plan to add extension telephones to your line, as well as your machine. While the simplest arrangement is a straightforward parallel connection, there are some problems with this. The most obvious is inadvertent interruption of a facsimile transmission caused by someone picking up an extension telephone to make an outgoing call. Also, the remote activation code feature may not operate reliably in such a simple configuration.


This machine may also be set to make a delayed transmission (i.e. a transmission at a pre-set time). This pre-set job may coincide with someone picking up an extension handset.

These problems can easily be eliminated, if you arrange modification of your extension wiring circuit, such that extension devices are connected “downstream” of your machine in a master/slave configuration (see fig. 2). In this configuration the machine can always detect whether a telephone is in use. Thus it will not attempt to seize the line during that time. This is known as “telephone off-hook detection.”

The inadvisable configuration is shown in figure 1, and the recommended master/slave configuration is shown in figure 2.


This new connection configuration can be arranged by contacting BT, Kingston upon Hull Telecommunications, your PBX maintainer or a qualified telephone installation company as appropriate. Simply explained, the extension telephone circuit should be terminated on a normal modular plug (BT 431A style), which in turn should be put into the modular socket of the white “T”-shaped connector provided as part of the line cord assembly.

### Inadvisable connection of extension sockets (Fig. 1.)



- 1 Extension socket
- 2 Master socket
- 3 Incoming line

### Recommended connection of extension sockets (Fig. 2.)



- 1 Extension socket
- 2 Master socket
- 3 Incoming line

The fax machine must be plugged into the master socket.

### NOTE

These telephones are now connected as external devices (See *Connecting an external or extension telephone* on page 34.), because they are connected to the fax machine via the T-connector.

## Using remote codes

### Remote Activation Code

If you answer a fax call on an extension or external telephone, you can tell your machine to receive it by dialling the Remote Activation Code \* **5 1**. Wait for the chirping sounds and then replace the handset. (See *Fax Detect* on page 28.)

If you answer a fax call at the external telephone, you can make the machine receive the fax by pressing **Mono Start** or **Colour Start** and **2** to choose *Receive*.


### Remote Deactivation Code

If you receive a voice call and the machine is in Fax/Tel mode, it will start to sound the F/T Ring (fast double-ring) after the initial ring delay. If you pick up the call on an extension telephone, you can turn the F/T Ring off by pressing **# 5 1** (make sure you press this *between* the rings).

If the machine answers a voice call and fast double-rings for you to take over, you can take the call at the external telephone by pressing **Tel/R**.

### Changing the remote codes

If you want to use Remote Activation, you have to turn on the remote codes. The preset Remote Activation Code is \* **5 1**. The preset Remote Deactivation Code is **# 5 1**. If you want to, you can replace them with your own codes.

- 1 Press  (**FAX**).
- 2 Press **Menu, 3, 1, 5**.
- 3 Press **▲** or **▼** to choose *On* (or *Off*). Press **OK**.
- 4 Enter the new Remote Activation Code. Press **OK**.

- 5 Enter the new Remote Deactivation Code. Press **OK**.


- 6 Press **Stop/Exit**.

### NOTE

- If you are always disconnected when accessing your external TAD remotely, try changing the Remote Activation Code and Remote Deactivation Code to another three-digit code using the numbers **0-9**, **\***, **#**.
- Remote Codes might not work with some telephone systems.

## How to dial


### Manual dialling

- 1 Load your document.
- 2 Press  (FAX).
- 3 Press all of the digits of the fax number.



- 4 Press **Mono Start** or **Colour Start**.

### Speed Dialling

- 1 Load your document.
- 2 Press  (Address Book).
- 3 Press ▲ or ▼ to choose Search. Press **OK**.
- 4 Do one of the following:
  - To search numerically, press ▲ or ▼ to choose the number, and then press **OK**.
  - To search alphabetically, enter the first letter of the name using the dial pad, then press ◀ or ▶ to choose the name, and then press **OK**.
- 5 Press **Mono Start** or **Colour Start**. The machine scans and sends the fax.

### Fax Redial

If you are sending a fax manually and the line is busy, press **Redial/Pause**, and then press **Mono Start** or **Colour Start** to try again. If you want to make a second call to the last number dialled, you can save time by pressing **Redial/Pause** and **Mono Start** or **Colour Start**.

**Redial/Pause** only works if you dialled from the control panel.

If you are sending a fax automatically and the line is busy, the machine will automatically redial up to three times at five minute intervals.

#### NOTE

In Real Time Transmission the automatic redial feature does not work when using the scanner glass.

## Storing numbers

You can set up your machine to do the following types of easy dialling: Speed Dial and Groups for broadcasting faxes.

(See Advanced User's Guide: *Setting up Groups for Broadcasting and Broadcasting (Monochrome only)*.)


### NOTE


If you lose electrical power, the Speed Dial numbers that are in the memory will not be lost.

## Storing a pause

Press **Redial/Pause** to put a 3.5-second pause between numbers. If you are dialling overseas, you can press **Redial/Pause** as many times as needed to increase the length of the pause.

## Storing Speed Dial numbers

You can store up to 40 two-digit Speed Dial numbers, and each number has a name. When you dial, you will only have to press a few keys (for example:  (**Address Book**), **OK**, **#**, the two-digit number, and **Mono Start** or **Colour Start**).

- 1 Press  (**Address Book**) and **▲** or **▼** to choose **Set Speed Dial**. Press **OK**.
- 2 Use the dial pad to enter a two-digit Speed Dial location number (01-40). Press **OK**.
- 3 Enter the fax or telephone number (up to 20 digits). Press **OK**.
- 4 Do one of the following:
  - Enter the name (up to 16 characters) using the dial pad.  
Press **OK**. (For help entering letters, see *Entering Text* on page 103.)
  - To store the number without a name, press **OK**.
- 5 Do one of the following:
  - To store another Speed Dial number, go to step 2.
  - To finish the setting, press **Stop/Exit**.

## Changing and deleting Speed Dial numbers

If you try to store a Speed Dial number where a number has already been stored, the LCD will show the name or number that has been stored there, and will ask you to do one of the following:

#05:MIKE

1.Change 2.Exit

- Press **1** to change or delete the stored number.
- Press **2** to exit without making a change.

If you choose **1**, you will be able to change the stored number and name, or enter a new one. You can delete the Speed Dial number by deleting the fax number.

Follow the instructions below:

- 1 Do one of the following:
  - To change the stored number, use ◀ or ▶ to position the cursor under the digit you want to change, then press **Clear**. Re-enter the number.  
Press **OK**. Go to step 2.
  - To delete the Speed Dial number, press **Clear** to delete each digit of the fax number.  
Press **OK**. Go to step 3.
- 2 Enter a new name if needed. Press **OK**.

### NOTE

To change a character, press ◀ or ▶ to position the cursor under the character you want to change, then press **Clear**. Re-enter the character.

(For help entering letters, see *Entering Text* on page 103.)

- 3 If you are finished making changes, press **Stop/Exit**.


# 8


## Making copies

### How to copy

The following steps show the basic copy operation.

- 1 Do one of the following to load your document:
  - Place the document *face down* in the ADF.  
(See *Using the ADF* on page 19.)
  - Place the document *face down* on the scanner glass.  
(See *Using the scanner glass* on page 20.)

- 2 Press  (**COPY**).  
The LCD shows the default copy settings:



- 1 **Copy Ratio**
- 2 **Quality**
- 3 **No. of Copies**  
Use the dial pad to enter the number of copies.

### NOTE

The default setting is FAX mode. You can change the amount of time that the machine stays in COPY mode after the last copy operation.  
(See *Advanced User's Guide: Mode Timer (MFC model)*.)

- 3 If you want more than one copy, enter the number (up to 99).
- 4 Press **Mono Start** or **Colour Start**.


### Stop copying

To stop copying, press **Stop/Exit**.



## Copy options

When you want to quickly change the copy settings *temporarily* for the next copy, use the **Copy Options** key.



The machine returns to its default settings 1 minute after it finishes copying, or if the mode timer returns the machine to Fax mode.

(See *Advanced User's Guide: Mode Timer (MFC model)*.)

### (Basic User's Guide)

For information about changing the following copy settings, see page 41.

- Paper Type
- Paper Size

### (Advanced User's Guide)

For information about changing the following copy settings, see *Advanced User's Guide: Copy options*.


- Quality
- Enlarge/Reduce
- Page Layout
- 2in1 (ID)
- Stack/Sort
- Density
- Remove Bkg. Clr

### NOTE

If you want to sort copies, use the ADF.


## Paper Type

If you are copying on a special type of paper, set the machine for the type of paper you are using to get the best print quality.

- 1 Load your document.
- 2 Press  (**COPY**).
- 3 Enter the number of copies you want.
- 4 Press **Copy Options** and ▲ or ▼ to choose *Paper Type*. Press **OK**.
- 5 Press ▲ or ▼ to choose *Plain Paper*, *Inkjet Paper*, *Brother BP71*, *Other Glossy* or *Transparency*. Press **OK**.
- 6 If you do not want to change any further settings, press **Mono Start** or **Colour Start**.

## Paper Size

If you are copying on paper other than A4 size, you will need to change the Paper Size setting. You can copy only on A4, A5, Photo (10 × 15 cm) or Letter paper.

- 1 Load your document.
- 2 Press  (**COPY**).
- 3 Enter the number of copies you want.
- 4 Press **Copy Options** and ▲ or ▼ to choose *Paper Size*. Press **OK**.
- 5 Press ▲ or ▼ to choose *A4*, *A5*, *10 (W) x15 (H) cm*, or *Letter*. Press **OK**.
- 6 If you do not want to change any further settings, press **Mono Start** or **Colour Start**.

## Printing a document

The machine can receive and print data from your computer. To print from a computer, you must install the printer driver.

(For more information, see Software and Network User's Guide.)

- 1 Install the Brother printer driver from the CD-ROM. (See Quick Setup Guide.)
- 2 From your application, choose the Print command.
- 3 Choose the name of your machine in the **Print** dialog box and click **Properties** or **Preferences**, depending on the application you are using.
- 4 Choose the settings you want to change in the Properties dialog box. Commonly used settings include:
  - **Media Type**
  - **Print Quality**
  - **Paper Size**
  - **Orientation**
  - **Colour / Greyscale**
  - **Ink Save Mode**
  - **Scaling**
  - **2-sided / Booklet**
- 5 Click **OK**.
- 6 Click **Print** (or **OK** depending on the application you are using) to begin printing.

## Before scanning

To use the machine as a scanner, install a scanner driver.

- Install the scanner drivers from the CD-ROM. (See Quick Setup Guide: *Install MFL-Pro Suite*.)

## Scanning a document as a PDF file using ControlCenter4 (Windows<sup>®</sup>)

(For detailed information, see Software and Network User's Guide.)


### NOTE

- The screens on your PC may vary depending on your model.
- This section is based on using the Advanced Mode of ControlCenter4.


ControlCenter4 is a software utility that lets you quickly and easily access the applications you use most often. Using ControlCenter4 eliminates the need to manually launch specific applications.

1 Load your document. (See *How to load documents* on page 19.)


2 (Windows<sup>®</sup> XP, Windows Vista<sup>®</sup> and Windows<sup>®</sup> 7)

Open ControlCenter4 by clicking  (Start)/All Programs/Brother/MFC-XXXX (where XXXX is your model name)/ControlCenter4. The ControlCenter4 application will open.

(Windows<sup>®</sup> 8)


Click  (Brother Utilities), and then click the drop-down list and select your model name (if not already selected). Click **SCAN** in the left navigation bar, and then click **ControlCenter4**. The ControlCenter4 application will open.

- 3 If the ControlCenter4 Mode screen appears, choose the **Advanced Mode**, and then click **OK**.





- 4 Make sure the machine you want to use is selected from the **Model** drop-down list.

- 5 Set the scanning configuration.  
Click **Configuration**, and then select **Button settings**, **Scan** and **File**.



The configuration dialog box appears. You can change the default settings.




- 1 Choose **PDF (\*.pdf)** from the **File Type** drop-down list.
- 2 You can enter the file name you want to use for the document.
- 3 You can save the file to the default folder, or choose your preferred folder by clicking the  (**Browse**) button.
- 4 You can choose a scanning resolution from the **Resolution** drop-down list.
- 5 You can choose the document size from the **Document Size** drop-down list.

- 6 Click **OK**.

- 7 Click the **Scan** tab.
- 8 Click **File**.






- 9 Click **Scan**.  
The machine starts the scanning process. The folder where the scanned data is saved will open automatically.




# How to change the machine's SCAN mode settings for PDF scanning using ControlCenter4 (Windows®)


You can change your machine's **SCAN** mode settings using ControlCenter4. (Windows®)

- 1 (Windows® XP, Windows Vista® and Windows® 7)  
Open ControlCenter4 by clicking  (**Start**)/**All Programs**/**Brother**/**MFC-XXXX** (where XXXX is your model name)/**ControlCenter4**. The ControlCenter4 application will open.  
(Windows® 8)  
Click  (**Brother Utilities**), and then click the drop-down list and select your model name (if not already selected). Click **SCAN** in the left navigation bar, and then click **ControlCenter4**. The ControlCenter4 application will open.
- 2 Make sure the machine you want to use is selected from the **Model** drop-down list.
- 3 Click the **Device Settings** tab.
- 4 Click **Device Scan Settings**.



- 5 Choose the **File** tab. You can change the default settings.




- 1 Choose **PDF (\*.pdf)** from the **File Type** drop-down list.
- 2 You can enter the file name you want to use for the document.
- 3 You can save the file to the default folder, or choose your preferred folder by clicking the  (**Browse**) button.
- 4 You can choose a scanning resolution from the **Resolution** drop-down list.
- 5 You can choose the document size from the **Document Size** drop-down list.

- 6 Click **OK**.



## How to scan a document as a PDF file using the control panel (Windows<sup>®</sup> and Macintosh)

- 1 Load your document. (See *How to load documents* on page 19.)
- 2 Press  (**SCAN**).
- 3 Press ▲ or ▼ to choose `Scan to File`.  
Press **OK**.
- 4 Do one of the following:
  - If you want to use the default settings, go to step 7.
  - If you want to change the default settings, go to step 5.
- 5 Press ▲ or ▼ to choose `On`.  
Press **OK**.
- 6 Choose the settings for `Scan Type`, `Resolution`, `File Type`, `Scan Size` and `Remove Bkg. Clr` as needed.  
Press **OK**.
- 7 Press **Mono Start** or **Colour Start**.  
The machine starts the scanning process.

### NOTE

---

The following scan modes are available.

- Scan to E-mail
- Scan to Image
- Scan to OCR
- Scan to File

# A

## Routine maintenance

### Replacing the ink cartridges

Your machine is equipped with an ink dot counter. The ink dot counter monitors the level of ink in each of the four cartridges. When the machine detects an ink cartridge is running out of ink, the machine will display a message.

The LCD will show which ink cartridge is low or needs replacing. Be sure to follow the LCD prompts to replace the ink cartridges in the correct order.

Even though the machine tells you to replace an ink cartridge, there will be a small amount of ink left in the ink cartridge. It is necessary to keep some ink in the ink cartridge to prevent air from drying out and damaging the print head assembly.


#### **⚠ CAUTION**

If ink gets in your eyes, wash it out with water at once and call a doctor if you are concerned.



#### **IMPORTANT**

Brother multifunction machines are designed to work with ink of a particular specification and will work to a level of optimum performance and reliability when used with Brother Original ink cartridges. Brother cannot guarantee this optimum performance and reliability if ink or ink cartridges of other specifications are used. Brother does not therefore recommend the use of cartridges other than Brother Original cartridges or the refilling of used cartridges with ink from other sources. Damage to the product caused by the use of consumables manufactured by third parties may not be covered by the product warranty. Please refer to the terms of the product warranty.

- 1 Open the ink cartridge cover (1).  
If an ink cartridge has reached the end of its life, the LCD shows  
B&W Print Only or Cannot Print.






- 2 Press the lock release lever (1) as shown to release the cartridge indicated on the LCD. Remove the cartridge from the machine.



- 3 Open the new ink cartridge bag for the colour indicated on the LCD, and then take out the ink cartridge.


- 4 Turn the green release lever on the orange protective packing (1) counterclockwise until it releases the vacuum seal. Then remove the orange protective packing as shown.




### IMPORTANT

- DO NOT shake the ink cartridges. If ink gets on your skin or clothing, immediately wash it off with soap or detergent.
- DO NOT touch the cartridge in the area indicated (2); this can prevent the machine from detecting the cartridge.

- 5 Each colour has its own correct position. Insert the ink cartridge in the direction of the arrow on the label.



- 6 Gently push the back of the ink cartridge—marked PUSH—until the cartridge lever lifts, and then close the ink cartridge cover.



- 7 The machine will automatically reset the ink dot counter.

## NOTE

- If you replaced an ink cartridge, for example Black, the LCD may ask you to verify that it is a brand new one (for example, *Did You Change Blck?*). For each new cartridge you installed, press **1** (*Yes*) to reset the ink dot counter for that colour. If the ink cartridge you installed is not a brand new one, be sure to press **2** (*No*).
- If the LCD shows *No Ink Cartridge* or *Cannot Detect* after you install the ink cartridge, check that the ink cartridge is a brand new Brother Original cartridge and that it is installed correctly. Remove the ink cartridge and reinstall it slowly and firmly until the cartridge lever lifts.


## IMPORTANT

- DO NOT take out ink cartridges if you do not need to replace them. If you do so, it may reduce the ink quantity and the machine will not know the quantity of ink left in the cartridge.
- DO NOT touch the cartridge insertion slots. If you do so, the ink may stain your skin.
- If you mix the colours by installing an ink cartridge in the wrong position, the LCD shows *Wrong Ink Colour*. Check which ink cartridges are not matched by colour to their ink cartridge positions and move them to their correct positions.
- Once you open an ink cartridge, install it in the machine and use it up within six months of installation. Use unopened ink cartridges by the expiration date written on the cartridge package.
- DO NOT dismantle or tamper with the ink cartridge; this can cause the ink to leak out of the cartridge.


# Cleaning and checking the machine

## Cleaning the scanner glass

- 1 Unplug the machine from the electrical socket.
- 2 Lift the document cover (1). Clean the scanner glass (2) and the white plastic (3) with a soft lint-free cloth moistened with a non-flammable glass cleaner.



- 3 In the ADF unit, clean the white bar (1) and the glass strip (2) with a lint-free cloth moistened with a non-flammable glass cleaner.



### NOTE

In addition to cleaning the glass strip with a non-flammable glass cleaner, run your finger tip over the glass strip to see if you can feel anything on it. If you feel dirt or debris, clean the glass strip again concentrating on that area. You may need to repeat the cleaning process three or four times. To test, make a copy after each cleaning attempt.



When there is a spot of dirt or correction fluid on the glass strip, the printed sample shows a vertical line.



After the glass strip is cleaned, the vertical line is gone.

## Cleaning the print head

To maintain good print quality, the machine will automatically clean the print head when needed. You can start the cleaning process manually if there is a print quality problem.

Clean the print head if you get a horizontal line in the text or graphics, or blank text on your printed pages. You can clean Black only; Yellow, Cyan, and Magenta at once; or all four colours at once.

Cleaning the print head consumes ink. Cleaning too often uses ink unnecessarily.

### IMPORTANT

DO NOT touch the print head. Touching the print head may cause permanent damage and may void the print head's warranty.

- 1 Press **Menu**, **1**, **2**.
- 2 Press **▲** or **▼** to choose **Black**, **Colour** or **All**. Press **OK**.  
The machine cleans the print head. When cleaning is finished, the machine will go back to the FAX mode.

### NOTE

- If you clean the print head at least five times and the print has not improved, try installing a new Brother Original Innobella™ ink cartridge for each problem colour. Try cleaning the print head again up to five more times. If the print has not improved contact Brother customer service or your local Brother dealer.
- You can also clean the print head from your PC.  
(See Software and Network User's Guide.)

## Checking the print quality

If faded or streaked colours and text appear on your printouts, some of the print head nozzles may be clogged. You can check this by printing the Print Quality Check Sheet and looking at the nozzle check pattern.

- 1 Press **Menu**, **1**, **1**.
- 2 Press **▲** or **▼** to choose **Print Quality**. Press **OK**.
- 3 Press **Colour Start**.  
The machine starts printing the Print Quality Check Sheet.
- 4 Check the quality of the four colour blocks on the sheet.
- 5 The LCD asks you if the print quality is OK.  
Do one of the following:
  - If all lines are clear and visible, press **1** (**Yes**) to finish the Print Quality check and go to step 6.
  - If you can see missing short lines as shown below, press **2** to choose **No**.

OK



Poor



- 6 The LCD asks you if the print quality is OK for black and then the three colours. Press **1** (**Yes**) or **2** (**No**).
- 7 The LCD asks you if you want to start cleaning. Press **1** (**Yes**).  
The machine starts cleaning the print head.

- 8 After the cleaning procedure is finished, press **Colour Start**.  
The machine prints the Print Quality Check Sheet again. Return to step 4.

- 9 Press **Stop/Exit**.

If you clean the print head at least five times and the print has not improved, try installing a new Genuine Brother Brand replacement ink cartridge for each problem colour. Try cleaning the print head again up to five more times. If the print has not improved, contact Brother customer service or your local Brother dealer.

### IMPORTANT

DO NOT touch the print head. Touching the print head may cause permanent damage and may void the print head's warranty.

### NOTE





When a print head nozzle is clogged the printed sample looks like this.

After the print head nozzle is cleaned, the horizontal lines are gone.

## Checking the print alignment

If your printed text becomes blurred or images become faded, you may need to adjust the print alignment after transporting the machine.


- 1 Press **Menu, 1, 1**.
- 2 Press **▲** or **▼** to choose *Alignment*. Press **OK**.
- 3 Press **Mono Start** or **Colour Start**. The machine starts printing the Alignment Check Sheet.



- 4 For the "A" pattern, press the number of the test print that has the least visible vertical stripes (1-9). Repeat this step for the B, C, D and E patterns. In the example number 6 is the best choice for A, B, C, D and E.
- 5 Press **Stop/Exit**.

## NOTE

---



When the print alignment is not adjusted correctly, text looks blurry like this.

---

After the print alignment is adjusted correctly, text looks like this.

## Setting the date and time

The LCD shows the date and time. If it is not correct, follow these instructions to re-enter it.

You can add the date and time to each fax you send by setting your Station ID.

- 1 Press **Menu, 0, 1, 1**.
- 2 Enter the last two digits of the year using the dial pad, and then press **OK**.
- 3 Enter the two digits for the month using the dial pad, and then press **OK**.
- 4 Enter the two digits for the day using the dial pad, and then press **OK**.
- 5 Enter the time (in 24-hour format) using the dial pad, and then press **OK**.  
(For example, enter 19:45 for 7:45 PM.)
- 6 Press **Stop/Exit**.



# B

# Troubleshooting

If you think there is a problem with your machine, check each of the items below first and follow the troubleshooting tips.

You can correct most problems by yourself. If you need additional help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips.

Visit us at <http://solutions.brother.com/>.

## Identifying your problem

First, check the following:

- The machine's power cord is connected correctly and the machine's power switch is turned on.
- All of the protective parts have been removed.
- Paper is inserted correctly in the paper tray.
- The interface cables are securely connected to the machine and the computer.
- LCD messages

(See *Error and maintenance messages* on page 59.)

If you did not solve your problem with the above checks, identify your problem and then go to the suggested page.

Paper handling and Printing problems:

- *Printing Difficulties* on page 76
- *Print Quality Difficulties* on page 78
- *Paper Handling Difficulties* on page 79
- *Printing Received Faxes* on page 81

Telephone and Fax problems:

- *Telephone Line or Connections* on page 81
- *Handling Incoming Calls* on page 84
- *Receiving Faxes* on page 82
- *Sending Faxes* on page 84

Copying problems:

- *Copying Difficulties* on page 85

Scanning problems:

- *Scanning Difficulties* on page 85

Software problems:

- *Software Difficulties* on page 85

## Error and maintenance messages

As with any sophisticated office product, errors may occur and consumable items may need to be replaced. If this happens, your machine identifies the error or required routine maintenance and shows the appropriate message. The most common error and maintenance messages are shown in the table.

You can clear most errors and perform routine maintenance by yourself. If you need additional help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips:

Visit us at <http://solutions.brother.com/>.

Error Message	Cause	Action
B&W Print Only Replace XX Ink	<p>One or more of the colour ink cartridges have reached the end of their life.</p> <p>You can use the machine in monochrome mode for approximately four weeks depending on the number of pages you print.</p> <p>While this message appears on the LCD, each operation works in the following way:</p> <ul style="list-style-type: none"> <li>■ <b>Printing</b> If you choose <b>Greyscale</b> in the <b>Advanced</b> tab of the printer driver, you can use the machine as a monochrome printer. 2-sided printing is not available when this message appears.</li> <li>■ <b>Copying</b> If the paper type is set to <b>Plain Paper</b> you can make copies in monochrome.</li> <li>■ <b>Faxing</b> If the paper type is set to <b>Plain Paper</b> or <b>Inkjet Paper</b>, the machine will receive and print the faxes in monochrome.  If a sending machine has a colour fax, the machine's "handshake" will ask that the fax be sent as monochrome.</li> </ul>	<p>Replace the ink cartridges. (See <i>Replacing the ink cartridges</i> on page 50.)</p> <p><b>NOTE</b></p> <p>The machine will stop all print operations, you cannot use the machine until a new ink cartridge is installed in the following cases:</p> <ul style="list-style-type: none"> <li>• If you unplug the machine or take out the ink cartridge.</li> <li>• If the paper type is set to anything except <b>Plain Paper</b> or <b>Inkjet Paper</b>.</li> <li>• (Windows®) If you check <b>Slow Drying Paper</b> in the <b>Basic</b> tab of the printer driver. (Macintosh) If you check <b>Slow Drying Paper</b> in the <b>Print Settings</b> of the printer driver.</li> </ul>
BT Call Sign On (U.K. only)	BT Call Sign is set to ON. You cannot change the Receive Mode from Manual to another mode.	Set BT Call Sign to OFF. (See <i>Advanced User's Guide: BT Call Sign (U.K. only)</i> .)



Error Message	Cause	Action
Cannot Detect	You installed a new ink cartridge too quickly and the machine did not detect it.	Take out the new ink cartridge and re-install it slowly and firmly until the cartridge lever lifts. (See <i>Replacing the ink cartridges</i> on page 50.)
	An ink cartridge is not installed correctly.	
	If you are using non Brother Original ink, the machine may not detect the ink cartridge.	Replace the cartridge with a Brother Original ink cartridge. If the error message remains, contact Brother customer service or your local Brother dealer.
Cannot Print Replace XX Ink	One or more of the ink cartridges have reached the end of their life. The machine will stop all print operations. While memory is available, monochrome faxes will be stored in the memory. If a sending machine has a colour fax, the machine's "handshake" will ask that the fax be sent as monochrome.	Replace the ink cartridges. (See <i>Replacing the ink cartridges</i> on page 50.)
Clean Unable XX Init Unable XX Print Unable XX Scan Unable XX	The machine has a mechanical problem. A foreign object, such as a paper clip or a piece of ripped paper, is in the machine.	Open the scanner cover and remove any foreign objects and paper scraps from inside the machine. If the error message continues, do the following.  See <i>Transferring your faxes or Fax Journal report</i> on page 66 before disconnecting the machine so you will not lose any important messages. Then disconnect the machine from the power for several minutes and reconnect it.
Close Ink Cover	The ink cartridge cover is not locked in the closed position.	Firmly close the ink cartridge cover until it locks into place.
Comm.Error	Poor telephone line quality caused a communication error.	If the problem continues, call the telephone company and ask them to check your telephone line.
Cover is Open	The scanner cover is not locked in the closed position.	Lift the scanner cover, and then close it again.
		Make sure the telephone line cord and USB cable (if used) have been guided correctly through the cable channel and out the back of the machine.
Data Remaining	Print data is left in the machine's memory.	Press <b>Stop/Exit</b> . The machine will cancel the job and clear it from the memory. Try to print again.

Error Message	Cause	Action
Disconnected	The other person or other person's fax machine stopped the call.	Try to send or receive again. If calls are stopped repeatedly and you are using a VoIP (Voice over IP) system, try changing the Compatibility to Basic (for VoIP). (See <i>Telephone line interference / VoIP</i> on page 86.)
Document Jam	The document was not inserted or fed correctly, or the document scanned from the ADF was too long.	(See <i>Using the ADF</i> on page 19.) (See <i>Document jam</i> on page 67.)
High Temperature	The room temperature is too high.	After lowering the room temperature, allow the machine to cool down to room temperature and then try again.
Ink Box Full	<p>The ink absorber box or flushing box is full. These components are periodic maintenance items that may require replacement after a period of time to ensure optimum performance from your Brother machine. Because these components are periodic maintenance items, the replacement is not covered under the warranty. The need to replace these items and the time period before replacement is dependent on the number of purges and flushes required to clean the ink system. These boxes acquire amounts of ink during the different purging and flushing operations. The number of times a machine purges and flushes for cleaning varies depending on different situations. For example, frequently powering the machine on and off will cause numerous cleaning cycles since the machine automatically cleans itself upon power up. The use of non-Brother ink may cause frequent cleanings because non-Brother ink could cause poor print quality, which is resolved by cleaning. The more cleaning the machine requires, the faster these boxes will fill up.</p> <p><b>NOTE</b></p> <p><i>Repairs resulting from the use of non-Brother supplies may not be covered under the stated product warranty.</i></p>	<p>The ink absorber box or flushing box will need to be replaced. Call Brother Customer Service or your local Brother Authorised Service Centre to have your machine serviced.</p> <p>Other reasons for cleaning are:</p> <ol style="list-style-type: none"> <li>1 After a paper jam has been cleared, the machine automatically cleans itself before the next received fax is printed.</li> <li>2 The machine automatically cleans itself after sitting idle for more than 30 days (infrequent use).</li> <li>3 The machine automatically cleans itself after ink cartridges of the same colour have been replaced 12 times.</li> </ol>

<b>Error Message</b>	<b>Cause</b>	<b>Action</b>
InkBox NearFull	The ink absorber box or flushing box is nearly full.	Contact Brother customer service or your local Brother dealer.
Ink Low XXXXXXXX	One or more of the ink cartridges are near the end of their life. If one of the colour ink cartridges is near the end of its life and someone is sending you a colour fax, your machine's "handshake" will ask that the fax be sent in monochrome. If the sending machine has the ability to convert it, the colour fax will be printed at your machine as a monochrome fax.	Order a new ink cartridge. You can continue printing until the LCD shows <i>Cannot Print</i> . (See <i>Replacing the ink cartridges</i> on page 50.)
Low Temperature	The room temperature is too low.	After increasing the room temperature, allow the machine to warm up to room temperature and then try again.
No Caller ID	There is no incoming call history. You did not receive calls or you have not subscribed to the Caller ID service from your telephone company.	If you want to use the Caller ID feature, call your telephone company. (See <i>Caller ID (U.K. and Ireland only)</i> on page 29.)
No Ink Cartridge	An ink cartridge is not installed correctly.	Take out the new ink cartridge and re-install it slowly and firmly until the cartridge lever lifts. (See <i>Replacing the ink cartridges</i> on page 50.)

Error Message	Cause	Action
No Paper Fed	The machine is out of paper or paper is not correctly loaded in the paper tray.	Do one of the following: <ul style="list-style-type: none"> <li>■ Refill the paper in the paper tray, and then press <b>Mono Start</b> or <b>Colour Start</b>.</li> <li>■ Remove and reload the paper, then press <b>Mono Start</b> or <b>Colour Start</b>. (See <i>Loading paper and other print media</i> on page 10.)</li> </ul>
	The paper tray was not fully inserted.	Remove the paper tray and re-install it until it locks into place, and then press <b>Mono Start</b> or <b>Colour Start</b> on the control panel.
	Paper dust has accumulated on the surface of the paper pick-up rollers.	Clean the paper pick-up rollers. (See <i>Advanced User's Guide: Cleaning the paper pick-up rollers.</i> )
	The Jam Clear Cover is not closed correctly.	Make sure the Jam Clear Cover is closed evenly at both ends. (See <i>Printer jam or paper jam</i> on page 68.)
	The paper is jammed in the machine.	Remove the jammed paper by following the steps in <i>Printer jam or paper jam</i> on page 68.  If this error occurs often during 2-sided printing, the paper feed rollers may be stained with ink. Clean the paper feed rollers. (See <i>Advanced User's Guide: Cleaning the paper feed rollers.</i> )
No Response/Busy	The number you dialled has not answered or is busy.	Verify the number and try again.
Not Registered	You tried to access a Speed Dial number that has not been stored in the machine.	Set up the Speed Dial number. (See <i>Storing Speed Dial numbers</i> on page 38.)



Error Message	Cause	Action
Out of Memory	The machine's memory is full.	<p><b>If a fax-sending or copy operation is in process:</b></p> <ul style="list-style-type: none"> <li>■ Press <b>Stop/Exit</b> and wait until the other operations that are in process finish, and then try again.</li> <li>■ Press <b>Mono Start</b> or <b>Colour Start</b> to choose <i>Send</i> to send the pages scanned so far.</li> <li>■ Press <b>Mono Start</b> or <b>Colour Start</b> to choose <i>Copy</i> to copy the pages scanned so far.</li> <li>■ Clear the data in the memory. To gain extra memory, you can turn off Memory Receive. (See Advanced User's Guide: <i>Turning off Memory Receive operation.</i>)</li> <li>■ Print the faxes that are in the memory. (See Advanced User's Guide: <i>Printing a fax from the memory.</i>)</li> </ul>
Paper Jam	The paper is jammed in the machine.	<p>Remove the jammed paper by following the steps in <i>Printer jam or paper jam</i> on page 68.</p> <p>Make sure the paper length guide is set to the correct paper size.</p> <p>If there is a repeat paper jam, a small piece of paper may be stuck in the machine. Make sure paper is not still jammed in the machine. (See <i>Additional paper jam clear operations</i> on page 71.)</p>
	Paper dust has accumulated on the surface of the paper pick-up rollers.	Clean the paper pick-up rollers. (See Advanced User's Guide: <i>Cleaning the paper pick-up rollers.</i> )
Wrong Ink Colour	An ink cartridge has been installed in the wrong position.	Check which ink cartridges are not matched by colour to their ink cartridge positions and move them to their correct positions.



Error Message	Cause	Action
Wrong Paper Size	The Paper Size setting does not match the size of paper in the tray. Or, you did not set the paper guides in the tray to the indicators for the paper size you are using.	<ol style="list-style-type: none"> <li data-bbox="999 304 1466 450">1 Check that the Paper Size you choose matches the size of paper in the tray. (See <i>Paper Size</i> on page 16.)</li> <li data-bbox="999 465 1466 667">2 Make sure you loaded the paper in a Portrait position, by setting the paper guides at the indicators for your paper size. (See <i>Loading paper and other print media</i> on page 10.)</li> <li data-bbox="999 683 1466 786">3 After you have checked the paper size and the paper position, press <b>Mono Start</b> or <b>Colour Start</b>.</li> </ol> <p data-bbox="999 801 1466 1010">If you are printing from your computer, make sure the paper size you choose in the printer driver matches the size of paper in the tray. (See <i>Software and Network User's Guide</i>.)</p>

## Transferring your faxes or Fax Journal report

If the LCD shows:

- Clean Unable XX
- Init Unable XX
- Print Unable XX
- Scan Unable XX

We recommend transferring your faxes to another fax machine or to your PC. (See *Transferring faxes to another fax machine* on page 66 or *Transferring faxes to your PC* on page 66.)

You can also transfer the Fax Journal report to see if there are any faxes you need to transfer. (See *Transferring the Fax Journal report to another fax machine* on page 67.)



### Transferring faxes to another fax machine

If you have not set up your Station ID, you cannot enter fax transfer mode. (See Quick Setup Guide: *Enter personal information (Station ID)*.)

- 1 Press **Menu, 9, 0, 1**.
- 2 Do one of the following:
  - If the LCD shows `No Data`, there are no faxes left in the machine's memory.  
Press **Stop/Exit**.
  - If the LCD shows `Enter Fax No.`, enter the fax number to which faxes will be forwarded.
- 3 Press **Mono Start**.

### Transferring faxes to your PC

You can transfer the faxes from your machine's memory to your PC.

- 1 Make sure you have installed **MFL-Pro Suite** on your PC, and then turn on **PC-FAX Receiving** on the PC. Do one of the following:  
(Windows® XP, Windows Vista® and Windows® 7)  
From  (**Start**), select **All Programs, Brother, MFC-XXXX, PC-FAX Receiving**, and select **Receive**. (XXXX is your model name.)  
(Windows® 8)  
Click  (**Brother Utilities**), and then click the drop-down list and select your model name (if not already selected). Click **PC-FAX Receive** in the left navigation bar, and then click **Receive**.
- 2 Make sure you have set PC-Fax Receive on the machine.  
(See *Advanced User's Guide: PC-Fax Receive (Windows®)*.)  
If faxes are in the machine's memory when you set up PC-Fax Receive, the LCD will ask if you want to transfer the faxes to your PC.
- 3 Do one of the following:
  - To transfer all faxes to your PC, press **1** (Yes).  
Press **▲** or **▼** to choose `Backup Print:On` or `Backup Print:Off`.  
Press **OK**.
  - To exit and leave the faxes in the memory, press **2** (No).
- 4 Press **Stop/Exit**.

## Transferring the Fax Journal report to another fax machine

If you have not set up your Station ID, you cannot enter fax transfer mode. (See Quick Setup Guide: *Enter personal information (Station ID)*.)


- 1 Press **Menu**, **9**, **0**, **2**.
- 2 Enter the fax number to which the Fax Journal report will be forwarded.
- 3 Press **Mono Start**.

## Document jam

Documents can jam in the ADF unit if they are not inserted or fed correctly, or if they are too long. Follow these steps to clear a document jam.

### Document is jammed in the top of the ADF unit

- 1 Take out any paper from the ADF that is not jammed.
- 2 Open the ADF cover.
- 3 Remove the jammed document by pulling it upward.



1 ADF cover

- 4 Close the ADF cover.


- 5 Press **Stop/Exit**.

### IMPORTANT

To avoid document jams, close the ADF cover correctly by pushing it gently in the centre.

### Document is jammed inside the ADF unit

- 1 Take any paper that is not jammed out of the ADF.
- 2 Lift the Document Cover.
- 3 Pull the jammed document out to the left.




1 Document Cover

- 4 Close the document cover.
- 5 Press **Stop/Exit**.

## Removing small documents jammed in the ADF

- 1 Lift the Document Cover.
- 2 Insert a piece of stiff paper, such as cardstock, into the ADF to push any small paper scraps through.



1 Document Cover

- 3 Close the document cover.
- 4 Press **Stop/Exit**.

## Printer jam or paper jam


Locate and remove the jammed paper by following these steps:

- 1 Unplug the machine from the electrical socket.


### IMPORTANT

Before you unplug the machine from the power source, you can transfer your faxes that are stored in the memory to your PC or another fax machine so you will not lose any important messages. (See *Transferring your faxes or Fax Journal report* on page 66.)


- 2 Pull the paper tray (1) completely out of the machine.




- 3 Pull the two green levers inside the machine towards you to release the jammed paper.




- 4 Place both hands under the plastic tabs on both sides of the machine to lift the scanner cover into the open position.



- 5 Pull the jammed paper (1) out of the machine.




- 6 Move the print head (if necessary) to take out any paper remaining in this area. Make sure that jammed paper is not left in the corners of the machine (1) and (2).




### IMPORTANT

- DO NOT touch the encoder strip (1). Doing this may cause damage to the machine.




- If the print head is in the right corner as shown in the illustration (2), you cannot move it. Re-connect the power cord. Hold down **Stop/Exit** until the print head moves to the centre. Then unplug the machine from the power source and take out the paper.
- If the paper is jammed under the print head, unplug the machine from the power source, and then move the print head to take out the paper.

Hold the concave areas with the triangle marks shown in the illustration (3) to move the print head.




- If ink gets onto your skin, immediately wash with soap and plenty of water.


- 7 Make sure you look carefully inside the machine (1) for any pieces of paper.




- 8 Look inside the machine from a lower angle, and make sure there are no pieces of paper remaining.




- 9 Open the Jam Clear Cover (1) at the back of the machine.




- 10 Remove the jammed paper.




- 11** Close the Jam Clear Cover.  
Make sure the cover is closed correctly.



- 12** Put the paper tray firmly back in the machine.



- 13** Lift the scanner cover (1) to release the lock. Gently push the scanner cover support down (2) and close the scanner cover (3) using both hands.



## ⚠ CAUTION

Be careful not to pinch your fingers when you close the scanner cover.

- 14** While holding the paper tray in place, pull out the paper support until it locks in the open position, and then unfold the paper support flap. Make sure you pull out the paper support until it locks into place.


- 15** Re-connect the power cord.

## NOTE


If there is a repeat paper jam, a small piece of paper may be stuck in the machine. (See *Additional paper jam clear operations* on page 71.)

## Additional paper jam clear operations


- 1** Unplug the machine from the electrical socket.
- 2** Pull the paper tray (1) completely out of the machine.





- 3 Pull the two green levers inside the machine towards you to release the jammed paper.



- 4 Place both hands under the plastic tabs on both sides of the machine to lift the scanner cover into the open position.




- 5 Load one sheet of thick A4 or Letter sized paper, such as glossy paper, deep into the machine as shown in the illustration.






- 6 If the thick paper is pushing any jammed paper out, remove the jammed paper.




**IMPORTANT**

DO NOT touch the encoder strip (1). Doing this may cause damage to the machine.




- 7 Pull the thick paper out of the machine.


- 8 Open the Jam Clear Cover (1) at the back of the machine.




- 9 Load one sheet of thick A4 or Letter sized paper, such as glossy paper, deep into the machine as shown in the illustration.




- 10 If the thick paper is pushing any jammed paper out, remove the jammed paper.



- 12 Close the Jam Clear Cover. Make sure the cover is closed correctly.




- 13 Lift the scanner cover (1) to release the lock. Gently push the scanner cover support down (2) and close the scanner cover (3) using both hands.



## IMPORTANT

DO NOT touch the encoder strip (1). Doing this may cause damage to the machine.




- 11 Pull the thick paper out of the machine.

## ⚠ CAUTION

Be careful not to pinch your fingers when you close the scanner cover.

- 14 Put the paper tray firmly back in the machine.



- 15 Re-connect the power cord.



# If you are having difficulty with your machine

## NOTE



- For technical help, you must contact Brother customer support.
- If you think there is a problem with your machine, check the following chart and follow the troubleshooting tips. You can correct most problems by yourself.
- If you need additional help, the Brother Solutions Center offers the latest FAQs and troubleshooting tips.

Visit us at <http://solutions.brother.com/>.






## Printing Difficulties

Difficulty	Suggestions
No printout.	Check that the correct printer driver has been installed and chosen.
	Check to see if the LCD is showing an error message. (See <i>Error and maintenance messages</i> on page 59.)
	<p>Make sure that the machine is online.</p> <p>(Windows® XP) Click <b>Start/Printers and Faxes</b>. Right-click <b>Brother MFC-XXXX Printer</b> (where XXXX is your model name). If the printer is offline, it will show <b>Use Printer Online</b>. Select this option to enable the printer.</p> <p>(Windows Vista®) Click  <b>/Control Panel/Hardware and Sound/Printers</b>. Right-click <b>Brother MFC-XXXX Printer</b> (where XXXX is your model name). If the printer is offline, it will show <b>Use Printer Online</b>. Select this option to enable the printer.</p> <p>(Windows® 7) Click  <b>/Devices and Printers</b>. Right-click <b>Brother MFC-XXXX Printer</b> (where XXXX is your model name) and choose <b>See what's printing</b>. Click <b>Printer</b> and make sure that <b>Use Printer Offline</b> is unchecked.</p> <p>(Windows® 8) Move your mouse to the lower right corner of your desktop. When the menu bar appears, click <b>Settings</b>, and then click <b>Control Panel</b>. In the <b>Hardware and Sound</b> (Hardware) group, click <b>View devices and printers</b>. Right-click <b>Brother MFC-XXXX Printer</b> (where XXXX is your model name) and select <b>See what's printing</b>. If printer driver options appear, select your printer driver. Click <b>Printer</b> in the menu bar and make sure that <b>Use Printer Offline</b> is not selected.</p>
	One or more ink cartridges have reached the end of their life. (See <i>Replacing the ink cartridges</i> on page 50.)

## Printing Difficulties (continued)

Difficulty	Suggestions
<p>No printout. (continued)</p>	<p>The document will not print if the old, unprinted data remains in the printer driver spooler. Open the printer icon, and then delete all the data. Your printer icon can be found in the following way:</p> <p>(Windows® XP) Click <b>Start/Printers and Faxes</b>.</p> <p>(Windows Vista®) Click  <b>/Control Panel/Hardware and Sound/Printers</b>.</p> <p>(Windows® 7) Click  <b>/Devices and Printers/Printers and Faxes</b>.</p> <p>(Windows® 8) Move your mouse to the lower right corner of your desktop. When the menu bar appears, click <b>Settings/Control Panel/Hardware and Sound (Hardware) group/View devices and printers/Printers</b>.</p> <p>(Mac OS X v10.6.8) Click <b>System Preferences/Print &amp; Fax</b>.</p> <p>(OS X v10.7.x, 10.8.x) Click <b>System Preferences/Print &amp; Scan</b>.</p>
<p>The headers or footers appear when the document displays on the screen but they do not show up when it is printed.</p>	<p>There is an unprintable area on the top and bottom of the page. Adjust the top and bottom margins in your document to allow for this.</p> <p>(See <i>Unprintable area</i> on page 15.)</p>
<p>Cannot perform "Page Layout" printing.</p>	<p>Check that the paper size setting in the application and in the printer driver are the same.</p>
<p>Print speed is too slow.</p>	<p>Try changing the printer driver setting. The highest resolution needs longer data processing, sending and printing time. Try the other quality settings in the printer driver as follows:</p> <p>(Windows®) Click <b>Colour Settings</b> on the <b>Advanced</b> tab, and make sure you uncheck <b>Colour Enhancement</b>.</p> <p>(Macintosh) Choose <b>Color Settings</b>, click <b>Advanced Color Settings</b>, and make sure you uncheck <b>Color Enhancement</b>.</p> <p>Turn the Borderless feature off. Borderless printing is slower than normal printing. (See Software and Network User's Guide.)</p>
<p>Colour Enhancement is not working correctly.</p>	<p>If the image data is not full colour in your application (such as 256 colour), Colour Enhancement will not work. Use at least 24 bit colour data with the Colour Enhancement feature.</p>
<p>Machine does not print from Adobe® Illustrator®.</p>	<p>Try to reduce the print resolution. (See Software and Network User's Guide.)</p>

## Print Quality Difficulties

Difficulty	Suggestions
Poor print quality.	<p>Check the print quality. (See <i>Checking the print quality</i> on page 54.)</p> <p>Make sure that the <b>Media Type</b> setting in the printer driver or the <i>Paper Type</i> setting in the machine's menu matches the type of paper you are using. (See <i>Paper Type</i> on page 16.)</p> <p>(See <i>Software and Network User's Guide</i>.)</p> <p>Make sure that your ink cartridges are fresh. The following may cause ink to clog:</p> <ul style="list-style-type: none"> <li>■ The expiration date written on the cartridge package has passed. (Brother Original cartridges stay usable for up to two years if kept in their original packaging.)</li> <li>■ The ink cartridge has been in your machine for over six months.</li> <li>■ The ink cartridge may not have been stored correctly before use.</li> </ul> <p>Make sure you are using Brother Original Innobella™ ink. Brother does not recommend the use of cartridges other than Brother Original cartridges or the refilling of used cartridges with ink from other sources.</p> <p>Make sure you are using one of the recommended types of paper. (See <i>Acceptable paper and other print media</i> on page 16.)</p> <p>The recommended environment for your machine is between 20 °C to 33 °C.</p>
<p>White horizontal lines appear in text or graphics.</p> 	<p>Clean the print head. (See <i>Cleaning the print head</i> on page 54.)</p> <p>Make sure you are using Brother Original Innobella™ ink.</p> <p>Try using the recommended types of paper. (See <i>Acceptable paper and other print media</i> on page 16.)</p> <p>To prolong print head life, provide the best ink cartridge economy and maintain print quality, we do not recommend frequently unplugging the machine and/or leaving the machine unplugged for extended periods of time. We recommend using  to power down the machine. Using  allows minimal power to the machine ensuring periodic cleanings of the print head occur.</p>
The machine prints blank pages.	<p>Clean the print head. (See <i>Cleaning the print head</i> on page 54.)</p> <p>Make sure you are using Brother Original Innobella™ ink.</p> <p>To prolong print head life, provide the best ink cartridge economy and maintain print quality, we do not recommend frequently unplugging the machine and/or leaving the machine unplugged for extended periods of time. We recommend using  to power down the machine. Using  allows minimal power to the machine ensuring periodic cleanings of the print head occur.</p>
Characters and lines are blurred.	Check the printing alignment. (See <i>Checking the print alignment</i> on page 55.)
Printed text or images are skewed.	<p>Make sure the paper is loaded correctly in the paper tray and the paper guides are adjusted correctly. (See <i>Loading paper and other print media</i> on page 10.)</p> <p>Make sure the Jam Clear Cover is closed correctly.</p>
Smudge or stain at the top centre of the printed page.	Make sure the paper is not too thick or curled. (See <i>Acceptable paper and other print media</i> on page 16.)

## Print Quality Difficulties (continued)

Difficulty	Suggestions
Printing appears dirty or ink seems to run.	Make sure you are using the recommended types of paper. (See <i>Acceptable paper and other print media</i> on page 16.) Don't handle the paper until the ink is dry.
	Make sure the print side is face down in the paper tray.
	Make sure you are using Brother Original Innobella™ ink.
	If you are using photo paper, make sure that you have set the correct paper type. If you are printing a photo from your PC, set the <b>Media Type</b> in the printer driver.
Ink is smudged or wet when using glossy photo paper.	Be sure to check the front and back of the paper. Place the glossy surface (printing surface) face down. (See <i>Paper Type</i> on page 16.)
	If you use glossy photo paper, make sure that the paper type setting is correct.
Stains appear on the reverse side or at the bottom of the page.	Make sure the printer platen is not dirty with ink. (See <i>Advanced User's Guide: Cleaning the machine's printer platen.</i> )
	Make sure you are using Brother Original Innobella™ ink.
	Make sure you are using the paper support flap. (See <i>Loading paper and other print media</i> on page 10.)
	Make sure the paper feed rollers are not dirty with ink. (See <i>Advanced User's Guide: Cleaning the paper feed rollers.</i> )
The machine prints dense lines on the page.	(Windows®) Check <b>Reverse Order</b> in the <b>Basic</b> tab of the printer driver.
The printouts are wrinkled.	(Windows®) In the printer driver <b>Advanced</b> tab, click <b>Colour Settings</b> and uncheck <b>Bi-Directional Printing</b> .
	(Macintosh) In the printer driver, choose <b>Print Settings</b> , click <b>Advanced</b> , choose <b>Other Print Options</b> and uncheck <b>Bi-Directional Printing</b> .
	Make sure you are using Brother Original Innobella™ ink.

## Paper Handling Difficulties

Difficulties	Suggestions
The machine does not feed paper.	Make sure the paper tray is pushed in all the way until it clicks into place.
	Make sure the Jam Clear Cover at the back of the machine is closed.
	If the LCD shows the Paper Jam message and you still have a problem, see <i>Error and maintenance messages</i> on page 59.
	If there is no paper, load a new stack of paper into the paper tray.
	If there is paper in the paper tray, make sure it is straight. If the paper is curled, straighten it. Sometimes it is helpful to remove the paper, turn the stack over and put it back into the paper tray.
	Reduce the amount of paper in the paper tray, and then try again.
	Clean the paper pick-up rollers. (See <i>Advanced User's Guide: Cleaning the paper pick-up rollers.</i> )
Photo paper does not feed correctly.	When you print on Brother Photo paper, load one extra sheet of the same photo paper in the paper tray. An extra sheet has been included in the paper package for this purpose.

## Paper Handling Difficulties (continued)

Difficulties	Suggestions
Machine feeds multiple pages.	<p>Do the following:</p> <p>(See <i>Loading paper and other print media</i> on page 10.)</p> <ul style="list-style-type: none"> <li>■ Make sure the paper is loaded correctly in the paper tray.</li> <li>■ Remove all the paper from the tray and fan the stack of paper well, then put it back in the tray.</li> <li>■ Make sure you do not push the paper in too far.</li> </ul> <p>Make sure the Jam Clear Cover is closed correctly. (See <i>Printer jam or paper jam</i> on page 68.)</p> <p>Make sure the Base Pad in the paper tray is not dirty. (See <i>Advanced User's Guide: Cleaning the paper pick-up rollers.</i>)</p>
There is a paper jam.	See <i>Printer jam or paper jam</i> on page 68. Make sure the paper guides are set to the correct paper size.
Paper jam reoccurs.	If there is a repeat paper jam, a small piece of paper may be stuck in the machine. Make sure paper is not still jammed in the machine. (See <i>Additional paper jam clear operations</i> on page 71.)
The paper jams when you use 2-sided print.	<p>Use one of the jam prevention settings, 2-sided1 or 2-sided2.</p> <p>For printing (See <i>Software and Network User's Guide.</i>)</p> <p>If paper jams occur often during 2-sided printing, the paper feed rollers may be stained with ink. Clean the paper feed rollers. (See <i>Advanced User's Guide: Cleaning the paper feed rollers.</i>)</p>



## Printing Received Faxes

Difficulty	Suggestions
<ul style="list-style-type: none"> <li>■ Condensed print</li> <li>■ Horizontal streaks</li> <li>■ Top and bottom sentences are cut off</li> <li>■ Missing lines</li> </ul>	Usually this is caused by a poor telephone connection. Make a copy; if your copy looks good, you probably had a bad connection, with static or interference on the telephone line. Ask the other party to send the fax again.
Vertical black lines when receiving.	The sender's scanner may be dirty. Ask the sender to make a copy to see if the problem is with the sending machine. Try receiving from another fax machine.
Left and right margins are cut off or a single page is printed on two pages.	If the received faxes are divided and printed on two pages or if you get an extra blank page, your <i>Paper Size</i> setting may not be correct for the paper you are using.  (See <i>Paper Size</i> on page 16.)
	Turn on Auto Reduction. (See <i>Advanced User's Guide: Printing a reduced incoming fax.</i> )
Received colour fax prints only in monochrome.	Replace each colour ink cartridge that has reached the end of its life, and then ask the other person to send the colour fax again. (See <i>Replacing the ink cartridges</i> on page 50.)

## Telephone Line or Connections

Difficulty	Suggestions
Dialling does not work. (No dial tone)	Check the line cord connections.
	Change the Tone/Pulse setting. (See <i>Quick Setup Guide.</i> )
	If there is no dial tone, connect a known-working telephone and telephone line cord to the socket. Then lift the external telephone's handset and listen for a dial tone. If there is still no dial tone, ask your telephone company to check the line and/or wall socket.
The machine does not answer when called.	Make sure the machine is in the correct Receive Mode for your setup. (See <i>Choose the Receive Mode</i> on page 25.) Check for a dial tone. If possible, call your machine to hear whether it answers. If there is still no answer, check the telephone line cord connection. If there is no ringing when you call your machine, ask your telephone company to check the line.



## Receiving Faxes

Difficulty	Suggestions
<p>Cannot receive a fax.</p>	<p>Check all line cord connections. Make sure the telephone line cord is plugged into the telephone wall socket and the LINE socket inside the machine. If you subscribe to DSL or VoIP services, call your service provider for connection instructions. To lower the modem speed and turn off ECM (error correction mode), see <i>Telephone line interference / VoIP</i> on page 86.</p> <p>Make sure the machine is in the correct Receive Mode. This is determined by the external devices and telephone subscriber services you have on the same line as the Brother machine. (See <i>Choose the Receive Mode</i> on page 25.)</p> <p>If you have a dedicated fax line and want your Brother machine to automatically answer all incoming faxes, select <b>Fax Only</b> mode.</p> <p>If your Brother machine shares a line with an external answering machine, select <b>External TAD</b> mode. In <b>External TAD</b> mode, your Brother machine will automatically receive incoming faxes and voice callers will be able to leave a message on your answering machine.</p> <p>If your Brother machine shares a line with other telephones and you want it to automatically answer all incoming faxes, select <b>Fax/Tel</b> mode. In <b>Fax/Tel</b> mode, your Brother machine will automatically receive faxes and produce a fast double-ring to alert you to answer voice calls.</p> <p>If you do not want your Brother machine to automatically answer incoming faxes, select <b>Manual</b> mode. In <b>Manual</b> mode, you must answer every incoming call and activate the machine to receive faxes.</p> <p>Another device or service at your location may be answering the call before your Brother machine answers. To test this, lower the Ring Delay setting:</p> <ul style="list-style-type: none"> <li>■ If the Receive Mode is set to <b>Fax Only</b> or <b>Fax/Tel</b>, reduce the Ring Delay to 1 ring. (See <i>Ring Delay</i> on page 27.)</li> <li>■ If the Receive Mode is set to <b>External TAD</b>, reduce the number of rings programmed on your answering machine to 2.</li> <li>■ If the Receive Mode is set to <b>Manual</b>, DO NOT adjust the Ring Delay setting.</li> </ul> <p>Have someone send you a test fax:</p> <ul style="list-style-type: none"> <li>■ If you received the test fax successfully, your machine is operating correctly. Remember to reset your Ring Delay or answering machine setting back to your original setting. If receiving problems recur after resetting the Ring Delay, then a person, device, or subscriber service is answering the fax call before the machine has a chance to answer.</li> <li>■ If you were not able to receive the fax, then another device or subscriber service may be interfering with your fax reception or there may be a problem with your fax line.</li> </ul>

## Receiving Faxes (continued)

Difficulty	Suggestions
<p>Cannot receive a fax. (continued)</p>	<p>If you are using a telephone answering machine (External TAD mode) on the same line as the Brother machine, make sure your answering machine is set up correctly. (See <i>Connecting an external TAD (telephone answering device)</i> on page 32.)</p> <ol style="list-style-type: none"> <li>1 Connect the external TAD as shown in the illustration on page 32.</li> <li>2 Set your answering machine to answer in one or two rings.</li> <li>3 Record the outgoing message on your answering machine.                             <ul style="list-style-type: none"> <li>■ Record five seconds of silence at the beginning of your outgoing message.</li> <li>■ Limit your speaking to 20 seconds.</li> <li>■ End your outgoing message with your Remote Activation Code for people sending manual faxes. For example: "After the beep, leave a message or press * 5 1 and <b>Start</b> to send a fax."</li> </ul> </li> <li>4 Set your answering machine to answer calls.</li> <li>5 Set your Brother machine's Receive Mode to External TAD. (See <i>Choose the Receive Mode</i> on page 25.)</li> </ol>
	<p>Make sure your Brother machine's Fax Detect feature is set to On. Fax Detect is a feature that allows you to receive a fax even if you have answered the call on an external or extension telephone. (See <i>Fax Detect</i> on page 28.)</p>
	<p>If you often get transmission errors due to possible interference on the telephone line, try changing the Compatibility setting to Basic (for VoIP). (See <i>Telephone line interference / VoIP</i> on page 86.)</p>
	<p>If you connect your machine to a PBX or ISDN line, set the menu setting of Telephone Line Type to your telephone line type. (See <i>Setting the Telephone Line Type</i> on page 30.)</p>

## Sending Faxes

Difficulty	Suggestions
Cannot send a fax.	Check all line cord connections. Make sure the telephone line cord is plugged into the telephone wall socket and the LINE socket inside the machine.
	Print the Transmission Verification Report and check for an error. (See <i>Advanced User's Guide: Reports</i> .)
	Ask the other party to check that the receiving machine has paper.
Poor fax send quality.	Try changing your resolution to <i>Fine</i> or <i>S.Fine</i> . Make a copy to check your machine's scanner operation. If the copy quality is poor, clean the scanner. (See <i>Cleaning the scanner glass</i> on page 53.)
Transmission Verification Report shows <i>RESULT:ERROR</i> .	There is probably temporary noise or static on the line. Try sending the fax again. If you send a PC FAX message and see <i>RESULT:ERROR</i> on the Transmission Verification Report, your machine may be out of memory. To gain extra memory, you can print fax messages from the machine's memory. (See <i>Advanced User's Guide: Printing a fax from the memory</i> .) If the problem continues, ask the telephone company to check your telephone line.
	If you often get transmission errors due to possible interference on the telephone line, try changing the machine's <i>Compatibility</i> setting to <i>Basic (for VoIP)</i> . (See <i>Telephone line interference / VoIP</i> on page 86.)
	If you connect your machine to PBX or ISDN, set the menu setting of <i>Telephone Line Type</i> to your telephone line type. (See <i>Setting the Telephone Line Type</i> on page 30.)
Vertical black lines when sending.	Black vertical lines on faxes you send are typically caused by dirt or correction fluid on the glass strip. Clean the glass strip. (See <i>Cleaning the scanner glass</i> on page 53.)

## Handling Incoming Calls

Difficulty	Suggestions
The machine "hears" a voice as a CNG Tone.	If <i>Fax Detect</i> is set to <i>On</i> , your machine is more sensitive to sounds. It may mistakenly interpret certain voices or music on the line as a fax machine calling and respond with fax-receiving tones. Deactivate the machine by pressing <b>Stop/Exit</b> . Try avoiding this problem by turning <i>Fax Detect</i> to <i>Off</i> . (See <i>Fax Detect</i> on page 28.)
Sending a fax call to the machine.	If you answered on an extension or external telephone, press your <i>Remote Activation Code</i> (the factory default is * 5 1). If you answered on an external telephone, press <b>Mono Start</b> or <b>Colour Start</b> , and press <b>2</b> to receive the fax. When your machine answers, hang up.
Custom features on a single line.	If you have <i>Call Waiting</i> , <i>Call Waiting/Caller ID</i> , <i>Caller ID</i> , <i>Voice Mail</i> , an answering machine, an alarm system or other custom feature on a single telephone line with your machine, it may create a problem sending or receiving faxes.  <b>For example:</b> If you subscribe to <i>Call Waiting</i> or another custom service and its signal comes through the line while your machine is sending or receiving a fax, the signal can temporarily interrupt the faxes. Brother's <i>ECM (Error Correction Mode)</i> feature should help overcome this problem. This condition is related to the telephone system industry and is common to all devices that send and receive information on a single, shared line with custom features. If avoiding a slight interruption is crucial to your business, we recommend using a separate telephone line with no custom features.

## Copying Difficulties

Difficulty	Suggestions
Vertical black lines or streaks appear in copies.	Black vertical lines on copies are typically caused by dirt or correction fluid on the glass strip. Clean the glass strip, scanner glass, white bar and white plastic above them. (See <i>Cleaning the scanner glass</i> on page 53.)
Poor copy results when using the ADF.	Try using the scanner glass. (See <i>Using the scanner glass</i> on page 20.)
Fit to Page does not work correctly.	Make sure your source document is not skewed. Reposition the document and try again.

## Scanning Difficulties

Difficulty	Suggestions
TWAIN or WIA errors appear when starting to scan. (Windows®)	Make sure the Brother TWAIN or WIA driver is chosen as the primary source in your scanning application. For example, in Nuance™ PaperPort™ 12SE, click <b>Scan Settings, Select</b> to choose the Brother TWAIN/WIA driver.
TWAIN or ICA errors appear when starting to scan. (Macintosh)	Make sure the Brother TWAIN driver is chosen as the primary source. In PageManager, click <b>File, Select Source</b> and choose the Brother TWAIN driver. You can also scan documents using the ICA Scanner Driver. (See Software and Network User's Guide.)
OCR does not work.	Try increasing the scanner resolution.  (Macintosh)  Presto! PageManager must be downloaded and installed before use. For more information, see <i>Accessing Brother Support (Macintosh)</i> on page 5.
Poor scanning results when using the ADF.  ■ Vertical black lines appear in the scanned data.	Clean the white bar in the ADF and the glass strip underneath it. (See <i>Cleaning the scanner glass</i> on page 53.)  Try using the scanner glass. (See <i>Using the scanner glass</i> on page 20.)

## Software Difficulties

Difficulty	Suggestions
Cannot install software or print.	(Windows®) Run the <b>Repair MFL-Pro Suite</b> program on the CD-ROM. This program will repair and reinstall the software.
"Device Busy"	Make sure the machine is not showing an error message on the LCD.



## Dial Tone detection

---

When you send a fax automatically, by default your machine will wait for a fixed amount of time before it starts to dial the number. By changing the Dial Tone setting to `Detection`, you can make your machine dial as soon as it detects a dial tone. This setting can save a small amount of time when sending a fax to many different numbers. If you change the setting and start having problems when dialing, you should change it back to the `No Detection` setting.

- 1 Press **Menu, 0, 4**.
- 2 Press **▲** or **▼** to choose `Detection` or `No Detection`. Press **OK**.
- 3 Press **Stop/Exit**.

## Telephone line interference / VoIP

---

If you are having problems sending or receiving a fax due to possible interference on the telephone line, you can change the compatibility setting which reduces the modem speed to minimise errors.

- 1 Press **Menu, 0, 6**.
- 2 Press **▲** or **▼** to choose `Normal` or `Basic(for VoIP)`. Press **OK**.
  - `Basic(for VoIP)` cuts the modem speed to 9,600 bps and turns off colour fax receiving and ECM, except for colour fax-sending. Unless interference is a recurring problem on your telephone line, you may prefer to use it only when needed.

To improve compatibility with most VoIP services, Brother recommends changing the compatibility setting to `Basic(for VoIP)`.
  - `Normal` sets the modem speed at 14,400 bps.
- 3 Press **Stop/Exit**.

### NOTE

---

VoIP (Voice over IP) is a type of phone system that uses an Internet connection, rather than a traditional phone line.

---

## Machine Information

### Checking the serial number

You can see the machine's serial number on the LCD.

- 1 Press **Menu, 6, 1**.  
Your machine's serial number will appear on the LCD.
- 2 Press **Stop/Exit**.

### Checking the firmware version

You can see the machine's firmware version on the LCD.

- 1 Press **Menu, 6, 2**.  
Your machine's firmware version will appear on the LCD.
- 2 Press **Stop/Exit**.

## Reset functions

The following reset functions are available:

- 1 **Machine Reset**  
You can reset the machine's settings, such as the Date and Time, telephone line type and Ring Delay.
- 2 **Address&Fax**  
Address & Fax resets the following settings:
  - Speed Dial  
(Speed-Dial and Setup Groups)
  - Station ID  
(Name and Number)
  - Report settings  
(Transmission Verification Report, Speed Dial and Fax Journal)
- 3 **All Settings**  
You can restore all settings to the factory default.  
Brother strongly recommends performing this procedure before handing over or disposing of the machine.

## How to reset the machine








- 1 Press **Menu, 0, 7**.
- 2 Press **▲** or **▼** to choose the reset function you want.  
Press **OK**.
- 3 Press **1** to reset the machine or press **2** to exit from the reset function.
- 4 Press **1** to reboot the machine.

## Using the Settings tables

Your machine is easy to set up and operate. All you have to do is press the Menu keys to choose the settings and options you want to set as they are displayed on the screen.

We have created step-by-step Settings tables so you can see all the available choices for each setting and feature at-a-glance. You can use these tables to quickly choose your preferred settings in the machine.

## Menu keys

	
<b>Menu</b> 	Access the menu.
	Go to the next menu level. Accept an option.
<b>Clear</b> 	Go back to the previous menu level. Delete an incorrect letter when you need to enter text into the machine.
	Scroll through the current menu level.
	Go back to the previous menu level.
<b>Stop/Exit</b> 	Exit the menu or stop the current operation.



To access the menu mode:

- 1 Press **Menu**.
- 2 Choose an option.  
You can scroll more quickly through each menu level by pressing ▲ or ▼ for the direction you want.

1. Ink

2. General Setup

3. Fax

4. Copy

5. Print Reports

6. Machine Info.

0. Initial Setup

- 3 Press **OK** when that option appears on the LCD.  
The LCD will then show the next menu level.
- 4 Press ▲ or ▼ to scroll to choose the setting you want to change.  
Press **OK**.
- 5 Press ▲ or ▼ to choose the option you want.  
Press **OK**.  
The LCD will show *Accepted*.
- 6 Press **Stop/Exit**.

# Menu table

The menu table will help you understand the menu selections in the machine's menu. The factory settings are shown in bold with an asterisk.

## NOTE

Once you learn the order of the options, you can access a setting by pressing **Menu**, pressing the number of the Level 1 option, pressing the number of the Level 2 option, and so on, until you see the setting you want.

Menu (  )

Level1	Level2	Level3	Options	Descriptions	Page
1. Ink	1. Test Print	—	Print Quality Alignment	Lets you check the print quality or alignment.	54 55
	2. Cleaning	—	Black Colour All	Lets you clean the print head.	54
	3. Ink Volume	—	-□□□□□□+ -■□□□□□+ -■■□□□□+ -■■■□□□+ -■■■■□□+ -■■■■■□+ -■■■■■■□+ -■■■■■■■+	Lets you check the available ink volume.	See ◆.
2. General Setup	1. Mode Timer	—	0 Sec 30 Secs 1 Min <b>2 Mins*</b> 5 Mins Off	Sets the time to return to Fax mode.	
	2. Paper Type	—	<b>Plain Paper*</b> Inkjet Paper Brother BP71 Other Glossy Transparency	Sets the type of paper in the paper tray.	16

◆ See Advanced User's Guide.

‡ See Quick Setup Guide.

The default settings are shown in Bold with an asterisk.

Level1	Level2	Level3	Options	Descriptions	Page
2.General Setup (Continued)	3.Paper Size	—	<b>A4*</b> A5 10x15cm Letter	Sets the size of the paper in the paper tray.	16
	4.Volume	1.Ring	Off Low <b>Med*</b> High	Adjusts the ring volume.	8
		2.Beeper	Off <b>Low*</b> Med High	Adjusts the volume level of the beeper.	9
		3.Speaker	Off Low <b>Med*</b> High	Adjusts the speaker volume.	9
	5.LCD Contrast	—	Light <b>Dark*</b>	Adjusts the contrast of the LCD.	9
	6.Sleep Mode	—	1 Min 2 Mins 3 Mins <b>5 Mins*</b> 10 Mins 30 Mins 60 Mins	You can choose how long the machine will remain idle before it goes into Sleep Mode.	See ♦.

♦ See Advanced User's Guide.

‡ See Quick Setup Guide.

The default settings are shown in Bold with an asterisk.

Level1	Level2	Level3	Options	Descriptions	Page
3. Fax	1.Setup Receive	1.Receive Mode	<b>Fax Only*</b> Fax/Tel External TAD Manual	Choose the Receive Mode that best suits your needs.	25
		2.Ring Delay	00 01 <b>02*</b> 03 04 05 06 07 08  (Example for the U.K.)	Sets the number of rings before the machine answers in Fax Only or Fax/Tel mode.	27
		3.F/T Ring Time	20Secs <b>30Secs*</b> 40Secs 70Secs	Sets the length of the fast double-ring time in Fax/Tel mode.	27
		4. Fax Detect	<b>On*</b> Off	Receives fax messages automatically when you answer a call and hear fax tones.	28
		5.Remote Codes	Remote Codes : (Options) <b>On*</b> Off Act.Code : (*51) Deact.Code : (#51)	Allows you to answer all calls at an extension or external telephone and use codes to turn the machine on or off. You can personalize these codes.	36
		6.Auto Reduction	<b>On*</b> Off	Cuts the size of incoming faxes to fit the paper size.	See ◆.
		7.Memory Receive	<b>Off*</b> PC Fax Receive	You can set the machine to send faxes to your PC.  If you choose PC-Fax Receive, you can turn on the safety feature Backup Print.	

◆ See Advanced User's Guide.

‡ See Quick Setup Guide.

The default settings are shown in Bold with an asterisk.

Level1	Level2	Level3	Options	Descriptions	Page
3. Fax (Continued)	2. Setup Send	1. Fax Resolution	<b>Standard*</b> Fine S. Fine Photo	Sets the default resolution for outgoing faxes.	See ◆.
		2. Contrast	<b>Auto*</b> Light Dark	Changes the lightness or darkness of faxes you send.	
		3. Real Time TX	Next Fax Only On <b>Off*</b>	Sends a fax without using the memory.	
		4. Overseas Mode	On <b>Off*</b>	If you are having problems sending faxes overseas, set this to On.	
		0. Glass ScanSize	<b>A4*</b> Letter	Adjusts the scan area of the scanner glass to the size of the document.	
	3. Report Setting	1. XMIT Report	On On+Image <b>Off*</b> Off+Image	Choose the initial setup for Transmission Verification Report.	24
		2. Journal Period	Off <b>Every 50 Faxes*</b> Every 6 Hours Every 12 Hours Every 24 Hours Every 2 Days Every 7 Days	Sets the interval for the automatic printing of the Fax Journal. If you have chosen any other option than Off or Every 50 Faxes, you can set the time for the chosen option. If you have chosen Every 7 Days, you can set the day of the week.	See ◆.
		4. Print Document	—	—	Prints incoming faxes stored in the memory.
	5. Remaining Jobs	—	—	Check which jobs are in the memory and cancel chosen jobs.	

◆ See Advanced User's Guide.


‡ See Quick Setup Guide.

The default settings are shown in Bold with an asterisk.


Level1	Level2	Level3	Options	Descriptions	Page
3. Fax (Continued)	0. Miscellaneous	1. TX Lock	—	Stops unauthorized users from changing the machine's current settings.	See ◆.
		2. BT Call Sign (U.K. Only)	On <b>Off*</b>	Uses with BT Call Sign.	
		3. Caller ID	<b>On*</b> Off Display ID	View or print a list of the last 30 Caller IDs stored in the memory.	29
4. Copy	1. Quality	—	<b>Normal*</b> Best	Chooses the Copy resolution for your type of document.	See ◆.
	2. Density	—	-□□□■+ -□□□□+ -□□■□+* -□■□□+ -■□□□+	Adjusts the density of copies.	
5. Print Reports	1. XMIT Verify	—	—	Prints these lists and reports.	
	2. Address Book	—	—		
	3. Fax Journal	—	—		
	4. User Settings	—	—		
	5. Caller ID	—	—		
6. Machine Info.	1. Serial No.	—	—	Lets you check the serial number of your machine.	87
	2. Version	—	—	Lets you check the firmware version of your machine.	
◆ See Advanced User's Guide.					
‡ See Quick Setup Guide.					
The default settings are shown in Bold with an asterisk.					

Level1	Level2	Level3	Options	Descriptions	Page
0.Initial Setup	1.Date&Time	1.Date&Time	—	Sets the date and time on the screen and in the headings of the faxes you send.	56
		2.Auto Daylight	<b>On*</b> Off	Automatically changes for Daylight Savings Time.	See ◆.
	2.Station ID	—	Fax: Name:	Enter your name and fax number to appear on each page you fax.	See ‡.
	3.Tone/Pulse	—	<b>Tone*</b> Pulse	Choose the dialling mode.	
	4.Dial Tone	—	Detection <b>No Detection*</b>	Turns Dial Tone Detection on or off.	86
	5.Phone Line Set	—	<b>Normal*</b> PBX ISDN	Choose the telephone line type.	30
	6.Compatibility	—	<b>Normal*</b> Basic(for VoIP)	Adjusts the modem speed to help resolve transmission problems.	86
	7.Reset	1.Machine Reset	1.Reset 2.Exit	You can reset the machine's settings, such as the Date and Time, telephone line type and Ring Delay.	87
		2.Address&Fax	1.Reset 2.Exit	Deletes all stored Speed Dial numbers and faxes, restores the Station ID, Speed Dial List, Transmission Verification Report and Fax Journal back to the factory default settings.	
		3.All Settings	1.Reset 2.Exit	Resets all the machine's settings back to the factory default.	
◆ See Advanced User's Guide.					
‡ See Quick Setup Guide.					
The default settings are shown in Bold with an asterisk.					

## Fax Resolution ( )

Level1	Level2	Level3	Options	Descriptions	Page
—	—	—	<b>Standard*</b> Fine S.Fine Photo	Sets the resolution for outgoing faxes.	See  .
◆ See Advanced User's Guide.					
The default settings are shown in Bold with an asterisk.					

## Copy Options ( )

Level1	Level2	Level3	Options	Descriptions	Page
<b>Quality</b>	—	—	<b>Normal*</b> Best	Choose the Copy resolution for the next copy.	See  .
<b>Enlarge/Reduce</b>	—	—	Fit to Page Custom (25-400%) 198% 10x15cm→A4 186% 10x15cm→LTR 141% A5→A4 <b>100%*</b> 97% LTR→A4 93% A4→LTR 83% LGL→A4 69% A4→A5 47% A4→10x15cm	You can choose the enlargement/reduce ratio for the next copy.	
<b>Paper Type</b>	—	—	<b>Plain Paper*</b> Inkjet Paper Brother BP71 Other Glossy Transparency	Choose the paper type that matches the paper in the tray.	41
<b>Paper Size</b>	—	—	<b>A4*</b> A5 10 (W) x15 (H) cm Letter	Choose the paper size that matches the paper in the tray.	41
◆ See Advanced User's Guide.					
The default settings are shown in Bold with an asterisk.					



Level1	Level2	Level3	Options	Descriptions	Page
Density	—	—	-■□□□+ -■□□□+ -□□■□+* -□□□■+ -□□□□■+	Adjusts the density of copies.	See ◆.
Stack/Sort	—	—	<b>Stack*</b> Sort	You can choose to stack or sort multiple copies.	
Page Layout	—	—	<b>Off (1in1) *</b> 2in1 (P) 2in1 (L) 2in1 (ID) 4in1 (P) 4in1 (L) Poster (3x3)	You can make N in 1 or Poster copies.	
No. of Copies	—	—	—	You can enter the number of copies that you want to make.	40
Remove Bkg.Clr	—	—	<b>Off*</b> Low Medium High	Change the amount of background colour that is removed.	See ◆.
◆ See Advanced User's Guide.					
The default settings are shown in Bold with an asterisk.					

## SCAN ( )

Level1	Level2	Level3	Options	Descriptions	Page	
Scan to E-mail	Set Options	—	<b>Off*</b> On	If you want to use the control panel to change the machine's settings, choose On.	See +.	
	The settings below will appear when On is selected in Set Options.					
	Scan Type	—	<b>Colour*</b> Black and White	You can choose the scan type for your document.		
	Resolution	—	100dpi <b>200dpi*</b> 300dpi 600dpi	You can choose the scan resolution for your document.		
	File Type	—	(If you choose the Colour option in the Scan Type setting) <b>PDF*</b> JPEG (If you choose the Mono option in the Scan Type setting) <b>PDF*</b> TIFF	You can choose the file format for your document.		
	Scan Size	—	<b>A4*</b> A5 10x15cm Business Card Letter	You can choose the scan size for your document.		
	Remove Bkg.Clr	—	<b>Off*</b> Low Medium High	Change the amount of background colour that is removed.		

+ See Software and Network User's Guide.


The default settings are shown in Bold with an asterisk.

Level1	Level2	Level3	Options	Descriptions	Page
Scan to Image	Set Options	—	<b>Off*</b> On	If you want to use the control panel to change the machine's settings, choose On.	See +.
	The settings below will appear when On is selected in Set Options.				
	Scan Type	—	<b>Colour*</b> Black and White	You can choose the scan type for your document.	
	Resolution	—	100dpi <b>200dpi*</b> 300dpi 600dpi	You can choose the scan resolution for your document.	
	File Type	—	(If you choose the Colour option in the Scan Type setting) <b>PDF*</b> JPEG (If you choose the Mono option in the Scan Type setting) <b>PDF*</b> TIFF	You can choose the file format for your document.	
	Scan Size	—	<b>A4*</b> A5 10x15cm Business Card Letter	You can choose the scan size for your document.	
	Remove Bkg.Clr	—	<b>Off*</b> Low Medium High	Change the amount of background colour that is removed.	
+ See Software and Network User's Guide.					
The default settings are shown in Bold with an asterisk.					

Level1	Level2	Level3	Options	Descriptions	Page	
<b>Scan to OCR</b> (Available after Presto! PageManager is downloaded for Macintosh users. See <i>Accessing Brother Support (Macintosh)</i> on page 5.)	<b>Set Options</b>	—	<b>Off*</b> On	If you want to use the control panel to change the machine's settings, choose On.	See +.	
	The settings below will appear when On is selected in Set Options.					
	<b>Scan Type</b>	—	Colour <b>Black and White*</b>	You can choose the scan type for your document.		
	<b>Resolution</b>	—	100dpi <b>200dpi*</b> 300dpi 600dpi	You can choose the scan resolution for your document.		
	<b>File Type</b>	—	<b>Text*</b> HTML RTF	You can choose the file format for your document.		
<b>Scan Size</b>	—	<b>A4*</b> A5 10x15cm Business Card Letter	You can choose the scan size for your document.			
+ See Software and Network User's Guide.						
The default settings are shown in Bold with an asterisk.						

Level1	Level2	Level3	Options	Descriptions	Page
Scan to File	Set Options	—	<b>Off*</b> On	If you want to use the control panel to change the machine's settings, choose On.	See +.
	The settings below will appear when On is selected in Set Options.				
	Scan Type	—	<b>Colour*</b> Black and White	You can choose the scan type for your document.	
	Resolution	—	100dpi <b>200dpi*</b> 300dpi 600dpi	You can choose the scan resolution for your document.	
	File Type	—	(If you choose the Colour option in the Scan Type setting) <b>PDF*</b> JPEG (If you choose the Mono option in the Scan Type setting) <b>PDF*</b> TIFF	You can choose the file format for your document.	
	Scan Size	—	<b>A4*</b> A5 10x15cm Business Card Letter	You can choose the scan size for your document.	
	Remove Bkg.Clr	—	<b>Off*</b> Low Medium High	Change the amount of background colour that is removed.	
+ See Software and Network User's Guide.					
The default settings are shown in Bold with an asterisk.					

 **(Address Book)**

Level1	Level2	Level3	Options	Descriptions	Page
<b>Search</b>	—	—	—	You can set up dial by pressing only a few keys.	37
<b>Set Speed Dial</b>	—	—	—	Stores Speed Dial numbers, so you can dial by pressing only a few keys (and <b>Start</b> ).	38
<b>Setup Groups</b>	—	—	—	Sets up Group numbers for broadcasting.	See  .
◆ See Advanced User's Guide.					
The default settings are shown in Bold with an asterisk.					

## Entering Text

When you are setting certain menu selections, such as the Station ID, you may need to enter text into the machine. Most dial pad keys have three or four letters printed on keys. The keys for **0**, **#** and **\*** are used for special characters.

Press the appropriate dial pad key the number of times shown in this reference table to access the character you want.

Press Key	one time	two times	three times	four times	five times
<b>2</b>	A	B	C	2	A
<b>3</b>	D	E	F	3	D
<b>4</b>	G	H	I	4	G
<b>5</b>	J	K	L	5	J
<b>6</b>	M	N	O	6	M
<b>7</b>	P	Q	R	S	7
<b>8</b>	T	U	V	8	T
<b>9</b>	W	X	Y	Z	9

## Inserting spaces

To enter a space in a fax number, press ► once between numbers. To enter a space in a name, press ► twice between characters.

### NOTE

The characters that are available may differ depending on your country.

## Making corrections

If you entered an incorrect character and want to change it, press ◀ to move the cursor under the incorrect character, and then press **Clear**. Enter the correct character. You can also use the cursor to go back and insert letters.

Press **Clear** for each character you want to erase.

## Repeating letters

If you need to enter a letter that is on the same key as the letter before, press ► to move the cursor to the right before you press the key again.

## Special characters and symbols

---

Press \*, # or 0 repeatedly until you see the special character or symbol you want.

Press \* for (space) ! " # \$ % & ' ( ) \* + , - . / €

Press # for : ; < = > ? @ [ ] ^ \_

Press 0 for Ä Ë Ö Ü À Ç È É 0



## General

### NOTE

This chapter provides a summary of the machine's specifications. For additional specifications visit <http://www.brother.com/>.

<b>Printer Type</b>	Inkjet	
<b>Print Head</b>	Mono:	Piezo with 210 nozzles × 1
	Colour:	Piezo with 70 nozzles × 3
<b>Memory Capacity</b>	64 MB	
<b>LCD (Liquid Crystal Display)</b>	16 characters × 1 line	
<b>Power Source</b>	AC 220 to 240V 50/60Hz	
<b>Power Consumption</b> <sup>1</sup>	Copying Mode:	Approx. 16 W <sup>2</sup>
	Ready Mode:	Approx. 3 W <sup>3</sup>
	Sleep Mode:	Approx. 1.1 W <sup>3</sup>
	Off:	Approx. 0.2 W <sup>3 4</sup>



<sup>1</sup> Measured when the machine is connected to the USB interface. Power consumption varies slightly depending on the usage environment or part wear.

<sup>2</sup> When using ADF, resolution: standard / document: ISO/IEC 24712 printed pattern.

<sup>3</sup> Measured according to IEC 62301 Edition 2.0.

<sup>4</sup> Even when the machine is turned off, it will automatically turn itself on periodically for print head maintenance, and then turn itself off.

## Dimension



### Weight

8.1 kg

### Noise Level

#### Sound Pressure

Operating:  $L_{pAm} = 50 \text{ dB(A)}$  (Maximum) <sup>1</sup>

#### Sound Power <sup>2 3</sup>

Copying <sup>4</sup>:  $L_{WAd} = 5.98 \text{ B(A)}$  (Mono)

$L_{WAd} = 5.77 \text{ B(A)}$  (Colour)

Ready:  $L_{WAd} = 2.97 \text{ B(A)}$  (Mono/Colour)

### Temperature

Operating: 10 to 35 °C

Best Print Quality: 20 to 33 °C

### Humidity

Operating: 20 to 80% (without condensation)

Best Print Quality: 20 to 80% (without condensation)

### ADF (automatic document feeder)

Up to 20 pages

Paper: 80 g/m<sup>2</sup> A4 or Letter size

### Document Size

ADF Width: 148 mm to 215.9 mm

ADF Length: 148 mm to 355.6 mm

Scanner Glass Width: Max. 215.9 mm

Scanner Glass Length: Max. 297 mm

<sup>1</sup> Noise depends on printing conditions.

<sup>2</sup> In accordance with ISO9296

<sup>3</sup> Office equipment with  $L_{WAd} > 6.30 \text{ B(A)}$  is not suitable for use in room where people require high levels of concentration. Such equipment should be placed in separate rooms because of the noise emission.

<sup>4</sup> Copy speed: 6 cpm (Mono)/3 cpm (Colour)  
These copy speeds were measured in the manner of 3.5.1 of RAL-UZ171.

# Print media

## Paper Input

## Paper Tray

- Paper type:

Plain Paper, Inkjet Paper (coated paper),  
Glossy Paper<sup>1</sup> and Transparency<sup>1 2</sup>

- Paper size<sup>3</sup>:

A4, Executive, Letter, A5, A6, Envelopes (Com-10, DL, C5, Monarch),  
Photo (10 × 15 cm), Photo 2L (13 × 18 cm) and Index Card  
(127 × 203 mm)

Width: 98 mm - 215.9 mm

Length: 148 mm - 297 mm

For more details, see *Paper weight, thickness and capacity*  
on page 18.

- Maximum paper tray capacity:

Approx. 100 sheets of 80 g/m<sup>2</sup> plain paper

## Paper Output

Up to 50 sheets of 80 g/m<sup>2</sup> plain paper (face up print delivery to the output  
paper tray)<sup>1</sup>

<sup>1</sup> For glossy paper or transparencies, remove printed pages from the output paper tray immediately after they exit the machine to avoid smudging.

<sup>2</sup> Use only transparency paper recommended for inkjet printing.

<sup>3</sup> See *Paper type and size for each operation* on page 18.

# Fax

<b>Compatibility</b>	ITU-T Group 3
<b>Modem Speed</b>	Automatic Fallback 14,400 bps
<b>Scanning Width</b>	ADF: 208 mm (A4) Scanner Glass: 204 mm (A4)
<b>Printing Width</b>	204 mm (A4)
<b>Greyscale</b>	Monochrome: 8 bit (256 levels) Colour: 24 bit (8 bit per colour/ 256 levels)
<b>Resolution</b>	Standard 203 × 98 dpi (Mono) 203 × 196 dpi (Colour) Fine 203 × 196 dpi (Mono/Colour) Superfine 203 × 392 dpi (Mono) Photo 203 × 196 dpi (Mono)
<b>Speed Dial</b>	40 stations
<b>Groups</b>	Up to 6
<b>Broadcasting</b>	90 (40 Speed Dial/50 Manual Dial)
<b>Automatic Redial</b>	3 times at 5 minute intervals
<b>Memory Transmission</b>	Up to 170 <sup>1</sup> pages
<b>Out of Paper Reception</b>	Up to 170 <sup>1</sup> pages

<sup>1</sup> "Pages" refers to the "ITU-T Test Chart #1" (a typical business letter, Standard resolution, MMR code). Specifications and printed materials are subject to change without prior notice.

# Copy

<b>Colour/Monochrome</b>	Yes/Yes
<b>Copy Width</b>	204 mm <sup>1</sup>
<b>Multiple Copies</b>	Stacks/Sorts up to 99 pages
<b>Enlarge/Reduce</b>	25% to 400% (in increments of 1%)
<b>Resolution</b>	Prints up to 1200 × 2400 dpi

<sup>1</sup> When copying on A4 size paper.

# Scanner

<b>Colour/Monochrome</b>	Yes/Yes
<b>TWAIN Compliant</b>	Yes (Windows® XP <sup>1</sup> /Windows Vista®/Windows® 7/Windows® 8) (Mac OS X v10.6.8, 10.7.x, 10.8.x)
<b>WIA Compliant</b>	Yes (Windows® XP <sup>1</sup> /Windows Vista®/Windows® 7/Windows® 8)
<b>ICA Compliant</b>	Yes (Mac OS X v10.6.8, 10.7.x, 10.8.x)
<b>Colour Depth</b>	30 bit colour Processing (Input) 24 bit colour Processing (Output) / 256 levels per colour
<b>Greyscale</b>	10 bit colour Processing (Input) 8 bit colour Processing (Output) / 256 levels per colour
<b>Resolution</b>	Up to 19200 × 19200 dpi (interpolated) <sup>2</sup> Up to 1200 × 2400 dpi (optical) (Scanner Glass) Up to 1200 × 600 dpi (optical) (ADF)
<b>Scanning Width and Length</b>	(Scanner Glass) Width: Up to 213.9 mm Length: Up to 295 mm (ADF) Width: Up to 213.9 mm Length: Up to 353.6 mm

<sup>1</sup> Windows® XP in this User's Guide includes Windows® XP Home Edition, Windows® XP Professional, and Windows® XP Professional x64 Edition.

<sup>2</sup> Maximum 1200 × 1200 dpi scanning when using the WIA Driver for Windows® XP, Windows Vista®, Windows® 7 and Windows® 8 (resolution up to 19200 × 19200 dpi can be selected by using the Brother scanner utility).

# Printer

<b>Resolution</b>	Up to 1200 × 6000 dpi
<b>Printing Width</b> <sup>3</sup>	204 mm [210 mm (borderless) <sup>1</sup> ]
<b>Borderless</b> <sup>2</sup>	A4, Letter, A6, Photo (10 × 15 cm), Index Card (127 × 203 mm), Photo 2L (13 × 18 cm)
<b>Print Speed</b> <sup>4</sup>	

<sup>1</sup> When the Borderless feature is set to On.

<sup>2</sup> See *Paper type and size for each operation* on page 18.

<sup>3</sup> When printing on A4 size paper.

<sup>4</sup> For detailed specifications visit <http://www.brother.com/>.

# Interfaces

## USB <sup>1 2</sup>

A USB 2.0 interface cable that is no longer than 2 m.

- <sup>1</sup> Your machine has a Hi-Speed USB 2.0 interface. The machine can also be connected to a computer that has a USB 1.1 interface.
- <sup>2</sup> Third party USB ports are not supported.



# Computer requirements

SUPPORTED OPERATING SYSTEMS AND SOFTWARE FUNCTIONS					
Computer Platform & Operating System Version		PC Interface	Processor	Hard Disk Space to install	
		USB <sup>2</sup>		For Drivers	For Applications (including Drivers)
Windows® Operating System	Windows® XP Home <sup>1 4</sup>	Printing PC Fax <sup>3</sup> Scanning	32bit (x86) or 64bit (x64) processor	150 MB	1 GB
	Windows® XP Professional <sup>1 4</sup>				
	Windows Vista® <sup>1 4</sup>			500 MB	1.3 GB
	Windows® 7 <sup>1 4</sup> Windows® 8 <sup>1 4</sup>			650 MB	
Macintosh Operating System	Mac OS X v10.6.8 OS X v10.7.x OS X v10.8.x	Printing PC Fax (Send) <sup>3</sup> Scanning	Intel® Processor	80 MB	550 MB
<p>Conditions:</p> <p><sup>1</sup> For WIA, 1200 × 1200 resolution. Brother Scanner Utility enables to enhance up to 19200 × 19200 dpi.</p> <p><sup>2</sup> Third party USB ports are not supported.</p> <p><sup>3</sup> PC Fax supports black and white only.</p> <p><sup>4</sup> PaperPort™ 12SE supports Windows® XP Home (SP3 or greater), XP Professional (SP3 or greater), XP Professional x64 Edition (SP2 or greater), Windows Vista® (SP2 or greater), Windows® 7 and Windows® 8.</p>					
			<p>For the latest driver updates, visit us at <a href="http://solutions.brother.com/">http://solutions.brother.com/</a>.</p> <p>All trademarks, brand and product names are the property of their respective companies.</p>		

## Consumable items

**Ink** The machine uses individual Black, Yellow, Cyan and Magenta ink cartridges that are separate from the print head assembly.

**Service Life of Ink Cartridge** The first time you install a set of ink cartridges the machine will use an amount of ink to fill the ink delivery tubes for high quality printouts. This process will only happen once. After this process is complete the cartridges provided with your machine will have a lower yield than standard cartridges (80%). With all following ink cartridges you can print the specified number of pages.

**Replacement Consumables**

- <Standard Yield Black> LC121BK
- <Standard Yield Yellow> LC121Y
- <Standard Yield Cyan> LC121C
- <Standard Yield Magenta> LC121M

Black, Yellow, Cyan and Magenta - Approximately 300 pages <sup>1</sup>

- <High Yield Black> LC123BK
- <High Yield Yellow> LC123Y
- <High Yield Cyan> LC123C
- <High Yield Magenta> LC123M

Black, Yellow, Cyan and Magenta - Approximately 600 pages <sup>1</sup>

<sup>1</sup> Approx. cartridge yield is declared in accordance with ISO/IEC 24711.

For more information about the replacement consumables, visit us at <http://www.brother.com/pageyield/>.

### What is Innobella™?

Innobella™ is a range of genuine consumables offered by Brother. The name "Innobella™" derives from the words "Innovation" and "Bella" (meaning "Beautiful" in Italian) and is a representation of the "innovative" technology providing you with "beautiful" and "long lasting" print results.

When you print photo images, Brother recommends Innobella™ glossy photo paper (BP71 series) for high quality. Brilliant prints are made easier with Innobella™ Ink and paper.



## A

Address Book	
Speed Dial	
changing .....	39
deleting .....	39
setting up .....	38
using .....	37
ADF (automatic document feeder) .....	19
Answering machine (TAD) .....	32
connecting .....	32
Apple Macintosh	
See Software and Network User's Guide.	
Automatic	
fax receive .....	25
Fax Detect .....	28

## B

Brother	
CreativeCenter .....	4

## C

Caller ID .....	29
print list .....	30
view list .....	30
Cleaning	
print head .....	54
scanner .....	53
Connecting	
external TAD (answering machine) .....	32
external telephone .....	34
Consumable items .....	114
Control panel overview .....	6
ControlCenter	
See Software and Network User's Guide.	
Copy	
paper size .....	41
paper type .....	41
using scanner glass .....	20
Custom telephone features on a single line .....	84

## D

Dialling	
a pause .....	38
access codes and credit card	
numbers .....	39
Address Book .....	37
manual .....	37
Document	
loading .....	19, 20

## E

Envelopes .....	12, 13, 18
Error messages on LCD .....	59
B&W Print Only .....	59
Cannot Detect .....	60
Cannot Print .....	60
Clean Unable .....	60
Comm. Error .....	60
Cover is Open .....	60
Data Remaining .....	60
Document Jam .....	61
Init Unable .....	60
Ink Box Full .....	61
Ink Low .....	62
InkBox NearFull .....	62
No Ink Cartridge .....	62
No Paper Fed .....	63
Not Registered .....	63
Out of Memory .....	64
Paper Jam .....	64
Print Unable .....	60
Scan Unable .....	60
Wrong Paper Size .....	65
Extension telephone, using .....	35, 36
External telephone, connecting .....	34

<b>F</b>		<b>J</b>	
<hr/>		<hr/>	
Fax codes		Jams	
changing .....	36	document .....	67
Remote Activation Code .....	28, 34, 36	paper .....	68
Remote Deactivation Code .....	34, 36		
using .....	36	<b>L</b>	
Fax Detect .....	28	<hr/>	
Fax, from PC		LCD (Liquid Crystal Display) .....	6, 88
See Software and Network User's Guide.		Contrast .....	9
Fax, stand-alone		<b>M</b>	
receiving .....	25	<hr/>	
difficulties .....	81, 82	Macintosh	
F/T Ring Time, setting .....	27	See Software and Network User's Guide.	
Fax Detect .....	28	Maintenance, routine	
from extension telephone .....	34, 36	replacing ink cartridges .....	50
Ring Delay, setting .....	27	Manual	
telephone line interference / VoIP .....	86	dialling .....	37
sending .....	22	receive .....	25
change scanner glass size .....	23	Multi-line connections (PBX) .....	33
colour fax .....	23		
difficulties .....	84	<b>N</b>	
telephone line interference / VoIP .....	86	<hr/>	
Transmission Verification Report .....	24	Nuance™ PaperPort™ 12SE	
Fax/Tel mode		See Software and Network User's Guide.	
answering at extension		Also see Help in the PaperPort™ 12SE	
telephones .....	34, 36	application.	
Remote Activation Code .....	34, 36	<b>P</b>	
Remote Deactivation Code .....	34, 36	<hr/>	
Ring Delay .....	27	Paper .....	16, 107
		capacity .....	18
<b>G</b>		loading .....	10, 12
<hr/>		loading envelopes .....	12
Greyscale .....	108, 110	printable area .....	15
		size .....	16
<b>H</b>		size of document .....	19
<hr/>		type .....	16, 18
Help		Presto! PageManager	
LCD messages .....	88	See Software and Network User's Guide.	
using menu keys .....	88	Also see Help in the Presto! PageManager	
Menu Table .....	90	application.	
		Print	
<b>I</b>		difficulties .....	76
<hr/>		paper jams .....	68
Ink cartridges		printable area .....	15
ink dot counter .....	50	resolution .....	111
replacing .....	50	specifications .....	111
Innobella™ .....	114		

Printing	
See Software and Network User's Guide.	
Programming your machine	88

## R

Receive Mode	
External TAD	25
Fax Only	25
Fax/Tel	25
Manual	25
Redial/Pause	37
Remote Setup	
See Software and Network User's Guide.	
Reports	
Caller ID List	30
Resolution	
copy	109
fax	108
print	111
scan	110
Ring Delay, setting	27

## S

Scanning	
See Software and Network User's Guide.	
Serial Number	
how to find.....	See inside front cover
Sockets	
EXT	
External telephone	34
Speed Dial	
changing	39
setting up	38
Step-by-step Settings Tables	88

## T

TAD (telephone answering device),	
external	25, 32
connecting	32
Receive Mode	25
recording OGM	33
Telephone line	
connections	32
difficulties	81
interference / VoIP	86
multi-line (PBX)	33
type	30

Text, entering	103
special characters	104
Transferring your faxes or	
Fax Journal report	66
Transparencies	16, 17, 18, 107
Troubleshooting	
document jam	67
error messages on LCD	59
if you are having difficulty	
copying	85
document jam	67
incoming calls	84
paper handling	79
print quality	78
printing	76
printing received faxes	81
receiving faxes	82
scanning	85
software	85
telephone line or connections	81
maintenance messages on LCD	59
paper jam	68

## U

Unscannable area	21
------------------	----

## V

Volume, setting	
beeper	9
ring	8
speaker	9

## W

Windows®	
See Software and Network User's Guide.	

# brother®

**Visit us on the World Wide Web**  
**<http://www.brother.com/>**

This machine is approved for use in the country of purchase only. Local Brother companies or their dealers will only support machines purchased in their own countries.



[www.brotherearth.com](http://www.brotherearth.com)