

Model Name:TD-2130N, TD-2120N

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.4W	0.3W	0min	60min
USB Port1	1.2W	0.3W	0min	60min
USB Port2	1.4W	0.3W	0min	60min
Wi-Fi®	1.8W	0.3W	0min	60min
Bluetooth®	1.5W	0.3W	0min	60min
RS-232C	1.2W	0.3W	0min	60min
All network ports activated and connected	2.0W	0.3W	0min	60min

#### How to enable/disable Wireless LAN

To activate the wireless function:


- ❶ Install the PA-WI-001 unit on the printer.  
Make sure that the cable for the unit is connected to the printer.
- ❷ Flip the switch up to turn the device on.
- ❸ Make sure that the network cable is not connected to the printer, and then turn on the printer.

To deactivate the wireless function:


- ❶ Turn off the printer.
- ❷ Flip the switch down to turn the device off.
- ❸ Turn on the printer.

#### How to enable/disable Bluetooth function

To activate the Bluetooth function:

- ❶ Install the PA-BI-001 unit on the printer.  
Make sure that the cable for the unit is connected to the printer.
- ❷ Flip the switch up to turn the device on.
- ❸ Make sure that the network cable is not connected to the printer, and then turn on the printer.
- ❹ Hold down (about 5 seconds) the  (Feed) button until the STATUS indicator blinks in green.
- ❺ If the printer was automatically turned off, turn it on again.
- ❻ Check that the STATUS indicator is lights in green.

To deactivate the Bluetooth function:

- ❶ Hold down (about 5 seconds) the  (Feed) button until the STATUS indicator blinks in green.
- ❷ If the printer was automatically turned off, turn it on again.