


brother

MPRINT

User's Guide

MW-260MFi
Mobile Printer



English

- Before using this printer, be sure to read this User's Guide.
- We suggest that you keep this manual in a handy place for future reference.

Introduction

Thank you for purchasing the MPrint MW-260MFi (hereinafter referred to as "the printer").

This is a slim, lightweight thermal black-and-white mobile printer, which, by connecting to a computer or mobile device, can print via simple operations.

This document contains precautions regarding use and operation of the printer. Before using this printer, be sure to read this document to ensure correct use of the printer.

After reading this document, store it carefully in an easily accessible location for future reference.

- The contents of this document are subject to change without prior notice.
- The contents of this document may not be duplicated or reproduced, either partially or in full, without permission.
- Any discrepancies or errors should be communicated to the manufacturer. The contact information is provided at the end of this section.
- We assume no responsibility for damage arising from earthquakes, fire, other disasters, actions of third parties, the user's intentional or negligent operation, misuse, or operation under other special conditions.
- We assume no responsibility for damage (such as losses, loss of business profits, lost profits, business disruptions, or a lost means of communication) possibly resulting from the use or inability to use this printer.
- If this printer is found to be defective due to faulty manufacturing, we shall replace it during the warranty period. We assume no further responsibility.
- We assume no responsibility for damage resulting from a malfunction or other abnormal operations of this printer through the use of incompatible equipment and incompatible software.

Brother website information

The latest information is provided on our website.

You are invited to visit the Brother website to view the latest product information, and download the updated printer driver and instruction manuals.

- Mobile printer products:
www.brother.com
- Service and support:
Support website (Brother Solutions Center)
support.brother.com

You can download the software installer from the Brother website (www.brother.com/inst).

On the information page for developers, you can download SDK and development information supporting each host free of charge.

- Mobile printer information for developers:
www.brother.com/product/dev

Contents

Introduction	1
Contents	1
Composition of Instruction Manuals	2
Package Contents	2
Part Names	3
Operating Procedures	5
Removing the protective film	5
Inserting/removing the rechargeable battery	5
Charging	6
Indicator lights	9
Turning on/off the printer	12
Using IrDA (infrared)	13
Using Bluetooth	14
Preparing the paper	17
Loading the paper cassette	19
Using the printer	21
Feeding paper	22
Using the paper guide	23
Maintenance	24
Appendix	26
Troubleshooting	26
Product specifications	29
Frequently Asked Questions	30

1 Composition of Instruction Manuals

The Safety Instructions, User's Guide, and Software User's Guide are provided for this printer.

Download the Software User's Guide from Brother Solutions Center at support.brother.com.

The outline of each document is as follows:

Product Safety Guide

Describes precautions for handling the printer.

User's Guide

Describes how to set up the printer, and how to install the driver and software.

Software User's Guide


Describes how to use the software.

2 Package Contents

Printer




USB cable




Paper cassette


Thermal paper C-211
(50 sheets)




Battery charger (AC adapter)



Li-ion battery (BT-200)



User's Guide (This document)




Product Safety Guide




3 Part Names

Right side



Left side




Part Names

Back

Battery cover

Battery connector



4 Operating Procedures


Removing the protective film

When the printer is shipped from the manufacturer, a protective film is affixed to the paper check window. Before using the printer, remove the protective film.

Inserting/removing the rechargeable battery

Inserting the rechargeable battery

- 1** Slide the rechargeable battery cover (at the back of the printer) in the direction indicated by (1).
- 2** Remove the cover and battery by lifting the edge at (2) with your finger.
- 3** Align the battery with the connector (3), and then install the rechargeable Li-ion battery.
- 4** Re-attach the cover.



Removing the rechargeable battery

- 1** Slide the rechargeable battery cover (at the back of the printer) in the direction indicated by (1).
- 2** Remove the cover and battery by lifting the edge at (2) with your finger.
- 3** Remove the rechargeable battery.
- 4** Re-attach the cover.



- When handling the rechargeable battery, see the *Product Safety Guide*.


Charging

This printer is equipped with a Li-ion battery. Use the AC adapter designed specifically for the printer to charge the battery. After purchasing this printer, be sure to charge the battery fully before using it (the charging indicator light lights up in orange while charging).


1 Plug the AC adapter cord into the AC adapter connector on the printer.

2 Plug the AC adapter plug into an AC power outlet (AC 110 V-120 V).

Charging of the Li-ion battery automatically begins.



- The charging indicator light lights up in orange.
- When charging has finished, the charging indicator light goes off.
- If the charging indicator light does not light up in orange, the battery may not be correctly installed.





- It takes approximately three hours for the battery to recharge from a completely empty state to a fully charged state (with the printer turned off).
- Charge the battery at an ambient temperature of 5-40°C/41-104°F. (Otherwise, the battery cannot be charged.)
If the temperature moves out of the above range during the charging process, the charging stops and the charging indicator light goes off.
- When you use the printer with Bluetooth, we recommend turning off the power during the charging process. When the printer enters Bluetooth sleep mode, the sleep mode continues to consume battery power even after battery charging has finished and the battery is fully charged.


3 When finished, disconnect the AC adapter.



- The printer cannot be operated solely with the AC adapter. The rechargeable Li-ion battery must be installed.



- To protect the circuitry, the battery cannot be charged if the unit is in a location exposed to extremely high or extremely low temperatures.
- Do not wind the AC adapter cord around the adapter or bend the cord, otherwise the cord may be damaged.



Storing the rechargeable Li-ion battery when the printer is not in use




- When storing the rechargeable Li-ion battery, remove it from the printer, and then store the battery in a location where it is not exposed to high humidity or fluctuating temperatures (a temperature between 15-25°C and 59-77°F and humidity between 40% and 60% are recommended).
- * Storing the rechargeable Li-ion battery in a location exposed to high temperatures will cause it to deteriorate. Do not store the battery in a location exposed to direct sunlight or high temperatures (such as inside a vehicle, near a heater, or on a heated carpet).
- If you do not intend to use the printer for a long period of time, remove the rechargeable Li-ion battery from the printer, and then store the battery in a cool, dark place.
Avoid storing the battery when it is fully charged. We recommend using the printer until the charging indicator light flashes once, and then storing the battery.
- * Make sure the AC adapter is unplugged from the printer before storing it.
- * Do not allow metal to come in contact with the terminals. The battery may be damaged if the terminals are short-circuited.
- To prevent deterioration due to over-discharging of the battery, charge it once every six months during storage, and use it until the charging indicator light flashes once.

Indicator lights

■ Status indicator light

A blue or green status indicator light indicates the printer is operating correctly, while a red light indicates an error has occurred.

When the status indicator light is green, the USB or IrDA interface can be used. When the light is blue, the Bluetooth and USB interfaces are available for communication; however, when a connection has been established using one of the interfaces, data cannot be received using the other interface until printing has finished.



Indicator light color	Indicator light status	Printer status
Blue	Constantly lit	Waiting for incoming data (via Bluetooth or USB)
	Flashing	Communicating (receiving print data)
	Flashing in long intervals	Sleep mode (power-saving standby state, available only when receiving data with Bluetooth)
Green	Constantly lit	Waiting for incoming data (via IrDA or USB)
	Flashing	Communicating (receiving print data)
Red	Flashing	An error has occurred.
	Constantly lit	A system error has occurred.

Operating Procedures

If an error has occurred, check for the following causes:


Error description	Remedy
<p>No paper cassette has been loaded. The paper cassette has been loaded facing in the wrong direction. There is no more paper.</p>	<p>Correctly load a paper cassette containing paper (→ see page 17).</p>
<p>A paper misfeed occurred.</p>	<p>Remove the paper cassette once, or turn off and on the printer to clear the error. Remove the misfed paper (→ see page 22). If you do not remove the misfed paper after turning off and on the printer, the error persists. Clean the paper feed roller and remove paper powder (→ see page 25).</p>
<p>A transmission error occurred.</p>	<p>Check the transmission status (→ see page 14). Wait for a few seconds. If the printer has recovered from the error, resend the data to resume printing. If the printer does not recover during a Bluetooth connection, re-establish the connection.</p>
<p>An overheat error occurred.</p>	<p>The inside of the printer has started to overheat. Wait until it cools down. If an overheat error has occurred during the printing process, the paper being printed is fed and discharged.</p>

If a system error has occurred:

The printer may be damaged. Contact your Brother dealer or Brother Customer Support.

■ Charging indicator light

You can check the status of the power supply by observing the charging indicator light. The charging indicator light has two functions.



(1) Indicating the charging status
(when the AC adapter is connected)

Indicator light color	Indicator light status	Printer status
Orange	Constantly lit	Charging
	Off	Finished charging
	Flashing	Malfunctioning battery

(2) Indicating the battery level
(while running with the Li-ion battery)

Indicator light status	Battery level
Off	30% or more charged
Flashing once	Less than 30% charged
Flashing twice	Less than 20% charged
Continues to flash three times	Almost empty




- Try to discharge the battery completely before recharging it, to increase battery lifetime.
- Wait to recharge the battery until the light continues to flash three times.


Turning on/off the printer

1 Press and hold the power switch for a short while

→ until the green or blue status indicator light is lit.



→ When the printer is turned on, the status indicator light lights up in blue (when the interface switch is set to Bluetooth) or in green (when the interface switch is set to IrDA)
(→ see *Indicator lights* on page 9).



- To prevent the printer from accidentally being turned on, it does not turn on if the power switch is lightly pressed. Therefore, if the printer does not turn on, hold the power switch down for a short while.
- To conserve the power of the rechargeable Li-ion battery, the following printer functions work during operation.

When the interface switch is set to Bluetooth:

If there is no operation or data transmission for a set time period, the printer automatically enters the sleep mode (→ see page 9). The length of time until the printer automatically enters the sleep mode can be specified from Printer Properties > Device Setup > Utilities (→ see the *Software User's Guide*).

When the interface switch is set to IrDA:

If there is no operation or data transmission for a set time period, the printer automatically turns off. The length of time until the printer automatically turns off can be specified from Printer Properties > Device Setup > Utilities (→ see the *Software User's Guide*).

Using IrDA (infrared)

1 Select IrDA (infrared) using the interface switch.

→ When the power is turned on, the status indicator light lights up in green.

2 Position the printer and the mobile device so that their IrDA infrared ports are facing each other and are 20 cm/7.9" or less apart.



- When IrDA (infrared) is selected, you cannot use the Bluetooth function.

- During transmission, do not move the printer or the mobile device.
- Make sure there are no obstacles between the printer and the mobile device.
- If the printer is connected with a USB cable or if the mobile device is connected using a serial interface, the infrared transmission cannot be used.
- IrDA infrared transmission between computers is not supported.
- For more information, see the instruction manual for the mobile device.

Using Bluetooth

About Bluetooth

■ Precautions for using Bluetooth

Wireless connections are used in a wide range of fields. To prevent malfunctions, therefore, turn off Bluetooth in the following areas or locations:

- Hospitals
- Aircraft
- Locations with inflammable substances, such as gasoline or petrol stations
- During fire alarms

■ For better transmission

Bluetooth connectivity varies greatly according to the operating environment. If a good connection cannot be achieved, try connecting again. Connections are difficult to achieve in the following locations:

- Near electronic equipment
- Near broadcasting stations or wireless base stations
- Near a wireless LAN (IEEE 802.11)

■ Other features of Bluetooth technology


Equipment using Bluetooth technology may take a few seconds until the Bluetooth functionality can be used after it is turned on. The length of time differs depending on the equipment.

■ Precautions for printing data using Bluetooth


If using a computer, make sure the Bluetooth function is available for the computer or mobile device before installing the printer driver for the printer.

The following describes the basic procedure for setting up transmission between the printer and the mobile device using Bluetooth. For more information, see the instruction manual for the mobile device.

- 1** Switch the interface switch to activate Bluetooth.



→ The status indicator light lights up in blue.



- When Bluetooth is selected, you cannot use the IrDA (infrared) function.

- 2** Run the Bluetooth connection software on the computer or mobile device.
- 3** Search for Bluetooth devices using the Bluetooth connection software.
 - "MW-260MF_****" will be found, where "****" is the last four digits of the serial number (PIN).
- 4** Select this printer from the list of Bluetooth devices found, and establish the connection. When connecting the computer or mobile device to this printer for the first time, you are requested to enter the PIN (or password).

- 5** Enter the PIN (or password or passcode) (at the time of shipment from the factory, the last four digits of the printer serial number are specified as the PIN).



- The printer is registered as connected via the Bluetooth connection software.

- 6** When a computer is used, select "serial port" as the connection method to the printer in the Bluetooth connection software.
Depending on the Bluetooth device, you may also be requested to enter the PIN at the second and following connections.



- Depending on the type of computer or mobile device you use, you need the COM port number to print.
- If the printer becomes disconnected because the iPad/iPad Air/iPad mini/iPhone/iPod touch is moved away from the printer, select "Bluetooth" in the device settings, and then tap the device you want to connect to from the list of Bluetooth devices.

Preparing the paper


Use only the paper cassette designed exclusively for this printer. Use of any other paper may cause paper misfeeds or damage the printer.

Preparing the paper cassette

Prepare the paper cassette before loading it into the printer.

- Be careful not to drop any paper while the paper cassette is being prepared.

- 1** Firmly fold the lid back along the fold (1).



- 2** Insert the tab on the lid into the slit (2) at the back of the cassette.




Handling the paper cassette

- This printer determines the paper type depending on the loaded paper cassette, then automatically selects the settings appropriate for that type of paper. Do not transfer paper to a different paper cassette.
- Do not try to reuse paper that has already passed through the printer.
- The paper cassette is made of cardboard. After finishing using the paper cassette, dispose of it according to local regulations.
- Do not use a torn or deformed paper cassette, otherwise damage may result.
- Do not prepare the paper cassette in extremely humid locations, otherwise a malfunction may result.
- Do not touch paper cassettes or paper with wet hands, otherwise a malfunction may result.
- Store the paper cassette out of extremely hot, extremely humid, or extremely dusty locations, and out of direct sunlight.
- When storing the paper cassette, be sure to close its lid.
- Do not leave paper cassettes in a closed vehicle under a hot sun.
- Use the paper as quickly as possible, otherwise it may become discolored.

Loading the paper cassette


- 1** Slide the paper cassette cover (on the top of the printer) in the direction indicated by (1).

→ The paper cassette cover opens in the direction indicated by (2).



- 2** Insert the paper cassette.


The paper type indication on the paper cassette should face up. The end of the paper should point toward you.



- When loading the paper cassette, make sure it is correctly aligned and the end of the paper is not folded, otherwise a paper misfeed may result.
- When exchanging the paper cassette, disconnect the AC adapter and USB cable in advance.


Operating Procedures

- 3** Close the paper cassette cover in the direction indicated by (3).



- 4** Slide the paper cassette cover in the direction indicated by (4).


If the paper cassette is correctly loaded, the paper type indication on the cassette can be seen through the paper check window.



→ The paper cassette cover is locked.



- Do not remove the paper from the paper cassette and load it directly into the printer.
- To change the paper type, load a different paper cassette.
- While the printer is printing, do not apply pressure to the paper output slot or place anything on the printer.



If paper is not correctly fed, see page 25.

Using the printer

Before using the printer, install software, such as the printer driver and P-touch Editor label creation software.

Installable software and documents:

- **P-touch Editor**
P-touch Editor 5.1 enables you to create various labels with complex layouts using fonts, templates, and clip art.
- **P-touch Update Software**
Use this software when updating P-touch Editor.
- **Printer Setting Tool**
Use this tool to set up P-touch templates.
- **Printer driver**
Use this driver to print data from the printer.
- **Manuals**

1 You can download the software installer from the Brother website (www.brother.com/inst).

2 Double-click the downloaded ".exe" file and follow the on-screen instructions to start installation. Before installation begins, you are prompted to select software and manuals in the dialog box presenting items to be installed. Recommended software and manuals have been selected by default.


3 Follow the on-screen instructions to complete installation.

Feeding paper

If a paper misfeed occurs, remove the paper by the following procedure:

If the paper has been fed out of the paper output slot:


- 1** Pull the paper out of the paper output slot. Clean the paper feed roller and remove paper powder (→ see page 25).



- When pulling the paper out, be careful not to tear it.

If the paper has not been fed out of the paper output slot:

- 1** Open the paper cassette cover.
- 2** Remove the paper cassette.
- 3** Pull out the misfed paper. Clean the paper feed roller and remove paper powder (→ see page 25).



- When pulling the paper out, be careful not to tear it.




- Pulling the paper out does not adversely affect the printer's operation.

Using the paper guide

Installing the paper guide*

* The paper guide (PG-200) is sold separately.


- 1** Position the paper guide so that the paper check window is visible.
- 2** Align the tabs on the left and right sides with the slots, and then press down until they are locked into place.



- The paper guide is not intended to be frequently installed and removed. Frequently installing and removing the paper guide may damage the printer or cause the cover or paper guide to warp.

Removing the paper guide

- 1** Open the paper cassette cover.
- 2** One side at a time, use a standard (slotted) screwdriver to unhook the paper guide tabs near the areas indicated by (1).



Maintenance



- Turn off the printer before cleaning it.

Cleaning the printer

Clean the printer's surface.

- 1** Clean off any dust or other dirt from the printer by wiping it using a soft, dry cloth.

If the printer is extremely dirty, wipe it using a slightly damp cloth.




- Do not use benzene, paint thinners, or any other solvents, otherwise the printer may become discolored or deformed.

Cleaning the sensors

If the sensors are dirty, they cannot correctly detect the paper cassette, and a malfunction may result.

- 1** Clean the sensors using a dry cleaning tool, such as a cotton swab.




Cleaning the paper feed roller

If the paper feed roller is dirty, paper may not be fed correctly.

1 Affix a piece of Scotch tape to the paper feed roller.

2 Remove the Scotch tape from the paper feed roller.

→ Any dirt on the paper feed roller is removed with the tape.




Rotate the paper feed roller, and repeat the procedure to clean the entire surface of the roller.

5 Appendix


Troubleshooting

Symptoms and remedies

Problem	Solution
The printer cannot be turned on.	<p>Press and hold the power switch for a short while (→ see page 12).</p> <p>The rechargeable Li-ion battery needs recharging (→ see page 6).</p> <p>The rechargeable Li-ion battery is not installed. Install the rechargeable Li-ion battery.</p>
Although the print command was issued, the printer does not print.	<p>With an IrDA connection:</p> <p>Make sure there are no obstacles between the printer and the mobile device. or infrared communication port of a portable telephone, and check that they are 20 cm/7.9" or less apart (→ see page 13).</p> <p>Disconnect the USB cable if connected.</p> <p>If the AC adapter is connected, noise from the AC power outlet may be stopping the communication. Unplug the AC adapter.</p> <p>When the interface switch is set to Bluetooth, IrDA cannot be used. Set the switch to IrDA, and check that the status indicator light lights up in green.</p> <p>With a Bluetooth connection:</p> <p>Make sure a valid Bluetooth connection is available to the computer or mobile device (see the instruction manual for the computer or mobile device).</p> <p>Make sure another computer or mobile device is not transmitting data to the printer using USB or Bluetooth (→ see page 14).</p> <p>When the interface switch is set to IrDA, Bluetooth cannot be used. Set the switch to Bluetooth, and check that the status indicator light lights up in blue.</p>

Problem	Solution
Although the print command was issued, the printer does not print.	<p>With a USB connection: Check that the printer is securely connected to the computer with the USB cable. Make sure another computer or mobile device is not transmitting data to the printer using USB or Bluetooth (→ see page 14).</p>
There is a paper misfeed.	Remove the misfed paper (→ see page 22).
Even after the misfed paper was removed, the error cannot be cleared.	There may still be some torn paper in the printer. Contact your Brother dealer or Brother Customer Support.
An indicator light is lit or flashing.	See <i>Indicator lights</i> on page 9.
The paper cassette cover came off.	<p>Insert the pins into the white paper cassette cover holders (at the areas indicated by "B" below) until they are locked into place. The pins fit smoothly if the two parts are angled to form a "V".</p>
	

Appendix

Problem	Solution
The paper does not feed.	<p>Make sure the lid of the paper cassette is firmly folded along the fold (1) (→ see page 17). Make sure the paper cassette cover is securely closed (→ see page 20). The paper may be dirty. Pull out the first sheet from the back of the paper cassette, and then load the paper cassette again (→ see pages 17 and 19). Clean the paper feed roller (→ see page 25).</p> <p>Slide two movable parts from position (1) to (2) as shown below, and then close the cover. (When the cover is closed, the movable parts move back to position (1).) (This symptom may occur if you do not use the printer over a long period of time.)</p> 

Product specifications


Printer specifications

Model name		MW-260MFi
Indicators		Status indicator light (blue/green/red)
		Charging indicator light (orange)
Printing	Method	Direct thermal printing with a line thermal print head
	Resolution	300 dpi x 300 dpi
	Print speed	20 seconds/sheet approx. (standard text on thermal paper with 7% coverage at an ambient temperature of 25°C/77°F)
	Number of printable pages	Up to 50 during continuous printing with a fully charged battery. ^{*1} Using Bluetooth sleep mode affects this figure. (Based on 7% coverage at an ambient temperature of 25°C/77°F) (Standard paper manufactured by Brother: A6 thermal)
Paper supply method		Brother paper cassette, automatic paper feed mechanism
Paper		Brother A6 cut paper (105 mm x 148 mm/4.5" x 5.8")
Print area		97.5 mm x 140.6 mm/3.8" x 5.5"
Power supply		Li-ion battery (BT-200: 7.4 V), charging adapter
Interface		Complies with USB Ver. 2.0 (Full Speed), Bluetooth Ver. 2.1 + EDR class 2 SPP, iAP, and IrDA (infrared) Ver. 1.3
Dimensions		130 mm (W) x 210 mm (D) x 18.5 mm (H)/ 5.1" (W) x 8.3" (D) x 0.7" (H)
Weight		approximately 520 g/1.15 lbs (including rechargeable Li-ion battery and a paper cassette containing 50 sheets of plain thermal paper)

^{*1} Continuous printing of the Brother standard pattern (7% coverage) on A6 thermal paper C-211 with a new fully charged battery, using the USB interface at an ambient temperature of 25°C/77°F. At a lower ambient temperature, fewer pages can be printed.

6 Frequently Asked Questions

- **I often wound the cord of the charging AC adapter around the adapter or bent the cord to move the adapter. This often causes the cord to break and the adapter to stop working.**



→ When carrying the AC adapter, securely bind the cord using a tie wrap to prevent any load from being applied to the cord.

- **I often carried the printer with the USB cable connected to it. Doing so caused the USB connector to break and subsequently there is no USB connection available now.**

→ Disconnect the USB cable when carrying the printer. Even if you put the printer in a bag, if the USB cable is connected to it, a large amount of pressure will be applied to the USB connector when the cable moves inside the bag.


- **When I left the printer in my car, the printer was affected by the high interior temperature and became deformed. Consequently, a malfunction occurred. Furthermore, the thermal paper turned black.**

→ The temperature inside a car may become extremely high. Do not leave the printer inside a vehicle.

- The printer can be used in the following environment:
 - Temperature: 0-40°C/32-104°F
 - Humidity: 20% to 80%
 - (Maximum wet-bulb temperature: 27°C/80°F)

- Do not operate or store the printer in a location exposed to extremely high or extremely low temperatures, extreme humidity, clogging dust, or extreme vibrations, such as those:
 - Inside a vehicle (particularly in a closed car under a hot sun)
 - Near water, such as in a bathroom or near a water heater, or in an extremely humid location
 - In a location where it is exposed to moisture, such as rain or mist
 - In an extremely hot location, such as near naked flames, heaters, or in direct sunlight
 - In a location where condensation may form

→ An optional car adapter is provided but it is only for the purpose of charging the battery. Exposing the printer to high temperatures causes the paper to become discolored and the battery to deteriorate. Do not leave the printer inside a vehicle.




- **I often pressed the power switch using a sharp object, such as the tip of a pen, which might apply high pressure to the switch. The switch subsequently broke and did not function from that point.**
 - Press the power switch with your finger.
- **I stamped a seal on printed text. The ink did not dry completely, and printed text was erased when I rubbed it with my finger.**
 - Stamping a seal on the heat-sensitive surface is not recommended. In addition, all stamp manufacturers do not recommend stamping a seal on heat-sensitive surfaces. Make sure you check this before using stamps. As is the case with ink, pens or adhesives, such as Scotch tape may cause printed text to be erased.

Frequently Asked Questions

- **Paper cannot be fed, although there is still paper left in the cassette.**

→ Contamination of the paper feed roller may prevent some sheets of paper from being picked up.

Use Scotch tape to remove dirt on the paper feed roller.



- **To increase the life of the Li-ion battery:**

→ • We recommend discharging the Li-ion battery completely before recharging it. Avoid recharging the battery frequently before it is completely discharged.*

• Storing the rechargeable Li-ion battery in a location exposed to high temperatures will cause it to deteriorate. Do not store the rechargeable Li-ion battery in a location exposed to high temperatures (such as inside a closed car under a hot sun) or direct sunlight.


• If you do not intend to use the printer for a long period of time, remove the rechargeable Li-ion battery from the printer, and then store the battery in a cool, dark place (at a temperature of 20°C/68°F or less) to maintain performance. As the battery discharges naturally, charge it once every six months while storing it in a cool, dark place.*

* Caution: About the battery level

When the charging indicator light flashes once repeatedly, the battery level is less than 30%.

- **The AC adapter connector on the printer has broken, and the battery cannot be recharged.**

→ If you carry the printer with the AC adapter plug connected, the AC adapter connector on the printer may be damaged. To prevent this problem, remove the AC adapter plug from the connector whenever carrying the printer.



Carrying the printer with the AC adapter plug connected applies a periodic force to the plug. The force applied to the plug generates a load on the connector on the printer, and solder in the connector may fracture and result in disconnection.

As the printer is a precision device, pay careful attention when removing or inserting the AC adapter plug.

- **Using paper other than that genuine Brother paper may cause frequent paper feed errors.**

→ For Brother mobile printers, make sure you use paper supplied by Brother. If other paper has been used, paper feed failures may occur frequently, which cannot be solved by cleaning the paper feed mechanism.

For any failures caused by paper other than Brother paper, you will be liable for repair costs even if the charge-free warranty period is still in effect.

Incidentally, certain types of paper from other suppliers may not cause failures.

- **Handling the paper cassette**

→ The Brother mobile printer determines the paper type depending on the loaded paper cassette, then automatically selects the settings that are appropriate for that type of paper.

Do not transfer paper to a different paper cassette. Do not try to reuse paper that has already passed through the printer. Doing so may cause double feeding, empty feeding, or other types of paper feed errors, or cause a print head failure.

Frequently Asked Questions

- **If the printer has been moved to a cool temperature environment:**

→ The printer may not work when the ambient temperature is lower than 0 °C/32 °F. In an ultralow temperature environment (at -10 °C/14 °F or lower), the number of printable pages becomes less.

Print data from the printer in a location with an ambient temperature of 0 °C/32 °F or higher. If the printer has been moved to a cool temperature environment, gradually increase the temperature to be closer to the external temperature to prevent condensation from forming.

- **Storing thermal paper**

[Storing before printing]

→ Store thermal paper inside its packaging (protected from light and air) at an ambient temperature of 25 °C/77 °F and a humidity of 65% RH or lower. Use the paper within one year after the purchase date.

[Storing after printing]

→ Store the (filed or unfiled) thermal paper in a cool and dark location at 25 °C/77 °F or lower.

[Precautions for storage]

→ Do not allow the following items to come in contact with the heat-sensitive surface or back surface:

- 1) Back carbon and carbonless paper, and diazotype paper
 - 2) Flexible polyvinyl chloride products, rubber mats, rubber erasers, and other materials containing plasticizer
 - 3) Adhesive tapes, correction fluids, permanent markers, and felt pens
 - 4) Organic compounds containing alcohol, ketone, ester, or the ether group
 - 5) Leather products, hand creams, hair products, and cosmetics
- Do not soak the thermal paper in rain, water, sweat, or other liquids.
 - Do not touch the thermal paper with wet or sweaty hands.
 - Do not glue the heat-sensitive surface. When gluing the back surface, use starch, poval, CMC, or other waterborne adhesives.

Frequently Asked Questions

- When the heat-sensitive surface or back surface is stamped with a seal, the white heat-sensitive surface will become discolored or the printed part will fade due to a chemical reaction with the ink contents.
- Do not scratch the heat-sensitive surface or apply frictional heat to it.
- Copy your important documents and store the copies separately.

[Precautions regarding thermal paper]

1. Descriptions concerning short- and long-term storage of the thermal paper after being printed are primarily intended as general information. Brother does not guarantee the relevant numeric values, service life, or other descriptions.
2. The printing performance described herein may be affected by the paper storage environment, the presence of grease or contamination, printing environment, and other factors. Therefore, check the actual printing performance in your environment after you purchase the printer, and then use the printer under your own responsibility.
3. Brother assumes no responsibility for any damage or lost profits that result from observing the contents of this document.

brother

Printed in Japan
LBF086001

