



Model Name: PT-P950NW


Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.4W	0.3W	0min	240min
USB	1.3W	0.3W	0min	240min
Wi-Fi	1.6W	0.3W	0min	240min
Bluetooth	1.5W	0.3W	0min	240min
RS-232C	1.4W	0.3W	0min	240min
All network ports activated and connected	2.0W	0.3W	0min	240min

### How to enable/disable Wireless LAN

To activate the wireless function:







Press and hold the  (Power) button to turn the machine on, and then press and hold the  (Wi-Fi) button for one second.

To deactivate the wireless function:


Press and hold the  (Wi-Fi) button again to turn the wireless function off.

### How to enable/disable Bluetooth

To activate the Bluetooth function:

- ① Start the Printer Setting Tool with the computer.
- ② **For Windows®:**  
Set [**Bluetooth usage**] under [**Bluetooth**] tab to [**Enable**] in the Communication Settings.
- For Mac:**  
Set [**Bluetooth usage**] under [**Bluetooth Settings**] tab to [**Enable**] in the Printer Setting Tool.
- ③ Install the optional Bluetooth interface (PA-BI-002) to the machine.
- ④ Set the switch on the Bluetooth Interface to the on position.
- ⑤ While pressing and holding the  (Wi-Fi) button on the printer, press and hold the  (Power) button until the  (Power) indicator lights in green and the  (Status) indicator lights in orange.
- ⑥ Press and hold the  (Feed&Cut) button for more than 5 seconds.  
Confirm the  (Status) indicator flashes in green and the indicator on the Bluetooth Interface lights in green.

To deactivate the Bluetooth function:

- ① Press and hold the  (Feed&Cut) button for more than 5 seconds.
- ② Set the switch on the Bluetooth Interface to the off position.