

Model Name:RJ-4250WB

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	1.4W	0.3W	0min	60min
Wi-Fi®	1.5W	0.3W	0min	60min
Bluetooth®	1.5W	0.3W	0min	60min
All network ports activated and connected	1.6W	0.3W	0min	60min

How to enable/disable Wireless LAN

To activate the wireless function:

Press the Menu/ ▼ (Select) button to select the [WLAN] menu and then press the ↑ (Feed)/ OK button. Set [On/Off] to [On].

To deactivate the wireless function:

Press the Menu/ ▼ (Select) button to select the [WLAN] menu and then press the ↑ (Feed)/ OK button. Set [On/Off] to [Off].

How to enable/disable Bluetooth function

To activate the Bluetooth function:

Press the Menu/ ▼ (Select) button to select the [Bluetooth] menu, and then press the ↑ (Feed)/ OK button.

Select [On/Off] and then press the ↑ (Feed)/ OK button. Select [On].

To deactivate the Bluetooth function:

Press the Menu/ ▼ (Select) button to select the [Bluetooth] menu, and then press the ↑ (Feed)/ OK button.

Select [On/Off] and then press the ↑ (Feed)/ OK button. Select [Off].