P-touch

PT-H103W

English

applications. Select from the many frames, character sizes and

With your PT-H103W, you can create labels for multiple

styles to design beautiful custom labels. In addition, the variety of Tape Cassette available allows you to print labels with different widths and exciting colors. Read this manual carefully before you begin and keep the

manual in a handy place for future reference





Safety Precautions

AWARNING Indicates a potentially installation which, if not avoided, could result in serious injuries. Indicates a potentially hazardous

Follow these guidelines to avoid the risk of fire, burns, injury rupture, overheating, abnormal odor or smoke.

- rupture, overheating, abnormal odor or smoke.
 Do not use the P-touch labeler in places of high humidity such as bathrooms.
 Do not allow the P-touch labeler/batteries to get wet, for example, by handling them with wet hands or spilling beverages on to them.
 Since loss of eyesight may result when leaked fluid from batteries gets into your eyes, immediately rinse your eyes with a large amount of clean water, and then seek medical attention.
 Do not disassemble or modify the P-touch labeler/batteries.
 Do not allow a metal object to contact both the plus and minus ends of a battery.
 Do not use sharp objects, such as tweezers or a metallic pen, to change the batteries.
 Do not throw the batteries into fire or expose to heat.
 Remove batteries immediately and stop using the P-touch labeler if you notice abnormal odor, heat, discoloration, deformation or anything unusual while using or storing it.
- Do not use a damaged or leaking battery as the fluid may get on your hands. Do not use a deformed or leaking batterý or one whose lábel is damaged. There is a possibility of generating heat.

ACAUTION situation which, if not avoided,

may result in minor or moderate

Indicates a potentially hazardous

Follow these guidelines to avoid personal injury, liquid eakage, burns or heat.

- When the P-touch labeler is not being used, store it out of the reach of children. In addition, do not allow children to put the P-touch labeler parts or labels in their mouths. If any object has been swallowed, seek medical attention.

 Do not touch metal parts around the print head immediately after printing.

 Do not touch the cutter blade.

 If leaked fluid from batteries gets on your skin or clothes, immediately rinse them with clean water.
- If leaked fluid from batteries gets on your skin or clothes, immediately rinse them with clean water.
 Remove the batteries if you do not intend to use the P-touch labeler.
 Do not use a battery other than that specified. Do not use combinations of old and new batteries or combinations of different types, different charging levels, different manufacturers or different models. Do not insert a battery with its plus and minus ends reversed.
 Do not drop or hit the P-touch labeler.
 Do not press on the LCD display.
 Do not put your finger inside the P-touch labeler when you close the Cassette Cover.
 Before using Ni-MH rechargeable batteries, carefully read the instructions for the batteries and battery charger, and be sure to use them correctly.
 When using Ni-MH rechargeable batteries, charge the batteries with a specialized battery charger before using the batteries.

General Precautions

- Depending on the location, material, and environmental conditions, the label may unpeel or become irremovable, the color of the label may change or be transferred. unpeel or become irremovable, the color of the label may change or be transferred to other objects. Before applying the label, check the environmental conditions and the material.
- the material.

 Do not use the P-touch labeler in any way or for any purpose not described in this guide. Doing so may result in accidents or damage the P-touch labeler.

 Use only Brother TZe tapes with the P-touch labeler. Do not use tapes that do not have the Eg mark
- Only use a soft, dry cloth to clean the labeler; never use alcohol or other organic solvents.

 Use a soft wipe to clean the print head; never touch the print head.

- Do not put any foreign objects into the tape exit slot or battery compartment, etc.
 Do not place the P-touch labeler/batteries in direct smilght or rain, near heaters or other hot appliances, in any location exposed to extremely high or low temperature: **BASIC USAGE** (e.g., on the dashboard or in the back of your car) or high humidity, or in dusty
- Do not apply excessive pressure to the cutter lever.
- Do not try to print if the cassette is empty; it will damage the print head. Do not pull the tape while printing or feeding; it will damage the tape and the P-touch
- Any data stored in memory will be lost due to failure or repair of the P-touch labeler The P-touch labeler is not equipped with a charging feature for rechargeable
- The length of the printed label may differ from the displayed label length.

 A protective clear plastic sticker is placed over the display during manufacturing and shipping. This sticker should be removed prior to use.

 When power is disconnected for more than three minutes, all text, format settings and any text files stored in the memory will be cleared.

Federal Communications Commission(FCC) Compliance Notice (For USA Only)


This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.
Increase the separation between the equipment and receiver.
Connect the equipment into an outlet on a circuit different from that to which

4


Consult the dealer or an experienced radio/TV technician for help.

Power Supply and Tape Cassette



Open the Cassette Cover by pressing the above indicated area at the top end of the

- If a Tape Cassette is already installed, remove it by pulling it straight up. Also, if batteries are already installed, remove them. Make sure that the power is turned off when
- replacing batteries or Tape Cassettes



Insert six new AAA alkaline batteries (LR03) or fully charged Ni-MH batteries (HR03), making sure that their poles point in the correct directions. Users of alkaline batteries: Always replace all six batteries at the same time with brand new ones. Users of Ni-MH batteries: Always replace all six batteries at the same time with fully charged ones.

Visit us at support.brother.com for the latest information

14. Style key

16. Caps key

17. Preview key

18. Menu key

20. Print kev


21. Enter key

23. Frame key

24. Accent key

19. Clear key

15. Character key




Insert a Tape Cassette, making sure that it locks into place.

- · Make sure that the end of the tape feeds under the tape guides.
- Use only Brother TZe tapes with this machine.

Securely close the Cassette Cover, making

sure that it locks into place.



1. Size 2. Cursor Caps Underline/Frame

Width Style 7. Label Length

If a specific label length selected, 🖺 also appears Guidance (left, right) Power key

11. Cursor key: Left 12. Backspace key

NOTE

• The LCD shows one row of 12 characters; however, the text that you enter can be up to 80 characters in length.

· While selecting the settings, press the Space key to go back to the default item The print preview is a generated image of the label, and may differ from the actual label when printed.

Label length shown on LCD may slightly differ from the actual

Specifications

 $(W \times D \times H)$ Weight:

Approx. 0.9 lb. (Approx. 390 g) (without batteries and Tape Cassette) Six AAA alkaline batteries (LR03) Six AAA Ni-MH batteries (HR03)*

Tape Cassette:

Power supply:

0.13" (3.5 mm), 0.23" (6 mm), 0.35" (9 mm), 0.47" (12 mm)

Should you encounter any problems with your product, please do not return your product to the store! After referring to the User's guide, if you still need assistance, call Brother Customer Service at: Voice: 1-877-BROTHER (1-877-276-8437) Web: <u>www.brother-usa.com</u>

Fax: 1-901-379-1210 you need to locate a service center, please call -877-BROTHER or visit us at www.brother-usa.com

Approx. 4.4" × 8.2" × 2.4" (Approx. 110 (W) × 208 (D) × 59 (H) mm)

Brother TZe tape (width)

*1 Visit us at support.brother.com for the latest information

Menu → ◄ / ► [Unit] ←

Select a language ()

3 Set the unit of measurement.

The default setting is [inch].

Initial Settings

1 Start your machine.

2 Set the language.

● NOTE

 The machine automatically turns off if no keys are pressed within five minutes.

Supply power by using six AAA batteries, and then press (b)

Menu → ✓ / ► [Language] → → ✓ / ►

To cancel any operation, press (BS)

Troubleshooting

► Error me	► Error message					
Message	Cause/Remedy					
Low Battery!	The batteries are weak. If using AAA alkaline batteries: Replace them with new ones. If using Ni-MH batteries: Charge them fully.					
Battery Dead	The installed batteries are running low.					
Invalid!	An invalid number was entered as the label length.					
	You tried to print a text file when there is no data stored in the memory.					
No Text!	Print is pressed when no text is entered.					
	You tried to select Text Preview or Cable Label when no text is entered.					
	You tried to enter a 3rd line by pressing					
Line Limit!	You tried to print or preview two lines of text while 0.13" (3.5 mm) or 0.23" (6 mm) tape is installed. Install tape of a larger size.					
No Cassette!	You tried to print a label when there is no cassette installed.					
Cutter Error	The tape cutter lever was used during the printing process.					
Text Full!	The maximum number of characters (80 characters)					

have already been entered

Message	Cause/Remedy				
Text Limit!	Since the number of entered characters exceeds label length, reduce the text, or select [Auto] as the label length.				
No Frame OK?	Printing on 0.13" (3.5 mm) tape with invalid Frame setting ON. (Select to print with no Frame, to cancel.)				
OK to Feed?	Feeding tape after printing when [Chain Print] is selected. Refer to "Setting Margin".				
Wrong Tape!	Use a Tape Cassette with the TEG mark.				

A blank horizontal line

appears through the printed label.

Problem	Solution				
The display stays blank after you have turned on the machine.	Check that the batteries are correctly inserted. If the batteries are weak, replace them.				
When the label is printed out, the margin(space) is too large on both sides of the text.	See "Setting Margin" in this users guide and select [Half] or [Narrow] to have smaller margins for your label.				
The machine does not print, or the printed characters are not formed properly.	Check that the Tape Cassette has been inserted correctly. If the Tape Cassette is empty, replace it. Check the Cassette Cover is properly closed.				
The setting has cleared on its own.	The batteries may be weak. Replace them. When power is disconnected for more than three minutes, all text & formats in the display will be lost. Language and Unit settings will also be cleared.				

There maybe some dust on the print

head. Remove the Tape Cassette and use a dry cotton swab to gently wipe the

print head with an up-and-down motion.

Problem	Solution
The machine has "locked up" (i.e., nothing happens when a key is pressed, even though the machine is on.)	Refer to "Resetting the P-touch".
The power turns off when you try to print.	The batteries may be weak. Replace them. Check that the batteries are correctly inserted.
The tape does not feed properly or the tape gets stuck inside the machine.	Check that the end of the tape feeds under the tape guides. The cutter lever is used while printing. I not touch the cutter lever during printin.
All text and format settings need to be cleared to create a new label.	Press Geor and select [Text&Format]
The LCD is set to an incorrect language.	Refer to "Initial Settings".

Entering Text

► Switching Upper Case/Lower Case

Upper case (A-a ON) Lower case (A-a OFF)

► Making Two Lines of Text To make two lines of text, do one of following:

a) Enter the text for the first line and then press for the second line

b) Move the cursor to where the second line starts and press

Use either 0.35" (9 mm) or 0.47" (12 mm) wide tape for two line text. Label image LCD display ABC+DEF_ ABC DEF

NOTE

Do not press (after the second line; otherwise the "Line Limit!" error message will appear.

► To Clear

By pressing (BS), the letters will be deleted one by one.

To delete all text and settings: Clear → ◄ / ► [Text&Format] ← To delete text only Clear → ✓/ ► [Text Only] ←

Printing Labels

▶ Preview

You can preview the text before printing

Only the text can be previewed, not the size, font or any

► Feeding (Tape Feed)

Menu → ✓/▶ [Feed] ←

▶ Printing

• If you need only 1 copy of the label, press without

selecting the number of copies. · The number of copies can also be specified by pressing a


· To prevent damage to the tape, do not touch the cutter lever while the message "Printing..." or "Feeding..." is displayed. · To cut off the label, push in the tape cutter lever on the upper-

right corner of the machine. • Peel the printed label from the backing and apply the label. · You can print up to 9 copies of each label

▶ Setting Margin

Menu → ✓ / ► [Margin] ← → [Full/Half/Narrow/Chain Print] ←

[Full]/[Half]/[Narrow]



[Chain Print]

For creating a label containing text in various styles 1. Enter text. 2. Press [Print], then [Copies:] appears.

3. Press ✓ / ► or enter number with number keys to select the number of copies

4. Press . Printing will start, and then the message "OK to Feed?" appears.

5. Press (BS) to enter more text.

6. Clear the text, enter the text for the next label, and then press Print 7. When the message "OK to Feed?" appears after the last

label is printed, press **8.** After the tape is fed, press the cutter lever to cut off the

Label image

ABC

ABC

NOTE • When [Half] or [Narrow] is set, the displayed label length is the



• To print more than 1 copy of a label with minimum margin, set the margin to [Narrow].

• When [Chain Print] is set, feed the tape before using the cutter otherwise a part of the text may be cut off. Also, cut along the

*Feed the tape before using the cutter. Do not pull the tape since this may damage the Tape Cassette.

▶ Entering Accented Characters

Α	Á Å Å Ä Æ Ā Ą Å Ā Ă				áàâä	æã	ąåāă
С	ÇČĆ	D	ĎĐ	С	ÇČĆ	d	ď ð đ
Е	ÉÉÉÉÉÉÉ			е	éèêëęěėē		
G	ĢĞ	1	111111	g	ģğ	i	11111
K	Ķ	L	ŁĹĻĽ	k	ķ	1	1 [] []
Ν	ÑŇŃŅ	R	ŘŔŖ	n	ñňńņ	r	řŕŗ
0	ÓÒÔØÖÕŒŐ			0	ó ò ô ø ö õ œ ő		
S	šśşşβ	Т	ŤΤÞ	s	šśşşβ	t	ť ţ þ
U	0000000			u	0 0 0 0 0 0 0		
Υ	ÝΫ	Z	ŽŽŽ	У	ýÿ	Z	žźŻ

 The order of accented characters differs depending on the selected LCD language

• To cancel the current operation, press (BS).

► Changing Label Length

Menu → ✓/ ► [Label Length] ← →

 NOTE After the label is printed, cut along the printed dots (:) with

 ◄ / ► [Auto/1.2"-12.0" (30-300 mm)]

scissors so that the label length matches the machine setting If a specific label length has been selected, 🛕 also appears in

Saving Label Files

also edit and overwrite the stored label.

You can save up to 9 labels and recall them for printing at a later date. A maximum of 80 characters can be saved per file, a

Menu → ◀ / ▶ [File] → ◀ / ▶ [Print] →

maximum total of 720 characters for the total memory. You can

▶ Save

Menu → ✓/ ► [File] ← → ✓/ ► [Save] ←
→ 4 /▶ ii •
► Open

| Menu | → | / ▶ [File] | → | → / ▶ [Open] | → |

[Copies:] ◀ / ▶ 1 - 9 → ←

→ ✓/► 1:P-touch

Cutter Unit:


If you try to store a label when there is already a label stored to that number, a message "Overwrite?" will appear. Press 🔎 to save your new label. Press (BS) to cancel.

Accessories **Tape Cassettes** Visit support.brother.com for a list of

TC-4 (replacement)

If the cutter blade becomes dull after repetitive use and the tape cannot be cut cleanly, replace with a new cutter (stock no. TC-4). You may

obtain this item from an authorized Brother reseller. ► Replacing the Cutter Unit 1. Pull out the two sections of the cutter unit (green) in the



2. Install a new cutter unit. Push it in until it snaps into place. **A** Do not touch the cutter blade directly with your fingers.

Resetting the P-touch

You can reset the P-touch labeler when you want to initialize the settings, or in the event the P-touch labeler is not working properly.

1 Turn off the P-touch labeler, hold down Menu and R and then press to turn the P-touch back on.

Release Menu and R. The P-touch labeler turns on with the internal memory reset. ■ NOTE

All text, settings and stored files are cleared.

DON'T FORGET TO REGISTER! Registering your product will provide purchase confirmation, proof of ownership and, if you choose, allow us to notify you of product enhancements and special offers!

You can register online at: www.registermybrother.com

LIMITED WARRANTY Product warranty information can be found online at www.brother-usa.com/brother-support

Frame Key Frame

*• 🌣

A A A

ૈ\•

AA

w.E.

Q:____

=:

Frames cannot be printed on 0.13" (3.5mm) tape

settings to enter the text.

2 Press // to select the settings.

Medium

Small

Normal

Outline

Shadow

I+Bold

I+Outline

I+Shadow

× 1/2

Menu → 1

Menu → 2

Menu → 3

Menu → 4

Menu -> 5

Menu → 6

Menu → 7

Menu 🔷 🗔

Short Cut Keys

_abel Length

Bold

USEFUL FUNCTION KEYS

Text Keys Size / Sity/e / Monu + 1

1 Press Size or Sity/e or Menu + 1 to select the

Size or Sty/e or Menu + 1 → ✓/ ► Select an item ←

18

1 1

Press Frame* to select the frame design

12345

-2843

**---*

§.

NOTE

Sty/e

Frame* Select a frame

¥ _{

,⊗ø ∴≅,

OQ.

×

城

Α

Α

A

Α

Α

A

A

∢

Α

А

This function allows you to create cable labels as below with 2 lines of text wrapping around cable. We recommend using Brother Flexible

ID tape when wrapping. Refer to the insertion sheet included with Flexible ID tape about the recommended conditions for use

Cable Label




[Input text] ABC 159 Menu (Cable) (Cable)

[Print OK?] \rightarrow [Copies: 1] \triangleleft / \triangleright / $1 - 9 \rightarrow$ \bigcirc

With the Cable Label function, [Auto] is automatically selected for the label length and [Full] for the margins.

Press [symbol to select various symbols

To enter Basic symbols:



To enter Pictograph symbols

For example, a shoe 🛎 is displayed as \Xi in the screen A 😘 🗗 🚳 💯 🚳 🔞 👑 Ů 출 중 중 중 **중 중 중** | 237 | 📤 | 🤿 | 🐉 | 🗗 | 😘

∨ | 1/3 | XX |) (| To print all pictographs:

AND-MANDHRO CRORODOS ERANTRAS GIRRAFENDO (UNMERIA KRYCHRAMIN CRACOTELERIA) TORRESCORO VICES SCHORLANKO DEGORRAGO F-MANDRAFTE HEGROYDON JECANORADA (DESPIS-O PROGRESSE SARODON-HH UTURONROSA

Symbol Key Symbol

Symbol → ✓ / ► [Basic] → ✓ / ► Choose a symbol ✓

→ ✓ / ► Choose a symbol ←

Υ 정 표 형 ብ 째 Ω ™ ≠

Symbol → ✓ / ► [Print List] → ← Print OK?] → ←

NOTE

Press (BS) to return to the previous step.