

Model Name: PT-P950NW

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.4W	-	0min	-
USB	1.2W	-	0min	-
Wireless LAN	1.5W	-	0min	-
Bluetooth	1.5W	-	0min	-
RS-232C	1.4W	-	0min	-
All network ports activated and connected	1.9W	-	0min	-

Technical characteristics of the product model of the external power supply

Input : 100V-240Vac, 1.8A, 50-60Hz

Output : 24Vdc, 2.65A

How to enable/disable Wireless LAN

To activate the wireless function:

Press and hold the (Power) button to turn the printer on, and then press and hold the (Wi-Fi) button for one second.

To deactivate the wireless function:

Press and hold the (Wi-Fi) button again to turn the wireless function off.

How to enable/disable Bluetooth (Option)

To activate the Bluetooth function:

1. Start the Printer Setting Tool with the computer.
2. For Windows:
Set [Bluetooth usage] under [Bluetooth] tab to [Enable] in the Communication Settings.
For Mac:
Set [Bluetooth usage] under [Bluetooth Settings] tab to [Enable] in the Printer Setting Tool.
3. Install the optional Bluetooth interface (PA-BI-002) to the printer.
4. Set the switch on the Bluetooth Interface to the on position.
5. While pressing and holding the (Wi-Fi) button on the printer, press and hold the (Power) button until the (Power) indicator lights in green and the (Status) indicator lights in orange.
6. Press and hold the (Feed&Cut) button for more than 5 seconds.
Confirm the (Status) indicator flashes in green and the indicator on the Bluetooth Interface lights in green.

To deactivate the Bluetooth function:

1. Press and hold the (Feed&Cut) button for more than 5 seconds.
2. Set the switch on the Bluetooth Interface to the off position.