

Linking to a scale and printing weight, price & barcode scale.lbx

Media: RD 102mmx50mm



4 text objects

1 bar code object

1 image object

Of the following objects, specify the text object as uneditable, and then convert it to an image. (Select the “Text Cannot Be Edited” check box on the [Expanded] tab of the Text Properties.)

- XX Stores
- Weight
- Unit Price
- Price
- /g
- Euro symbol

Note: Since there are five objects that data is fed into, the object names must be changed so that they are in the order of the data outputted from the scale. (Change the text entered in the “Object Name” box on the [Expanded] tab of the Text Properties. For details on the object order, refer to “P-touch Template Limitations”.)

Using the Transfer Manager, specify the template as number 1, and then transfer it.

If the data outputted from the scale is “Round Beef (Japan),200,4.4,4.40,123456789123 CR LF”:

CR: Carriage return code (0Dh)


LF: Line feed (0Ah)

scaletxt

Round Beef(Japan),200,4.4,4.40,123456789123 0Dh 0Ah

Specify the following in P-touch Template settings tool.

- ① Select “P-touch Template” beside “Default Command Mode”.
- ② Specify template number 1.
- ③ Input “,” beside “Data Delimiter for P-touch Template”.
- ④ Select “Command Character” under “Trigger for P-touch Template Printing”.
- ⑤ Input “\0D\0A” to specify CR LF beside “Command Character”.



Print result

