

brother



D034FG001

TZ@HG@HS@
TAPE TAPE TAPE

P-touch

PT-E310BT/PT-E510/PT-E560BT

EN Product Safety Guide

Make sure you read this guide before using the Label Printer. Keep this guide in a safe place for future reference.

For FAQs, troubleshooting tips, and to download software and manuals, visit support.brother.com.

Safety Precautions

- For servicing, adjustments, or repairs, contact Brother customer service or your local Brother dealer.
- If the product operates abnormally or any error occurs, or if any cable is damaged, turn the product off, disconnect all cables, and contact Brother customer service or your local Brother dealer.
- We assume no responsibility for damages arising from natural or man-made disasters, such as earthquakes or fires, or actions of third parties, the user’s intentional or negligent operation, misuse, or operation under other special conditions.
- As long as permitted by applicable laws, we assume no responsibility for damage (such as loss of business profits, business disruptions or a lost means of communication) that may result from the use of, or inability to use, the product.
- We assume no responsibility for damages that may result from incorrect operation of the product by connecting incompatible equipment or using incompatible software.
- We assume no responsibility for any damage or lost profits arising from the use of labels created with this product, the disappearance or change of data due to failure, repair, or supplies, and we do not accept any claim from a third party.
- Brother reserves the right to make changes without notice to the information in this guide or other documentation for this product. Furthermore, Brother shall not be responsible for any damages (including consequential) caused by reliance on the product documentation, including, but not limited to, typographical and other errors. The latest version of your product documentation is available from the Brother support website at support.brother.com.
- For more information about software and using the product on a network, see the *User’s Guide*, which can be found on the Brother support website at support.brother.com.
- Product models, accessories, and supplies may vary depending on the country or region.
- This product is approved for use in the country or region of purchase only.

⚠ DANGER Failure to observe instructions and warnings could result in death or serious injuries.

Follow these guidelines to avoid the risk of heat generation, smoking, explosion, or fire.

- Rechargeable Li-ion Battery**
- DO NOT allow the battery to come into contact with liquids.
- DO NOT charge, use, or leave the battery in high-temperature (above 80°C) locations.
- DO NOT charge the battery using an unsupported method. For instructions on how to charge the battery, see the *User’s Guide*.
- DO NOT use the battery other than for its intended purpose.
- DO NOT expose the battery to heat and fire.
- DO NOT connect the + and - terminals with metal objects, such as wire.
- DO NOT carry or store the battery with metal objects.
- DO NOT damage the battery in any way.
- DO NOT solder any connections to the battery.
- DO NOT disassemble or modify the battery.
- DO NOT dispose of the battery with household waste.

⚠ WARNING Failure to observe instructions and warnings could result in death or serious injuries.

Follow these guidelines to avoid the risk of heat generation, smoking, explosion, fire, or injury.

- Product, Rechargeable Li-ion Battery, USB Type-C® Cable, and AC Adapter for USB Type-C® (PA-AD-004 / Optional)**
- To avoid damaging these products, DO NOT:
 - Place heavy objects on them.
 - Disassemble or modify them.
 - Drop or hit them.
 - Allow them to get wet, for example, by handling them with wet hands or spilling liquids on them.
- DO NOT operate, charge, or store these products in the following locations, otherwise a fire, electrical shock, smoke, or damage may occur:
 - In an extremely humid or cold location (see the “Specifications” section in your model’s *User’s Guide*).
 - In a location where it is exposed to condensation or moisture, such as bathrooms or water heaters.
 - In an extremely dusty location.
 - In an extremely hot location, such as near open flames, heaters, or in direct sunlight.
 - In a closed car in direct sunlight.
 - At a high altitude.
 - During a thunderstorm.
- DO NOT use the Label Printer if water or foreign objects get inside it. Disconnect the AC Adapter and remove the battery (if installed), and then contact your local Brother dealer for repairs.
- If foreign objects are inserted into the Label Printer or its slots, connectors, ports, or Battery Compartment, stop using the Label Printer, turn off the power, and then disconnect each cable or remove the battery (if installed).
- Stop using the Label Printer if you notice an unusual smell, noise, increased heat, discolouration, or if the printer’s case looks damaged.
- DO NOT use a damaged AC Adapter.
- DO NOT allow babies or children to play with the plastic bag that contained the Label Printer. Dispose of the bag or keep it away from babies and children. There is a risk of suffocation.
- DO NOT use the Label Printer in special environments, such as near medical equipment. Electromagnetic waves may cause medical equipment to malfunction.
- Users with pacemakers must move away from the Label Printer if they sense any abnormalities. Then, immediately seek the advice of a medical professional.
- DO NOT forcibly bend or pull the AC Adapter or USB cable.
- DO NOT touch the AC Adapter or power plug with wet hands, otherwise an electrical shock may occur.
- Brother strongly recommends that you use the specified AC Adapter (available as an optional purchase).
- Use only the USB cable included with your Label Printer. Failure to do so may result in an injury to yourself or others, or damage to the Label Printer, or other property. Brother does not assume any responsibility for any accident or damage resulting from not using the specified USB cable.
- DO NOT connect the included USB cable to other products.
- Connect the AC Adapter to a standard electrical socket (AC 100-240 V 50/60 Hz).
- Insert the plug firmly into the electrical socket.
- DO NOT use the battery if it is damaged or leaking.
- Keep the battery away from babies and children. If it is ingested, seek medical attention immediately.
- DO NOT use sharp objects, such as tweezers or pens, to remove or replace the battery.
- If liquid from the battery gets into your eyes, wash them immediately with clean water. Seek medical attention immediately.
- Keep your hands and hair away from the Cutter Unit.
- DO NOT touch the Cutter Unit’s blade or insert your fingers inside the Tape Exit Slot.
- DO NOT touch the Print Head or any metal parts near the Print Head as they become very hot during, and immediately after use.

(This illustration shows the PT-E560BT model. The actual product image may differ depending on your model.)

- If you notice any damage or abnormalities while using the AC Adapter, do not touch it. Disconnect the power supply to the electrical socket in a safe manner, such as by turning off the breaker, and contact your Brother dealer or Brother customer service.

⚠ CAUTION

Failure to observe instructions and warnings could result in minor or moderate injuries.

- Rechargeable Li-ion Battery**
- If liquid from the battery gets onto skin or clothes, immediately rinse them with water.

- Product, Rechargeable Li-ion Battery, USB Type-C® Cable, and AC Adapter for USB Type-C® (PA-AD-004 / Optional)**
- Use only the battery included with this product.
- DO NOT drop the Label Printer when removing it from the box or relocating it, otherwise you may get injured.
- Be careful when closing the rear cover. There is a risk of injury if your fingers get caught between the upper and lower parts of the cover.
- When you are not using the Label Printer, store it out of the reach of children. In addition, do not allow children to pull the Label Printer parts or labels in their mouths. If any object has been swallowed, seek medical attention immediately.
- DO NOT leave the Label Printer or any tape within the reach of young children.
- Store the Label Printer on a flat and stable surface.
- Remove the battery and disconnect the AC Adapter if you do not intend to use the Label Printer for an extended period of time.
- DO NOT apply excessive pressure to the LCD.
- When disconnecting the AC Adapter from the electrical socket, always hold the AC Adapter.
- DO NOT overload an electrical circuit with the AC Adapter.
- (PT-E310BT) DO NOT open the rear cover when operating the Cutter Unit.
- (PT-E310BT) DO NOT apply excessive pressure to the Cutter Unit.

Regulation

| |
|--|
| CAUTION |
| RISK OF EXPLOSION IF BATTERY IS REPLACED WITH AN INCORRECT TYPE. DISPOSE OF USED BATTERIES ACCORDING TO LOCAL REGULATIONS. |

Compliance Statement of Wireless equipment (Thailand only)

This telecommunication equipment conforms to the standard or technical requirements of NBTC.

เครื่องวิทยุคมนาคมที่มีระดับการแผ่คลื่นแม่เหล็กไฟฟ้าสอดคล้องตามมาตราฐานความปลอดภัยต่อสุขภาพของมนุษย์จากการใช้เครื่องวิทยุคมนาคมที่คณะกรรมการกิจการโทรคมนาคมแห่งชาติประกาศกำหนด

Contact Information

Visit global.brother/en/gateway for contact information on your local Brother office.

© 2023 Brother Industries, Ltd. All rights reserved.

AR دليل سلامة المنتج

تأكد من قراءة هذا الدليل بعناية قبل استخدام طابعة المُلصقات. احتفظ بهذا الدليل في مكان يسهل الوصول إليه للرجوع إليه مستقبلاً.

لمطالعة الأسئلة الشائعة واستشفاف الاطلال واصلاحها وتنزيل البرامج والاطلة، تفضل زيارة support.brother.com

احتياطات الأمان

- ولصيانة المنتج، أو تعديله، أو إصلاحه، اتصل بخدمة عملاء Brother أو موزع Brother المحلي.
- إذا كان المنتج يعمل بشكل غير طبيعي أو عند حدوث أي خطأ، أو تلف أي كابل، فأوقف تشغيل المنتج، وافصل جميع الكابلات، واتصل بخدمة عملاء Brother أو موزع Brother المحلي.
- تخلى الشركة مسؤوليتها عن أي أضرار ناجمة عن الكوارث الطبيعية أو الحوادث، مثل الزلازل أو الحرائق، أو تصرفات لأطراف ثالثة، أو حالات ناتجة عن إهمال مقصود أو غير مقصود من المستخدم أو سوء استخدام الجهاز أو تشغيله في ظروف خاصة أخرى.
- إلى الحد الذي تسمح به القوانين المطبقة، تخلى الشركة مسؤوليتها عن الأضرار (مثل الخسائر، أو خسارة الربح التجاري أو خسارة الأرباح، أو تعطيل العمل أو فقد وسائل الاتصال) التي قد تنتج عن استخدام المنتج أو عن عدم القدرة على استخدامه.
- تخلى الشركة مسؤوليتها عن أي أضرار قد تنتج عن عملية تشغيل المنتج بشكل غير صحيح نتيجة توصيله بأجهزة غير متوافقة أو استخدام برامج غير مناسبة.
- تخلى الشركة مسؤوليتها عن أي ضرر أو خسارة أو نتيجة عن الربح ناتجة عن استخدام المُلصقات التي تم إنشاؤها مع هذا المنتج، أو اختفاء البيانات أو تغييرها بسبب العطل، أو الإصلاح، أو العناصر المستهلكة، ونحن لا نقبل أي دعوى من طرف ثالث.
- تحتفظ Brother بالحق في إجراء تغييرات بدون إشعار مسبق على المعلومات الواردة في هذا الدليل أو الوثائق الأخرى لهذا المنتج. كما تخلى شركة Brother مسؤوليتها عن أي أضرار (بما في ذلك الأضرار الطبيعية) ناتجة عن الأضرار على استخدام على وثائق المنتج، بما في ذلك، على سبيل المثال لا الحصر، الأخطاء المطبعية وغيرها. يُتاح أحدث نسخة من وثائق المنتج من موقع الدعم [Brother support.brother.com](http://support.brother.com).
- الدعم [Brother support.brother.com](http://support.brother.com) هو الموقع المستخدم على شبكة، راجع "دليل المستخدم" المتاح على موقع الدعم.
- قد تختلف طرز المنتج، والملصقات، واللوازم المُلصقة حسب الدولة أو المنطقة.
- هذا المنتج صالح للاستخدام في الدولة أو المنطقة التي يُشترى فيها فقط.

قد يؤدي عدم اتباع التعليمات والتحذيرات إلى الوفاة أو حدوث إصابات خطيرة.

التزم بهذه الإرشادات لتجنب خطر البعث الحرارة أو الدخان، أو خطر الانفجار أو النار.

بطارية الليثيوم أيون (Li-ion) القابلة لإعادة الشحن

- لا تدع مجالاً لملامسة البطارية للسوائل.
- تجنب شحن البطارية أو استخدامها أو وضعها في أماكن عرضة لدرجات الحرارة العالية (أعلى من 80 درجة مئوية).
- تجنب شحن البطارية باستخدام طرق غير مدعومة. للإطلاع على تعليمات بخصوص كيفية شحن البطارية، راجع "دليل المستخدم".
- تجنب استخدام البطارية لغير الغرض المخصص لها.
- تجنب جعل البطارية عرضة للحرارة والنار.
- تجنب توصيل طرفي التوصيل (+) و (-) بأغراض معنوية مثل الأسلاك.
- لا تحمّل البطارية أو تخزنها مع أغراض معدنية.
- تجنب تعرض البطارية للتلف بأي شكل من الأشكال.
- تجنب لحام أي وصلات في البطارية.
- لا تقم بلك أو تعديل البطاريات.
- لا تتخلص من البطارية مع النفايات المنزلية.

⚠ تحذير قد يؤدي عدم اتباع التعليمات والتحذيرات إلى الوفاة أو حدوث إصابات خطيرة.

اتبع هذه الإرشادات لتجنب خطر البعث الحرارة أو الدخان، أو خطر الانفجار أو النار أو الإصابة.

يتضمن المنتج بطارية ليثيوم أيون قابلة لإعادة الشحن، وكابل USB Type-C، ومحول تيار متردد لـ USB Type-C

- لتجنب تلف هذه المنتجات، لا تقم بما يلي:
 - وضع أغراض ثقيلة عليهم.
 - تفكيكهم أو تعديلهم.
 - إسقاطهم أو ارتطامهم.

- تعرضهم للبلل، على سبيل المثال، الإسمك بهم بأيدي مبللة أو سكب السوائل عليهم.
- احرص على عدم تشغيل أو شحن أو تخزين هذه المنتجات في الأماكن التالية، حيث يؤدي عدم الالتزام بذلك إلى حدوث حرائق أو صدمات كهربائية أو دخان أو تلفيات:
 - في مكان رطب أو بارد للغاية (راجع قسم "المواصفات" في دليل مستخدم الطراز الخاص بك).
 - في مكان رطب أو عرضة للماء مثل الحمامات أو سخانات المياه.
 - في الأماكن المليئة بالأتربة.
- في الأماكن الحارة للغاية، مثل الأماكن القريبة من مصادر اللهب أو السخانات أو في أشعة الشمس المباشرة.
- في السيارة المغلقة تحت أشعة الشمس المباشرة.
- في الأماكن المغلقة.
- أثناء المعالجة الرديئة.

تجنب استخدام طابعة المُلصقات في حال دخول الماء أو الأجسام الغريبة بداخلها. افصل محول التيار المتردد وقم بإزالة البطارية (إذا كانت مثبتة بالفعل)، ثم توصل مع موزع Brother المحلي لإجراء الإصلاحات اللازمة.

في حالة دخول أجسام غريبة في طابعة المُلصقات أو فتحها، أو مواصلاتها، أو مناقتها، أو حجرة البطارية بها، فأوقف استخدام طابعة المُلصقات، وأوقف تشغيلها، وافصل جميع الكابلات أو ازرع البطاريات (إذا كانت مثبتة).

- تجنب استخدام طابعة المُلصقات إذا لاحظت رائحة غير معتادة، أو أوضاعاً، أو زيادة الحرارة، أو تغير اللون، أو إذا بدت على علية الطابعة علامات تلف.
- تجنب استخدام محول تيار متردد تلف.
- لا تسمح للرضع والأطفال بالعبث بالكيبس البلاستيكي الذي يغط طابعة المُلصقات. وتخلص منه أو احتفظ به بعيدًا عن متناول الأطفال والرضع. قد يؤدي عدم الالتزام بذلك إلى خطر الاختناق.
- تجنب استخدام طابعة المُلصقات في بيئات خاصة، مثل بالقرب من الأجهزة الطبية. قد تؤدي الموجات الكهرومغناطيسية إلى حدوث عطل الأجهزة الطبية.
- يجب على المستخدمين ذوي أجهزة تنظيم ضربات القلب الابتعاد عن طابعة المُلصقات في حالة احساسهم بأي شعور غير طبيعي. ثم طلب المشورة على الفور من متخصص في الرعاية الطبية.
- لا تقم بتثي أو سحب محول التيار المتردد أو كابل USB بالقوة.
- تجنب ملامسة محول التيار المتردد أو القابس بأيدي مبللة، حيث يؤدي عدم الالتزام بذلك إلى حدوث صدمة كهربائية.
- توصيك Brother بشدة باستخدام محول التيار المتردد المحدد (متوفر لدينا للشراء وحده).
- استخدم كابل USB المترققين مع طابعة المُلصقات فحسب. قد يؤدي الإخفاق في القيام بذلك إلى إصابتك أو إصابة الآخرين، أو إلحاق الضرر بطابعة المُلصقات أو الممتلكات الأخرى. لا تتحمل شركة Brother أي مسؤولية تجاه أي حدث أو تلف ينتج عن عدم استخدام كابل USB المحدد.
- تجنب توصيل محول التيار المتردد بمقبس كهربائي قديم (تيار متردد 100-240 فولت، 50/60 هرتز).
- أدخل القابس بحكام في المقبس الكهربائي.

- احرص على عدم استخدام البطارية القابلة لإعادة الشحن، إذا كانت تالفة أو بها تسريب.
- احتفظ بالبطارية بعيدًا عن الأطفال والرضع. إذا ابتلعها طفل أو رضيع، فالتمس رعاية طبية على الفور.
- تجنب استخدام الأدوات الحادة مثل الملائط أو الأقلام، لإزالة البطاريات، أو تغييرها.
- إذا تلامس سائل من البطاريات مع عينيك، فاغسلهما على الفور بماء نظيف. التمس رعاية طبية على الفور.
- حافظ على يديك وشعرك بعيدًا عن وحدة القاطعة.
- تجنب لمس شفرة وحدة القاطعة أو إدخال أصابعك بقتحة خروج الشريط.
- لا تلمس رأس الطابعة أو أي أجزاء معدنية بالقرب منها لأنها تصبح ساخنة للغاية أثناء الاستخدام ولمدة وجيزة بعده مباشرة.

(يوضح هذا الرسم التوضيحي طراز PT-E560BT. قد تختلف صورة المنتج الفعلية حسب الطراز الخاص بك.)

- رأس الطابعة
- وحدة القاطعة
- فتحة خروج الشريط

- إذا لاحظت أي تلف أو خلل أثناء استخدام محول التيار المتردد، فتجنب لمسه. افصل مصدر الطاقة عن المقبس بطريقة آمنة؛ من خلال إيقاف تشغيل وحدة القاطعة، وتواصل مع موزع Brother أو خدمة عملاء Brother.

⚠ تنبيه

قد يؤدي عدم اتباع هذه التعليمات والتحذيرات إلى إصابات خفيفة أو متوسطة.

بطارية الليثيوم أيون (Li-ion) القابلة لإعادة الشحن

- في حالة تسرب سوائل من البطارية ووصولها إلى بشرتك أو ملابسك، فاغسلهما على الفور بماء نظيف.

يتضمن المنتج بطارية ليثيوم أيون قابلة لإعادة الشحن، وكابل USB Type-C، ومحول تيار متردد لـ USB Type-C (PA-AD-004 / اختياري)

- لا تستخدم إلا البطارية المرفقة مع هذا المنتج.
- تجنب إسقاط طابعة المُلصقات عند إزالتها من الصندوق أو نلقها، حيث يؤدي عدم الالتزام بذلك إلى تعرضك للإصابة.
- كن حذرًا عند إغلاق الغطاء الخلفي. هناك خطر التعرض للإصابة إذا انشتر إصبعك بين الأجزاء العلوية والسفلية للغطاء.
- إذا كنت لا تستخدم طابعة المُلصقات، فخزنها بعيدًا عن متناول الأطفال. فضلًا عن ذلك، لا تسمح للأطفال من الأجزاء، اطلب الرعاية الطبية على الفور.
- تجنب ترك طابعة المُلصقات، أو أي شريط في متناول الأطفال الصغار.
- حُزن طابعة المُلصقات على سطح مستقر و مسنور وثابت.
- اِزرع البطاريات وافصل محول التيار المتردد إذا كنت لا تنوي استخدام طابعة المُلصقات لفترة زمنية طويلة.
- تجنب الضغط بقوة على شاشة عرض LCD.
- عند فصل محول التيار المتردد من المقبس الكهربائي، احرص على الإسمك بمحول التيار المتردد في هذه الأثناء.
- تجنب وضع حملًا زائدًا على أي دائرة كهربائية يوضع محول التيار المتردد.
- لا تفتح الغطاء الخلفي عند تشغيل وحدة القاطعة.
- تجنب الضغط بقوة على وحدة القاطعة.

اللاححة

تنبيه

خطر حدوث انفجار في حالة استبدال البطارية بنوع غير مناسب.
تخلص من البطاريات المستهلكة وفقًا للوائح المحلية.

معلومات الاتصال

تفضل زيارة global.brother/en/gateway للحصول على معلومات الاتصال الخاصة بمكتب Brother المحلي.

حقوق النشر © 2023 Brother Industries, Ltd. جميع الحقوق محفوظة.

