



AirPrint allows you to easily print from an iOS device (iPad, iPhone, or iPod touch).

You do not need to install a printer driver.


iPad, iPhone, iPod, iPod touch, Macintosh, OS X and Safari are trademarks of Apple Inc., registered in the U.S. and other countries. AirPrint and the AirPrint logo are trademarks of Apple Inc.

Operating environment:

OS X v10.8 or later / iOS 7.x or later (Refer to Brother Solutions Center (support.brother.com) for the latest information on supported OSs.)

How to print:

● **Printing from iPad, iPhone and iPod touch**

- ① Make sure your printer is turned on and connected via ad hoc, wireless direct, or Wi-Fi network connection.
- ② Open the page that you want to print.
- ③ Tap the  action icon.
- ④ Tap **Print**.
- ⑤ Select the printer.
- ⑥ Select and change any desired printer options.
- ⑦ Tap **Print**.

● **Printing using OS X v10.8 or later**

NOTE: You must add the printer to your Mac's printer list before you can print.

1. Select **System Preferences** from the Apple Menu.
2. Click **Print & Scan** or **Printers & Scanners**.
3. Click the + icon below the Printers pane on the left.
4. Click **Add Printer or Scanner**. The **Add** screen appears.
5. Select your printer, and then select **AirPrint** from the **Use** pop-up menu.
6. Click **Add**.

- ① Make sure your printer is turned on and connected via ad hoc, wireless direct, Wi-Fi network, or USB connection.
- ② Open the page you want to print.
- ③ Click the **File** menu, and then select **Print**.
- ④ Make sure your printer is selected.
- ⑤ Select any available options, such as the number of pages to print. (Options vary depending on the printer.)
- ⑥ Click **Print**.

Product support:

support.brother.com