Start Here

MFC-9120CN

Before you can use the machine, please read this Quick Setup Guide for the correct setup and installation.
To view the Quick Setup Guide in other languages, please visit http://solutions.brother.com/.

❗ IMPORTANT

DO NOT connect the interface cable yet.

1 Unpack the machine and check the components

	User's Guide	**Telephone Line Cord**
Quick Setup Guide	**CD-ROM** (Windows®) (Macintosh)	**Telephone Line Cord Adapter** (Australia only)
Waste Toner Box (pre-installed)	**Belt Unit** (pre-installed)	**Drum Unit and Stater Toner Cartridge Assemblies** (Black, Cyan, Magenta and Yellow)

Australia and New Zealand	**Hong Kong, Malaysia and Singapore**	**India**	**Philippines and Thailand**	**AC Power Cord**
The mains plug supplied with this machine is a grounded three pin plug.			The mains plug supplied with this machine is a side grounded two pin plug.	

The mains plug supplied with this machine is a grounded three pin plug. | The mains plug supplied with this machine is a side grounded two pin plug. | **AC Power Cord**

Make sure that the AC socket will accept the supplied grounded pin plug. This machine must be grounded, If in doubt, call a qualified electrician.

ARL/ASA/NZ Version 0

⚠ WARNING

- **Plastic bags are used in the packaging of your machine. To avoid danger of suffocation, please keep these bags away from babies and children.**

- **This machine is heavy and weighs approximately 22.9 kg. (50.5 lb). To prevent injuries use at least two people to lift the machine. Be careful not to pinch your fingers when you put the machine back down.**

📝 Note

Keep a minimum gap around the machine as shown in the illustration.

📝 Note

- *The components included in the box may differ depending on your country.*

- *Save all packing materials and the box in case for any reason you must ship your machine.*

- *The interface cable is not a standard accessory. Buy the appropriate interface cable for the interface you want to use (USB or Network).*

- *To ensure safe operation the supplied plug must be inserted only into a standard power outlet that is properly grounded through the standard electrical wiring. Non grounded equipment may cause an electrical shock hazard, and may cause excessive electrical noise radiation.*

USB cable

- *Please make sure you use a USB 2.0 cable (Type A/B) that is no longer than 2 metres.*

- *DO NOT connect the interface cable at this time. Connecting the interface cable is done during MFL-Pro installation process.*

- *When you use a USB cable, make sure you connect it to the USB port of your computer and not to a USB port on a keyboard or non-powered USB hub.*

Network cable

Use a straight-through Category 5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.

Symbols used in this guide

⚠ WARNING	WARNINGs tell you what to do to prevent possible personal injury.
⚠ CAUTION	CAUTIONs specify procedures you must follow or avoid to prevent possible minor injuries.
❗ IMPORTANT	IMPORTANT specifies procedures you must follow or avoid to prevent possible damage to the machine or other objects.
📝 Note	Notes tell you how you should respond to a situation that may arise or give tips about how the current operation works with other features.
🔍 User's Guide Network User's Guide	Indicates reference to the User's Guide or Network User's Guide which is on the CD-ROM we have supplied.

2 Remove the packing material from the machine

a Remove the packing tape from the outside of the machine.

**b** Open the top cover by lifting up on the handle ①.

**c** Remove the packing material from the inside of the machine.

3 Install the drum unit and toner cartridge assemblies

a Unpack the four drum unit and toner cartridge assemblies and gently shake each of them from side to side several times to distribute the toner evenly inside the assembly.


**b** Remove the protective cover by pulling on the tab as shown in the illustration.

Note

Do not touch the surface of the packing film. It may contain toner powder which can stain your skin and clothing.


IMPORTANT

To avoid print quality problems, DO NOT touch the surface of the drum unit.

c Slide all four of the drum unit and toner cartridge assemblies into the machine as shown in the illustration. Make sure that you match the toner cartridge colour to the same colour label on the machine.

C - Cyan   Y - Yellow

M - Magenta   K - Black

d Close the top cover of the machine.

4 Load paper in the paper tray

a Pull the paper tray completely out of the machine.

b While pressing the green paper-guide release lever ❶, slide the paper guides to fit the paper size you are loading in the tray. Make sure that the guides are firmly in the slots.

c Fan the stack of paper well to avoid paper jams and misfeeds.

d Put paper in the tray, and make sure that the paper is below the maximum paper mark ①. The side to be printed on must be face down.

e Put the paper tray firmly back in the machine. Make sure that it is completely inserted into the machine.

f Unfold the support flap ① to prevent paper from sliding off the face-down output tray.

5 Connect the power cord and telephone line

a Make sure that the machine's power switch is off. Connect the AC power cord to the machine.

b Plug the AC power cord into an AC outlet. Turn the power switch on.

6

**c** Connect the telephone line cord. Connect one end of the telephone line cord to the socket on the machine marked **LINE** and the other end to a telephone wall socket.

> ⚠️ **IMPORTANT**
>
> **The telephone line cord MUST be connected to the socket on the machine marked LINE.**

⚠️ WARNING

The machine must be grounded using an earthed plug.

Since the machine is grounded through the power outlet, you can protect yourself from potentially hazardous electrical conditions on the telephone network by keeping the power cord connected to your machine when you connect it to a telephone line. Similarly, you can protect yourself when you want to move your machine by disconnecting the telephone line first and then the power cord.

📝 Note

If you are sharing one telephone line with an external telephone, connect it as shown below.

Before you connect the external telephone, remove the protective cap ❶ from the EXT. jack on the machine.

(Example for Australia)

1 Extension telephone
2 External telephone

📝 Note

If you are sharing one telephone line with an external telephone answering machine, connect it as shown below.

Before you connect the external telephone answering machine, remove the protective cap ❶ from the EXT. jack on the machine.


(Example for Australia)

🔍 *Set the receive mode to* `External TAD` *if you have an external answering machine. See Choose a Receive Mode on page 8. For additional details, see* Connecting an external TAD *in* Chapter 7 *of the* User's Guide.

6 Set your country (for Australia/New Zealand customer only)

You must set your country so that the machine works correctly on local telecommunication lines in each country.

a Check that the power is turned on by plugging in the power cord and turn the power switch on.

Press **OK**.

```
Set country
Press OK key
```

b Press ▲ or ▼ to select your country (`Australia` or `New Zealand`).

```
Australia
Select ▲▼ or OK
```

c Press **OK** when the LCD shows your country.

d The LCD prompts you to make sure of the country again.

```
Australia?
1.Yes 2.No
```

e Do one of the following:
- If the LCD shows the correct country, press **1** to go to step **f**.
- Press **2** to go back to step **b** to select the country again.

f After the LCD shows `Accepted`, the machine will restart automatically. After the restart, the LCD shows `Please Wait`.

7 Choose a Receive Mode

There are four possible receive modes: `Fax Only`, `Fax/Tel`, `Manual` and `External TAD`.

Do you want to use the telephone features of your machine (if available) or an external telephone or external telephone answering device connected on the same line as the machine?

Yes → Are you using the voice message function of an external telephone answering device?

No → `Fax Only`
Your machine automatically answers every call as a fax.

No → Do you want the machine to answer fax and telephone calls automatically?

Yes → `Fax/Tel`
Your machine controls the line and automatically answers every call. If the call is not a fax, the phone will ring for you to pick up the call.

No → `Manual`
You control the phone line and must answer every call yourself.

Yes → `External TAD`
Your external telephone answering device (TAD) automatically answers every call. Voice messages are stored on the external TAD. Fax messages are automatically printed.

a Press **Menu**, **0**, **1**.

```
Initial Setup
1.Receive Mode
```

b Press ▲ or ▼ to choose the receive mode. Press **OK**.

c Press **Stop/Exit**.

🔍 *For more details, see* Receiving a fax *in* Chapter 6 *of the* User's Guide*.*

8 Set the LCD contrast (if needed)

If you are having difficulty reading the LCD, try changing the contrast setting.

a Press **Menu**, **1**, **6**.

```
General Setup
6.LCD Contrast
```

b Press ▲ to increase the contrast.

—OR—

Press ▼ to decrease the contrast.

Press **OK**.

c Press **Stop/Exit**.

9 Set the date and time

The machine displays the time, and if you set up the station ID the date and time will be added to each fax you send.

a Press **Menu**, **0**, **2**.

b Enter the last two digits of the year on the dial pad, and then press **OK**.

```
Date&Time
Year:2009
```

(e.g. Enter **0**, **9** for 2009.)

c Enter the two digits for the month on the dial pad, and then press **OK**.

```
Date&Time
Month:03
```

(e.g. Enter **0**, **3** for March.)

d Enter the two digits for the day on the dial pad, and then press **OK**.

```
Date&Time
Day:25
```

(e.g. Enter **2**, **5**.)

e Enter the time in 24-hour format on the dial pad, and then press **OK**.

```
Date&Time
Time:15:25
```

(e.g. Enter **1 5**, **2 5** for 3:25 P.M.)

f Press **Stop/Exit**.

10 Enter personal information (station ID)

You should store your name and fax number to be printed on all fax pages that you send.

a Press **Menu**, **0**, **3**.

b Enter your fax number (up to 20 digits) on the dial pad, and then press **OK**.

```
Station ID
Fax:
```

c Enter your telephone number (up to 20 digits) on the dial pad, and then press **OK**. If your telephone number and fax number are the same, enter the same number again.

```
Station ID
Tel:
```

d Use the dial pad to enter your name (up to 20 characters), and then press **OK**.

```
Station ID
Name:
```

Note

- *See the following chart for entering your name.*
- *If you need to enter a character that is on the same key as the last character, press ▶ to move the cursor to the right.*
- *If you entered a letter incorrectly and want to change it, press ◀ or ▶ to move the cursor to the incorrect character, press Clear/Back.*

Press key	One time	Two times	Three times	Four times	Five times
2	A	B	C	2	A
3	D	E	F	3	D
4	G	H	I	4	G
5	J	K	L	5	J
6	M	N	O	6	M
7	P	Q	R	S	7
8	T	U	V	8	T
9	W	X	Y	Z	9

For more details, see Entering text *in the* User's Guide.

e Press **Stop/Exit**.

Note

If you make a mistake and want to start again, press Stop/Exit and go back to step a.

11 Fax Transmission Report

Your Brother machine is equipped with a Transmission Verification Report that can be used as confirmation that you sent a fax. This report lists the name or fax number of the receiving party, the date, time, and duration of the transmission, the number of pages transmitted, and whether or not the transmission was successful. If you want to use the Fax Transmission Report feature see *Chapter 11 Printing reports* in the *User's Guide*.

12 Set tone or pulse dialling mode (not available for New Zealand)

Your machine comes set for Tone dialling service. If you have Pulse dialling service (rotary), you need to change the dialling mode.

a Press **Menu**, **0**, **4**.

```
Initial Setup
4.Tone/Pulse
```

b Press ▲ or ▼ to choose Pulse (or Tone). Press **OK**.

c Press **Stop/Exit**.

13 Dial Prefix

The dial prefix setting will automatically dial a predefined number before every fax number you dial. For example: If your phone system requires a 9 to dial an outside number this setting will automatically dial 9 for every fax you send.

a Press **Menu**, **0**, **6** (For New Zealand, press **5**).

b Enter the prefix number (up to 5 digits) on the dial pad, and then press **OK**.

✎ Note

*You can use the number 0 to 9, #, $*$ and !. (Press **Hook** to display "!".)*

You cannot use ! with any other numbers or characters.

*If your telephone system requires a timed break recall (hookflash), press **Hook** to enter the break*

c Press **Stop/Exit**.

14 Automatic Daylight Savings Time

You can set the machine to change automatically for daylight savings time. It will reset itself forward one hour in the Spring and backward one hour in the Autumn.

a Press **Menu**, **1**, **4**.

```
General Setup
4.Daylight Save
```

b Press ▲ or ▼ to choose On (or Off).
Press **OK**.

c Press **Stop/Exit**.

15 Choose your connection type

For USB Interface Users
Windows®, go to page 14
Macintosh, go to page 18

For Wired Network
Windows®, go to page 20
Macintosh, go to page 25

Note

For Windows Server® 2003/ 2008, see the Network User's Guide *on the CD-ROM.*

Windows®

USB

Macintosh

Windows®

Wired Network

Macintosh

For USB Interface Users
(Windows® 2000 Professional/XP/XP Professional x64 Edition/ Windows Vista®)

16 Before you install

a Make sure that your computer is ON and you are logged on with Administrator rights.

> **⚠ IMPORTANT**
>
> • **DO NOT connect the USB cable yet.**
>
> • **If there are any programs running, close them.**
>
> • **The screen may differ depending on the operating system.**
>
> • **The supplied CD-ROM includes ScanSoft™ PaperPort™ 11SE. This software supports Windows® 2000 (SP4 or greater), XP (SP2 or greater), XP Professional x64 Edition and Windows Vista®. Update to the latest Windows® Service Pack before installing MFL-Pro Suite.**

b Turn off and unplug the machine from the AC outlet and disconnect it from your computer, if you already connected an interface cable.

17 Install MFL-Pro Suite

a Put the supplied CD-ROM into your CD-ROM drive. If the model name screen appears, choose your machine. If the language screen appears, choose your language.

> **📝 Note**
>
> *If the Brother screen does not appear automatically, go to My Computer (Computer), double-click the CD-ROM icon, and then double-click Start.exe.*

b The CD-ROM main menu will appear. Click **Initial Installation**.


c Click **Install MFL-Pro Suite**.

Note

- *If the installation does not continue automatically, open the main menu again by ejecting and then reinserting the CD-ROM or double-click the **Start.exe** program from the root folder, and continue from step **c** to install MFL-Pro Suite.*

- *For Windows Vista®, when the **User Account Control** screen appears, click **Allow**.*

d When the ScanSoft™ PaperPort™ 11SE **License Agreement** window appears, click **Yes** if you agree to the Software **License Agreement**.

e The installation of ScanSoft™ PaperPort™ 11SE will automatically start and is followed by the installation of MFL-Pro Suite.

f When the Brother MFL-Pro Suite Software **License Agreement** window appears, click **Yes** if you agree to the Software **License Agreement**.

g Choose **Local Connection**, and then click **Next**. The installation continues.


Note

*If you want to install the PS driver (Brother's BR-Script Driver), choose **Custom Install** and then follow the on-screen instructions. When the **Select Features** screen appears, check **PS Printer Driver**, and then continue following the on-screen instructions.*

h If you do not want to monitor the machine status and error notification from your computer, uncheck **Enable Status Monitor** and then click **Next**.


i When this screen appears, go to the next step.

15

18 Connect the USB cable

IMPORTANT

- **DO NOT connect the machine to a USB port on a keyboard or a non-powered USB hub.**
- **Connect the machine directly to your computer.**

a Remove the label covering the USB interface connector.

b Connect the USB cable to the USB connector on the machine marked with the ⟵ symbol. Then connect the cable to your computer.

19 Connect the power cord

a Plug the AC power cord into an AC outlet. Turn the power switch on.

The installation will continue automatically. The installation screens appear one after another.

IMPORTANT

DO NOT cancel any of the screens during the installation. It may take a few seconds for all screens to appear.

Note

*For Windows Vista®, when this screen appears, select the check box and click **Install** to complete the installation correctly.*

b When the **On-Line Registration** screen is displayed, make your selection and follow the on-screen instructions. Once you have completed the registration process, close your web browser to return to this window. Then click **Next**.

USB

Windows®

20 Finish and restart

**a** Click **Finish** to restart your computer. After restarting the computer, you must be logged on with Administrator rights.

📝 **Note**

*If an error message appears during the software installation, run the **Installation Diagnostics** located in **Start/All Programs/Brother/ MFC-XXXX** (where MFC-XXXX is your model name).*

b If this screen appears, choose the firmware update setting and click **OK**.

📝 **Note**

Internet access is required for the firmware upgrade.

Finish The installation is now complete.

📝 **Note**

XML Paper Specification Printer Driver
The XML Paper Specification Printer Driver is the most suitable driver when printing from the applications that use the XML Paper Specification documents. Please download the latest driver by accessing the Brother Solutions Center at http://solutions.brother.com/.

Windows®

USB

Macintosh

17

For USB Interface Users
(Mac OS X 10.3.9 or greater)

16 Before you install

a Make sure your machine is connected to the power and your Macintosh is ON. You must be logged on with Administrator rights.

❶ IMPORTANT

**For the latest drivers and information on the Mac OS X you are using, visit http://solutions.brother.com/.**

17 Connect the USB cable

❶ IMPORTANT

- **DO NOT connect the machine to a USB port on a keyboard or a non-powered USB hub.**
- **Connect the machine directly to your Macintosh.**

a Remove the label covering the USB interface connector.

b Connect the USB cable to the USB connector on the machine marked with the ⟨⟩ symbol. Then connect the cable to your computer.

18 Install MFL-Pro Suite

a Put the supplied CD-ROM into your CD-ROM drive.

b Double-click **Start Here OSX** to install.

✎ Note

Please see the Software User's Guide *on the CD-ROM if you want to install the PS driver. (Brother's BR-Script Driver)*

c Please wait, it will take a few seconds for the software to install. After the installation, click **Restart** to finish installing the software.

d The Brother software will search for the Brother device.

e Choose the machine from the list, and then click **OK**.

**f** When this screen appears, click **OK**.

OK! **The installation of MFL-Pro Suite is now complete.**
Go to step 19 on page 19.

19 Install Presto! PageManager

When Presto! PageManager is installed OCR capability is added to Brother ControlCenter2. You can easily scan, share and organize photos and documents using Presto! PageManager.

a Double-click **Presto! PageManager** and follow the on-screen instructions.

Finish **The installation is now complete.**

For Wired Network Interface Users
(Windows® 2000 Professional/XP/XP Professional x64 Edition/
Windows Vista®)

16 Before you install

**a** Make sure that your computer is ON and you are logged on with Administrator rights.

IMPORTANT

- **If there are any programs running, close them.**
- **The screens may differ depending on the operating system.**
- **The supplied CD-ROM includes ScanSoft™ PaperPort™ 11SE. This software supports Windows® 2000 (SP4 or greater), XP (SP2 or greater), XP Professional x64 Edition and Windows Vista®. Update to the latest Windows® Service Pack before installing MFL-Pro Suite.**

! IMPORTANT

Disable all personal firewall software (other than Windows® Firewall), anti-spyware or antivirus applications for the duration of the installation.

b Unplug the machine from the AC outlet.

17 Connect the network cable

a Connect the network interface cable to the LAN connector marked with a 🖧 symbol and then connect it to a free port on your hub.

18 Connect the power cord

a Plug the AC power cord into an AC outlet. Turn the power switch on.

19 Install MFL-Pro Suite

a Put the supplied CD-ROM into your CD-ROM drive. If the model name screen appears, choose your machine. If the language screen appears, choose your language.

📝 **Note**

If the Brother screen does not appear automatically, go to My Computer (Computer), double-click the CD-ROM icon, and then double-click Start.exe.

**b** The CD-ROM main menu will appear. Click **Initial Installation**.

c Click **Install MFL-Pro Suite**.

📝 **Note**

* *If the installation does not continue automatically, open the main menu again by ejecting and then reinserting the CD-ROM or double-click the **Start.exe** program from the root folder, and continue from step **c** to install MFL-Pro Suite.*

* *For Windows Vista®, when the **User Account Control** screen appears, click **Allow**.*

d When the ScanSoft™ PaperPort™ 11SE **License Agreement** window appears, click **Yes** if you agree to the Software **License Agreement**.

e The installation of ScanSoft™ PaperPort™ 11SE will automatically start and is followed by the installation of MFL-Pro Suite.

f When the Brother MFL-Pro Suite Software **License Agreement** window appears, click **Yes** if you agree to the Software **License Agreement**.

Windows® Wired Network Macintosh

21

g Choose **Wired Network Connection**, and then click **Next**.


📝 **Note**

*If you want to install the PS driver (Brother's BR-Script Driver), choose **Custom Install** and then follow the on-screen instructions. When the **Select Features** screen appears, check **PS Printer Driver**, and then continue following the on-screen instructions.*

h For Windows® XP SP2 or greater/XP Professional x64 Edition/ Windows Vista® users, when this screen appears, choose **Change the Firewall port settings to enable network connection and continue with the installation. (Recommended)** and click **Next**.

If you are not using the Windows® Firewall, see the User's Guide for your software for information on how to add the following network ports.
- For network scanning, add UDP port 54925.
- For network PC-Fax receiving, add UDP port 54926.
- If you still have trouble with your network connection, add UDP port 137.

i If the machine is configured for your network, choose the machine from the list, and then click **Next**.

📝 **Note**

• *You can find your machine's IP address and the node name by printing out the Network Configuration List. See Print the Network Configuration List on page 29.*

• *If your machine is not found over the network, the following screen will appear.*

Confirm your network settings by following the on-screen instructions.

• *If the IP Address of the machine is not yet configured for use on your network, the following screen appears.*

*Click **OK** and then **Configure IP Address**. Enter an IP address for your machine that is suitable for your network by following the on-screen instructions.*

j If you do not want to monitor the machine status and error notification from your computer, uncheck **Enable Status Monitor** and then click **Next**.

k The installation of the Brother drivers will automatically start. The installation screens appear one after another.

⚠ IMPORTANT

DO NOT cancel any of the screens during the installation. It may take a few seconds for all screens to appear.

✎ Note

*For Windows Vista®, when this screen appears, select the check box and click **Install** to complete the installation correctly.*

l When the **On-Line Registration** screen is displayed, make your selection and follow the on-screen instructions. Once you have completed the registration process, close your web browser to return to this window. Then click **Next**.

20 Finish and restart

a Click **Finish** to restart your computer. After restarting the computer, you must be logged on with Administrator rights.

✎ Note

*If an error message appears during the software installation, run the **Installation Diagnostics** located in **Start/All Programs/Brother/ MFC-XXXX LAN** (where MFC-XXXX is your model name).*

b If this screen appears, choose the firmware update setting and click **OK**.

✎ Note

Internet access is required for the firmware upgrade.

23

21 Install MFL-Pro Suite on additional computers (if needed)

If you want to use your machine with multiple computers on the network, install MFL-Pro Suite on each computer. Go to step **19** on page 21.

Note

Network license (Windows®*)*
This product includes a PC license for up to 5 Users. This license supports the installation of the MFL-Pro Suite including ScanSoft™ PaperPort™ 11SE on up to 5 PCs on the network. If you want to use more than 5 PCs with ScanSoft™ PaperPort™ 11SE installed, please purchase the Brother NL-5 pack which is a multiple PC license agreement pack for up to 5 additional users. To purchase the NL-5 pack, contact your authorized Brother dealer or contact Brother customer service.

Finish **The installation is now complete.**

Note

XML Paper Specification Printer Driver
The XML Paper Specification Printer Driver is the most suitable driver when printing from the applications that use the XML Paper Specification documents. Please download the latest driver by accessing the Brother Solutions Center at http://solutions.brother.com/.

For Wired Network Interface Users (Mac OS X 10.3.9 or greater)

16 Before you install

a Make sure your machine is connected to the power and your Macintosh is ON. You must be logged on with Administrator rights.

> **❶ IMPORTANT**
>
> **For the latest drivers and information on the Mac OS X you are using, visit http://solutions.brother.com/.**

17 Connect the network cable

a Connect the network interface cable to the LAN connector marked with a 🔳 symbol and then connect it to a free port on your hub.

18 Install MFL-Pro Suite

a Put the supplied CD-ROM into your CD-ROM drive.

b Double-click **Start Here OSX** to install.

> **📝 Note**
>
> *Please see the* Network User's Guide *on the CD-ROM if you want to install the PS driver. (Brother's BR-Script Driver)*

c Please wait, it will take a few seconds for the software to install. After the installation, click **Restart** to finish installing the software.

d The Brother software will search for the Brother device.

25

e If the machine is configured for your network, choose the machine from the list, and then click **OK**.

📝 **Note**

If your machine is not found over the network, confirm your network settings.

📝 **Note**

*If this screen appears click **OK**.*

- *Enter a name for your Macintosh in **Display Name** up to 15 characters long and click **OK**. Go to **f**.*

- *If you want to use the machine's **Scan** key to scan over the network, you must check the **Register your computer with the "Scan To" function on the machine** box.*

- *The name you enter will appear on the machine's LCD when you press ⬆ and choose a scan option. (For more information, see* Network Scanning *in the* Software User's Guide *on the CD-ROM.)*

f When this screen appears, click **OK**.

OK! **The installation of MFL-Pro Suite is now complete. Go to step 19 on page 26.**

19 Install Presto! PageManager

When Presto! PageManager is installed OCR capability is added to Brother ControlCenter2. You can easily scan, share and organize photos and documents using Presto! PageManager.

a Double-click **Presto! PageManager** and follow the on-screen instructions.

20 Install MFL-Pro Suite on additional computers (if needed)

If you want to use your machine with multiple computers on the network, install MFL-Pro Suite on each computer. Go to step **18** on page 25.

Finish **The installation is now complete.**

For Network Users

BRAdmin Light utility (for Windows® users)

BRAdmin Light is a utility for initial setup of Brother network connected devices. It also can search for Brother products on your network, view the status and configure basic network settings, such as IP address.
For more information on BRAdmin Light, visit us at http://solutions.brother.com/.

📝 Note

If you require more advanced printer management, use the latest Brother BRAdmin Professional utility version that is available as a download from http://solutions.brother.com/.

Install the BRAdmin Light configuration utility

a Click **Network Utilities** on the menu screen.

b Click **BRAdmin Light** and follow the on-screen instructions.

Set your IP address, Subnet Mask and Gateway using BRAdmin Light

📝 Note

If you have a DHCP/BOOTP/RARP server in your network, you do not have to do the following operation. The machine will automatically obtain its own IP address.

a Start BRAdmin Light. It will search for new devices automatically.

b Double-click the unconfigured device.

📝 Note

The default password for the machine is 'access'. You can use BRAdmin Light to change this password.

c Choose **STATIC** for the **Boot Method**. Enter the **IP Address**, **Subnet Mask** and **Gateway**, and then click **OK**.

d The address information will be saved to the machine.

BRAdmin Light utility (for Mac OS X users)

BRAdmin Light is a utility for initial setup of Brother network connected devices. It also can search for Brother products on your network, view the status and configure basic network settings, such as IP address from a computer running Mac OS X 10.3.9 or greater.
The BRAdmin Light software will be installed automatically when you install the printer driver. If you have already installed the printer driver, you do not have to install BRAdmin Light again. For more information on BRAdmin Light, visit us at http://solutions.brother.com/.

Set your IP address, Subnet Mask and Gateway using BRAdmin Light

📝 **Note**
- *If you have a DHCP/BOOTP/RARP server in your network, you do not have to do the following operation. The machine will automatically obtain its own IP address.*

- *Make sure that version 1.4.2 or greater of Java™ client software is installed on your computer.*

- *The default password for the machine is 'access'. You can use BRAdmin Light to change this password.*

a Double-click **Macintosh HD** on your desktop.

b Choose **Library**, **Printers**, **Brother** and then **Utilities**.

c Double-click the file **BRAdmin Light.jar** and run the software. BRAdmin Light will then search for new devices automatically.

d Double-click the unconfigured device.

e Choose **STATIC** for **Boot Method**. Enter the **IP Address**, **Subnet Mask** and **Gateway**, and then click **OK**.

f The address information will be saved to the machine.

28

For Network Users

Web Based Management (web browser)

The Brother print server is equipped with a web server that allows you to monitor its status or change some of its configuration settings, using HTTP (Hyper Text Transfer Protocol).

Note
- *The User Name is 'admin' and the default password is 'access'. You can use a web browser to change this password.*
- *We recommend Microsoft® Internet Explorer® 6.0 (or higher) or Firefox 1.0 (or higher) for Windows® and Safari 1.3 for Macintosh. Please also make sure that JavaScript and cookies are always enabled in whichever browser you use. To use a web browser, you will need to know the IP address of the print server. The IP address of the print server is listed on the Network Configuration List.*

a Open your browser.

b Type http:// printer_ip_address /into your browser (Where "printer_ip_address" is the IP address of the printer or the print server name).
  - For example http://192.168.1.2/

🔍 *See* Chapter 11 *of the* Network User's Guide.

Print the Network Configuration List

You can print the Network Configuration List to confirm the current network settings. To print the Network Configuration List:

a Turn on the machine and wait until the machine is in the Ready state.

b Press **Reports**. Press ▲ or ▼ to choose Network Config.

```
Select ▲▼ or OK
6.Network Config
```

c Press **OK**.
  The machine will print the current network settings.

Restore the network settings to factory default

To restore all network settings of the internal Print/Scan server to factory default, please follow the steps below.

a Make sure the machine is not operating, then disconnect all the cables from the machine (except the power cord).

b Press **Menu**, **5**, **0**.

```
Network
0.Network Reset
```

c Press **1** to choose Reset.

d Press **1** to choose Yes.

**e** The machine will restart, re-connect cables once this is complete.

Options and Consumables

Options

The machine has the following optional accessory. You can expand the capabilities of the machine by adding this item. For more information about compatible SO-DIMM Memory, visit us at http://solutions.brother.com/.

🔍 *For installing the SO-DIMM Memory, see the* User's Guide *or visit http://solutions.brother.com/.*

SO-DIMM Memory
You can expand the memory by installing a (144-pin SO-DIMM) memory module.

When the time comes to replace consumable items, an error will be indicated by the LCD on the control panel. For more information about the consumables for your machine, visit us at http://solutions.brother.com/ or contact your local Brother reseller.

Toner cartridges	Drum units
TN-240C/TN-240M/TN-240Y/TN-240BK	DR-240CL [1]
Belt Unit (BU-200CL)	**Waste Toner Box (WT-200CL)**

[1] Contains a set of three colour drums and one black drum. All four drums are replaced at the same time.