

Information for compliance with Commission Regulation 801/2013


Model Name: MFC-J6720DW, MFC-J6520DW, MFC-J3720

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.6W	N/A	5min	N/A
USB	1.3W	N/A	5min	N/A
PictBridge	1.2W	N/A	5min	N/A
Wi-Fi	1.8W	N/A	5min	N/A
Telecom(FAX)	1.2W	N/A	5min	N/A
All network ports activated and connected	2.1W	N/A	5min	N/A

Model Name: MFC-J6920DW, MFC-J6925DW

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.6W	N/A	5min	N/A
USB	1.3W	N/A	5min	N/A
PictBridge	1.2W	N/A	5min	N/A
Wi-Fi	1.8W	N/A	5min	N/A
NFC	1.3W	N/A	5min	N/A
Telecom(FAX)	1.2W	N/A	5min	N/A
All network ports activated and connected	2.1W	N/A	5min	N/A

How to enable/disable Wireless LAN

To turn on the wireless network connection, press  **(Settings) > All Settings > Network > Network I/F > WLAN.**

To turn off, press  **(Settings) > All Settings > Network > Network I/F > Wired LAN.**

Note:

The message above may be slightly different from the actual message displayed.