

Information for compliance with Commission Regulation 801/2013

Model Name: HL-1210W, HL-1210WE, HL-1212W


Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	0.7W	0.3W	1min	61min
Wi-Fi	1.2W	N/A	1min	N/A
All network ports activated and connected	1.3W	N/A	1min	N/A

Model Name: HL-1211W

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	0.7W	0.3W	1min	481 min
Wi-Fi	1.2W	N/A	1min	N/A
All network ports activated and connected	1.3W	N/A	1min	N/A

How to enable/disable Wireless LAN

To turn on the wireless network connection, uninstall the drivers. Then reinstall the drivers.

To turn off, make sure that your machine is connected to wireless LAN access point/router, and then press  (WiFi) for 7 times in a row.