

## Information for compliance with Commission Regulation 801/2013

Model Name: DCP-L2520DW


Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	1.1W	0.1W	11min	71min
Wi-Fi	2.6W	N/A	11min	N/A
All network ports activated and connected	2.7W	N/A	11min	N/A

Model Name: MFC-L2700DW

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.1W	N/A	11min	N/A
USB	1.1W	N/A	11min	N/A
Wi-Fi	2.6W	N/A	11min	N/A
Telecom(FAX)	1.0W	N/A	11min	N/A
All network ports activated and connected	2.7W	N/A	11min	N/A

### How to enable/disable Wireless LAN

To turn on or off the wireless network connection, press the following buttons on your control panel or LCD.



#### Note:

Depending on your machine, you may need to press the **OK** button to select the option.  
The message above may be slightly different from the actual message displayed.