

Information for compliance with Commission Regulation 801/2013

Model Name: HL-L8350CDW

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.1W	N/A	9min	N/A
USB	0.9W	0.0W	9min	69min
Wi-Fi	5.8W	N/A	9min	N/A
All network ports activated and connected	5.9W	N/A	9min	N/A

Model Name: HL-L9200CDWT


Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.1W	N/A	9min	N/A
USB	1.1W	0.0W	9min	69min
Wi-Fi	7.3W	N/A	9min	N/A
All network ports activated and connected	7.5W	N/A	9min	N/A

Model Name: HL-L9300CDWTT

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	1.4W	N/A	9min	N/A
USB	1.3W	0.0W	9min	69min
Wi-Fi	9.2W	N/A	9min	N/A
All network ports activated and connected	9.2W	N/A	9min	N/A

How to enable/disable Wireless LAN

To turn on or off the wireless network connection, press the following buttons on your control panel or LCD.



Note:

Depending on your machine, you may need to press the **OK** button to select the option. The message above may be slightly different from the actual message displayed.