

Information for compliance with Commission Regulation 801/2013

Model Name: HL-5470DW


Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	0.6W	0.0W	3min	N/A
USB	0.5W	0.0W	3min	N/A
Wi-Fi	2.4W	0.0W	3min	N/A
All network ports activated and connected	2.4W	0.0W	3min	N/A

Model Name: HL-6180DW, HL-6180DWT

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	0.8W	0.0W	3min	N/A
USB	0.7W	0.0W	3min	N/A
Wi-Fi	2.4W	0.0W	3min	N/A
All network ports activated and connected	2.5W	0.0W	3min	N/A

How to enable/disable Wireless LAN

To turn on or off the wireless network connection, press the following buttons on your control panel or LCD.



Note:

Depending on your machine, you may need to press the **OK** button to select the option. The message above may be slightly different from the actual message displayed.