

Information for compliance with Commission Regulation 801/2013

Model Name: ADS-1100W


Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	1.0W	0.3W	10min	250min
Wi-Fi	1.5W	0.3W	10min	N/A
All network ports activated and connected	1.5W	0.3W	10min	N/A

How to enable/disable Wireless LAN

To turn on or off the wireless network connection, follow the steps below:

1. Open the Top Cover and the Front Cover.



2. Press  for about five seconds until the machine beeps.
3. Close the Front Cover. When WLAN is enabled, the WiFi light is on. When WLAN is disabled, the WiFi light is off.