WARNING

OCE Version 0

Quick Setup Guide

Read the Product Safety Guide first, then read this Quick Setup Guide for the correct installation procedure.

brother




Watch our FAQ Videos for help with setting up your Brother machine. solutions.brother.com/videos


Visit the Brother support website http://support.brother.com

Unpack the machine and check the components

- 1. Remove the protective tape and film covering the machine, and also from the Touchscreen.
- 2. Make sure you have all components. The components included in the box may differ depending on your country.



Introductory Ink Cartridges [x4] Black Yellow Cyan Magenta



Quick Setup Guide Basic User's Guide **Product Safety Guide**



Power Cord




Telephone Line Cord Adapter



CD-ROM



USB Interface Cable



Maintenance Sheet



Telephone Line Cord

WARNING

Plastic bags are used in the packing of your machine. To avoid the danger of suffocation, keep these plastic bags away from babies and children. Plastic bags are not toys.

NOTE

- · Save all packing materials and the box in case for any reason you must ship your machine.
- For a network connection you must purchase a network interface cable. Please use the supplied USB cable for a USB connection.


USB cable

We recommend using a USB 2.0 cable (Type A/B) that is no more than 2 metres long.


Network cable

Use a straight-through Category5 (or greater) twisted-pair cable for 10BASE-T or 100BASE-TX Fast Ethernet Network.

Load plain A4 paper




Pull the paper tray completely out of the machine.



Adjust the paper guides


Fan the paper well and load it in the tray.




Pull out the paper support 1, and unfold the paper support flap 2.

Connect power cord and telephone line cord

If you are not using your machine as a fax, connect the power cord and go to 3




Connect the power cord. Lift the scanner cover.





Connect the telephone line cord. Use the socket marked LINE and guide the cord out the back of the machine.

NOTE

If you are sharing one telephone line with an external telephone, connect it as shown below.








Close the scanner cover.


Set your country (Available only for some countries)

- Press your country. Press OK.
- Press Yes or No.
- 3. After the LCD shows Accepted for a few seconds, the machine will restart automatically.

Install introductory ink cartridges




Open the ink cartridge cover 1.



Follow the Touchscreen instructions to install the ink cartridges. The machine will prepare the ink tube system for printing.

NOTE

You can adjust the angle of the control



Machine Settings


When the machine has finished the initial cleaning process, follow the Touchscreen instructions to configure the machine settings.


- Check print quality
- · Set date and time
- Set tray settings View operation tips
- Print the installation sheet


Choose your language (Available only for some countries)


- 1. Press 🔐
- Press All Settings.
- Swipe up or down, or press ▲ or ▼ to display Initial Setup. Press Initial Setup.
- **4.** Swipe up or down, or press ▲ or ▼ to display Local Language. Press Local Language.
- Press your language.
- 6. Press















Connect to your device and install software




For Wireless Networks

To connect additional computers, repeat Method A for each computer.

Method A Setup from the computer

Make sure that you are logged on with Administrator rights.



Put the CD-ROM into your CD-ROM drive. If you do not have a CD-ROM drive, download the software at:

For Windows®: solutions.brother.com/windows
For Macintosh: solutions.brother.com/mac





Follow the on-screen instructions to continue installation.


A USB cable may be needed in some cases.



Method B Manual setup using the Setup Wizard

■ Set up your machine

Write your wireless access point/router information in the area below.
 This information may be hidden on the bottom of the wireless access point/router. If you cannot find it, ask your network administrator or wireless access point/router manufacturer.



2. Press wifi on your Brother machine's Touchscreen, and then press Setup Wizard.

When Switch Network interface to wireless? is displayed, press Yes.

- 3. Select the SSID you wrote down in 1. Press OK.
- **4.** If the machine prompts you to enter a Network Key, enter the key you wrote down in **1**. Press OK.
- **5.** Press Yes to apply your settings.


■ Install Brother iPrint&Scan



&Scan

You can print from and scan to mobile devices using our free application "Brother iPrint&Scan."

Download and install the application from <u>solutions.brother.com/ips</u>.





Make sure that you are logged on with Administrator rights.



Put the CD-ROM into your CD-ROM drive. If you do not have a CD-ROM drive, download the software at: For Windows®: solutions.brother.com/windows
For Macintosh: solutions.brother.com/mac



Driver Domload

(Macintosh)

Finish

Finish

Follow the on-screen instructions to continue installation.

뀲

For Wired Networks

To connect additional computers, repeat this procedure for each computer.

■ Connect the network cable

■ Install MFL-Pro Suite





Make sure that you are logged on with Administrator rights.

Put the CD-ROM into your CD-ROM drive. If you do not have a CD-ROM drive, download the software at:

For Windows®:

solutions.brother.com/windows
For Macintosh:
solutions.brother.com/mac







Follow the on-screen instructions to continue installation.



For USB Connections

■ Install MFL-Pro Suite



Make sure that you are logged on with Administrator rights.

Put the CD-ROM into your CD-ROM drive. If you do not have a CD-ROM drive, download the software at: solutions.brother.com/windows


Follow the on-screen instructions.



Follow the on-screen instructions to continue installation.



■ Connect the USB cable



■ Install MFL-Pro Suite



Make sure that you are logged on with Administrator rights.

Put the CD-ROM into your CD-ROM drive. If you do not have a CD-ROM drive, download the software at: solutions.brother.com/mac





Finish

Internet access is required. Follow the on-screen instructions to continue installation.