

Information for compliance with Commission Regulation 801/2013


Model Name: DCP-J562DW

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	0.8W	0.2W	5min	60min
Wi-Fi	1.2W	N/A	5min	N/A
All network ports activated and connected	1.3W	N/A	5min	N/A

Model Name: MFC-J680DW

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	1.2W	0.2W	5min	60min
PictBridge(Wired)	1.2W	0.2W	5min	60min
Wi-Fi	1.7W	N/A	5min	N/A
Telecom(FAX)	1.2W	N/A	5min	N/A
All network ports activated and connected	1.8W	N/A	5min	N/A

How to enable/disable Wireless LAN

To turn on or off the wireless network connection, press  **(Settings) > All Settings > Network > WLAN Enable > On or Off.**

Note:

The message above may be slightly different from the actual message displayed.