

Information for compliance with Commission Regulation 801/2013

Model Name: MFC-J985DW

| Network Port | Power consumption | | Default Timer Values | |
|---|------------------------|----------|---------------------------|-------------|
| | Networked Standby mode | Off mode | To Networked Standby mode | To Off mode |
| Ethernet | 1.5W | N/A | 5min | N/A |
| USB | 1.3W | 0.2W | 5min | 60min |
| PictBridge(Wired) | 1.2W | 0.2W | 5min | 60min |
| Wi-Fi | 1.7W | N/A | 5min | N/A |
| NFC | 1.2W | 0.2W | 5min | 60min |
| Telecom(FAX) | 1.2W | N/A | 5min | N/A |
| All network ports activated and connected | 1.8W | N/A | 5min | N/A |

How to enable/disable Wireless LAN

To turn on or off the wireless network connection, press



(Settings) > All Settings > Network > Network I/F > WLAN or Wired LAN.