Information for compliance with Commission Regulation 801/2013

Model Name:MFC-J497DW, MFC-J491DW

| Network Port | Power consumption | | Default Timer Values | |
|---|-------------------|----------|----------------------|-------------|
| | Networked Standby | Off mode | To Networked Standby | To Off mode |
| | mode | On mode | mode | |
| USB | 1.0W | 0.2W | 5min | 120min |
| Wi-Fi | 1.3W | N/A | 5min | N/A |
| Telecom(FAX) | 0.9W | N/A | 5min | N/A |
| All network ports activated and connected | 1.3W | N/A | 5min | N/A |

How to enable/disable Wireless LAN

To turn on the wireless network connection, press Settings > Network > WLAN Enable > On. To turn off, press Settings > Network > WLAN Enable > Off.

Note:

The message above may be slightly different from the actual message displayed.