

Information for compliance with Commission Regulation 801/2013

Model Name: MFC-1911W

| Network Port | Power consumption | | Default Timer Values | |
|---|------------------------|----------|---------------------------|-------------|
| | Networked Standby mode | Off mode | To Networked Standby mode | To Off mode |
| USB | 0.9W | 0.3W | 1min | 481min |
| Wi-Fi | 1.9W | N/A | 1min | N/A |
| Telecom(FAX) | 1.3W | N/A | 1min | N/A |
| All network ports activated and connected | 2.4W | N/A | 1min | N/A |

How to enable/disable Wireless LAN

To turn on or off the wireless network connection, press **Menu > Network > WLAN > WLAN Enable > On or Off**.

Note:

You need to press ▲ or ▼ and the **OK** button to select the option.

The message above may be slightly different from the actual message displayed.