Information for compliance with Commission Regulation 801/2013

Model Name: MFC-T4500DW

| Network Port | Power consumption | | Default Timer Values | |
|-----------------------------|-------------------|----------|----------------------|--------|
| | Networked | Off mode | To Networked | To Off |
| | Standby mode | | Standby mode | mode |
| Ethernet | 1.5W | N/A | 5min | N/A |
| USB | 1.4W | 0.0W | 5min | 120min |
| Wi-Fi | 1.7W | N/A | 5min | N/A |
| Telecom(FAX) | 1.3W | N/A | 5min | N/A |
| All network ports activated | 2.2W | N/A | 5min | N/A |
| and connected | | | | |

How to enable/disable Wireless LAN

To turn on the wireless network connection, press (Settings) > All Settings > Network > Network I/F > WLAN.

To turn off, press (Settings) > All Settings > Network > Network I/F > Wired LAN.

Note:

The message above may be slightly different from the actual message displayed.