

Information for compliance with Commission Regulation 801/2013

Model Name: DCP-J1200W

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	0.8W	0.2W	5min	120min
Wi-Fi	1.0W	N/A	5min	N/A
All network ports activated and connected	1.1W	N/A	5min	N/A

How to enable/disable Wireless LAN

- 1 Press  (Wi-Fi) and  (Stop) simultaneously.

The **Power LED**, **Warming LED**, and **Ink LED** light up for one second, and then the **Wi-Fi LED** starts blinking.

- 2 Press **MONO COPY** to enable Wi-Fi.

- When Wi-Fi is enabled, the **Power LED** blinks once, and then the **Power LED** and **Wi-fi LED** are lit.
- When Wi-Fi is disabled, the **Power LED** blinks twice, and then the **Power LED** is lit.