

## Information for compliance with Commission Regulation 801/2013

Model Name: MFC-J1010DW

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	1.1W	0.2W	5min	120min
Wi-Fi	1.3W	N/A	5min	N/A
Telecom(FAX)	0.9W	N/A	5min	N/A
All network ports activated and connected	1.3W	N/A	5min	N/A

### How to enable/disable Wireless LAN

1. Press **Settings**.
2. Press the **Up** or **Down** arrow key to make your selections:
  - a. Select **Network**. Press **OK**.
  - b. Select **WLAN (Wi-Fi)**. Press **OK**.
  - c. Select **WLAN Enable**. Press **OK**.
  - d. Do one of the following:
    - To enable Wi-Fi, select **On**. Press **OK**.
    - To disable Wi-Fi, select **Off**. Press **OK**.