






1

FAQ [support.brother.com/videos](http://support.brother.com/videos)





- خرطيش الرقائق المعدنية غير متضمنة. يجب شراء خرطوشة الرقائق الصحيحة من أجل استخدام الجهاز.
- Foil cartridges are not included. You must purchase the correct foil cartridge to use your machine.
- Folienrollen sind nicht im Lieferumfang enthalten. Die richtige Folienrolle zur Nutzung des Geräts muss separat gekauft werden.
- Les cartouches de film ne sont pas incluses. Vous devez acheter la bonne cartouche de film pour pouvoir utiliser votre machine.
- Folie cartidges zijn niet inbegrepen. U moet de juiste foliecartridge aanschaffen om uw apparaat te kunnen gebruiken.
- Le cartucce di pellicola non sono incluse. È necessario acquistare la cartuccia corretta per utilizzare la macchina.
- Los cartuchos de foil no están incluidos. Debe comprar el cartucho de foil correcto para utilizar su máquina.
- Cartuchos de Foil não incluídos. Deverá adquirir o cartucho de foil correto para usar o seu equipamento.


2



3



4



5

