

Information for compliance with Commission Regulation 801/2013

Model Name: HL-L2400DWE, HL-L2400DW, HL-L2442DW

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	0.4W	0.1W	1min	121min
Wi-Fi	0.6W	N/A	1min	N/A
All network ports activated and connected	0.6W	N/A	1min	N/A

How to enable/disable Wireless LAN

1. Press the **Up** or **Down** arrow key to select the **Network** option, and then press **OK**.
2. Press the **Up** or **Down** arrow key to select the **WLAN(Wi-Fi)** option, and then press **OK**.
3. Press the **Up** or **Down** arrow key to select the **WLAN Enable** option, and then press **OK**.
4. Do one of the following:
 - To enable Wi-Fi, select **On**.
 - To disable Wi-Fi, select **Off**.
5. Press **Go**.