

Information for compliance with Commission Regulation 801/2013

Model Name: MFC-L2835DW, MFC-L2827DWXL, MFC-L2827DW, MFC-L2802DW, MFC-L2800DW, MFC-B7810DW

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	0.7W	N/A	1min	N/A
USB	0.6W	0.1W	1min	121min
Wi-Fi	0.8W	N/A	1min	N/A
Telecom(FAX)	0.6W	N/A	1min	N/A
All network ports activated and connected	2.9W	N/A	1min	N/A

How to enable/disable Wireless LAN

1. Press **Menu**.
2. Press the **Up** or **Down** arrow key to make your selections:
 - a. Select **Network**. Press **OK**.
 - b. Select **WLAN (Wi-Fi)**. Press **OK**.
 - c. Select **WLAN Enable**. Press **OK**.
 - d. Do one of the following:
 - To enable Wi-Fi, select **On**. Press **OK**.
 - To disable Wi-Fi, select **Off**. Press **OK**.