

## Information for compliance with Commission Regulation 801/2013

Model Name: MFC-L2861DW

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	0.7W	N/A	1min	N/A
USB	0.6W	0.1W	1min	481min
Wi-Fi	0.8W	N/A	1min	N/A
Telecom(FAX)	0.6W	N/A	1min	N/A
All network ports activated and connected	2.9W	N/A	1min	N/A

### How to enable/disable Wireless LAN

1. Press **Settings > All Settings > Network > WLAN (Wi-Fi)**.
2. Press the **Up** or **Down** arrow key to select the **WLAN Enable** option. Press **WLAN Enable**.
3. Do one of the following:
  - To enable Wi-Fi, select **On**. Press **OK**.
  - To disable Wi-Fi, select **Off**. Press **OK**.
4. Press **Home**.