Information for compliance with Commission Regulation (EU) 801/2013 (Great Britain only), (EU) 2023/826 (Europe only)

Model Name: HL-L9310CDW, HL-L8360CDW, HL-L8260CDW

| Network Port | Power consumption | | Default Timer Values | | Timer Values | |
|--|-------------------|------------|----------------------|-------------|--------------|-------------|
| | Networked | I()tt mode | To Networked | To Off mode | To Networked | To Off mode |
| | Standby mode | | Standby mode | | Standby mode | |
| USB | 1.1W | N/A | 1min | N/A | 0min~20min | N/A |
| Ethernet | 1.3W | N/A | 1min | N/A | 0min~20min | N/A |
| Wi-Fi | 1.4W | N/A | 1min | N/A | 0min~20min | N/A |
| NFC | 1.1W | N/A | 1min | N/A | 0min~20min | N/A |
| All network ports activated and connected* | 8.2W | | 1min | | 0min~20min | |

^{*}Power consumption is reduced as the number of activated and connected network ports decreases.


How to enable/disable Wireless LAN (available for certain models)



How to enable/disable Wi-Fi Direct® (available for certain models)



How to enable/disable NFC (available for certain models)



Power consumption

Your machine has power-saving functions. If you deactivate this function or choose to delay its activation, power consumption will increase.

Note

The Auto Power Off function has been updated with the new setting of 20 minutes.