

Information for compliance with Commission Regulation (EU) 2023/826

Model Name:MFC-T930DW

Network Port	Power consumption		Timer Values	
	Networked Standby	Off mode	To Networked Standby	To Off mode
Ethernet	0.9W	N/A	1min ~ 20min	N/A
USB	0.9W	N/A	1min ~ 20min	N/A
Wi-Fi	1.2W	N/A	1min ~ 20min	N/A
Telecom(FAX)	1.0W	N/A	1min ~ 20min	N/A
All network ports activated and connected	2.0W		1min ~ 20min	

How to enable/disable Wireless LAN

To turn on or off the wireless network connection, press the following buttons on your control panel or LCD.

Note:

Depending on your machine, you may need to press the OK button to select the option.

The message below may be slightly different from the actual message displayed.

Press **Settings**, and then press ▲ or ▼ to select the following:

1. Select **Network**. Press **OK**.
2. Select **WLAN(Wi-Fi)**. Press **OK**.
3. Select **WLAN Enable**. Press **OK**.
4. Select **On** or **Off**. Press **OK**.

How to enable/disable Wi-Fi Direct

Press **Settings**, and then press ▲ or ▼ to select the following:

1. Select **Network**. Press **OK**.
2. Select **Wi-Fi Direct**. Press **OK**.
3. Select **I/F Enable**. Press **OK**.
4. Select **On** or **Off**. Press **OK**.

Power consumption

Your machine has a power-saving function. If you deactivate this function or choose to delay its activation, power consumption will increase.