

Information for compliance with Commission Regulation (EU) 801/2013 (Great Britain only), (EU) 2023/826 (Europe only)

Model Name: DCP-J1260W

Network Port	Power consumption		Default Timer Values		Timer Values	
	Networked Standby	Off mode	To Networked Standby mode	To Off mode	To Networked Standby	To Off mode
USB	0.6W	N/A	1min	N/A	1min ~ 20min	N/A
Wi-Fi	0.9W	N/A	1min	N/A	1min ~ 20min	N/A
All network ports activated and connected	1.0W		1min		1min ~ 20min	

How to enable/disable Wireless LAN

To turn on or off the wireless network connection, press the following buttons on your control panel

Press **Wi-Fi** and **Stop** simultaneously, and then press **Mono Copy**.

How to enable/disable Wireless Direct

Press **Wi-Fi** and **Stop** simultaneously, and then press **Copy Shortcut**.