

**Information for compliance with Commission Regulation (EU) 801/2013 (Great Britain only), (EU) 2023/826 (Europe only)**

Model Name: HL-T4000DW

Network Port	Power consumption		Default Timer Values		Timer Values	
	Networked Standby	Off mode	To Networked Standby mode	To Off mode	To Networked Standby	To Off mode
Ethernet	1.2W	N/A	5min	N/A	1min ~ 20min	N/A
USB	1.1W	N/A	5min	N/A	1min ~ 20min	N/A
Wi-Fi	1.4W	N/A	5min	N/A	1min ~ 20min	N/A
All network ports activated and connected	2.0W		5min		1min ~ 20min	

**How to enable/disable wireless LAN (available on certain models)**



[Settings] > [All Settings] > [Network] > [Network I/F] > [Wired LAN] or [WLAN(Wi-Fi)].

**How to enable/disable Wi-Fi Direct® (available on certain models)**



[Settings] > [All Settings] > [Network] > [Wi-Fi Direct] > [I/F Enable] > [On] or [Off].

**How to enable/disable NFC (available on certain models)**



[Settings] > [All Settings] > [Network] > [NFC] > [On] or [Off].

**Power consumption**

Your machine has a power-saving function. If you deactivate this function or choose to delay its activation, power consumption will increase.