# Information for compliance with Commission Regulation (EU) 2023/826

# Model Name:MFC-T920DW

Network Port	Power consumption		Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	1.2W	N/A	1 - 60min	N/A
Ethernet	1.2W	N/A	1 - 60min	N/A
Wi-Fi	1.4W	N/A	1 - 60min	N/A
Telecom(FAX)	1.1W	N/A	1 - 60min	N/A
All network ports activated and connected*	2.2W		1 - 60min	

<sup>\*</sup>Power consumption is reduced as the number of activated and connected network ports decreases.

# How to enable/disable Wireless LAN (available for certain models)

press Settings, and then press ▲ or ▼ to select the following:

- 1. Select [Network]. Press OK.
- 2. Select [WLAN Enable]. Press OK.
- 3. Select [On] or [Off]. Press OK.

# How to enable/disable Wi-Fi Direct® (available for certain models)

press Settings, and then press ▲ or ▼ to select the following:

- 1. Select [Network]. Press OK.
- 2. Select [Wi-Fi Direct]. Press OK.
- 3. Select [I/F Enable]. Press OK.
- 4. Select [On] or [Off]. Press OK.

### Power consumption

Your machine has power-saving functions.

If you deactivate this function or choose to delay its activation, power consumption will increase.