

Channels Supported by Brother Machines for 5 GHz Wi-Fi Networks

NOTE: Applicable only to the countries listed in the table below.

When connecting your machine to a 5 GHz Wi-Fi® network, make sure your wireless LAN access point/router is set to one of the channels available in your country and listed in the table below (recommended channel: 5.2 GHz Band). For more information about changing the channel setting, see the instructions supplied with your wireless LAN access point/router.

✓: Channel supported by Brother machines ×: Channel not supported by Brother machines

Channel	5.2 GHz Band				5.3 GHz Band				5.6 GHz Band											5.8 GHz Band					
	36	40	44	48	52	56	60	64	100	104	108	112	116	120	124	128	132	136	140	144	149	153	157	161	165
Australia, Fiji, New Zealand, Papua New Guinea, Samoa, Tonga, Vanuatu, Hong Kong, Macau, Singapore	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	✓	×	✓	✓	✓	✓	✓