

Important Security Information

Factory Default Enabled Network Interfaces and Services*

Network Interfaces

- Ethernet: Network communication starts when a cable is connected.

Network Services

| Service | Protocol | Description |
|----------------------|--------------------|---|
| Web server | HTTPS | The web server is used for viewing and changing the machine's information and settings through Web Based Management and Brother's management tools. It also supports scanning using AirPrint Scan and Web Services. |
| SNMP | SNMP v1/v2c | SNMP is used for viewing and changing the machine's information through Brother's management tools. In the factory default settings, only viewing is enabled. |
| Port 9100 (Raw Port) | Port 9100 | Port 9100 is used for viewing and changing the machine's information through Brother's management tools. In the factory default settings, only viewing is enabled. |
| Network Scan | (Brother-original) | Network Scan is used for scanning through Brother's applications. |

*The above services may be disabled by default on some models.

You can disable these services in the left navigation bar on the Web Based Management page by selecting **Network > Network > Protocol**. If your model has the **Network** tab at the top of the screen, click this tab and select the **Protocol** option.

Product and Data Security

Product Installation

Unauthorised users may physically access or remotely manipulate the product through the network. Make sure you install the product in a secure location.

Personal Information

The personal information stored in the product may vary depending on the product - for example, it may include scan data, email addresses, and NFC card numbers. Changing the product's settings may increase the risk of unauthorised access to the personal information. Make sure you review the content and impact of the settings before making any changes.

Using TFTP

This product supports access to administrator information via TFTP, but this protocol does not guarantee secure network communications and is disabled by default. Make sure your network environment is protected against unauthorised access before enabling the protocol.

About Setting Lock and Secure Function Lock Features

The Setting Lock and Secure Function Lock features are disabled by default when you purchase the product. For instructions on how to enable them, see your product's Online User's Guide.

Other Information

Important

The available features depend on your model. For more information, see your model's Online User's Guide.

Trademarks

AirPrint is a Trademark of Apple Inc., registered in the U.S. and other countries.

Any trade names and product names of companies appearing on Brother products, related documents and any other materials are all trademarks or registered trademarks of those respective companies.