



■ Operation keys and LCD
Touches de fonctionnement et écran a cristaux liquides



- ① LCD (liquid crystal display)
 - ① Number of the selected stitch
 - ② Presser foot to be used
 - ③ Stitch length (mm)
 - ④ Stitch width (mm)
 - ⑤ Auto reverse/reinforcement
 - ② Stitch selection keys
 - ③ Stitch length adjustment key
 - ④ Stitch width adjustment key
 - ⑤ Character stitch indicator
 - ⑥ Satin stitch indicator
 - ⑦ Utility stitch indicator
 - ⑧ Stitch category selection key
 - ⑨ Sewing speed controller
 - ⑩ Needle position button
 - ⑪ Reverse/reinforcement stitch button
 - ⑫ Start/stop button
- ① Ecran a cristaux liquides
 - ① Numero du point selectionne
 - ② Pied presseur a utiliser
 - ③ Longueur du point (mm)
 - ④ Largeur du point (mm)
 - ⑤ Couture automatique de points inverses/renfort
 - ② Touches de selection de point
 - ③ Touche de reglage de la longueur du point
 - ④ Touche de reglage de la largeur du point
 - ⑤ Indicateur du point de caractere
 - ⑥ Indicateur du point satin
 - ⑦ Indicateur du point utilitaire
 - ⑧ Touche de selection de categorie de point
 - ⑨ Commande de vitesse de couture
 - ⑩ Touche de positionnement de l'aiguille
 - ⑪ Touche de point inverse/de renfort
 - ⑫ Touche Marche/Arret


■ Selecting a stitch
Selection d'un point




Refer to the Operation Manual for detailed instructions about sewing.
Reportez-vous au Manuel d'instructions pour des directives de couture plus detaillees.



Preparing the bobbin thread
Preparation du fil de la canette





Be sure to first read the "IMPORTANT SAFETY INSTRUCTIONS" in the Operation Manual.
Refer to the Operation Manual for detailed instruction.

Lisez attentivement les « INSTRUCTIONS DE SÉCURITÉ IMPORTANTES » du Manuel d'instructions.
Reportez-vous au Manuel d'instructions pour des directives détaillées.

■ List of stitches / Liste des points

00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15	16	17	18	19	20	21	22	23	24
25	26	27	28	29	30	31	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47	48	49
50	51	52	53	54	55	56	57	58	59	60	61	62	63	64	65	66	67	68	69	70	71	72	73	74
75	76	77	78	79	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95	96	97	98	99

00	01	02	03	04	05	06	07	08	09	10	11	12	13	14	15
16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
32	33	34	35	36	37	38	39								

01	02	03	04	05	06	07	08	09	10
A	B	C	D	E	F	G	H	I	J
11	12	13	14	15	16	17	18	19	20
K	L	M	N	O	P	Q	R	S	T
21	22	23	24	25	26	27	28	29	30
U	V	W	X	Y	Z	&	?	!	.
31	32	33	34	35	36	37	38	39	40
0	1	2	3	4	5	6	7	8	9
41	42	43	44	45	46	47	48	49	50
,	.	(	)	-	Ä	Å	Æ	Ñ	
51	52	53	54	55					
Ö	Ø	Ç	Ü	ß					

■ Useful Features / Fonctions utiles

- Quick-set bobbin
- Needle threader
- Fast bobbin winding system
- Canette à fixation rapide
- Enfileur d'aiguille
- Système d'embobinage rapide de la canette

Refer to the Operation Manual for detailed instruction.

Reportez-vous au Manuel d'instructions pour des directives détaillées.