

## Information for compliance with Commission Regulation 801/2013

Model Name: DC100

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB Port	1.9W	0.1W	20min	60min
Wi-Fi	1.9W	0.1W	20min	60min
All network ports activated and connected	1.9W	0.1W	20min	60min

How to enable/disable Wireless LAN

To turn the wireless network connection on or off, press ▼ or ▲ > [1.Network] > [1.WLAN Enable] > [ON] or [OFF]

Note:

You may need to press the OK button to select the option. The message above may be slightly different from the actual message displayed.