


EN Included Accessories

SC 附带的配件

EN Thank you for purchasing this machine.
The following accessories are included with this product.

SC 感谢购买此机器。
本产品附带以下配件。



*1 75/11 1 needle, 90/14 1 needle, 100/16 1 needle

*2 90/14 1 needle: Ball point needle (gold colored)

*1 75/11 1针, 90/14 1针, 100/16 1针

*2 90/14 1针: 圆头针 (金色)

No.	Part Name	Part Code
1	Zigzag foot "J" (on machine)	XZ5134-001
2	Buttonhole foot "A"	XC2691-133
3	Overcasting foot "G"	XC3098-031
4	Monogramming foot "N"	XD0810-031
5	Zipper foot "I"	X59370-021
6	Blind stitch foot "R"	XE2650-001
7	Button fitting foot "M"	XE2137-001
8	Seam ripper	XZ5082-001
9	Bobbin (4) (One bobbin is on machine.)	SFB
10	Needle set	XC8834-021
11	Ball point needle	XD0360-021
12	Cleaning brush	X59476-051
13	L-shaped screwdriver	XG0918-001
14	Bobbin case (on machine)	XF5707-101
15	Foot controller	XD0501-121 (Turkey area) XC8816-071 (Other areas)
16	Dust cover	XA2112-022
17	Wide table	WT17AP
18	Eyelet punch	XG7791-001
19	Operation Manual	Contact your authorized Brother dealer.
20	Quick Reference Guide	Contact your authorized Brother dealer.

编号	零件名	零件编号
1	曲折压脚“J”(已装在机器上)	XZ5134-001
2	钮孔压脚“A”	XC2691-133
3	包边压脚“G”	XC3098-031
4	交织字母压脚“N”	XD0810-031
5	拉链压脚“I”	X59370-021
6	暗缝迹压脚“R”	XE2650-001
7	钉钮压脚“M”	XE2137-001
8	拆线刀	XZ5082-001
9	梭芯(4) (机器已预装一个梭芯。)	X52800-120
10	针组	XC8834-021
11	圆头针	XD0360-021
12	清洁刷	X59476-051
13	L形螺丝刀	XG0918-001
14	内旋梭(已装在机器上)	XF5707-101
15	脚踏控制器	XC8816-071
16	防尘盖	XA2112-022
17	扩展台	WT17CN
18	打孔器	XG7791-001
19	使用说明书	请咨询Brother授权经销商。
20	快速操作指南	请咨询Brother授权经销商。

Note

- The presser foot holder screw is available through your authorized Brother dealer. (Part code: XG1343-001)

提示

- 压脚支架螺丝可在Brother 家用缝纫机授权销售代理商处购买。(零件编号: XG1343-001)



TC 隨附的配件





















KO 포함된 액세서리

الملحقات المرفقة AR

TC 感謝您購買本機。
本產品隨附以下配件。

KO 이 기기를 구입해 주셔서 감사합니다.
이 제품에는 다음 액세서리들이
포함되어 있습니다.

AR شكرًا لشرائك هذه الماكينة.
تم إرفاق الملحقات التالية مع هذا المنتج.

1. 	2. 	3. 	4. 	5. 	6. 	7. 	8. 	9. 
10.*1 	11.*2 	12. 	13. 	14. 	15. 	16. 	17. 	18. 
19. 	20. 							

*1 75/11 1支針・90/14 1支針・100/16 1支針
*2 90/14 1支針・圓頭針(鍍金針)

*1 75/11 바늘 1개, 90/14 바늘 1개, 100/16 바늘 1개
*2 90/14 바늘 1개: 볼 포인트 바늘 (금색)

1 1 إبرة مقاس 75/11, 1 1 إبرة مقاس 90/14, 1 1 إبرة مقاس 100/16
1 2* إبرة مقاس 90/14: إبرة كروية السن (ذهبية اللون)

編號	配件名稱	配件編號
1	萬用壓布腳「J」(在機上)	XZ5134-001
2	開釦眼壓布腳「A」	XC2691-133
3	車布邊壓腳「G」	XC3098-031
4	密針縫壓腳「N」	XD0810-031
5	拉鍊壓布腳「I」	X59370-021
6	暗針縫壓腳「R」	XE2650-001
7	縫鈕釦壓腳「M」	XE2137-001
8	拆線刀	XZ5082-001
9	梭子 (4) (一個梭子在機上)	SFB
10	車針組	XC8834-021
11	圓頭針	XD0360-021
12	清潔刷	X59476-051
13	L形螺絲起子	XG0918-001
14	梭殼 (在機上)	XF5707-101
15	腳踏板	XC8816-071
16	防塵蓋	XA2112-022
17	輔助桌	WT17AP
18	打孔錐子	XG7791-001
19	使用說明書	請洽詢 Brother 授權經銷商。
20	快速導覽手冊	請洽詢 Brother 授權經銷商。

번호	부품 명칭	부품 코드
1	지그재그 노루발 "J" (본체에 있음)	XZ5134-001
2	단춧구멍 노루발 "A"	XC2691-133
3	오버록 노루발 "G"	XC3098-031
4	모노그래밍 노루발 "N"	XD0810-031
5	지퍼 노루발 "I"	X59370-021
6	블라인드 노루발 "R"	XE2650-001
7	단추달미 노루발 "M"	XE2137-001
8	실뜯게	XZ5082-001
9	실토리(4) (한 개의 실토리는 기기에 있습니다.)	SFB
10	바늘 세트	XC8834-021
11	볼 포인트 바늘	XD0360-021
12	청소용 솔	X59476-051
13	L형 드라이버	XG0918-001
14	복집 (본체에 있음)	XF5707-101
15	발판	XC8816-071
16	먼지 커버	XA2112-022
17	와이드 테이블	WT17AP
18	아일렛 펀치	XG7791-001
19	작동 설명서	Brother 공인 대리점에 문의하세요.
20	빠른 설정가이드	Brother 공인 대리점에 문의하세요.

رقم	اسم القطعة	رمز القطعة
1	قدم الحياكة المتعرجة "J" (بالمachine)	XZ5134-001
2	دواسة غرز فتحات العرى "A"	XC2691-133
3	دواسة خياطة غرز التقوية "G"	XC3098-031
4	دواسة غرز الحروف الابتدائية "N"	XD0810-031
5	دواسة تركيب السحاب "I"	X59370-021
6	دواسة السرلفة "R"	XE2650-001
7	زر تركيب الأزرار "M"	XE2137-001
8	قاطع غرز الدرز	XZ5082-001
9	المكوك (4) (مكوك واحد بالمachine)	SFB
10	مجموعة الإبرة	XC8834-021
11	إبرة كروية السن	XD0360-021
12	فرشاة التنظيف	X59476-051
13	مفك شكل - L	XG0918-001
14	حاوية المكوك (بالمachine)	XF5707-101
15	دواسة القدم	XC8816-071
16	غطاء الغبار	XA2112-022
17	الطاولة العريضة	WT17AP
18	مقناب فتحات العرى	XG7791-001
19	دليل التشغيل	اتصل بوكيل شركة Brother المعتمد لديك
20	دليل مرجعي سريع	اتصل بوكيل شركة Brother المعتمد لديك

提醒

· Brother 授權經銷商有供應壓布腳腳
脛螺絲。(配件編號: XG1343-001)

참고

· 노루발 홀더 나사는 공인 Brother 대
리점을 통해 구입할 수 있습니다.
(부품 코드: XG1343-001)

ملاحظة

· يتوفر برغي تثبيت حامل القدم المضاعطة من خلال
وكيل شركة Brother المعتمد لديك.
(رمز القطعة: XG1343-001)