
We recommend that you keep this document nearby for future reference.


Thank you for purchasing this machine. The following accessories are included with this product.


		Part Name			Part Name
1.		Zigzag foot "J" (on machine)	12.	C	Free motion quilting foot "C"
2.		Advanced monogramming foot "N+"	13.	E	Free motion echo quilting foot "E" *Attach the included adapter to use this product.
4.	G	Overcasting foot "G"	14.		Free motion open toe quilting foot "O"
6		Zipper foot "I"	15.	r F	Embroidery foot "W"
5.	A+	Buttonhole foot "A+"	16.		
6.		Buttonhole foot stabilizer	17.		1/4" piecing foot with guide
7.	R R	Blind stitch foot "R"	18.		Adapter
8.		Button fitting foot "M"	19.		Screw (small)
9.		Compact dual feed foot	20.		Needle set 75/11 2 needles 90/14 2 needles 90/14 2 needles: Ball point needle (gold colored)
10.		Regular dual feed foot (on compact dual feed foot)	21.		Twin needle 2/11 needle
11.	(F)	Straight stitch foot			Ball point needle set 75/11 2 needles: Ball point needle for embroidery HAX130EBBR



D02AA1-001

	Part Name
	Spool cap (XL) × 2
	Spool holder × 2
	Spool cap base × 2
O	Spool felt × 2
Ô	Ring × 4
e Contraction of the second se	Bobbin clip × 10
°	Spool felt (on machine)
	Spool net × 2
	Embroidery needle plate cover
	Knee lifter
	Alternate bobbin case (no color on the screw)
	Standard bobbin case (green marking on the screw) (on machine)





🖞 Note

• The screw for the presser foot holder is available through your authorized Brother dealer.

## **Optional Accessories**

Various optional accessories are available to be purchased separately. Please visit our website for more details. To obtain optional accessories or parts, contact your nearest authorized Brother dealer.



## https://s.brother/codka/

	Part Name
	Operation Manual (Sewing)
	Operation Manual (Embroidery)
	Embroidery Design Guide
3.	DISNEY DESIGN GUIDE