


# EN Included Accessories

# SC 附带的配件

**EN** Thank you for purchasing this machine.  
The following accessories are included with this product.

**SC** 感谢购买此机器。  
本产品附带以下配件。



No.	Part Name	Part Code
1	Zigzag foot "J" (on machine)	XZ5134-001
2	Buttonhole foot "A"	XC2691-133
3	Overcasting foot "G"	XC3098-031
4	Monogramming foot "N"	XD0810-031
5	Zipper foot "I"	X59370-021
6	Blind stitch foot "R"	XE2650-001
7	Button fitting foot "M"	XE2137-001
8	Walking foot	F033CN F033N
9	1/4" piecing foot	F001CN F001N
10	Non stick foot	F007N F007CN
11	Seam ripper	XZ5082-001
12	Bobbin (4) (One bobbin is on machine.)	SFB CNBOBBIN
13	Needle set	XC8834-021
14	Ball point needle	XD0360-021
15	Twin needle	X59296-121
16	Cleaning brush	X59476-051
17	L-shaped screwdriver	XG0918-001
18	Extra spool pin	XG3488-001
19	Bobbin case (on machine)	XF5707-101
20	Foot controller	XD0501-121 (Turkey area) XC8816-071 (Other areas)
21	Dust cover	XA2112-022
22	Wide table	WT17CN WT17AP
23	Eyelet punch	XG7791-001
24	Finger guard	D01EG7-001
25	Operation Manual	Contact your authorized Brother dealer.
26	Quick Reference Guide	Contact your authorized Brother dealer.

编号	零件名	零件编号
1	曲折压脚“J”(已装在机器上)	XZ5134-001
2	钮孔压脚“A”	XC2691-133
3	包边压脚“G”	XC3098-031
4	交织字母压脚“N”	XD0810-031
5	拉链压脚“I”	X59370-021
6	暗缝针迹压脚“R”	XE2650-001
7	钉钮压脚“M”	XE2137-001
8	同步压脚	F033CN F033N
9	1/4英寸压脚	F001CN F001N
10	不粘压脚	F007N F007CN
11	拆线刀	XZ5082-001
12	梭芯(4) (机器已预装一个梭芯。)	SFB CNBOBBIN
13	针组	XC8834-021
14	圆头针	XD0360-021
15	双针	X59296-121
16	清洁刷	X59476-051
17	L形螺丝刀	XG0918-001
18	备用线筒轴	XG3488-001
19	内旋梭(已装在机器上)	XF5707-101
20	脚踏控制器	XC8816-071
21	防尘盖	XA2112-022
22	扩展台	WT17CN WT17AP
23	打孔器	XG7791-001
24	手指防护器	D01EG7-001
25	使用说明书	请咨询Brother授权经销商。
26	快速操作指南	请咨询Brother授权经销商。

## Note

- The presser foot holder screw is available through your authorized Brother dealer. (Part code: XG1343-001)

## 提示

- 压脚支架螺丝可在Brother家用缝纫机授权销售代理商处购买。(零件编号: XG1343-001)



# TC 隨附的配件

# KO 포함된 액세서리

# الملحقات المرفقة AR

TC 感謝您購買本機。  
本產品隨附以下配件。

KO 이 기기를 구입해 주셔서 감사합니다.  
이 제품에는 다음 액세서리들이  
포함되어 있습니다.

AR شكرًا لشرائك هذه الماكينة.  
تم إرفاق الملحقات التالية مع هذا المنتج.

\*1 75/11 1支針·90/14 1支針·100/16 1支針  
\*2 90/14 1支針·圓頭針(鍍金針)  
\*3 2/11 針

\*1 75/11 바늘 1개, 90/14 바늘 1개, 100/16 바늘 1개  
\*2 90/14 바늘 1개: 볼 포인트 바늘 (금색)  
\*3 2/11 바늘

1\* 1 إبرة مقياس 75/11, 1 إبرة مقياس 90/14  
1\* 1 إبرة مقياس 100/16  
1 2\* 1 إبرة مقياس 90/14: إبرة كروية السن  
(ذهبية اللون)  
3\* 1 إبرة 2/11

編號	配件名稱	配件編號
1	萬用壓布腳「J」(在機上)	XZ5134-001
2	開釦眼壓布腳「A」	XC2691-133
3	車布邊壓腳「G」	XC3098-031
4	密針縫壓腳「N」	XD0810-031
5	拉鍊壓布腳「I」	X59370-021
6	暗針縫壓腳「R」	XE2650-001
7	縫鈕釦壓腳「M」	XE2137-001
8	均勻送布壓布腳	F033CN F033N
9	1/4 英寸直線接合壓布腳	F001CN F001N
10	無阻力(皮革)壓布腳	F007N F007CN
11	拆線刀	XZ5082-001
12	梭子(4) (一個梭子在機上)	SFB CNBOBBIN
13	車針組	XC8834-021
14	圓頭針	XD0360-021
15	雙針	X59296-121
16	清潔刷	X59476-051
17	L形螺絲起子	XG0918-001
18	附加線輪柱	XG3488-001
19	梭殼(在機上)	XF5707-101
20	腳踏板	XC8816-071
21	防塵蓋	XA2112-022
22	輔助桌	WT17CN WT17AP
23	打孔錐子	XG7791-001
24	護指器	D01EG7-001
25	使用說明書	請洽詢 Brother 授權經銷商。
26	快速導覽手冊	請洽詢 Brother 授權經銷商。

번호	부품 명칭	부품 코드
1	지그재그 노루발 "J" (본체에 있음)	XZ5134-001
2	단추구멍 노루발 "A"	XC2691-133
3	오버록 노루발 "G"	XC3098-031
4	모노그래밍 노루발 "N"	XD0810-031
5	지퍼 노루발 "I"	X59370-021
6	블라인드 노루발 "R"	XE2650-001
7	단추달이 노루발 "M"	XE2137-001
8	워킹 노루발	F033CN F033N
9	1/4인치 노루발	F001CN F001N
10	논스틱 노루발	F007N F007CN
11	실뜯게	XZ5082-001
12	실토리(4) (한 개의 실토리는 기기에 있습니다.)	SFB CNBOBBIN
13	바늘 세트	XC8834-021
14	볼 포인트 바늘	XD0360-021
15	쌍침 바늘	X59296-121
16	청소용 솔	X59476-051
17	L형 드라이버	XG0918-001
18	보조 실패꽃이	XG3488-001
19	복집 (본체에 있음)	XF5707-101
20	발판	XC8816-071
21	먼지 커버	XA2112-022
22	와이드 테이블	WT17CN WT17AP
23	아일렛 펀치	XG7791-001
24	핑거 가드	D01EG7-001
25	작동 설명서	Brother 공인 대리점에 문의하세요.
26	빠른 설정가이드	Brother 공인 대리점에 문의하세요.

رقم	اسم القطعة	رمز القطعة
1	قدم الحياكة المتعرجة "J" (بالمالكية)	XZ5134-001
2	دواسة غرز فتحات الغرى "A"	XC2691-133
3	دواسة خياطة غرز التقوية "G"	XC3098-031
4	دواسة غرز الحروف الابتدائية "N"	XD0810-031
5	دواسة تركيب السحاب "I"	X59370-021
6	دواسة السرفلة "R"	XE2650-001
7	زر تركيب الأزرار "M"	XE2137-001
8	دواسة الغرز المستقيمة	F033CN F033N
9	دواسة ترفيع مقياس 1/4 بوصة	F001CN F001N
10	دواسة غير لاصقة	F007N F007CN
11	قاطع غرز الدرز	XZ5082-001
12	المكوك (4) (مكوك واحد بالمالكية)	SFB CNBOBBIN
13	مجموعة الإبرة	XC8834-021
14	إبرة كروية السن	XD0360-021
15	الإبرة المزودجة	X59296-121
16	فرشاة التنظيف	X59476-051
17	مفك شكل - L	XG0918-001
18	عمود ملف بكرة إضافي	XG3488-001
19	حاوية المكوك (بالمالكية)	XF5707-101
20	دواسة القدم	XC8816-071
21	غطاء الغبار	XA2112-022
22	الطاولة العريضة	WT17CN WT17AP
23	مقاب فتحات الغرى	XG7791-001
24	واقى الإصبع	D01EG7-001
25	دليل التشغيل	اتصل بوكيل شركة Brother المعتمد لديك
26	دليل مرجعي سريع	اتصل بوكيل شركة Brother المعتمد لديك

提醒  
· Brother 授權經銷商有供應壓布腳腳  
壓螺絲。(配件編號: XG1343-001)

참고  
· 노루발 홀더 나사는 공인 Brother 대  
리점을 통해 구입할 수 있습니다.  
(부품 코드: XG1343-001)

ملاحظة  
· يتوفر برغي تثبيت حامل القدم الضاغطة من خلال  
وكيل شركة Brother المعتمد لديك.  
(رمز القطعة: XG1343-001)