


## EN Included Accessories

We recommend that you keep this document nearby for future reference.

Thank you for purchasing this machine.  
The following accessories are included with this product.



No.	Part Name
1	Embroidery foot "W+" with LED pointer (on machine)
2	Needle set 75/11 6 needles: Ball point needle for embroidery
3	Bobbin × 10 (One bobbin is in machine.)
4	Seam ripper
5	Scissors
6	Cleaning brush
7	Screwdriver (small)
8	Screwdriver (large)
9	Disc-shaped screwdriver
10	Spool cap (small)
11	Spool cap (medium) × 2 (One spool cap is on machine.)
12	Spool cap (large)
13	Thread spool insert (mini king thread spool)
14	Vertical spool pin
15	Spool felt (on machine)
16	Spool net × 2
17	Embroidery needle plate cover
18	Touch pen (stylus)

No.	Part Name
19	Bobbin case (no color on the screw) (on machine)
20	Bobbin cover (on machine)
21	Embroidery frame with decal set 36 cm (H) × 24 cm (W) (approx. 14 inches (H) × 9-1/2 inches (W))
22	Embroidery frame with decal set 18 cm (H) × 13 cm (W) (approx. 7 inches (H) × 5 inches (W))
23	Embroidery positioning sticker sheets × 4
24	Lens calibration sheet
25	Embroidery bobbin thread (#90, white)
26	Stabilizer material
27	Accessory bag
28	Embroidery couching foot "Y"
29	Yarn guide for embroidery couching
30	Yarn threader
31	Operation Manual
32	Quick Reference Guide

"Embroidery Design Guide" can be downloaded at <https://s.brother/cmekb/> .

## EN Optional Accessories



Various optional accessories are available to be purchased separately. Please visit our website for more details.  
To obtain optional accessories or parts, contact your nearest authorized Brother dealer.

<https://s.brother/coeka/>



D02Y0J-001