

Information for compliance with Commission Regulation (EU)801/2013(Great Britain only), (EU)2023/826 (Europe only)

Model Name: SP-1

Network Port	Power consumption		Default Timer Values		Timer Values	
	Networked stanby mode	Off mode	To networked standby mode	To Off mode	To networked standby mode	To Off mode
Ethernet	0.8 W	N/A	5 min	N/A	0 min–20 min	N/A
USB	0.9 W	N/A	5 min	N/A	0 min–20 min	N/A
Wi-Fi	1.1 W	N/A	5 min	N/A	0 min–20 min	N/A
All network ports activated and connected	1.6 W		5 min		0 min–20 min	

How to enable/disable Wireless LAN

To turn on or off the wireless network connection, press  [Settings] > [Network] > [Network I/F] > [Wired LAN] or [WLAN(Wi-Fi)].

How to enable/disable Wi-Fi Direct

To turn on or off the Wi-Fi Direct connection, press  [Settings] > [Wi-Fi Direct] > [I/F Enable] > [On] or [Off].

Power consumption

Your machine has a power-saving function. If you deactivate this function or choose to delay its activation, power consumption will increase.