brother.



P-TOUCH EDITOR SOFTWARE USER'S GUIDE

PJ-623/PJ-663 Mobile Printer

> Version 0 UK ENG

Introduction

The Brother mobile printer, models PJ-623 and PJ-663 (with Bluetooth) are compatible with many Windows[®] and Macintosh[®] software applications, enabling you to print a full A4, letter or legal size document almost anywhere you need to work. The printers are also compatible with many mobile devices, printing plain text or formatted text from custom printing applications. The printers also come with P-touch Editor, a fully featured document design and layout software application which can help you create custom forms and templates, and save them to the printer's memory. This guide will show you how to download and manage these files using P-touch Transfer Manager and P-touch Library.

Important Notice

- The contents of this document and the specifications of this product are subject to change without notice.
- Brother reserves the right to make changes without notice in the specifications and materials contained herein and shall not be responsible for any damages (including consequential) caused by reliance on the materials presented, including but not limited to typographical and other errors relating to the publications.
- Screen images in this document may differ depending on your computer's operating system and your product model.
- Before using the printer, be sure to read all documents included with the printer for information about safety and correct operation.

Symbols used in this document

The following symbols are used throughout this document.



This symbol indicates information or directions that should be followed. Ignoring them may result in damage, or failed operations.



This symbol indicates notes that provide information or directions that will give a better understanding and help to use the product more efficiently.

About this document

This document (PDF) is included on the CD-ROM.

🖉 Note

If using $Adobe^{\ensuremath{\mathbb{R}}}$ Reader^{$\ensuremath{\mathbb{R}}$} to view this document on a computer, the cursor changes to $\ensuremath{\mathbb{R}}$ when the cursor is placed on a link. Click the link to open the corresponding page. For information about using $Adobe^{\ensuremath{\mathbb{R}}}$ Reader^{$\ensuremath{\mathbb{R}}$}, see the help file included with $Adobe^{\ensuremath{\mathbb{R}}}$ Reader^{$\ensuremath{\mathbb{R}}$}.

Table of Contents

1	How to install/uninstall P-touch Editor Software	1
	Installing P-touch Editor Software	1
	Uninstalling P-touch Editor Software	
2	How to use P-touch Editor	3
	Using P-touch Editor	3
	Starting P-touch Editor	
	Operation modes	5
	Using P-touch Editor Help	8
	Viewing the P-touch Editor help file	8
		10
	Printing the P-touch Editor help file	
3	How to use P-touch Transfer Manager & P-touch Library	11
3	How to use P-touch Transfer Manager & P-touch Library	11
3	How to use P-touch Transfer Manager & P-touch Library Using P-touch Transfer Manager	11
3	How to use P-touch Transfer Manager & P-touch Library	11 11 11
3	How to use P-touch Transfer Manager & P-touch Library Using P-touch Transfer Manager Starting P-touch Transfer Manager	11 11 11 13
3	How to use P-touch Transfer Manager & P-touch Library Using P-touch Transfer Manager Starting P-touch Transfer Manager Transferring templates or other data from the computer to the printer	11 11 11 13 17
3	How to use P-touch Transfer Manager & P-touch Library Using P-touch Transfer Manager Starting P-touch Transfer Manager Transferring templates or other data from the computer to the printer Backing up templates or other data saved in the printer	11 11 11 13 17 18
3	How to use P-touch Transfer Manager & P-touch Library Using P-touch Transfer Manager Starting P-touch Transfer Manager Transferring templates or other data from the computer to the printer Backing up templates or other data saved in the printer Deleting all data saved in the printer	11 111113171819
3	How to use P-touch Transfer Manager & P-touch Library Using P-touch Transfer Manager Starting P-touch Transfer Manager Transferring templates or other data from the computer to the printer Backing up templates or other data saved in the printer Deleting all data saved in the printer Using P-touch Library	11 1111131718191919
3	How to use P-touch Transfer Manager & P-touch Library Using P-touch Transfer Manager Starting P-touch Transfer Manager Transferring templates or other data from the computer to the printer Backing up templates or other data saved in the printer Deleting all data saved in the printer Using P-touch Library Starting P-touch Library	11 11131718191919

How to install/uninstall P-touch Editor Software

P-touch Editor allows you to create templates with various kinds of designs.

Refer to the P-touch Editor help file for template design samples and details on creating, printing, and saving your templates.

To download the latest driver and software, please visit the Brother Solutions Center website: <u>http://solutions.brother.com</u>

Installing P-touch Editor Software

1 Insert the CD-ROM into your computer's CD-ROM drive.

Setup		
brother		
PocketJet Installer	Click the button on the right to obtain the newest version.	olutions Center
PC (Windows) software	Windows based applications and p	rinter drivers.
▶ Display Software User's Guide		
+ Display User's Guide		
Download Windows Mobile printing software	•	
Installation language:	Pocké	et let
English	Pocké	et Je
		Exit
(c) 2010 Brother Industries, Ltd. All Rights Reserved.		LB3786001

- Click [PC (Windows) software], and then click [P-touch Editor 5.0].
- 3 Follow the on-screen instructions to install the software.
- 4 Click [**Finish**] to close the installation screen.



Uninstalling P-touch Editor Software

1 For Windows[®] XP:

From [Control Panel], go to [Add or Remove Programs]. The [Add or Remove Programs] dialogue box appears.

For Windows Vista[®] / Windows[®] 7:

From [Control Panel], go to [Programs] and open [Programs and Features]. The [Uninstall or change a program] dialogue box appears.

Choose [Brother P-touch Editor 5.0], and click [Remove] (XP) / [Uninstall] (Windows Vista[®] / Windows[®] 7).

3 Click [**OK**].

The uninstall operation starts. After the software is removed from your computer, the [Maintenance Complete] dialogue box appears.

 Close the [Add or Remove Programs] (XP) / [Programs and Features] (Windows Vista[®] / Windows[®] 7) dialogue box.
 P-touch Editor / P-touch Update Software has been uninstalled. How to use P-touch Editor

The following explanations and procedures depict Windows Vista[®], and may vary depending on your computer's operating system. In the screen shots, "XX-XXXX" is displayed to represent the printer model number.

Using P-touch Editor

Starting P-touch Editor

2



Click [Start]-[All Programs]-[Brother P-touch]-[P-touch Editor 5.0].

When P-touch Editor starts, the [**New/Open**] dialogue box is displayed. This dialogue box allows you to select whether you want to create a new template or open an existing template.

🖉 Note

- You can also start P-touch Editor using shortcuts, if you selected to create shortcuts during installation.
 - · Shortcut icon on the desktop: double-click to start P-touch Editor
 - · Shortcut icon in the Quick Launch bar: click to start P-touch Editor
- To change how P-touch Editor functions when it starts, click [Tools]-[Options] in the P-touch Editor menu bar to display the [Options] dialogue box. In the [General] tab, select the desired setting in the [Operations] list box under the [Startup Settings]. Normally, [Display New/Open Dialogue Box] will be selected.

How to use P-touch Editor

2 Select an option in the [**New/Open**] dialogue box and click [**OK**].

New/Open		×
Select Printer Brother XX-XXXX	Open Create a <u>N</u> ew Layout	View History
A4	New Select by Use	A
	A	
Check for Updates	Horizontal Text	Vertical Text
Help - How To	Do Not Display This Dialogue Box at Sta	OK Cancel

- The printer and media size can be selected in this dialogue box.
- Click [Open File] to display the [Open] dialogue box, where you can select and open a previously saved template.
- Click [View History] to open the [History] dialogue box, where you can select and open recently saved templates.
- Click [New] to select the desired orientation (vertical or horizontal) and create a new template.
- Click [Select by Use] to create a new template based on how it will be used.
- Click [Help How To] to view the P-touch Editor help file. The help file shows you step-by-step how to create a template.
- Click [Check for Updates] to look for a newer version of P-touch Editor online. If a newer version is available, the computer's web browser will open the Brother Solutions Center website, where you can download the latest version.

Operation modes

P-touch Editor has three different operation modes: [**Express**] mode, [**Professional**] mode, and [**Snap**] mode. You can easily switch between modes by using the mode selection buttons.

■ [Express] mode

This mode allows you to quickly and easily create templates that include text and images. The [**Express**] mode screen is explained below.



1 Menu bar

Provides access to all available commands, which are grouped under each menu title ([File], [Edit], [View], and [Insert], etc.) according to their functions.

2 Command bar

Provides access to frequently used commands, such as [New/Open], [Paper], [Text], [Frame], [Image], etc.

3 Draw/Edit toolbar

Provides tools for selecting objects, entering text, drawing graphics, etc.

4 Property bar

Allows you to edit the properties of text, graphics, etc.

5 Template window

Provides the area where you create and edit your templates.

6 Database window

Displays the content of a connected database or label list that can be used to add content to your templates.

7 Mode selection buttons

Allows you to switch to another operation mode.

🖉 Note

- You can show and hide different toolbars and windows using the commands in the [View] menu.
- For details about using [Express] mode, refer to the P-touch Editor help file.

■ [Professional] mode

This mode allows you to create templates using a wide-range of advanced tools and options. The [**Professional**] mode screen is explained below.



1 Menu bar

Provides access to all available commands, which are grouped under each menu title ([File], [Edit], [View], and [Insert], etc.) according to their functions.

2 Standard toolbar

Provides access to frequently used commands, such as New Layout, Open, Save, Print, etc.

3 Property palette

Provides access to the Print, Paper, Text, and Layout palettes. Click on the left side of each palette to show/hide the available properties.

4 Draw/Edit toolbar

Provides tools for selecting objects, entering text, drawing graphics, etc.

5 Template window

Provides the area where you create and edit your templates.

6 Database window

Displays the content of a connected database or label list that can be used to add content to your templates.

7 Mode selection buttons

Allows you to switch to another operation mode.

8 Side bar

Provides access to different tabs that allow you to insert and format text, bar codes, tables, etc., change the order of the objects to create a template, or set advanced settings.

🖉 Note

• You can show and hide different toolbars and windows using the commands in the [View] menu.

• For details about using [Professional] mode, refer to the P-touch Editor help file.

■ [Snap] mode

This mode allows you to capture all or a portion of your computer screen content, print it as an image, and save it for future use.

1 Click the [Snap] mode selection button. The [Description of Snap mode] dialogue box is displayed.

The following functions	can be used in Snap mode.	
Screen Capture	Drag-and-Drop	Print Text function
Flow		A.2033
Drop or Input	Drop of Input	
Click th	e P-touch icon to return to the	layout window.
Do Not Display This	Dialogue Again	

2 Click [**OK**]. The [**Snap**] mode palette is displayed.

P Snap Drop or Input

🖉 Note

- If you select the [**Do Not Display This Dialogue Again**] check box in the [**Description of Snap mode**] dialogue box, you switch to [**Snap**] mode next time without displaying the dialogue box.
- You can also start P-touch Editor in [Snap] mode by clicking [Start]-[All Programs]-[Brother P-touch]-[P-touch Editor 5.0 (Snap mode)].
- For details about using [Snap] mode, refer to the P-touch Editor help file.

Using P-touch Editor Help

Viewing the P-touch Editor help file

This section explains how to use the P-touch Editor help file.

Starting from the [Start] menu

Click [Start]-[All Programs]-[Brother P-touch]-[P-touch Editor 5.0 Help].



Starting from the [New/Open] dialogue box

When you start P-touch Editor and the [New/Open] dialogue box is displayed, click [Help - How To].



Starting from P-touch Editor

■ In [Express] mode or [Professional] mode:

Click the [Help] menu and select [P-touch Editor Help].



[Professional] mode



■ In [Snap] mode:

Place the mouse pointer within the [**Snap**] mode palette so that the four-way arrow pointer (the "move" pointer) is displayed, right click and then select [**P-touch Editor Help**].

[Snap] mode Srap Srap Sreen Capture Return to Edit Layout Snap Mode Description... P-touch Editor Help How To <u>A</u>bout... Exit

Mote

You can also press the [F1] key to open the P-touch Editor help file.

Printing the P-touch Editor help file

You can print P-touch Editor help file content for later reference.

- In the [Contents] tab, select the content that you want to print.
- 2 Click [**Print**] on the Toolbar.
- 3 Choose the range of topics to be printed, and click [OK].



4 Specify the [Printer] and click [Print].

3

How to use P-touch Transfer Manager & P-touch Library

P-touch Transfer Manager

This program allows you to transfer templates and other data to the printer and save backups of your data on the computer.

After P-touch Transfer Manager is used to transfer data to the printer, P-touch Template is used to send text data to the printer that will be inserted into the template and printed. For details on P-touch Template, download the P-touch Template manual (English only) from the Brother Solutions Center website: <u>http://solutions.brother.com</u>

Select your region and your country. Then choose your product and click on [Manuals].

P-touch Library

This program allows you to use your computer to manage P-touch templates and other data. You can use P-touch Library to print templates.

Using P-touch Transfer Manager

Starting P-touch Transfer Manager

Click [Start]-[All Programs]-[Brother P-touch]-[P-touch Tools]-[P-touch Transfer Manager 2.1]. When P-touch Transfer Manager starts, the main window is displayed.

Note

You can also start P-touch Transfer Manager from P-touch Editor.

Click [File]-[Transfer Template].

How to use P-touch Transfer Manager & P-touch Library

Main window

All Contents - P-touch <u>File Edit View Tool H</u> elp	Transfer Manager)		
Transfer Backup	Open Search	Display Style	×	
P-touch Lbrary Loral All Contents Databases Databases Databases Databases Transfer Manager Transfer Manager Transfer Manager Configurations Backups Docnfigurations Backups Docnfigurati	Name	Size Type	Date Locati	
For Help, press F1				

1 Menu bar

Provides access to various commands, which are grouped under each menu title ([File], [Edit], [View], [Tool], and [Help]) according to their functions.

2 Toolbar

Provides access to frequently used commands.

3 Printer selector

Allows you to select which printer the data will be transferred to. When you select a printer, only the data that can be sent to the selected printer is displayed in the data list.

4 Folder list

Displays a list of folders and printers. When you select a folder, the templates in the selected folder are displayed in the template list.

If you select a printer, the current templates and other data stored in the printer are displayed.

5 Template list

Displays a list of templates in the selected folder.

6 Preview

Displays a preview of the templates in the templates list.

Explanations of the Toolbar Icons

lcon	Button name	Function
	Transfer	Transfers templates and other data from the computer to the printer (available for USB connection only).
	Backup	Retrieves the templates and other data saved in the printer and saves it on the computer (available for USB connection only).
7	Open	Opens the selected template.
	Search	Allows you to search for templates or other data that are stored in the P-touch Library.
	Display Style	Changes the file display style.

Transferring templates or other data from the computer to the printer

Use the following procedure to transfer templates from the computer to the printer.



This feature is only available when the computer and printer are connected via USB.

 Connect the computer and the printer via USB and turn on the printer. The printer model name is displayed in the folder list. If you select a printer in the folder list, the current templates and other data stored in the printer are displayed.

2) Select the printer that you want to transfer the template or other data to.

All Contents - P-touch	Fransfer Manager					
Edit View Tool Help	Open Search	Display Style	Printer: All Printers All Printers Brother XX- Type Brother XX-	×	Location	
All Contents Filter Layouts Databases	Autinch shipping L. Autoconference roo E-VISITOR bi	18KB	Layout	2006/05/16 203924 2006/03/24 183956 2006/05/16 203538	C¥Documents and C¥Documents and C¥Documents and	
- 📑 Images Recycle Bin Search Results ransfer Manager PC (Brother XX-XXXX)						
- 1931 Configurations - 1933 Backups 9 PC (Brother XX-XXXX) - 1933 Configurations						
- 🙀 Backups J Brother XX-XXXX	No contents are sele	ected.				
telo, press F1	1					

All Contents - P-funch Transfer Manaer

 For GAL Yew Tell Byb

 Con Back
 Con Seach
 Con Seach

3 Right-click the [**Configurations**] folder, select [**New**], and then create a new folder.

In the example above, the folder [Transfer] was created.

4 Drag the template or other data that you want to transfer and place it in the new folder.

You can browse for templates or other data by selecting [All Contents] or by selecting one of the categories under [Filter], such as [Layouts].

When transferring multiple templates or other data, drag all the files that you want to transfer and place them in the new folder.

Each file is assigned a key number (memory location in the printer) when it is placed in the new folder.

	💣 🔍	-	All Printer			
ansfer Backup such Library	Open Search	Display Style	Туре	Date	Location	
All Contents	Mame Ax6inch shipping L.		Layout	2006/05/16 20:39:24	CivDocuments and	
Filter	Ax conference roo		Layout	2006/03/24 18:39:56	C#Documents and _	
Layouts	E-VISITOR BI		Layout		CWDocuments and	
 Databases Images 						
Recycle Bin Search Results						
ster Manager						
PC (Brother XX-XXXXX)						
Configurations						
Backups PC (Brother XX-30000)						
Configurations						

5 To change the key number assigned to an item, right-click the item, select [Key Assign], and then select the desired key number.



🖉 Note

- · All data transferred to the printer is assigned a key number.
- If the template or other data transferred to the printer has the same key number as another template already saved in the printer, the new template will overwrite the old one. You can confirm the templates key number assignments saved in the printer by backing up the templates or other data (see *Backing up* templates or other data saved in the printer on page 17).
- If the printer memory is full, remove one or more templates from the printer's memory. (see *Backing up templates or other data saved in the printer* on page 17).
- 6 To change the names of templates or other data that will be transferred, click on the desired item and enter the new name. The number of characters used for the template names may be limited depending on the printer model.

7 Select the folder containing the templates or other data that you want to transfer, and then click **[Transfer]**. A confirmation message will be displayed.

Eile <u>E</u> dit ⊻jew	<u>T</u> ool <u>H</u> elp			- P-touch Tra	inarch Hundger				
1 Transfer	Handkup	Copen	O Search	Display Style	Printer: All Printers				
P-touch Library		Transfer Nam		Size	Туре	Date	Key Assign	Name	
- 🔯 All Contents		E-VISITOR		470KB	Layout	2006/05/16 203538	1	E-VISITOR Ibl	
- 🌱 Filter									
- 🖻 Layouts - 📄 Databases									
images									
Recycle Bin									
Search Result	*								
Transfer Manager									
🛒 PC (Brother X	X-XXXXX								
🕀 🏂 Configurat	ions								
Deckups	er								
PC (Brother X	~ ~~~								
- S Configurat	inno								
Backups		í							

🖉 Note

8 Click [**OK**].

- You can also transfer individual items to the printer without adding them to a folder. Select the template or other data that you want to transfer, and then click [Transfer].
- Multiple items and folders can be selected and transferred in one operation.



The selected templates, folders or other data are transferred to the printer.

Backing up templates or other data saved in the printer

Use the following procedure to retrieve the templates or other data saved in the printer and save it on the computer.

- Backed up templates or other data cannot be edited on the computer.
- Depending on the printer model, templates or other data backed up from one printer model may not be able to be transferred to another printer model.

 Connect the computer and the printer via USB and turn on the printer. The printer model name is displayed in the folder list. If you select a printer in the folder list, the current templates and other data stored in the printer are displayed.

2 Select the printer to back up from, and then click [Backup]. A confirmation message is displayed.



Click [OK].

A

A new folder is created under the printer in the folder list. The folder name is based on the date and time of the backup. All of the printer's templates and other data are transferred to the new folder and saved on the computer.

<u>E</u> dit ⊻jew	<u>T</u> ool <u>H</u> elp							
Transfer	- Contraction (Contraction) Backup	Open Pr	inter Settings Sear	th Display Style	Printer: All Printers	•		
P-touch Library		Transfer Name	s	ize Type	Date	Key Assign	Name	
3 All Contents		E-VISITOR		KB -	2006/05/16 21:48:11	-	E-VISITORpd3	
🕈 Filter		G User Mag	1	KB -	2006/05/16 21:48:11	-	User Msg.pd3	
 Layouts 								
- 📄 Database - 🗟 Images	s							
Recycle Bin								
Search Resu	lte.							
ransfer Manage								
PC (Brother								
- 151 Configura	itions							
a Backups								
2006.	05/16 21:48:11							
		No contents	are selected.					
		No contents	are selected.					

Deleting all data saved in the printer

Use the following procedure to delete all templates or other data that are saved in the printer.



This feature is only available when the computer and printer are connected via USB.

1 Connect the computer and the printer via USB and turn on the printer. The printer model name is displayed in the folder list.

Right-click the printer, and then select [All Delete]. 2

😤 Brother XX-X		uch Transfer	Manager						B 🗙
Eile Edit View	Tool Help Backup	Open	O_ Search	Display Style	Printer: All Printers	×			
P-touch Library All Contents All Contents Priter Recycle Bin Search Resu Transfer Manage PC Brother So Configure Recycle Recycle	lts r XX=XXXX) ations	Transfer Name		109KB	Type Template Template	Date 2006/05/17 09/21 2006/05/17 09/16	Key Assign 1 2	- -	
	All De Proper		itents are	selected.					

A confirmation message is displayed.





Click [OK].

All templates and other data saved in the printer are deleted.

Using P-touch Library

Starting P-touch Library

Click [Start]-[All Programs]-[Brother P-touch]-[P-touch Tools]-[P-touch Library 2.1]. When P-touch Library starts, the main window is displayed.

Main window



1 Menu bar

Provides access to all available commands, which are grouped under each menu title ([File], [Edit], [View], [Tool], and [Help]) according to their functions.

2 Toolbar

Provides access to frequently used commands.

3 Folder list

Displays a list of folders. When you select a folder, the templates or other data in the selected folder is displayed in the templates list.

4 Templates list

Displays a list of the templates or other data in the selected folder.

5 Preview

Displays a preview of the templates or other data selected in the templates list.

Explanations of the Toolbar Icons

lcon	Button name	Function		
7	Open	Opens the selected template.		
	Print	Prints the selected template.		
	SearchAllows you to search for templates or other data the P-touch Library.			
	Display Style	Changes the file display style.		

Opening and editing templates

Select the template you want to open or edit, and then click [Open].

😤 All Contents - P-touch Library		
Eile Edit View Iool Help		
Open Print	Search Display Style	
P-touch Library	Search Display style	
Protoch Ubray Content Gild Content Gild Content Gild Recycle Bin Q Search Results		
	No contents are selected.	
For Help, press F1		NUM //

The program that is associated with the template will be started and you can edit the template.

Note

The program that starts depends on the type of file that is selected. For example, if you select a P-touch template, P-touch Editor starts.

Printing templates

All Contents - P-touch Library <u>File Edit View I</u> ool <u>H</u> elp		
Open Print	Search Display Style	
Fourch Library Garceness Garceness Garceness Garceness Garceness Construction Construction Construction Construction		
	No contents are selected.	
For Help, press F1		NUM

Select the template that you want to print and then click [Print].

The template is printed using the connected printer.

Searching for templates or other data

You can search for templates or other data registered to P-touch Library.

1

Click [Search].

The [Search] dialogue box is displayed.

All Contents - P-touch Lib <u>File</u> Edit <u>View</u> <u>Tool</u> <u>H</u>				
Open Print	Q	play Style		
- Ball Contents - Ball Contents - Ball Contents - Ball Contents - Ball Contents - Ball Contents	Search Multiple Parameters	€ AND C OR	[3	3
	□ Name □ □ Type □Layou □ Size From □ To □ Date From	t (b);bp;mbi) 0 KB 0 KB 6/15/2007 V		
	То	6/15/2007 V Begin Search Close		
For Help, press F1				NUM //



Specify the search criteria.

The following search criteria are available.

Settings	Details			
Multiple Parameters	Determines how the program searches when multiple criteria are specified. If you select [AND], the program searches for files that satisfy all of the criteria. If you select [OR], the program searches for files that satisfy any of the criteria.			
Name	Allows you to search for a template or other data by specifying the file name.			
Туре	Allows you to search for a template or other data by specifying the file type.			
Size	Allows you to search for a template or other data by specifying the file size.			
Date	Allows you to search for a template or other data by specifying the file date.			



3 Click [Begin Search]. The search begins.

All Contents - P-touch Library e Edit View Tool Help					
Open Print :	C Eiserch Display Style				
P-touch Library	Name	Size	Date	Location	
해 All Contents 영 Recycle Bin 및 Search Results	🖗 4x6 inch shipping L 18K	B	2006/05/16 203924	Leyout	
	From Brother Japan 102x150mm	To Brott 4×6ir	ner USA		
	Sample Labels 19801226	Sam	de Labels THER INTL	_	

4 Close the [Search] dialogue box.

The search results can be confirmed by clicking [Search Results] in the folder list.

Note

You can register templates or other data to P-touch Library by dragging and dropping the files to the [All Contents] folder or to the folder list. You can also configure P-touch Editor to register templates to P-touch Library automatically, using the following procedure.

- 1 From the P-touch Editor menu, select [Tools]-[Options].
- 2 In the [Options] dialogue box, click [Registration Settings] in the [General] tab.
- 3 Select the timing for registering templates created with P-touch Editor, and then click [OK].

brother.