

Model Name: QL-720NW, QL-710W

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
Ethernet	2.2W	N/A (Activating the Network) 0.2W (Deactivating the Network)	0min	N/A (Activating the Network) 60min (Deactivating the Network)
USB Port1	2.0W	N/A (Activating the Network) 0.2W (Deactivating the Network)	0min	N/A (Activating the Network) 60min (Deactivating the Network)
Wi-Fi	2.5W	N/A (Activating the Network) 0.2W (Deactivating the Network)	0min	N/A (Activating the Network) 60min (Deactivating the Network)
RS-232C	2.0W	N/A (Activating the Network) 0.2W (Deactivating the Network)	0min	N/A (Activating the Network) 60min (Deactivating the Network)
All network ports activated and connected	2.5W	N/A (Activating the Network) 0.2W (Deactivating the Network)	0min	N/A (Activating the Network) 60min (Deactivating the Network)

How to enable/disable Wireless LAN

To activate the wireless function:

Press and hold the Wi-Fi button until the « WiFi » (Wi-Fi) indicator starts blinking in green.

To deactivate the wireless function:

Press and hold the Wi-Fi button again to turn the wireless function off.