

Model Name: PJ-773

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB Port1	1.4W	0.3W	0min	15min
Wi-Fi	1.4W	0.3W	0min	15min
All network ports activated and connected	1.5W	0.3W	0min	15min

How to enable/disable Wireless LAN

To activate the wireless function:

Press and hold the ⏻ (Power) button to turn the printer on, and then press and hold the 📶 (Wi-Fi) button for one second.

To deactivate the wireless function:

Press and hold the 📶 (Wi-Fi) button again to turn the wireless function off.