

Model Name: PT-E850TKW

Network Port	Power consumption		Default Timer Values	
	Networked Standby mode	Off mode	To Networked Standby mode	To Off mode
USB	1.2W	0.3W	0min	240min
Wi-Fi	1.5W	0.3W	0min	240min
All network ports activated and connected	1.6W	0.3W	0min	240min

How to enable/disable Wireless LAN

To activate the wireless function:

Press and hold the ⏻ (Power) button to turn the P-touch on, and then press and hold the 📶 (Wi-Fi) button for one second.

To deactivate the wireless function:

Press and hold the 📶 (Wi-Fi) button again to turn the wireless function off.